

SX8634/35/44/45 Evaluation Kit

User's Guide



Table of Contents

1	Introduction	6
2	Getting Started	8
2.1	Kit Contents	8
2.2	Installation/Quick Start	9
2.3	GUI tooltips and Help	12
3	Hardware Description	13
21		12
211	USP Connector (#1)	11
0.1.1		. 14
3.1.Z		. 14
3.1.3		. 14
3.1.4	UN/OFF switch (#4)	. 14
3.1.5	Test Switch (#5)	. 14
3.1.6	Power Indication LED (#6)	. 14
3.1.7	FT2232D (#7)	. 14
3.1.8	Stand-alone Jumpers (#8)	. 14
3.1.9	Header (#9)	. 15
3.1.10	SX8634, SX8635, SX8644, SX8645 (#10)	. 15
3.1.11	LEDs on GPIO[70] (#11)	. 15
3.1.12	Touch Sensors (#12)	. 15
32	Default EVK hardware, settings	15
4	Guided Tour of the GUI/EVK	16
	Introduction	16
12	Active/Dozo/Sloop Mode/M/ako.up	16
4.2	Active/Doce/Steep Mode/Wake-up	10
4.3		10
4.4	LED mapping on GPO pins	18
4.5	Sensors for buttons, slider or wheel	18
4.6	Monitor mode	20
4.7	Sensitivity	22
5	GUI Description	24
5.1	GUI Overview	24
5.2	File Menu	25
5.2.1	Connect/Disconnect	. 25
5.2.2	Open SPM	. 25
5.2.3	Save SPM	. 26
5.2.4	Save SPM As	. 26
525	Fxit	26
53	Action Menu	26
531	Potrosh	20
522	Comparate officet	. 20 ວຣ
5.5.Z		. 20
5.3.3	Operating mode	. 21
5.3.4		. 21
5.4	Help Menu	28
5.4.1	Overview	. 28
5.4.2	Help	. 28
5.4.3	User's Guide	. 28
5.4.4	About SX863x/4x Evaluation Kit	. 28
5.5	Toolbar	29
5.6	Statusbar	30
5.7	Sensor Status	31
5.8	GUI tabs	34
5.8 1	General tab	34
5.8.2	Can Sensors tab	35
583	Ruttons tab	20
0.0.0 Day: 0.0		. 53
KeV 0.9	2 – September 2010 Z WWW.semtech.com	



5.8.4	Slider/Wheel tab	40
5.8.5	Mapping tab	41
5.8.6	GPIO tab	42
5.8.7	SPM/I2C tab	43
6	Schematics	45
7	Layout	53
8	References	61



Table of Figures

Figure 1: Typical Application		6
Figure 2: EVK Contents		
Figure 3: EVK startup		
Figure 4: SX864x EVK LEDs and sensors		
Figure 5: SX863x EVK LEDs and sensors		
Figure 6: EVK GUI window		
Figure 7: button BT0 touched (SX864x) or proxir	nitv detected (Sx863x)	
Figure 8: tooltip example		
Figure 9: SX8644FVK Board Picture		13
Figure 10: SX8645EVK Board Picture		
Figure 11: Jumpers		14
Figure 12: Header		15
Figure 13: Operating Modes		16
Figure 14: GPIO tab modified (i)		17
Figure 15: GPIO tab modified (ii)		
Figure 16: Manning tab modified		18
Figure 17: Cap Sensors modified		19
Figure 18: Cap Sensors tab		20
Figure 10: Monitor tab		
Figure 20: Select thresholds hystoresis		
Figure 21: two successive touches on button 0		۲ ــــــــــــــــــــــــــــــــــــ
Figure 22: consitivity (5) of button 0		
Figure 22: sensitivity (3) of button 0	consitivity (1) of button 0	
Figure 23. Sensitivity (0) of button 0,	sensitivity (1) of button 0	23 24
Figure 24. SX8034/44 GOI Overview		
Figure 25: SX8035/45 GUI Overview		
Figure 20. File Meriu		
Figure 27: SPM File Example (begin)		
Figure 28: SPM File Example (end)	••••••	
Figure 29: Action Menu		
Figure 30: Operating Mode		
Figure 31: Confirm NVM burn	••••••	
Figure 32: Confirmation INVIVI is burned		
Figure 33: GUI Help Menu		
Figure 34: About window		
Figure 35: Toolbar		
Figure 36: I2C address		
Figure 37: Statusbar		
Figure 38: Statusbar with error message		
Figure 39: Statusbar with SPM file		
Figure 40: Sensor status for SX8634/44EVK and	d SX8634/45EVK	
Figure 41: Example BT0 and BT2 touched		
Figure 42: Example slider touched		
Figure 43: Example slider move high and move	low	
Figure 44: Example wheel touched		
Figure 45: Example wheel move counter clock w	vise and move clock wise	
Figure 46: general tab		
Figure 47: cap sensors tab		
Figure 48:monitor enabled		
Figure 49:monitor window		
Figure 50:show/hide monitor signals		
Figure 51:example: super pose thresholds of but	tton 0	
Figure 52:graph pop up window		
Rev 0.9 – September 2010	4	www.semtech.com



Figure 53: buttons tab.	39
Figure 54 slider or wheel tab	. 40
Figure 55 mapping tab	. 41
Figure 56 GPIO tab	. 42
Figure 57 SPM/I2C tab	. 43
Figure 58 SPM expanding General	. 44
Figure 59: SX8644EVK schematic page 1/2	. 45
Figure 60: SX8644EVK schematic page 2/2	. 46
Figure 61: SX8645EVK schematic page 1/2	. 47
Figure 62: SX8645EVK schematic page 2/2	. 48
Figure 63: SX8634EVK schematic page 1/2	. 49
Figure 64: SX8634EVK schematic page 2/2	. 50
Figure 65: SX8635EVK schematic page 1/2	. 51
Figure 66: SX8635EVK schematic page 2/2	. 52
Figure 67: SX8644EVK top layer	. 53
Figure 68: SX8644EVK mid layer 1	. 53
Figure 69: SX8644EVK mid layer 2	. 54
Figure 70: SX8644EVK bottom layer	. 54
Figure 71: SX8645EVK top layer	. 55
Figure 72: SX8645EVK mid layer 1	. 55
Figure 73: SX8645EVK mid layer 2	. 56
Figure 74: SX8645EVK bottom layer	. 56
Figure 67: SX8634EVK top layer	. 57
Figure 72: SX8634EVK mid layer 1	. 57
Figure 73: SX8634EVK mid layer 2	. 58
Figure 74: SX8634EVK bottom layer	. 58
Figure 67: SX8635EVK top layer	. 59
Figure 72: SX8635EVK mid layer 1	. 59
Figure 73: SX8635EVK mid layer 2	. 60
Figure 74: SX8635EVK bottom layer	. 60
Figure 75: SX8634/44EVK, SX8635/45EVK stacked layer information	. 60



1 Introduction

This document describes the evaluation kits of the:

- SX8634 (proximity, buttons and slider)
- SX8635 (proximity, buttons and wheel)
- SX8644 (buttons and slider)
- SX8645 (buttons and wheel)
- In this user guide the term EVK refers to the SX8634EVK, SX8635EVK SX8644EVK and SX8645EVK

The SX863x and SX864x family (see references [1] to [13]), is an ultra low power, fully integrated 12 (or 8) -channel solution for capacitive touch-buttons, slider and wheel and proximity applications with enhanced LED drivers. The SX863x/4x family features dedicated capacitive sense inputs (that requires no external components) in addition to 8 general purpose I/O ports (GPIO). Each GPIO is typically configured as LED driver with independent PWM source for enhanced lighting control such as intensity and fading. SX863x offers additionally proximity detection.















SX8645

Figure 1: Typical Application



SX863x and SX864x main features include:

- Proximity Sensing (for SX863x Family)
- Complete 12 Sensors Capacitive Touch Controller for Buttons and Slider
 - Pre-configured for 6 Buttons and a Slider (SX8644), Wheel (SX8645)
 - 8 LED Drivers with Individual Intensity, Fading Control and Autolightening Mode
 - 256 steps PWM Linear and Logarithmic control
- High Resolution Capacitive Sensing
 - Up to 100pF of Offset Capacitance Compensation at Full Sensitivity
 - Capable of Sensing through Overlay Materials up to 5mm thick
- Extremely Low Power Optimized for Portable Application
 - 8uA (typ) in Sleep Mode
 - 80uA (typ) in Doze Mode (Scanning Period 195ms)
 - 260uA (typ) in Active Mode (Scanning Period 30ms)
- Programmable Scanning Period from 15ms to 1500ms
- ♦ Auto Offset Compensation
 - Eliminates False Triggers due to Environmental Factors (Temperature, Humidity)
 - Initiated on Power-up and Configurable Intervals
- Multi-Time In-Field Programmable Firmware Parameters for Ultimate Flexibility
 On-chip user programmable memory for fast, self contained start-up
- Smart Wake-up Sequence for Easy Activation from Doze
- No External Components per Sensor Input
- Internal Clock Requires No External Components
- Differential Sensor Sampling for Reduced EMI
- ♦ 400 KHz Fast-Mode I²C Interface with Interrupt



2 Getting Started

2.1 Kit Contents

As illustrated in the figure below, the Evaluation kit is composed of:

- > SX8634EVK, SX8635EVK , SX8644EVK, SX8645EVK board with 2mm acrylic glass overlay.
- > CDROM including all necessary PC software and documentation (requires min. Windows XP)
- > Mini USB cable to connect the SX8634EVK, SX8635EVK, SX8644EVK, SX8645EVK board to the PC



SX8644EVK

SX8645EVK



SX8634EVK

SX8635EVK

Figure 2: EVK Contents

Rev 0.9 - September 2010



2.2 Installation/Quick Start

- 1- Put the CDROM in your computer. If the installation does not start automatically, launch "SX863xSX864xEvaluationKitSetup.exe" manually.
- 2- Follow installation guidelines until the process is completed. Please note that .NET Framework 3.5 and the FTDI USB driver will be automatically downloaded/installed if not detected on your computer.
- 3- For SX864x only: Assure the switch #5 is always in the left position.
- 4- Set the ON/OFF switch (#4) to OFF (left position).
- 5- Connect the EVK board to the PC with the mini USB cable to connecter #1.



Figure 3: EVK startup

- 6- The PC will recognize the EVK.
- 7- Set the ON/OFF switch (#4) to ON (right position).
- 8- The red LED (#6) will light up

The EVK is now read to be used in stand alone demo mode (without GUI).

Touching the buttons BT0 to BT5 (#12) will enable the corresponding green LEDs (#11), D0 to D5. Releasing the buttons will turn off the LEDs.



Figure 4: SX864x EVK LEDs and sensors

Rev 0.9 – September 2010







Figure 5: SX863x EVK LEDs and sensors

Moving a finger on the slider or wheel (#12) will enable the green LEDs (#11), D6 and D7 depending on the direction of the finger.

For the SX863x the orange LED (d0) will show proximity as soon as the user approaches the EVK.

For more detailed evaluation and changing the default configuration of the EVK the GUI needs to be started.

- 9- Launch "Sx863xSX864xEVK" from PC Start menu.
- 10- The EVK will be connected automatically and the following window will appear. (In case the auto connect did not succeed: Click on "Disconnect/Connect" button in toolbar or select 'Connect' in File menu)



Figure 6: EVK GUI window

The product is shown in the left bottom corner of the GUI.

- 11- a) SX864x: Touch with your finger a button (e.g. BT0) on the EVK and the GUI shows BT0 is touched (white).
 - b) Sx863x: Approach with your finger the EVK and the Gui shows proximity detection (BT0 touched, white)





Figure 7: button BT0 touched (SX864x) or proximity detected (Sx863x)

The EVK and GUI are operational.



2.3 GUI tooltips and Help

All GUI buttons, LEDs, scroll bars, icons have tooltips which show briefly the functionality. The tooltips can be activated by the user by moving the mouse over the desired area (see example I2C address selection).



Figure 8: tooltip example



3 Hardware Description

The EVK boards are described in this chapter. Please refer to the schematics and layout provided at the end of the document for more details about the exact hardware implementation.

3.1 Overview



Figure 9: SX8644EVK Board Picture



Figure 10: SX8645EVK Board Picture



3.1.1 USB Connector (#1)

The USB connector allows the EVK to be connected to a PC from which it will get its power and configuration/control commands via the dedicated software.

3.1.2 VREG (#2)

VREG is fixed to the typical operating voltage of 3.3V using the Semtech Sc153 voltage regulator, ensuring correct I2C communication between the SX863x/4x and the FT2232D.

3.1.3 EEPROM (#3)

FT2232D is associated to an EEPROM which keeps the FTDI chip's parameters when power is turned off. The EEPROM is used to customize USB device description.

3.1.4 ON/OFF switch (#4)

The ON/OFF switch turns ON (right position) or OFF (left position) the supply for the SX863x/4x and at the same time the red power indication LED (#6).

3.1.5 Test Switch (#5)

Only applicable for SX864x: This switch is for Semtech internal use and needs to be always in the left position. The EVK will not operate if this switch is in the wrong position.

3.1.6 Power Indication LED (#6)

The read LED indicates if the SX863x/4x are turned ON or OFF, according the position of switch (#4).

3.1.7 FT2232D (#7)

The FT2232D from FTDI will be used as a USB to I2C bridge between the PC and the SX863x/4x; moreover it will also monitor and control RESETB and INTB signals (similar to what a host would do in a final application). The USB bridge is supplied directly over the USB cable.

3.1.8 Stand-alone Jumpers (#8)

These six jumpers are connecting the FT2232D bridge to the SX863x/4x.

Their purpose is, as their name suggests, being able to disconnect the SX863x/4x from the rest of the circuitry to access it externally (with an external host, sharing another I2C bus, etc.).

RESETB
V3V3
VDD_LED
INTB
SCL
SDA

Figure 11: Jumpers



3.1.9 Header (#9)

The header, 2x 10 pins allows the user connect to the different signals on the board e.g. for monitoring purposes.





3.1.10 SX8634, SX8635, SX8644, SX8645 (#10)

The Semtech Touch controller product.

3.1.11 LEDs on GPIO[7..0] (#11)

Eight green LEDs (D0..D7) are connected to the eight GPIOs of the SX8644 or SX8645 for visual feedback. Seven green LEDs (D1..D7) and one orange LED (D0, proximity) are connected to the eight GPIOs of the SX8634 or SX8635 for visual feedback.

3.1.12 Touch Sensors (#12)

Different size touch buttons and slider, wheel are connected to the SX863x/4x. The sensor area is covered by 2 mm thick transparent, acrylic glass.

3.2 Default EVK hardware settings.

Default settings of jumpers and switches:

- All jumpers need to be mounted.
- The ON/OFF switch (#4) can be in ON (right position) or OFF (left position).
- SX864x: The test switch (#5) needs to be in the left position.



4 Guided Tour of the GUI/EVK

4.1 Introduction

The paragraphs in this chapter allow the user to get to know the basics of the EVK and the SX863x/4x and to get the user acquainted with the GUI and the EVK and the way to use them.

The more technical details and functioning are described in following chapters and in the product datasheets (references [1] to [13]).

The steps in this chapter are straight forward and do not require a very detailed knowledge of the SX863x/4x neither of the EVK.

4.2 Active/Doze/Sleep Mode/Wake-up

Directly after a power up of the EVK the SX863x/4x will enter Active mode and sensor pins will be sensed every 30ms.

The user can change the operation mode by clicking on the icons.

The actual operation mode is then highlighted as shown below.



Figure 13: Operating Modes

The sensor pins are sensed every 195 ms in Doze Mode.

There are 2 ways from Doze mode to Active mode.

1) Use the Operating mode icon Active

2) Touching the button BT0 for at least 195ms. After the release of BT0 the Active mode is entered automatically. This is the so-called automatic wakeup. In case other buttons are touched nothing happens and Doze mode is maintained.

4.3 LED fading on GPO pins

Touching BT0 will enable LED D0 on the EVK. When BT0 is released the LED will remain on for some time and then go OFF slowly. It is easy to change the LED behavior by the following steps.

- select the GPIO tab



General	Cap Sensors Buttons	Slider/Wheel	Mapping GP	10 SPM / 12C					
_		107	106	105	104	103	102	101	100
	Mode:	GPO _	GPO 💌	GPO 💌	GPO 💌	GPO 💌	GPO 💌	GPO 💌	GPO 💌
	State after powerup:	OFF	• OFF •	OFF 💌	OFF 💌	OFF 💌	OFF 💌	OFF 💌	OFF 💌
	Autolight:	ON .	r ON 🔽	ON 💌	ON 💌	ON 💌	ON 💌	ON 💌	ON 💌
	Polarity:	Inverted	Inverted	Inverted 💌	Inverted 💌	Inverted 💌	Inverted 💌	Inverted 💌	Inverted 💌
	ON intensity:	255	255	255 🛨	255 🛨	255 🛨	255 🛨	255 🛨	255 🛨
	OFF intensity:	0	: 0 :	0	0	0	0 🕂	0	0 🛨
	Function:	Log	Log 💌	Log 💌	Log 💌	Log 💌	Log 💌	Log 💌	Log 💌
SPM	Inc factor:	1	1 -	1 💌	1 💌	1 💌	1 💌	1 💌	1 💌
	Dec factor:	1	1 -	1 💌	1 💌	1 💌	1 💌	1 💌	1 💌
	Inc time:	OFF	OFF 💌	OFF 💌	OFF 💌	OFF 💌	OFF 💌	OFF 💌	OFF
	Dec time:	0.5 ms	• 0.5 ms 💌	2.0 ms 💌	2.0 ms 💌	2.0 ms 💌	2.0 ms 💌	2.0 ms 💌	OFF 💽
	OFF delay:	OFF	OFF 💌	1.0 s 💌	1.0 s 💌	1.0 s 💌	1.0 s 💌	1.0 s 💌	OFF 💌
	Pullup/Pulldown:	Disabled _	Disabled	Disabled 💌	Disabled 💌	Disabled 💌	Disabled 💌	Disabled 💌	Disabled 💌
	Interrupt:	None	None 🔽	None 💌	None 💌	None 💌	None 💌	None 💌	None 🔻
	Debounce:	OFF	P OFF 🔽	OFF 🔽	OFF 🔽	OFF 🔽	OFF 🔽	OFF 🔽	OFF 🔽
	GPO control:	OFF	OFF 🔽	OFF 🔽	OFF 🔽	OFF 🔽	OFF 🔽	OFF 🔽	OFF 🔽
12C	GPI status:						0		
	GPP intensity:	0	- O			0 -	0 -	0 -	

Figure 14: GPIO tab modified (i)

Change the Dec time (default 2ms) and OFF delay (default 1.0s) to OFF. Each modification on this tab is immediately written to the EVK. After this is done the LED will turn off directly after a release.

eneral	Cap Sensors	Buttons	Slider/Wh	eel	Mapping	GPI	SPM /	12C										
			107		106		105		104		103		102		101		100	
	Mode:		GPO	•	GPO	•	GPO	•	GPO	•	GPO	•	GPO	•	GPO	•	GPO	◄
	State after p	owerup:	OFF	•	OFF	•	OFF	•	OFF	•	OFF	•	OFF	•	OFF	-	OFF	•
	Autolight:		ON	•	ON	•	ON	•	ON	•	ON	•	ON	•	ON	-	ON	•
	Polarity:		Inverted	•	Inverted	•	Inverted	•	Inverted	•	Inverted	•	Inverted	•	Inverted	•	Inverted	•
	ON intensity		25	5 🛨	25	5 🛟	255	;÷	255	5÷	255	÷	25	5 🛟	25	5 🕂	25	크
	OFF intensity	y:		0 🛨		0÷)÷)÷		÷		0÷)÷	64	43
	Function:		Log	-	Log	-	Log	•	Log	•	Log	•	Log	•	Log	-	Log	7
SPM	Inc factor:		1	-	1	•	1	•	1	•	1	•	1	•	1	-	1	•
	Dec factor:		1	-	1	-	1	•	1	•	1	•	1	•	1	-	1	•
	Inc time:		OFF	•	OFF	•	OFF	•	OFF	•	OFF	•	OFF	•	OFF	•	OFF	•
	Dec time:		0.5 ms	•	0.5 ms	•	2.0 ms	•	2.0 ms	•	2.0 ms	•	2.0 ms	•	2.0 ms	•	OFF	•
	OFF delay:		OFF	•	OFF	•	1.0 s	•	1.0 s	•	1.0 s	•	1.0 s	•	1.0 s	•	OFF	•
	Pullup/Pulld	own:	Disabled	7	Disabled	-	Disabled	v	Disabled	7	Disabled	-	Disabled	-	Disabled	-	Disabled	7
	Interrupt:		None	-	None	-	None	v	None	-	None	-	None	-	None		None	_
	Debounce:		OFF	-	OFF	-	OFF	7	OFF	7	OFF	7	OFF	-	OFF	-	OFF	$\overline{}$
	GPO control	:	OFF	-	OFF	-	OFF	-	OFF	-	OFF	-	OFF	-	OFF	-	OFF	-
I2C	GPI status:		0		0								0		0		0	
	GPP intensit	y:		0 ÷		0 ÷			() <u>÷</u>		A.		0÷) <u>^</u>	()÷

Figure 15: GPIO tab modified (ii)

Change the OFF intensity (default 0) to 64. The LED D0 will be enabled at very low brightness in the OFF state.



4.4 LED mapping on GPO pins

LED D0 on the EVK is mapped to button BT0. It is easy to map LED D0 to another button and e.g. swap with button1

General Cap	Sensors 🛛 I	Buttons 🛛 Slide	ar/Wheel	Mapping	g GPIO	SPM / 120	:					
	Sequ	ence	Key0		Key1	K	ey2	Key3		Key4	Key5	т
	10	Btnl))Btn0		BtnO	Btnl	0	Btn0	<u>I</u>]Bh	nU 🔄]
Autolight —	107	106		105		104	103		102	101	10	0
High	/CW 💌	Low/CCW	▼ Bt	n5	▼ Btn4	•	Btn3	▼ Bt	n2 🤇	Btn0	▼ Btn1	
Group0							Group1 -					
Slider/Whe	el-> 🗖	Segment	🗖 Hig	h/CW	Low/	CCW	Slider/Wh	eel ->	Touch	🗖 High/	rcw 🗖	Low/CCW
🗖 Btn11		Btn10	🗌 Btn	9	🗌 Btn8		🗖 Btn11		🗖 Btn10	🗖 Btn9		Btn8
🗖 Btn7		Btn6	🗌 Btn	5	🔲 Btn4		🗖 Btn7		🗖 Btn6	🗖 Btn5		Btn4
🗖 Btn3		Btn2	🗖 Btn	1	🗖 Btn0		🗖 Btn3		🗖 Btn2	🗖 Btn1		Btn0
Segment hyste	eresis:	2 📫	%									

Figure 16: Mapping tab modified

In the example above LED D0 is mapped to Button 1 (default is button 0) and LED D1 is mapped to button 0 (default is button 1).

4.5 Sensors for buttons, slider or wheel

The SX8634/44 and SX8635/45 start up with six buttons and six sensors in the slider or wheel. This can be easily changed in the Cap Sensor tab.

The configuration below shows a example which uses a slider with 5 sensors (6 per default), the buttons 0, 2, and 4 were turned off to save power consumption and button 6 was enabled.



General (Cap Sensors	Buttons [9	Slider/Whe	el Mapp	ing GPIC) [SPM /	12C								1				
Individual	sensitivity:		⊙ ON	O OFF											$\left \right $) (
Mode: Sensitivity: Thresh: Periodic of Data mor	Cap0	Cap1 Button 💌 5 🔹 640 🛫 tion:	Cap2 OFF	2 Ca Buttor 2 64	p3 C	Cap4 5 ÷ 8 640 ÷ 9	Cap5 utton V 7 V 512 V	Cap6 Button	Cap7 Slider 5 448	Ca Slider	p8 C	a p9 I er ▼ SI 5÷	Cap10 ider ▼ 5 ▼ 1 448 ▼ 7	Cap11 Slider 💌 5 😳 448 😳	BT0 BT1 BT2		BT6 BT7 BT7 BT8	0	· 2022
		CapO	Cap1	Cap2	Cap3	Cap4	Cap5	Cap6	Cap7	Cap8	Cap9	Cap10	Cap11		BT3		BT9		Ň
	Raw:	-149	-83	-100	-20	-85	-20	-100	-124	-125	-113	-75	-84		$\left \right $)	\frown		\sim
	Avg:	-185	-86	-118	-29	-115	-43	-154	-138	-149	-137	-149	-147			\mathcal{I}	\bigcirc		
	Diff:	0	47	57	31	0	0	1	41	57	40	80	38		BT4		BT10		
	Peak-Peak:	48	50	39	22	32	23	53	37	33	20	15	25				\frown		
	Noise RMS:	36	3	18	9	30	23	54	14	24	24	74	63			\mathcal{I}	\bigcirc		
						Sta	art	10.							BT5		BT11		

Figure 17: Cap Sensors modified

The GUI shows at the right side the modified users configuration. Green icons are enabled sensors and the grey icons are disabled sensors.



4.6 Monitor mode

Touching a sensor does not always mean the EVK will consider this as a touch.

It might e.g. be that the touch is only partly on the sensor area or maybe the overlay material is replaced by something thicker.

The EVK parameters are set such that sensor area, overlay material and thickness are operational.

In case the user changes the hardware or just needs to observe raw signals the GUI can be set in monitor mode.

Follow the next steps:

-select the Cap Sensors tab

General	Cap Sensors	Buttons 9	Slider/Whe	el 🛛 Mappi	ing GPIC) SPM /	'12C							
Individual	sensitivity:		● ON	O OFF										
	Cap0	Cap1	Cap2	Caj	p3 C	ap4	Cap5	Cap6	Cap7	Ca	p8 (Cap9	Cap10	Cap11
Mode:	Button 💌	Button 💌	Button	- Buttor	n 💌 But	ton 💌 🖪	lutton 💌	Slider 💌	Slider	✓ Slider	💽 Slic	ler 💌 S	ilider 💌	Slider 💌
Sensitivity	: 5 🛨	5 🛟	5	3	5 🕂 📔	5÷	7 🗧	5 🗧	5	-	5 🕂 📔	5 🛨 📘	5 🛟	5÷
Thresh:	640 🛨	640 🗧	640	64	0.3	640 🕂 🗌	512 🗧	448 🗧	448	- 44	8 🕂 📃	448 🗧	448 🗧	448 🗧
Periodic o	iffset compensal	tion:	Disabled		-									
r chodic c	mot compensa		1											
[^{−Data} mo	nitoring													
		CapO	Cap1	Cap2	Cap3	Cap4	Cap5	Cap6	Cap7	Cap8	Cap9	Cap10	Cap11	
	Raw:	-6	-35	-35	-25	29	-57	-25	-68	-93	-43	-50	-22	
	Avg:	-68	-68	-64	-74	22	-85	-54	-95	-49	-99	-88	-63	
	Diff:	42	0	42	41	22	36	19	62	47	56	27	23	
	Peak-Peak:	2754	149	133	153	144	203	143	212	150	157	171	184	
	Noise RMS:	62	33	29	49	7	28	29	27	44	56	38	41	
						S	tart	hin.						

Figure 18: Cap Sensors tab

- then push the Start button at the bottom.







Figure 19: Monitor tab

The left graph shows the current values of all enabled sensors.

The right graph shows the sensor values over time (like an oscilloscope).

- select button 0 in the lower right corner



Figure 20: Select thresholds, hysteresis

This will superpose the detection threshold and hysteresis (yellow and green lines) on the graphs.

If one touches button0 and the red signal goes above the threshold+hysteresis the SX8644 or SX8645 considers that as a touch.

If the signal goes below the threshold – hysteresis the button is released.





Figure 21: two successive touches on button 0

- click on the stop button Stop on the Cap Sensor tab to go back to normal mode.

4.7 Sensitivity

The sensor sensitivity needs to be adapted to the thickness of the overlay, permittivity of the overlay, the size of the buttons and detection thresholds.

The following shows a typical example of changing the sensitivity of the sensors using the EVK.

If the user touches button 0 as in the previous section then the sensor values are relatively large as the threshold is passed with a lot off margin.

The sensitivity of a button can be modified easily in the Cap Sensors Tab.

	CapO
Mode:	Button 💌
Sensitivity:	5 🛨
Thresh:	640 🛨

Figure 22: sensitivity (5) of button 0

The default sensitivity for button 0 is five. A lower sensitivity would operate as well for button 0. Going into monitor mode as described in the previous section is required to observe the sensor signal and thresholds and hysteresis.





Figure 23: sensitivity (0) of button 0,

sensitivity (1) of button 0

The above figures show that button 0 requires at least a sensitivity of 1 to pass the detection threshold and hysteresis (green) If the sensitivity is set to 0 the sensor values are not large enough to exceed the threshold and a touch will never be

detected.



5 GUI Description

5.1 GUI Overview

> SX863x/SX864x Evaluation Kit		
Genetal Can Sensors Buttone Sider Wheel Manning GPID SPM //20		
General Cap Sensors Buttons Slider/Wheel Mapping GPI0 SPM / 12C I2C Address: Dx2B I2C Active scan period: 30 \$ ms Doze scan period: 195 \$ ms Passive timer: 0 \$ \$	BT0 BT6 BT1 BT7 BT1 BT7 BT3 BT9 BT4 BT10 BT5 BT11	•
Product SX8634 SPM: QSM 0x6F O		
- SPM File: -		

Figure 24: SX8634/44 GUI Overview

File Action Help Image: Active Doze Sleep 122 address: 0x28 General Cap Sensors Buttons Sider/wheel Mapping B10 B16 B10 B16 B10 B16 B16 B17 Image: Caddress: I2C Address: Dv28 Image: Caddress: Dv28
General Cap Sensors Buttoms Silder/Wheel Mapping GPI0 SPM / I2C
Lefereral Cap Sensors Buttons Slider/Wheel Mapping GPI0 SPM / I2C
Active scan period: .000 ms Doce scan period: .1950 ms Passive time: .000 s

Figure 25: SX8635/45 GUI Overview



5.2 File Menu

File menu contains general purpose functions. Most of them can also be accessed on the toolbar by clicking directly on the icon.

File	Action Help
-\$>	Disconnect
2	Open SPM
	Save SPM
ø	Save SPM As
	Exit

Figure 26: File Menu

5.2.1 Connect/Disconnect

This item is used to connect/disconnect the GUI to/from the EVK. The icon and name of the menu item dynamically changes depending on the current connection state.

This feature is also available directly on the toolbar.

5.2.2 Open SPM

The GUI offers the possibility to save/load the SPM parameters into/from a file.

The "Open SPM" feature reads a SPM file, stored on the PC, and copies the content to the SPM of the SX863x/4x.

This feature is also available directly on the toolbar.

File Edit	Search Vie	ew Format	Language	Settings M	a
] 🔓 🖨	88	i 🔓 🔒 📗	* 🖻 🜔	> C	
😑 sx8644	EVK.spm 🔀				
1	#Addre	ess[Hex]	Value	[Hex]	
2	0x00	0x31			
3	0x01	0x00			
4	0x02	0x10			
5	0x03	OxOD			
6	0x04	Ox2B			
7	0x05	0x02			
8	0x06	OxOD			
9	0x07	0x00			
10	0x08	0x00			

Figure 27: SPM File Example (begin)

The SPM files contain 128 data bytes for the address 0x00 to 0x7F. The end of the SPM file is shown below.



File Edit S	Search Vie	w Format
🖪 🖨 🖻	🖬 🔓	Го 👌
😑 sx8644E\	/K.spm 🔀	
126	0x7C	0x22
127	Ox7D	0x41
128	Ox7E	OxFF
129	Ox7F	OxDO
130		

Figure 28: SPM File Example (end)

5.2.3 Save SPM

This feature saves the current SPM from the SX863x/4x in the currently opened SPM file and overriding it. after confirmation by the user.

This feature is also available directly on the toolbar.

5.2.4 Save SPM As

This is the standard derivate of the "Save SPM" feature used to save the current SPM to a different name.

5.2.5 Exit

This item closes the GUI.

5.3 Action Menu



Figure 29: Action Menu

5.3.1 Refresh

This item is used to read values from the EVK to update the GUI in case these both are out of sync.

This feature is also available directly on the toolbar.

5.3.2 Compensate offset

This item is used to force a compensation of parasitic capacitances. By clicking on the item the GUI issues the I2C command to start the compensating procedures in the SX863x/4x.

This feature is also available directly on the toolbar.



5.3.3 Operating mode

This item is used to change the operating mode of the EVK. This feature is also available directly on the toolbar.

Act	ion	Help						
	<u>R</u> e	fresh			Sle	ер	8	I2C a
123	⊆o	mpensate	Offset		Whee	el Ì M	lappii	ng G
	Q	erating mo	ode	•	~	<u>A</u> ct	ive	
3	<u>N</u> V	M burn				<u>D</u> o:	ze	
_						Sle	ер	

Figure 30: Operating Mode

5.3.4 NVM burn

This item is used to write permanently the SPM content in the NVM.

This feature is also available directly on the toolbar.

The NVM can be burned three times so the burn feature needs to be selected with precaution.

By selecting the item the user needs to confirm the NVM burn. The burn is confirmed by entering the key "A55A" and by selecting the Yes button.

🗲 Do you confirm the	NVM burn ?	×
unlock key (see us	erguide):	
Yes	No	

Figure 31: Confirm NVM burn

After the NVM burn the GUI will inform the user the NVM burning is terminated.

×
NVM burned
OK

Figure 32: Confirmation NVM is burned

After a power down-power up sequence the EVK will start up with the new settings.



5.4 Help Menu

5.4.1 Overview

Help	D
0	Help
	User's Guide
	About SX864x Evaluation Kit
	Figure 33: GUI Help Menu

5.4.2 Help

This item shows or hides the help window. The help window shows useful information when the user moves the mouse over GUI items, registers etc...

This feature is also available directly on the toolbar.

5.4.3 User's Guide

This item opens the User's guide (pdf).

5.4.4 About SX863x/4x Evaluation Kit

This item shows the versions of the GUI and SX863x/4x.

About SX863x/SX864x Ev	aluation Kit	X
About SX863x/SX864x Ev	atuation Kit SX863xSX864xEVK FTDI bridge SX863xEVK Gui Version 1.0.0 - 24.09.2010 14:17:12 Firmware v1.1.0 - Dec 14 2009 Copyright © 2010 SEMTECH Enables the evaluation of Semtech Capacitive Sensors	×.]
	Products, SX863x and SX864x	

Figure 34: About window



5.5 Toolbar

The toolbar allows the user to choose rapidly an action without browsing through the file, action and help menu. The description of the items can be found in the previous menu sections.

💕 🔒 🐟	2 🔡	Active	Doze	Sleep	3	I2C address:	0x2B	•	0
		Fig	gure 3	5: Tool	bar				

riguro co. rocibar

The I2C address is showing the address the GUI uses to communicate with the EVK (default address 0x2B). If a SX863x/4x with a different address is connected then the user can select the GUI address by typing directly the address value or by using the scroll bar.

I2C address:	0x2B 🝷
ng GPIO S	0x2B
	0x2C 0x2D
	0x2E
	0x2F 0x30
	0x31 🔜
	0x32 💌

Figure 36: I2C address



5.6 Statusbar

The status bar shows useful information on the the status of the GUI and the EVK.

D0 😑	5X8644 SPM: QSM 0xD0 🥥
SPM File: -	

Figure 37: Statusbar

The product field shows the detected product on the EVK (SX8634, SX8635, SX8644 or SX8645).

The **SPM** field shows the origin of the SPM. This will be QSM, NVM1, NVM2 or NVM3.

The last two fields show the CRC of the SPM calculated by the GUI and if that CRC corresponds to the CRC of the EVK.

A green LED shows both CRCs are identical.

An orange LED shows that the CRCs are different. Clicking the 'refresh' item is will synchronize the GUI and the EVK and the LED will turn green.

The fields at the bottom of the Status bar show error messages or the actual name of the used SPM file. E.g. an error message will appear if the GUI tries to connect to an EVK which is not powered.



Figure 38: Statusbar with error message

In case the user opens or saves a SPM file then the current SPM file name appears at the right bottom side of the status bar.

Product

Figure 39: Statusbar with SPM file



5.7 Sensor Status

The sensor status shows buttons and a slider for the SX8634/44EVK and buttons and a wheel for the SX8635/45EVK.



Figure 40: Sensor status for SX8634/44EVK and SX8634/45EVK

In the case of the SX8634/44 six green buttons are shown and six chevrons for the slider. In the case of the SX8635/45 six buttons are shown and the wheel is composed of six segments. The sensor status area will change according the number of buttons, sensors in a slider or wheel.

The sensor status is taken from the I2C registers of the SX8634/44 and SX8635/45. If the user touches a button strongly enough then the GUI turns the corresponding button into white.







If the slider is touched strongly enough then the position of the finger on the slider is shown by a small red bar and by the position value (position is 31 in the example below).

If the slider is not touched the small red bar disappears while the GUI maintains the last touched position.



Figure 42: Example slider touched

Two purple indicators at the top and bottom of the slider show the move high or move low information taken from the I2C registers.

Dark purple means no move detected. Bright purple means a move high or move low is detected.





Figure 43: Example slider move high and move low

If the wheel is touched strongly enough then the position of the finger on the wheel is shown by a small red circle and by the position value (position is 39 in the example below).

If the wheel is not touched the red circle turns into grey while the GUI maintains the last touched position.



Figure 44: Example wheel touched

Two purple indicators at the top of the wheel show the move counter clock wise and move clock wise information taken from the I2C registers.

Dark purple means no move detected. Bright purple means a move counter clock wise or clock wise is detected.



Figure 45: Example wheel move counter clock wise and move clock wise

Rev 0.9 - September 2010



5.8 GUI tabs

The GUI uses seven tabs:

- General
- Cap Sensors
- Buttons
- Slider/Wheel
- Mapping
- GPIO
- SPM/I2C

The content of the tabs allow the user to change the configuration of the SX863x/4x. The tabs are organized according the sections of the SPM which are described in detail in the datasheets of the SX863x/4x family [1] to [13].

Each tab shows specific configuration data which can be changed by the user. The GUI assists the user by entering high level parameters so that it is not required to know the detailed hexadecimal information. Parameters will be grayed out if the user does not have to program them or if they do not apply.

In case the user prefers to enter direct hexadecimal data then this can be done in the SPM/I2C tab

5.8.1 General tab



The general tab allows the user to change the system settings of the EVK.

Rev 0.9 – September 2010



5.8.2 Cap Sensors tab

ieneral C	ieral Cap Sensors Buttons Slider/Wheel Mapping GPIO SPM / I2C													
ndividual s	fividual sensitivity: OUN OUFF													
	CapO	Cap1	Cap2	Cap	p3 C	ap4	Cap5	Cap6	Cap7	Cap	58 C	ap9	Cap10	Cap11
/ode:	Button 💌	Button 💌	Button	Button	n 💌 But	ton 🗾 B	utton 💌	Wheel 💌	Wheel	▼ Whee	I 🗾 Wh	eel 🗾 🛛	/heel 🗾	Wheel 💌
ensitivity:	5 🗧	5 🛟	5	3	5 🖶 📔	5 🛨	7 🕂	5 🛨	5	3	5 🕀 🔽	5 🛨	5 🛨	5 🛨
hresh:	640 🛨	640 🛨	640	64	0 🗄 🕅	640 🛨 「	512 🛨	448 🔅	448	44	8.3	448 🛨 🗍	448 🛨	448 🛨
Periodic off	fset compensal	tion:	Disabled		-									
oneare an	riodic offset compensation: Usabled													
-Data mon	nitoring													
-Data mon	nitoring													
Data mon	hitoring	СарО	Cap1	Сар2	Cap3	Cap4	Сар5	Сарб	Cap7	Cap8	Сар9	Cap10	Cap11	
Data mon	nitoring Raw:	Cap0	Cap1 0	Сар2 0	Сар3 0	Cap4	Сар5 0	Сарб 0	Сар7 0	Сар8 0	Сар9 0	Cap10 0	Cap11 0	
Data mon	nitoring Raw: Avg:	Сар0 0 0	Cap1 0	Сар2 0	Сар3 0	Сар4 0	Сар5 0	Сар6 0	Сар7 0	Сар8 0	Сар9 О	Cap10 0	Cap11 0	
Data mon	nitoring Raw: Avg: Diff:	Сар0 0 0 0	Cap1 0 0 0	Сар2 0 0 0	Cap3 0 0 0	Сар4 0 0	Cap5 0 0	Сарб 0 0 0	Сар7 0 0	Сар8 0 0	Сар9 0 0	Cap10 0 0 0 0 0	Cap11 0 0 0	
-Data mon	Naw: Avg: Diff: Peak-Peak:	Cap0 0 0 0 0 0	Cap1 0 0 0 0 0	Cap2 0 0 0 0	Cap3 0 0 0 0 0 0	Cap4 0 0 0 0 0	Cap5 0 0 0 0 0 0 0	Сарб 0 0 0 0 0	Cap7 0 0 0	Cap8 0 0 0 0 0 0	Cap9 0 0 0 0 0 0	Cap10 0 0 0 0 0	Cap11 0 0 0 0 0 0 0 0	
Data mon	itoring Raw: Avg: Diff: Peak-Peak: Noise RMS:	Сар0 0 0 0 0 0 0	Cap1 0 0 0 0 0 0	Cap2 0 0 0 0 0 0 0	Cap3 0 0 0 0 0	Cap4 0 0 0 0 0 0	Cap5 0 0 0 0 0 0 0 0 0	Сарб 0 0 0 0 0 0 0	Cap7 0 0 0 0	Cap8 0 0 0 0	Cap9 0 0 0 0 0	Cap10 0 0 0 0 0 0	Cap11 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	
Data mon	nitoring Raw: Avg: Diff: Peak-Peak: Noise RMS:	Cap0 0 0 0 0 0 0	Cap1 0 0 0 0 0 0	Cap2 0 0 0 0 0 0	Cap3 0 0 0 0 0 0 0 0 0	Cap4 0 0 0 0 0	Cap5 0 0 0 0 0	Сарб 0 0 0 0 0 0 0	Cap7 0 0 0 0 0	Cap8 0 0 0 0 0	Cap9 0 0 0 0 0	Cap10 0 0 0 0 0 0 0	Cap11 00 00 00 00	
Data mon	Noise RMS:	Cap0 0 0 0 0 0	Cap1 0 0 0 0 0 0	Cap2 0 0 0 0 0	Cap3 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Cap4 0 0 0 0 0 0 5t	Cap5 0 0 0 0 0	Сарб 0 0 0 0 0	Cap7 0 0 0 0	Cap8 0 0 0 0	Cap9 0 0 0 0 0 0 0	Cap10 0 0 0 0 0 0	Cap11 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	

Figure 47: cap sensors tab

The top of the cap sensor tab is dedicated to the parameters associated to the sensors pins CAP0 to CAP11of the SX863x/4x.

The bottom part of this tab allows the user to monitor noise estimators for each pin. The monitor is enabled by choosing the 'Start' button.

The small monitor icon will be enabled and the 'Start' button turns in to the 'Stop' button.



Figure 48:monitor enabled

In monitor mode the EVK is scanned every 195ms as the data rate over the USB is increased and the GUI needs to comply to this increased data throughput.





By clicking on the monitor icon the GUI opens the monitor window

Figure 49:monitor window

The monitor window shows the cap sensor (difference) data (see datasheet for details). The left side of the window (graph header 'All') shows the current value of all enabled cap sensors. The right side of the window (graph header 'Capx') shows the values of all cap sensors over time.

At the very right side the user can hide or show signals by checking the boxes next to the Cap text.

Cap0	
🔽 Cap1	
🗹 Cap2	
🔽 Cap3	
🔽 Cap4	
🔽 Cap5	
💌 Сарб	
🔽 Cap7	
🔽 Cap8	
💌 Сар9	
🗹 Cap10	
🔽 Cap11	

Figure 50:show/hide monitor signals





Thresholds can be superposed on the graphs by selecting buttons, wheel or slider.

Figure 51:example: super pose thresholds of button 0





Figure 52:graph pop up window

By a right button mouse click on the graph a pop up window appears which allows the user to copy, save and print the graph. Furthermore the user can zoom or un-zoom into specific graph regions of interest.



5.8.3 Buttons tab

Can Camara	Buttons	Clider At the of	Manairal	CDIO	leon usel								
Cap Sensors	Duttons	Silder/Wrieer	Mapping	ario									
		_											
		Touc	h report:										
		Interr	upt:				On both 💌						
		Rele	ase deboun	ce:		ļ	OFF 💌	Samples					
		Touc	h debounce	в:			OFF 💌	Samples					
		Aver	age thresho	ld:			320 📫						
		Nega	ative offset o	compen	sation threshold:	:	320 ≑						
		Nega	ative offset o	compens	sation trigger:	ļ	1 🗧	Samples					
		Hyste	eresis:			ļ	10 🗧	%					
		Stud	k at timeout:				0 🕂	s					
	Cap Sensors	Cap Sensors Buttons	Cap Sensors Buttons Slider/Wheel Touc Inter Relea Touc Aver Nega Nega Hysta Stuck	Cap Sensors Buttons Slider/Wheel Mapping Touch report: Interrupt: Interrupt: Release debound Touch debounder Average threshold Negative offset of Negative offset of Nysteresis: Stuck at timeout	Cap Sensors Buttons Slider/Wheel Mapping GPIO Touch report: Interrupt: Interrupt: Release debounce: Touch debounce: Touch debounce: Average threshold: Negative offset compent: Negative offset compent: Hysteresis: Stuck at timeout: Stuck at timeout: Stuck at timeout:	Cap Sensors Buttons Slider/Wheel Mapping GPI0 SPM / I2C Touch report: Interrupt: Interrupt: Release debounce: Interrupt: Touch debounce: Average threshold: Negative offset compensation threshold Negative offset compensation trigger: Hysteresis: Stuck at timeout:	Cap Sensors Buttons Slider/Wheel Mapping GPID SPM / I2C Touch report: Interrupt: I	Cap Sensors Buttons Slider/Wheel Mapping GPIO SPM / I2C Interrupt: Touch report: ALL Interrupt: On both Interrupt: Interrupt: On both Interrupt: On both Interrupt: Touch debounce: OFF Interrupt: OFF Interrupt: Average threshold: 320 320 Interrupt: Interrupt: Negative offset compensation threshold: 320 Interrupt: Interrupt: Negative offset compensation threshold: 320 Interrupt: Interrupt: Negative offset compensation threshold: 0 Interrupt: Interrupt: Negative offset compensation threshold: 0 Interrupt: Interrupt: Negative offset compensation trigger: 1 Interrupt: Interrupt: Negative offset compensation trigger: 10 Interrupt: Interrupt: Stuck at timeout: 0 Interrupt: Interrupt: Interrupt:	Cap Sensors Buttons Silder/Wheel Mapping GPI0 SPM / I2C Interrupt: Interrupt: Interrupt: Interrupt: Interrupt: Samples Interrupt: Interrupt: Interrupt: Interrupt: Samples Interrupt: Interrupt: Interrupt: Samples Average threshold: Intershold: Intershold: Intershold: Negative offset compensation threshold: Intersite Intersite Intersite Negative offset compensation trigger: Intersite Intersite Intersite Intersite Negative offset compensation trigger: Intersite Intersite Intersite Intersite Intersite Negative offset compensation trigger: Intersite Intersi	Cap Sensors Buttons Slider/Wheel Mapping GPI0 SPM / I2C Interrupt: ALL< Interrupt: On both Release debounce: OFF Samples Touch debounce: OFF Samples Average threshold: 320 Negative offset compensation threshold: 320 Negative offset compensation trigger: 1 Samples Hysteresis: 10 2 Stuck at timeout: 0 3 s	Cap Sensors Buttons Slider/Wheel Mapping GPI0 SPM / I2C Touch report: ALL Interrupt: Interrupt: Interrupt: Interrupt: Samples Inder debounce: OFF Samples Samples Average threshold: 320 ± Negative offset compensation threshold: 320 ± Negative offset compensation trigger: 1 ± Samples Hysteresis: I0 ± Stuck at timeout: I0 ± s s	Cap Sensors Buttoms Slider/Wheel Mapping GPI0 SPM / I2C Interrupt: ALL Interrupt: On both Interrupt: Samples Interrupt: On both Interrupt: Samples Samples Average threshold: 320 Samples Negative offset compensation threshold: 320 Negative offset compensation threshold: 320 Samples Samples Stuck at timeout: 0 Image: Image: Image: Stuck at timeout: 0 Image: Image: Image: Image:	Cap Sensors Buttons Slider/Wheel Mapping GPI0 SPM / I2C Touch report: ALL< Interrupt: On both Release debounce: OFF Samples Touch debounce: OFF Samples Average threshold: 320 - Negative offset compensation threshold: 320 - Negative offset compensation threshold: 320 - Hysteresis: 10 - z Stuck at timeout: 0 - s

Figure 53: buttons tab

The buttons tab allows the user to change the configuration of the buttons.



5.8.4 Slider/Wheel tab

General Cap Sensors Buttons Slider/	Wheel Mapping GPIO SPM / I2C		
	Release debounce:	OFF 💌	Samples
	Touch debounce:	OFF 💌	Samples
	Stuck at timeout:	0	\$
	Hysteresis:	12 🕂	
	Normalization factor:	10.00000	
	Average threshold:	320 🛨	
	Negative offset compensation threshold:	320 🗧	
	Negative offset compensation trigger:	1 🕂	Samples
	Move detection Threshold:	5 🕂	%
	Wheel angle offset:	0	Steps

Figure 54 slider or wheel tab

The slider or wheel tab allows the user to change the configuration of the slider (SX8634/44EVK) or the wheel (SX8635/45EVK).



5.8.5 Mapping tab

General Cap	Sensors Buttons Slic	ler/Wheel Mapping) GPIO SPM / 12(
-Wakeup	Sequence	Key0 0 🔽 Btn0	Key1 K	ey2 Key VBtn0	3 Key Btn0	v4 Key ∑∫Btn0	15
-Autolight	107 106 /CW 💌 Low/CCW	IO5 T Btn5	IO4 ▼ Btn4 ▼	IO3 Btn3 T E	102 Itn2 🔽 🖪	101 tn1 💌 Bi	100 n0 💌
Group0 Slider/Whe Btn11 Btn7 Btn3	el-> 🗌 Segment 🗍 Btn10 🔲 Btn6 🔲 Btn2	High/CW Btn9 Btn5 Btn1	Low/CCW Btn8 Btn4 Btn0	Group1 Slider/Wheel -> Btn11 Btn7 Btn3	Touch Btn10 Btn6 Btn2	High/CW Btn9 Btn5 Btn1	Low/CCW Btn8 Btn4 Btn0
Segment hyste	resis: 2÷	%					

Figure 55 mapping tab

The mapping tab allows the user to change the configuration of the mapping.



5.8.6 GPIO tab

General	Cap Sensors Buttons	Slider/Wheel	Mapping ¹	GPIO	SPM / I	2C										
_		107	106		105		104		103		102		101		100	
	Mode:	GPO 💽	GPO	•	GPO	•	GPO	•	GPO	•	GPO	•	GPO	•	GPO	•
	State after powerup:	OFF	OFF	•	OFF	•	OFF	•	OFF	•	OFF	•	OFF	•	OFF	•
	Autolight:	ON -	ON	•	ON	•	ON	•	ON	•	ON	•	ON	•	ON	•
	Polarity:	Inverted •	Inverted	•	Inverted	•	Inverted	•	Inverted	•	Inverted	•	Inverted	•	Inverted	•
	ON intensity:	255	255	÷	255	÷	255	÷	255	;÷	255	÷	255	5÷	255	; 🕂
	OFF intensity:	0		÷	0	÷		÷)÷	()÷)÷		Ð
	Function:	Log	Log	•	Log	•	Log	•	Log	•	Log	•	Log	•	Log	•
SPM	Inc factor:	1	1	•	1	•	1	•	1	•	1	•	1	•	1	•
	Dec factor:	1	1	•	1	•	1	•	1	•	1	•	1	•	1	•
	Inc time:	OFF	OFF	•	OFF	•	OFF	•	OFF	•	OFF	•	OFF	•	OFF	•
	Dec time:	0.5 ms 💌	0.5 ms	•	2.0 ms	•	2.0 ms	•	2.0 ms	•	2.0 ms	•	2.0 ms	•	2.0 ms	•
	OFF delay:	OFF 💽	OFF	•	0.6 s	•	0.6 s	•	0.6 s	•	0.6 s	•	0.6 s	•	0.6 s	•
	Pullup/Pulldown:	Disabled 🔄	Disabled	$\overline{}$	Disabled	-	Disabled	-	Disabled	-	Disabled	-	Disabled	-	Disabled	~
	Interrupt:	None	None	$\overline{}$	None	7	None	-	None	-	None	-	None	-	None	7
	Debounce:	OFF	OFF	-	OFF	-	OFF	-	OFF	-	OFF	-	OFF	-	OFF	-
	GPO control:	OFF	OFF	$\overline{\mathbf{v}}$	OFF	-	OFF	-	OFF	-	OFF	-	OFF	-	OFF	
12C	GPI status:				-		-				0				-	
	GPP intensity:	0		- 	0	*	0	+ 7	(÷	(() ÷		F

Figure 56 GPIO tab

The GPIO tab allows the user to change the configuration of the GPIO either through the SPM or through the I2C registers.



5.8.7 SPM/I2C tab

General Cap Sensors Buttons Slider/Wheel Mapping GPIO SPI	4 / I2C			
SPM	I2C Reg	sters		
🕀 General	Register	Addr	Value	
	IrqSrc	0x00	0x02	
Buttons Slider/Wheel	CapStatMsb	0x01	0x00	
	CapStatLsb	0x02	0x00	
⊞ GPIO	SIdPosMsb	0x03	0x00	
	SIdPosLsb	0x04	0x32	
	Reserved	0x05	0x00	
	Reserved	0x06	0x00	
	GpiStat	0x07	0x00	
	SpmStat	0x08	0x00	Undata
	CompOpMode	0x09	0x28	
	GpoCtrl	0x0A	0x00	
	GppPinld	0x0B	0x00	
	GppIntensity	0x0C	0x00	
	SpmCfg	0x0D	0x00	
	SpmBaseAddr	0x0E	0xF9	
	Reserved	0x0F	0x00	
General	SpmKeyMsb	0xAC	0x00	
	SpmKeyLsb	0xAD	0x00	
	SoftReset	0xB1	0x00	

Figure 57 SPM/I2C tab

The SPM/I2C tab allows the user to change the configuration on a lower level as the previous tabs.

The I2C registers can be directly written (white boxes). As soon as data is entered the data becomes red (indicating that the GUI is being updated but not yet the EVK) and is written to the EVK after the 'Enter' key (data becomes black again showing GUI and EVK are in sync).

The GUI reads the I2C registers at each interrupt from the EVK. A manual read/write of the I2C registers can be done by selecting the 'Update' button on the right side of this tab.



The SPM is shown in this tab as hexadecimal values. Experienced users can enter data here directly without passing through the previous described tabs.

The GUI assures that entering data in this tab or in the other tabs remain coherent.

The details of the SPM can be shown by expanding each separate line (click on the '+' box).

	S	PM
Ξ	General	
	12CAddress	0x2B
	ActiveScanPeriod	0x02
	DozeScanPeriod	0x0D
	PassiveTimer	0x00
Ð	Cap Sensors	
Ŧ	Buttons	
Ð	Slider/Wheel	
Ð	Mapping	
Ŧ	GPIO	
Ca	ap Sensors	

Figure 58 SPM expanding General

Hexadecimal values can be entered and will be written to the EVK immediately after the pushing the Enter key.



6 Schematics



Figure 59: SX8644EVK schematic page 1/2





Figure 60: SX8644EVK schematic page 2/2





Figure 61: SX8645EVK schematic page 1/2





Figure 62: SX8645EVK schematic page 2/2





Figure 63: SX8634EVK schematic page 1/2





Figure 64: SX8634EVK schematic page 2/2





Figure 65: SX8635EVK schematic page 1/2





Figure 66: SX8635EVK schematic page 2/2



7 Layout



x:0.0 E146V01a TOP LAYER

Figure 67: SX8644EVK top layer



Figure 68: SX8644EVK mid layer 1

Rev 0.9 - September 2010





Figure 69: SX8644EVK mid layer 2





Rev 0.9 - September 2010









Figure 72: SX8645EVK mid layer 1

Rev 0.9 - September 2010





Figure 73: SX8645EVK mid layer 2



Figure 74: SX8645EVK bottom layer

Rev 0.9 - September 2010





Figure 75: SX8634EVK top layer



Figure 76: SX8634EVK mid layer 1





Figure 77: SX8634EVK mid layer 2



Figure 78: SX8634EVK bottom layer







Figure 80: SX8635EVK mid layer 1





Figure 81: SX8635EVK mid layer 2



Figure 82: SX8635EVK bottom layer

FR41,6mmCu35uStackLayerTOP Solder Mask : 25 - 30uMTOP Copper : 35uMEPOXY : 380uMMid Layer 1 Copper : 35uMEPOXY : 700uMMid Layer 2 Copper : 35uMEPOXY : 380uMBOT Copper : 35uMBOT Solder Mask : 25 - 30uM

Figure 83: SX8634/44EVK, SX8635/45EVK stacked layer information

Rev 0.9 - September 2010



8 References

- > [1] SX8643 Datasheet
- [2] SX8644 Datasheet
- > [3] SX8645 Datasheet
- [4] SX8646 Datasheet
- > [5] SX8647 Datasheet
- > [6] SX8648 Datasheet
- > [7] SX8649 Datasheet
- > [8] SX8633 Datasheet
- > [9] SX8634 Datasheet
- > [10] SX8635 Datasheet
- > [11] SX8636 Datasheet
- > [12] SX8638 Datasheet
- > [13] SX8639 Datasheet



© Semtech 2010

All rights reserved. Reproduction in whole or in part is prohibited without the prior written consent of the copyright owner. The information presented in this document does not form part of any quotation or contract, is believed to be accurate and reliable and may be changed without notice. No liability will be accepted by the publisher for any consequence of its use. Publication thereof does not convey nor imply any license under patent or other industrial or intellectual property rights. Semtech assumes no responsibility or liability whatsoever for any failure or unexpected operation resulting from misuse, neglect improper installation, repair or improper handling or unusual physical or electrical stress including, but not limited to, exposure to parameters beyond the specified maximum ratings or operation outside the specified range.

SEMTECH PRODUCTS ARE NOT DESIGNED, INTENDED, AUTHORIZED OR WARRANTED TO BE SUITABLE FOR USE IN LIFE-SUPPORT APPLICATIONS, DEVICES OR SYSTEMS OR OTHER CRITICAL APPLICATIONS. INCLUSION OF SEMTECH PRODUCTS IN SUCH APPLICATIONS IS UNDERSTOOD TO BE UNDERTAKEN SOLELY AT THE CUSTOMER'S OWN RISK. Should a customer purchase or use Semtech products for any such unauthorized application, the customer shall indemnify and hold Semtech and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs damages and attorney fees which could arise.

Contact Information

Semtech Corporation Advanced Communications and Sensing Products Division 200 Flynn Road, Camarillo, CA 93012 Phone: (805) 498-2111 Fax: (805) 498-3804





Общество с ограниченной ответственностью «МосЧип» ИНН 7719860671 / КПП 771901001 Адрес: 105318, г.Москва, ул.Щербаковская д.З, офис 1107

Данный компонент на территории Российской Федерации

Вы можете приобрести в компании MosChip.

Для оперативного оформления запроса Вам необходимо перейти по данной ссылке:

http://moschip.ru/get-element

Вы можете разместить у нас заказ для любого Вашего проекта, будь то серийное производство или разработка единичного прибора.

В нашем ассортименте представлены ведущие мировые производители активных и пассивных электронных компонентов.

Нашей специализацией является поставка электронной компонентной базы двойного назначения, продукции таких производителей как XILINX, Intel (ex.ALTERA), Vicor, Microchip, Texas Instruments, Analog Devices, Mini-Circuits, Amphenol, Glenair.

Сотрудничество с глобальными дистрибьюторами электронных компонентов, предоставляет возможность заказывать и получать с международных складов практически любой перечень компонентов в оптимальные для Вас сроки.

На всех этапах разработки и производства наши партнеры могут получить квалифицированную поддержку опытных инженеров.

Система менеджмента качества компании отвечает требованиям в соответствии с ГОСТ Р ИСО 9001, ГОСТ РВ 0015-002 и ЭС РД 009

Офис по работе с юридическими лицами:

105318, г.Москва, ул.Щербаковская д.3, офис 1107, 1118, ДЦ «Щербаковский»

Телефон: +7 495 668-12-70 (многоканальный)

Факс: +7 495 668-12-70 (доб.304)

E-mail: info@moschip.ru

Skype отдела продаж: moschip.ru moschip.ru_4

moschip.ru_6 moschip.ru_9