
19 FEB 08 Rev D



Mass Termination Assembly (MTA)-100 Insulation Displacement Contact (IDC) Closed-End Receptacle Connectors

With Lock (Ramp) With Lock (Ramp) and Polarizing Tabs

Figure 1

#### 1. INTRODUCTION

Terminating Head 58246-1 (shown in Figure 1) is designed to terminate discrete wire in MTA-100 IDC closed-end receptacle connectors with lock (ramp) and with lock and polarizing tabs. Slotted contacts for insulation displacement termination are preassembled on 2.54-mm [.100-in.] centerlines in each color-coded housing for a specific wire size.

The head must be installed in Pistol Grip Manual Handle Assembly 58074–1 or Pistol Grip Pneumatic Handle Assembly 58075-1. For head installation and removal, refer to Instruction Sheet 408-6790 for the manual handle assembly and 408-6789 for the pneumatic handle assembly.

For detailed connector description and application requirements, refer to Application Specification 114-1019.

Read these and all referenced instructions thoroughly before using the head.



All numerical values in this instruction sheet are in metric units [with U.S. customary units in brackets]. Dimensions are in millimeters [and inches]. Figures are not drawn to scale.

Reasons for reissue of this instruction sheet are provided in Section 8, REVISION SUMMARY.

## 2. DESCRIPTION

The head serves as a guide and support for the connector during termination. Features of the head (shown in Figure 1) and their function are as follows. Wire Inserter — forces the wire into the two slotted beams of the contact. Note that it provides support for the contact beams when applying insertion force on the wire.

Adjuster (Insertion Rod) — is a piston for the wire inserter and regulates wire inserter travel.

Feed Slide — automatically positions the connector after each termination.

Locating Pawl (or Anti-Backup Pawl) — aligns the connector for insertion, and retains it during termination.

### 3. SETUP AND TEST INSPECTION

The adjuster (insertion rod) is preset for wire sizes 28 through 22 AWG. If the wire is being inserted too deeply or not deeply enough inside the contact, it may be necessary to adjust the depth of the wire inserter or, in addition, if the pneumatic handle assembly is being used, it may be necessary to adjust the air pressure. Proceed as follows:

#### 3.1. Setup

TOOLING ASSISTANCE CENTER 1-800-722-1111

PRODUCT INFORMATION 1-800-522-6752

1. Determine the wire size, and select the appropriate color-coded connector from Figure 2.

WIRE SIZE (AWG)	CONNECTOR COLOR CODE	
28	Green	
26	Blue	
24	Natural	
22	Red	

Figure 2

<sup>©2008</sup> Tyco Electronics Corporation, Harrisburg, PA All International Rights Reserved

TE logo and Tyco Electronics are trademarks.

<sup>\*</sup>Trademark. Other products, logos, and company names used are the property of their respective owners.

This controlled document is subject to change. For latest revision and Regional Customer Service, visit our website at www.tycoelectronics.com

2. Using a small knife, cut off the wire retainers (strain relief) of the connector. This will provide a clear view for inspecting the connector for a properly terminated wire in the contact. See Figure 3.



Wire retainers are removed in a connector for testing only. DO NOT use such connectors for production application.

- 3. Make a test termination according to Steps 1 through 5 of Section 5, TERMINATING PROCEDURE.
- 4. Push the connector out of the right side of the head.
- 5. Check that the wire insertion depth is within the dimension given in Figure 3.



To obtain the wire insertion depth, measure from the front of the contact beam to the center of the wire as shown in Figure 3 – or – measure from the front of the contact beam to the back of the wire and subtract the wire diameter divided by 2.

If it is not, proceed as follows:

For the manual handle assembly, refer to Section 4, WIRE INSERTION DEPTH ADJUSTMENT.

For the pneumatic handle assembly, if the wire is inserted too deeply (more than the required wire insertion depth), refer to Section 4, WIRE INSERTION DEPTH ADJUSTMENT. If the wire is not inserted deeply enough (less than the required wire insertion depth), increase the air pressure by 69 kPa [10 psi]. Repeat the termination procedure and check the insertion depth. Continue in this manner until either the proper insertion depth is obtained or the air pressure is set to 483 kPa [70 psi]. If the proper insertion depth is NOT reached at 483 kPa [70 psi], return the air pressure to 276 kPa [40 psi], and refer to Section 4.


6. Inspect the termination according to Paragraph 3.2.

# 3.2. Termination Inspection (Refer to Figure 3)



Refer to 114–1019 for detailed explanation of the termination inspection requirements.

- 1 The required wire insertion depth is within the dimension given in Figure 3 (refer to Step 5 of Paragraph 3.1 for measurement).
- 2 The end of the wire extends past the contact beam by at least 1.52 mm [.060 in.].



- 3 The contact beams are NOT deformed. If damage is apparent, replace the contacts in accordance with the instructions packaged with the connector.
- 4 The wire insulation is NOT nicked or cut in any area other than the two contact slots.
- 5 The wire extends past the wire retainer (strain relief) of the connector.

## 4. WIRE INSERTION DEPTH ADJUSTMENT (See Figure 4)

- 1. Remove the head from the handle assembly.
- 2. If the wire is inserted too deeply (more than the required wire insertion depth), reduce the wire insertion depth by turning the adjuster  $^{1}/_{6}$  of a revolution *clockwise*. The wire insertion depth will be reduced by approximately 0.20 mm [.008 in.].




If the wire is bottomed in the contact slot, this indicates that the adjuster is set to the maximum wire insertion depth — DO NOT turn the adjuster counterclockwise; otherwise damage to the head may occur.

If the wire is not inserted deeply enough (less than the required wire insertion depth), increase the wire insertion depth by turning the adjuster  $^{1}/_{6}$  of a revolution *counterclockwise*. The wire insertion depth will be increased by approximately 0.20 mm [.008 in.].



When turning the adjuster counterclockwise, make sure to check the wire insertion depth after EACH <sup>1</sup>/<sub>6</sub> revolution. If the adjuster is set past the maximum setting, damage to the head may occur.

# Wire Insertion Depth Adjustment



Turn COUNTERCLOCKWISE to Increase Wire Insertion Depth

DO NOT Turn Past Maximum Setting Refer to CAUTION

**Note:**  $^{1}/_{6}$  Revolution Equals 0.20 mm [.008 in.] Adjustment Figure 4

# 5. TERMINATING PROCEDURE (Refer to Figure 5)



There is no wire preparation required.

- 1. Insert the connector into the left side of the head.
- 2. Align the contact to be terminated with the wire inserter of the head (shown in Figure 1). Make sure that the locating pawl rests between the connector index ribs.
- 3. Insert an unstripped wire into the funnel area between the contact and the wire inserter until it bottoms on the tool base.
- 4. Squeeze the cam handle (manual) or depress the trigger (pneumatic) of the handle assembly, and hold it until the ratchet releases (manual) or the wire inserter bottoms (pneumatic).
- 5. Release the cam handle or trigger. The wire inserter will retract and the feed slide will automatically advance the connector to the next contact position.



The locating pawl will move up and down as the connector is automatically advanced through the head. However, if movement is obstructed, or if desired, the locating pawl can be depressed and the connector moved manually out of the RIGHT side of the head.

- 6. Repeat Steps 2 through 5 until all contacts have been terminated.
- 7. Inspect each termination according to Paragraph 3.2.

#### 6. MAINTENANCE AND INSPECTION

# 6.1. Daily Maintenance

- 1. Remove dust, moisture, and other contaminants with a clean, soft brush or lint–free cloth. DO NOT use objects that could damage the head.
- 2. Make sure that all components are in place and properly secured.
- 3. Actuate the tool to make sure that the mechanisms inside the head function smoothly.

# 6.2. Periodic Maintenance

- 1. Remove any accumulated film with a suitable cleaning agent that will not affect plastic.
- 2. Make sure all components are in place and properly secured.
- 3. Check for chipped, cracked, worn, or broken areas on the head. If damage is evident, repair or replace the head.




Figure 5

# 6.3. Inspection

Regular inspections should be performed by quality control personnel with a record of quality control inspections remaining with the personnel responsible for the head. One inspection per month is the recommended frequency; however, operator training and skill, amount of use, working conditions, and established company standards are all factors to be considered in establishing inspection frequency.

## 7. REPLACEMENT AND REPAIR


Customer–replaceable parts are listed in Figure 6. A complete inventory should be stocked and controlled to prevent lost time when replacement of parts is necessary. Parts other than those listed should be replaced by Tyco Electronics Corporation to ensure quality and reliability. Order replacement parts through your representative, or call 1–800–526–5142, or send a facsimile of your purchase order to 717–986–7605, or write to:

CUSTOMER SERVICE (038–035) TYCO ELECTRONICS CORPORATION PO BOX 3608 HARRISBURG PA 17105–3608 For customer repair service, call 1–800–526–5136.

#### 8. REVISION SUMMARY

Revisions to this instruction sheet include:

- Updated document to corporate requirements
- Removed connector part numbers
- Modified Figure 3
- Modified Step 5 of Paragraph 3.1 and Point 1 of Paragraph 3.2
- Modified Step 2 of Section 4
- Added phone number for customer repair service



	REPLACEMENT PARTS			
ITEM	PART NUMBER	DESCRIPTION	QTY PER HEAD	
1	312150-1	HEAD, Finished	1	
2	312158-2	HOUSING, Insert	1	
3	6-22278-5	SPRING, Compression	1	
4	312161-1	PAWL, Locating	1	
5	4-22430-8	SCREW, Machine (4-40 × .875 in. L)	4	
6	21041-7	PIN, Spiral Spring	1	
7	312192-1	PAWL, Feed	1	
8	312160-1	INSERTER, Wire	1	
9	22488-5	SPRING, Compression	1	
10	312149-1	ADJUSTER, Rod Insertion	1	
11	312148-1	ROD, Inserter	1	
12	3-21028-2	PIN, Slotted Spring	1	
13	312159-1	CAM, Traverse Slide	1	
14	1-23147-2	SPRING, Compression	1	
15	312151-1	SLIDE, Feed	1	

Figure 6

# **ПОСТАВКА** ЭЛЕКТРОННЫХ КОМПОНЕНТОВ

многоканальный

Общество с ограниченной ответственностью «МосЧип» ИНН 7719860671 / КПП 771901001 Адрес: 105318, г.Москва, ул.Щербаковская д.3, офис 1107

# Данный компонент на территории Российской Федерации Вы можете приобрести в компании MosChip.

Для оперативного оформления запроса Вам необходимо перейти по данной ссылке:

# http://moschip.ru/get-element

Вы можете разместить у нас заказ для любого Вашего проекта, будь то серийное производство или разработка единичного прибора.

В нашем ассортименте представлены ведущие мировые производители активных и пассивных электронных компонентов.

Нашей специализацией является поставка электронной компонентной базы двойного назначения, продукции таких производителей как XILINX, Intel (ex.ALTERA), Vicor, Microchip, Texas Instruments, Analog Devices, Mini-Circuits, Amphenol, Glenair.

Сотрудничество с глобальными дистрибьюторами электронных компонентов, предоставляет возможность заказывать и получать с международных складов практически любой перечень компонентов в оптимальные для Вас сроки.

На всех этапах разработки и производства наши партнеры могут получить квалифицированную поддержку опытных инженеров.

Система менеджмента качества компании отвечает требованиям в соответствии с ГОСТ Р ИСО 9001, ГОСТ РВ 0015-002 и ЭС РД 009

# Офис по работе с юридическими лицами:

105318, г. Москва, ул. Щербаковская д. 3, офис 1107, 1118, ДЦ «Щербаковский»

Телефон: +7 495 668-12-70 (многоканальный)

Факс: +7 495 668-12-70 (доб.304)

E-mail: info@moschip.ru

Skype отдела продаж:

moschip.ru moschip.ru\_6 moschip.ru 4 moschip.ru 9