### Evaluates: MAX31730

#### **General Description**

The MAX31730 evaluation kit (EV kit) provides the hardware and software graphical user interface (GUI) necessary to evaluate the MAX31730 3-channel remote temperature sensor in a  $\mu$ MAX® or TDFN package. The EV kit includes a MAX31730 installed, as well as three external diode-connected transistors and a USB-to-SMBus/I<sup>2</sup>C interface.

#### **EV Kit Contents**

Assembled circuit board including MAX31730

Ordering Information appears at end of data sheet.

Mini USB cable

#### **Features**

- Easy Evaluation of the MAX31730
- Three External Diode-Connected Transistors
- EV Kit Hardware is USB Powered (USB Cable Included)
- USB HID Interface
- Windows XP<sup>®</sup>- and Windows<sup>®</sup> 7-Compatible Software
- RoHS Compliant
- Proven PCB Layout
- Fully Assembled and Tested

 $\mu MAX$  is a registered trademark of Maxim Integrated Products, Inc.

Windows and Windows XP are registered trademarks and registered service marks of Microsoft Corporation.



# maxim integrated

#### MAX31730U EV Kit Photo

#### **EV Kit Files**

FILE	DESCRIPTION
MAX31730EVKitSetup.EXE	Application Program

Note: The .EXE is downloaded as a .ZIP file.

#### **Quick Start**

#### Required Equipment

- MAX31730 EV Kit Hardware
- Windows XP or Windows 7 PC
- Spare USB port
- Mini USB cable (included)

**Note:** In the following sections, software-related items are identified by bolding. Text in **bold** refers to items directly from the install or EV kit software. Text in **bold and under-lined** refers to items from the Windows operating system.

#### Procedure

The EV kit is fully assembled and tested. Follow the steps below to verify board operation:

- 1) Ensure that jumpers/shunts (J22, J1–J3) are installed.
- 2) Set the EV kit hardware on a nonconductive surface to ensure that nothing on the PCB gets shorted together.
- Prior to starting the GUI, connect the EV kit hardware to a PC using the supplied Mini-USB cable, or equivalent. The power LED (D20) should be green and the com LED (D21) should be red and slowly flash orange.
- 4) Windows should automatically begin installing the necessary device driver. The USB interface of the EV kit hardware is configured as an HID device and therefore does not require a unique/custom device driver. Once the driver installation is complete, a Windows message appears near the <u>System</u> <u>Icon</u> menu indicating that the hardware is ready to use. Do not attempt to run the GUI prior to this message. If you do, you must close the application and restart it once the driver installation is complete. On some versions of Windows, administrator privileges may be required to install the USB device.
- Once the device driver installation is complete. Visit <u>www.maximintegrated.com/evkitsoftware</u> to download the latest version of the EV kit software, MAX31730EVKitSetup.ZIP. Save the EV kit software to a temporary folder.
- 6) Unzip the .ZIP file and double-click the .EXE file to run the installer. A message box stating: **The publisher could not be verified. Are you sure you want to run this software?** may appear. If so, click **Yes**.

- 7) Follow the instructions on the installer and once complete, click **Finish**. The default location of the GUI is in the program files directory.
- When the GUI appears, the text in the bottom right-hand corner should display EV Kit Hardware Connected. The com LED (D21) on the EV kit board should turn green.

#### **Detailed Description of Software**

#### **Software Startup**

If the MAX31730 EV kit is connected when the software is opened, the software first initializes the hardware to communicate. The software then searches for all slave addresses on the I<sup>2</sup>C bus and connects to the first valid slave address. The GUI displays **EV Kit Hardware Connected** in the bottom right-hand corner. If the EV kit is not connected on software startup, the GUI populates with default EV kit values. Once the EV kit is connected, the GUI executes the sequence above.

#### Menu and Status Bar

The File menu item contains save and load options. To save the current GUI configuration, select Save Config or Save Config As. This saves all the configuration registers to an XML file. If a device is connected, this reads and saves data directly from the device; otherwise, it saves the configuration that is currently displayed on the GUI. Load Config writes all the configuration data stored in the XML file to the device and then performs a read to update the GUI with the new values. If a device is not connected, Load Config writes to a virtual device and displays the data on the GUI. The Device menu item allows the user to connect to a desired device. Find Slave Addresses searches for all slave addresses connected to the I<sup>2</sup>C bus. To select a device, click Select Slave Address and all the slave addresses found are shown and are selectable. The Options menu contains the Polling Rate option and the Log Polling Data to File option. The Polling Rate sets the delay between reads. To save the polling data to a CSV file, check the Log Polling Data to File option and then click Start Polling to select a name for the file and begin reading.

#### Evaluates: MAX31730

#### Status Log

The status log below the tabs displays all the actions the GUI performs. Whenever an SMBus command is read or written, the action is confirmed by the log. The log can be cleared by pressing the **Clear** button.

#### **Status Tab**

The **Status** tab sheet (Figure 1) displays all the current temperatures and the fault status. All values in the **Temperature Status** group box are read when the tab is selected. To read the values again, press the **Read Temp Status** button. The **One Shot Read** button is only enabled when the device is in standby mode by checking the **Stop** option on the **Config** tab (Figure 2). The **Over Temp** and

**Under Temp** status is read from Thermal Status, High Temperature (32h) and Thermal Status, Low Temperature (33h) registers. The **Diode Fault** status is read from Diode Fault Status (36h) register. The **Temperature** column is read from the temperature registers (00h to 07h) and the **Highest Temperature** is read from registers 10h to 11h. To graph the temperatures, start polling by clicking the **Start Polling** button in the menu bar. To stop polling, press the **Stop Polling** button. Polling automatically stops if items in the **File** or **Connection** menu are selected, or if the **POR** button is pressed. To save the polling data to a CSV file, check **Log Polling Data to File** in the **Options** menu before polling is started.



Figure 1. MAX31730 EV Kit Software GUI (Status Tab)

#### **Configuation Tab**

The **Config** tab sheet (Figure 2) contains all the configuration registers. All values are read when the tab is selected. In the tables, hold the mouse over the column header to see which register(s) the cells in the column read/write to. The **Beta Value** column is the only column where all the cells are read-only. If the **Extended Range** checkbox in the **Configuration Register (13h)** group box is checked, all the temperature values on the **Config** and **Status** tab are updated to reflect the extended range format. The hex values stored in these registers are not changed.

#### **Registers Tab**

The **Registers** tab sheet (Figure 3) displays all the registers and their current data. To read the registers, press the **Read All** button. To write to a register, enter the hex value in the cell and click another cell or press Enter on the keyboard.

Status Config F	Options Help Registers SMBu	s Controls					Start Pollin	g
Temp Sensor	Temp Enable	Highest Temp Enable	THERM Mask	Therma	al High Limit (°C)	Refer	rence Temp (°C	2)
Local				127.000	0	0.000	0	
Remote 1				127.000	0	0.000	0	
Remote 2				127.000	0	0.000	0	
Remote 3				127.000	0	0.000	0	
Temp Sensor	Filter Enable	Custom Ideality Enable	Custom Offset	Enable	Beta Comp Ena	ble	Beta Value	
Local								-
Remote 1						0	.67	-
Remote 2						0	.67	-
Remote 3						0	.67	-
Custom	Offset 0.0000	°C ✓ Exte	nded Range	Compa	arator		POR	

Figure 2. MAX31730 EV Kit Software GUI (Config Tab)

tatus Con						Start Poling
	fig Registers SMBus Controls					
Address	Register Name	Туре		Hex Value	-	Read All
00h	Local Temperature MSB	Read Only	15			NOTE: For Read/Write
01h	Local Temperature LSB	Read Only	B0			registers the Hex Value
02h	Remote 1 Temperature MSB	Read Only	17			can be edited in the table
03h	Remote 1 Temperature LSB	Read Only	A0			
04h	Remote 2 Temperature MSB	Read Only	17		≡	
05h	Remote 2 Temperature LSB	Read Only	A0			
06h	Remote 3 Temperature MSB	Read Only	18			
07h	Remote 3 Temperature LSB	Read Only	60			
10h	Highest Temperature MSB	Read Only	18			
11h	Highest Temperature LSB	Read Only	60			
12h	Highest Temperature Enable	Read/Write	FF			
13h	Configuration	Read/Write	10			
14h	Custom Ideality Factor	Read/Write	18			
15h	Custom Ideality Enable	Read/Write	00			
16h	Custom Offset	Read/Write	77			
17h	Offset Enable	Read/Write	00			
18h	Filter Enable	Read/Write	00			
19h	Beta Compensation Enable	Read/Write	00			
1Ah	Beta Value Channel 1	Read Only	00			
1Bh	Beta Value Channel 2	Read Only	00			
1Ch	Beta Value Channel 3	Read Only	00		-	
				^		
					D	integrated.
				+ Cl	ear	

Figure 3. MAX31730 EV Kit Software GUI (Registers Tab)

#### Evaluates: MAX31730

#### **SMBus Controls Tab**

The **SMBus Controls** tab sheet (Figure 4) allows the user to read and write to registers using hex values. The **One and Two Byte Operations (all HEX values)** group box contains controls to read/write 1 or 2 bytes at a time. To read or write a register, enter the register address desired in the **Addr** or **Start Addr** edit box and press the **Read** or **Write** button. The **Bitwise Read/Write** group box allows the user to read/write the data in binary format. To read or write a register, enter the register address in the **Address** edit box and press the **Read** or **Write** button. The data bits can be flipped by pressing the bit buttons. The **All 0's**, **All 1's**, and **Invert** buttons are useful shortcuts to change all the bits at one time. The **Page Mode (all HEX values)** group box reads/writes one page (8 bytes) at a time. To read or write a page of memory, enter the starting register address in the **Starting Address** edit box and press the **Read** or **Write** button.



Figure 4. MAX31730 EV Kit Software GUI (SMBus Controls Tab)

#### **Detailed Description of Hardware**

#### User-Supplied I<sup>2</sup>C Interface

To communicate with the MAX31730 using a usersupplied I<sup>2</sup>C interface, first remove all J22 jumpers to disconnect the on-board USB I<sup>2</sup>C interface. Connect all pins on header H1 to the off-board I<sup>2</sup>C interface.

#### **Changing the Slave Address**

The default slave address for the IC is 38h. This address can be changed to an address listed in <u>Table 1</u> by removing jumper J4 and populating resistor R3.

#### **Table 1. Slave Addresses**

SLAVE ADDRESS	<b>R3(</b> Ω)
9Eh	Open (> 12kΩ)
9Ch	9.31kΩ
9Ah	6.81kΩ
98h	4.75kΩ
3Eh	3.01kΩ
3Ch	1.69kΩ
3Ah	750Ω
38h	0 (short to GND with J4 installed)

#### Table 2. Description of LEDs

LED	COLOR	DESCRIPTION
D1	Red	THERM: A thermal fault has occured.
D20 (Power) D21 (Com)	Red	USB Power Fault: A fault oc- curred due to overvoltage limit, current limit, or thermal limit.
	Green	USB Power: USB power supply is on.
	Red	Communication: After the soft- ware has initialized the hard- ware, the LED flashes red when an I <sup>2</sup> C command is received.
	Green	Initialized: Hardware has been initialized by software.

#### **User-Supplied Remote Diode**

To connect a user-supplied external remote diode, first remove the channel jumper (J1, J2, or J3) to disconnect the on-board diode. Then connect DXP1, DXP2, or DXP3 and DXN to the external diode. For the TDFN package, each diode has a separate DXN for each channel.

#### **Troubleshooting**

The EV kit should work on the first try directly out of the box. In the rare occasion that a problem is suspected, see Table 4 to help troubleshoot the issue.

# Table 3. Description of Jumpers (J1–J4,J22)

JUMPER	JUMPER NAME	DESCRIPTION
J1	Enable Q1	Connects the remote diode- connected transistor Q1 to DXP1.
J2	Enable Q2	Connects the remote diode- connected transistor Q2 to DXP2.
J3	Enable Q3	Connects the remote diode- connected transistor Q3 to DXP3.
J4	ADD	Connects pin ADD to GND.
	VDUT-3.3V	Supplies 3.3V from the USB I <sup>2</sup> C dongle to the EV kit board.
J22	SCL-SCL	Connects SCL from the USB I <sup>2</sup> C dongle to the IC's SCL.
	SDA-SDA	Connects SDA from the USB I <sup>2</sup> C dongle to the IC's SDA.

### Table 4. Troubleshooting

SYMPTOM	CHECK	SOLUTION
	Is the LED labeled D20 red?	If yes, then the electronic fuse is in a fault state. Inspect for electrical shorts on the PCB and make sure that the PCB is not sitting on a conductive surface.
GUI says hardware not found	Does the LED labeled D21 turn green when the GUI is running?	If not, then exit the GUI and try running it again. If D20 still does not turn green, then exit the GUI and try connecting the USB cable to a different USB port on the PC and wait for a Windows message that states the hardware is ready to use. Run the GUI again.
	Are any of the LEDs illuminated?	If not, then the PCB may not be getting power from USB. Try a different USB cable or a different USB port.
No slave address found and read/writes fail	Jumper J22	Make sure three jumpers on J22 are installed.
GUI always displays a diode fault on the <b>Status</b> tab	J1, J2, or J3	For the on-board diodes, jumpers J1–J3 must be installed to connect the diode to DXP.

### Evaluates: MAX31730

### **Component List**

DESIGNATION	QTY	DESCRIPTION
C1, C212	2	0.1µF, X7R ceramic capacitors (0805)
C1A–C1C	3	100pF, X7R ceramic capacitors (0805)
C2A–C2C, C215	0	Do not populate, ceramic capacitors (0805)
C201, C202, C204	3	10µF, X5R ceramic capacitors (0805)
C203, C214	2	0.01µF, X7R ceramic capacitors (0805)
C211	1	1µF, X7R ceramic capacitor (0805)
C213	1	0.22µF, X7R ceramic capacitor (0805)
D1	1	Red LED (1206)
D20, D21	2	Red/green dual LEDs
D22	1	30V, 3A Schottky diode (MINI2)
H1	1	4-pin header, 2.54mm pitch
J1–J4	4	2-pin headers, 2.54mm pitch
J20	1	5-pin female Mini-USB
J21	0	Do not populate, header
J22	1	6-pin (2 x 3) header, 2.54mm pitch
Q1–Q3	3	Bipolar BJT PNP (SOT23) Fairchild MMBT3906
R3	0	Do not populate, resistor (0805)
R4, R210, R215, R216	4	4.7kΩ ±1% resistors (0805)
R5, R211, R212	3	330Ω ±1% resistors (0805)

DESIGNATION	QTY	DESCRIPTION
R201, R202, R214	3	0Ω ±1% resistors (0805)
R203, R205	2	560Ω ±1% resistors (0805)
R204	1	100kΩ ±1% resistor (0805)
R206	1	45.3kΩ ±1% resistor (0805)
R207	1	10kΩ ±1% resistor (0805)
R213	1	2.2kΩ ±1% resistor (0805)
TP1, TP9, TP10	3	Red test points
TP1A–TP1C, TP2, TP2A–TP2C, TP3–TP5	10	White test points
TP6–TP8	3	Black test points
U1	1	3-channel remote temperature sensor Maxim MAX31730AUB+ (10 µMAX) or MAX31730ATC+ (12 TDFN)
U20	1	Microcontroller (28 SO) Microchip PIC18LF2550-I/SO
U21	1	50mA to 600mA current-limit switch (6 SOT23) Maxim MAX4995AAUT+
U22	7	500mA LDO regulator (8 TDFN-EP*) Maxim MAX8902BATA+
X1	1	48MHz, 3.3V oscillator (SMD)
	7	Jumpers/shunts
	1	Mini-USB cable
	1	PCB: MAX31730 EV Kit

\*EP = Exposed pad.

### **Component Supplier**

SUPPLIER	PHONE	WEBSITE
Fairchild Semiconductor	408-822-2000	www.fairchildsemi.com

Note: Indicate that you are using the MAX31730 when contacting this component supplier.

Evaluates: MAX31730



Figure 5a. MAX31730U EV Kit Schematic ( $\mu$ MAX) (Sheet 1 of 2)



Figure 5b. MAX31730T EV Kit Schematic (TDFN) (Sheet 1 of 2)

Evaluates: MAX31730



Figure 5c. MAX31730 EV Kit Schematic (µMAX or TDFN) (Sheet 2 of 2)



Figure 6. MAX31730U EV Kit PCB Layout—Top (µMAX)



Figure 7. MAX31730U EV Kit PCB Layout—Bottom (µMAX)



Figure 8. MAX31730T EV Kit PCB Layout—Top (TDFN)



Figure 9. MAX31730T EV Kit PCB Layout—Bottom (TDFN)

# **Ordering Information**

PART	IC PACKAGE	TYPE
MAX31730UEVKIT#	10 µMAX	EV Kit
MAX31730TEVKIT#	12 TDFN	EV Kit

#Denotes RoHS compliant.

### Evaluates: MAX31730

### **Revision History**

REVISION NUMBER	REVISION DATE	DESCRIPTION	PAGES CHANGED
0	8/13	Initial release	—
1	6/15	Added TDFN package version of the EV Kit and revised User-Supplied Remote Diode section and Component List.	1, 2, 7, 9, 11, 15, 16

For pricing, delivery, and ordering information, please contact Maxim Direct at 1-888-629-4642, or visit Maxim Integrated's website at www.maximintegrated.com.

Maxim Integrated cannot assume responsibility for use of any circuitry other than circuitry entirely embodied in a Maxim Integrated product. No circuit patent licenses are implied. Maxim Integrated reserves the right to change the circuitry and specifications without notice at any time.





Общество с ограниченной ответственностью «МосЧип» ИНН 7719860671 / КПП 771901001 Адрес: 105318, г.Москва, ул.Щербаковская д.З, офис 1107

#### Данный компонент на территории Российской Федерации

Вы можете приобрести в компании MosChip.

Для оперативного оформления запроса Вам необходимо перейти по данной ссылке:

#### http://moschip.ru/get-element

Вы можете разместить у нас заказ для любого Вашего проекта, будь то серийное производство или разработка единичного прибора.

В нашем ассортименте представлены ведущие мировые производители активных и пассивных электронных компонентов.

Нашей специализацией является поставка электронной компонентной базы двойного назначения, продукции таких производителей как XILINX, Intel (ex.ALTERA), Vicor, Microchip, Texas Instruments, Analog Devices, Mini-Circuits, Amphenol, Glenair.

Сотрудничество с глобальными дистрибьюторами электронных компонентов, предоставляет возможность заказывать и получать с международных складов практически любой перечень компонентов в оптимальные для Вас сроки.

На всех этапах разработки и производства наши партнеры могут получить квалифицированную поддержку опытных инженеров.

Система менеджмента качества компании отвечает требованиям в соответствии с ГОСТ Р ИСО 9001, ГОСТ РВ 0015-002 и ЭС РД 009

#### Офис по работе с юридическими лицами:

105318, г.Москва, ул.Щербаковская д.З, офис 1107, 1118, ДЦ «Щербаковский»

Телефон: +7 495 668-12-70 (многоканальный)

Факс: +7 495 668-12-70 (доб.304)

E-mail: info@moschip.ru

Skype отдела продаж: moschip.ru moschip.ru\_4

moschip.ru\_6 moschip.ru\_9