

# Grove - Serial RF Pro ONE User Manual

Release date: 2015/9/22

Version: 1.0

Wiki:http://www.seeedstudio.com/wiki/index.php?title=Twig -

<u>Serial\_RF\_Pro\_v0.9b</u>

Bazaar: http://www.seeedstudio.com/depot/Grove-Serial-RF-Pro-p-

<u>794.html</u>



# **Document Revision History**

Revision	Date	Author	Description
1.0	Sep 22, 2015	Jiankai.li	Create file



# Contents

Doo	cument l	Revision History2
1.	Introdu	ction2
2.	Feature	3
3.	Applica	ation Ideas4
4.	Specifi	cation
5.	Interfac	ce Function ······6
6.	Usage	
	6.1	Config and Inquiry methods7
	6.2	Communication Mode ·····8
7.	Referen	nce10
8.	Resour	ces15



#### Disclaimer

For physical injuries and possessions loss caused by those reasons which are not related to product quality, such as operating without following manual guide, natural disasters or force majeure, we take no responsibility for that.

Under the supervision of Seeed Technology Inc., this manual has been compiled and published which covered the latest product description and specification. The content of this manual is subject to change without notice.

#### Copyright

The design of this product (including software) and its accessories is under tutelage of laws. Any action to violate relevant right of our product will be penalized through law. Please consciously observe relevant local laws in the use of this product.



### 1. Introduction

Grove-Serial RF Pro is a low cost, high performance transparent FSK transceiver with operating at 433/470/868/915 MHz, and the best performance is at 433M(Default). There is a UART interface that is easy to realize the wireless data transmission with only providing the UART data. It is flexible for the users to set the UART baud rate, frequency, output power, data rate, frequency deviation, receiving bandwidth etc parameters. It is your ideal choice for designing wireless data transmission products which can be widely used on wireless data transmission field.





## 2. Features

- Grove compatible
- High output power
- High output power
- Small size
- Longer transmission distance



# 3. Application Ideas

- Remote control, remote measurement system
- Wireless meter
- Access control
- Identification system
- Data collection
- IT household appliance
- Baby monitoring system



# 4. Specification

Item	Min	Typical	Max	Unit
Working Voltage	4.75	5.0	5.25	VDC
Current at sleep mode	1			uA
output power	1	-	20	dB
Communication Speed	1.2	-	115.2	Kbps
Transmission Distance(Max)	1			Km
Sensitivity	-117			dBm
Communication Protocol	UART			/
Operate Temperature	-40	-	+85	°C



# 5. Interface Function



Pad Type (5V Logic level)	Description	
G(GND)	Ground port	
EN(ENABLE)	Set low for normal mode as data transceiver (Default is low with 10k to GND). Set high to put into sleep mode.	
CON(CONFIG)	Set low for configuration mode (connect to GND). Set high for communication (Default is high).	
RX	UART Data input	
TX	UART Data output	
V(VCC)	Designed for 5V(+)supply	
AT	Antenna pin	



## 6. Usage

Here we show two RF Pro Grove units mutually transmitting/receiving data. You need two RF Pro Grove units and two Seeeduino to do the demo.

Connect one Grove - Serial RF Pro to UART of Grove - Base Shield and plug Grove - Base

Shield into Seeeduino.



• Connect another Grove - Serial RF Pro to Seeeduino using the same method.

#### 6.1 Config and Inquiry methods

The module will be ready for Config status if ENABLE pin is low, CONFIG pin is low. It will be in Config if the red and green LED keep lighting. Then you can Config & inquiry on the module.

- Connect CON pin to LOW/GND to enter configure mode.
- Send command to modify and query the config of the module. Config & Inquiry instruction

description see Reference.

The Config instruction format is as AA+FA+[instruction]+[parameter]. The instruction is 1 byte, the parameter is the HEX data of 0-4 bytes (in big-endian ordering, with the high byte before the low byte).

#### Note:

1) Do remember the UART transfer speed (default is 9600, better not change) if you make some



change, or you won't be able to control the module. The instruction's transfer speed will change accordingly if changes the transfer speed of UART. The range of transfer speed of the instruction is from 1.2Kbps - 115.2K bps.

2) LED Function Description:

The red and green LED will flash when there is power and the module is working.

The module will be ready for configuration mode if EN(ENABLE) pin is low(default is low), CON(Config) pin is low. When in configuration mode, the red and green LED will both be solidly lit. The green and red LED will not be solidly lit if the module is not in configuration mode.

The red LED flash when the module is transmitting, the red LED will be off when the transmission is finished.

The green LED is off when the module is waiting for data to be received, the green LED will flash once when the module receives data.

#### 6.2 Communication Mode

• Upload the below code into Seeeduino, Please click <u>here</u> if you do not know how to upload.

//send data routine

```
// link between the computer and the SoftSerial Shield
//at 9600 bps 8-N-1
//Computer is connected to Hardware UART
//SoftSerial Shield is connected to the Software UART:D2&D3
#include <SoftwareSerial.h>
SoftwareSerial SoftSerial(11, 10); // TX, RX
int buffer[64];
int count=0:
void setup()
 SoftSerial.begin(9600);
                                       // the SoftSerial baud rate
 Serial.begin(9600);
                                // the Serial port of Arduino baud rate.
void loop()
 delay(1000);
 SoftSerial.write(0xAA);
 SoftSerial.write(0xFA);
```



```
SoftSerial.write(0xE1);
```

```
if (SoftSerial.available())
                                       // if date is coming from software serial port ==> data
is coming from SoftSerial shield
  {
   while(SoftSerial.available())
                                // reading data into char array
    {
    buffer[count++]=SoftSerial.read(); // writing data into array
     if(count == 64)break;
   }
   for (int i=0; i<count; i++) {
     Serial.print(buffer[i],HEX); // if no data transmission ends, write buffer to
hardware serial port
   }
   clearBufferArray(); // call clearBufferArray function to clear the stored data from
the array
   count = 0;
                                 // set counter of while loop to zero
 }
 if (Serial.available())
                             // if data is available on hardware serial port ==> data is
coming from PC or notebook
   SoftSerial.write(Serial.read()); // write it to the SoftSerial shield
 Serial.println("...");
void clearBufferArray()
                        // function to clear buffer array
{
 for (int i=0; i<count;i++)</pre>
    { buffer[i]=NULL;}
                                   // clear all index of array with command NULL
```

#### • You can see as show below after open serial monitor.

👔 SSCOM3.2 (Author: NieXiaoMeng . http://www.mcu51.com, Email: 💻 💻 🗶	👔 SSCOM3.2 (Author: NieXiaoMeng - http://www.mcu51.com, Email:
123412341234	ABCDABCDABCD
OpenFile FileMm SendFile SaveBata Clear F MexData ComMun COM47 V @ CloseCom Help WWW.MCU51.COM EXT	OpenFile FileMn SendFile SaveData Clear HexData ComNum COM65 V @ CloseCom Help WWW.MCU51.COM EXT
Baudha 9600 V DTR RTS DataBi 8 V Send eve 1000 ms/Time StopBi 1 V SendHEX SendHex VerifyNone V PlowCoNone V ABCD	BaudRa 9600 V DTR RTS Databi 8 V Send evel 1000 mc/Time StepBi 1 V SendHEX SendNew VerifyNone V Data input: SEND Your surrestion



# 7. Reference

The following table lists the commands and responses involved in interacting with Serial RF Pro v0.9b.

Instruction(HEX)	Description	Config instruction(HEX)	Return Value
F0	Reset to default parameters (except UART transfer speed), no parameter follows	AA FA FO	4F 4B 0D 0A (OK /r/n)
E1	Reading the current Config parameter, no parameter follows	AA FA E1	<pre>16 bytes: (following the order below) working frequency-4 bytes, wireless data rate-4 bytes, receiving bandwidth-2 bytes, frequency deviation-1 byte, transmission power-1 byte, UART transfer speed-4 bytes</pre>



D2	Set         up         working           frequency         ,           [parameter]4         byte         ,           [parameter] Unit :Hz.         .           Set up range:         .           HM-TRP-433:         .           41400000-         .           454000000Hz;         .           HM-TRP-470:         .           45000000Hz;         .           HM-TRP-868:         .           849000000-         .           889000000Hz;         .           HM-TRP-915:         .           89500000-         .	Example: Config instruction: AA FA D2 36 89 CA C0, set up frequency as 915000000Hz.(0x36 89 CA C0=91500000) Config instruction: AA FA D2 19 DE 50 80, set up frequency as 434000000Hz.(0x19 DE 50 80=43400000)	4F 4B 0D 0A (OK /r/n)
С3	935000000Hz Set up wireless data rate , [parameter]4 byte , [parameter] unit :bps. Set up range:1200- 115200 bps	Example: Config instruction: AA FA C3 00 00 25 80,set up transfer speed as 9600bps.(0x00 00 25 80=9600) Config instruction: AA FA C3 00 00 96 00, set up transfer speed as 38400bps.(0x00 00 96 00=38400)	4F 4B 0D 0A (OK /r/n)



В4	Set up receiving bandwidth , [parameter]2 byte , [parameter]Unit :KHz Set up range:30- 620KHz	Example: Config instruction: AA FA B4 00 69, set up receiving band as 105KHz.(0x00 69=105) Config instruction: AA FA B4 01 2C, set up receiving band as 300KHz.(0x01 2C=300)	4F 4B 0D 0A (OK /r/n)
A5	Set up frequency deviation, [parameter]1 byte , [parameter]Unit :KHz Set up range:10- 160KHz	Example: Config instruction: AA FA A5 23, set up modulation frequency as 35KHz.(0x23=35) Config instruction: AA FA A5 32, set up modulation frequency as 50KHz.(0x32=50)	4F 4B 0D 0A (OK /r/n)
96	Set up transmission power ,[parameter]1 byte, 0~7level Set up range:0- 7level(1-20 dBm)	Example: Config instruction: AA FA 96 07, set up transmission power as level 7 (+20 dBm) Config instruction:AA FA 96 03, set up transmission power as level 3 (+8 dBm) Transmission power as level 3 (+8 dBm) 5	4F 4B 0D 0A (OK /r/n)



		+14dBm 4 +11dBm 3 +8dBm 2 +5dBm 1 +2dBm 0 +1dBm	
1E	Set up UART transfer speed , [parameter]4 byte, [parameter] unit: bps Set up range:1200- 115200 bps	Example: Config Instruction :AA FA 1E 00 00 25 80,set up speed as 9600bps.(0x00 00 25 80=9600) Config instruction :AA FA 1E 00 00 96 00, set up speed as 38400bps.(0x00 00 96 00=38400)	4F 4B 0D 0A (OK /r/n)
87	Wireless signal strength when receiving useful data, follows no [parameter]	Config Instruction: AA FA 87	RSSI value is 8 bit, range: 0-255



78	Disturb wireless signal strength, follows no [parameter] Note: Modulation index : h = Fd/Rb, Range is 0.5 ~ 32. If h>1, BW =Rb+2Fd; If h<1, BW =2Rb+ Fd.	Config Instruction: AA FA 78	RSSI value is 8 bit , range: 0-255
----	--	------------------------------	---------------------------------------



# 8. Resources

- Serial RF Pro Demo Code
- the HopeRF HM-TRP Series 100mW Transceiver modules V1.0 Datasheet





Общество с ограниченной ответственностью «МосЧип» ИНН 7719860671 / КПП 771901001 Адрес: 105318, г.Москва, ул.Щербаковская д.З, офис 1107

#### Данный компонент на территории Российской Федерации

Вы можете приобрести в компании MosChip.

Для оперативного оформления запроса Вам необходимо перейти по данной ссылке:

#### http://moschip.ru/get-element

Вы можете разместить у нас заказ для любого Вашего проекта, будь то серийное производство или разработка единичного прибора.

В нашем ассортименте представлены ведущие мировые производители активных и пассивных электронных компонентов.

Нашей специализацией является поставка электронной компонентной базы двойного назначения, продукции таких производителей как XILINX, Intel (ex.ALTERA), Vicor, Microchip, Texas Instruments, Analog Devices, Mini-Circuits, Amphenol, Glenair.

Сотрудничество с глобальными дистрибьюторами электронных компонентов, предоставляет возможность заказывать и получать с международных складов практически любой перечень компонентов в оптимальные для Вас сроки.

На всех этапах разработки и производства наши партнеры могут получить квалифицированную поддержку опытных инженеров.

Система менеджмента качества компании отвечает требованиям в соответствии с ГОСТ Р ИСО 9001, ГОСТ РВ 0015-002 и ЭС РД 009

#### Офис по работе с юридическими лицами:

105318, г.Москва, ул.Щербаковская д.З, офис 1107, 1118, ДЦ «Щербаковский»

Телефон: +7 495 668-12-70 (многоканальный)

Факс: +7 495 668-12-70 (доб.304)

E-mail: info@moschip.ru

Skype отдела продаж: moschip.ru moschip.ru\_4

moschip.ru\_6 moschip.ru\_9