

# emUSB

USB Device stack

CPU-independent


User & Reference Guide

Document: UM09001

Software version: 2.50h

Revision: 0

Date: May 29, 2015



A product of SEGGER Microcontroller GmbH & Co. KG

[www.segger.com](http://www.segger.com)

## **Disclaimer**

Specifications written in this document are believed to be accurate, but are not guaranteed to be entirely free of error. The information in this manual is subject to change for functional or performance improvements without notice. Please make sure your manual is the latest edition. While the information herein is assumed to be accurate, SEGGER Microcontroller GmbH & Co. KG (SEGGER) assumes no responsibility for any errors or omissions. SEGGER makes and you receive no warranties or conditions, express, implied, statutory or in any communication with you. SEGGER specifically disclaims any implied warranty of merchantability or fitness for a particular purpose.

## **Copyright notice**

You may not extract portions of this manual or modify the PDF file in any way without the prior written permission of SEGGER. The software described in this document is furnished under a license and may only be used or copied in accordance with the terms of such a license.

© 2010 - 2015 SEGGER Microcontroller GmbH & Co. KG, Hilden / Germany

## **Trademarks**

Names mentioned in this manual may be trademarks of their respective companies.

Brand and product names are trademarks or registered trademarks of their respective holders.

## **Contact address**

SEGGER Microcontroller GmbH & Co. KG

In den Weiden 11

D-40721 Hilden

Germany

Tel. +49 2103-2878-0

Fax. +49 2103-2878-28

E-mail: [support@segger.com](mailto:support@segger.com)

Internet: <http://www.segger.com>

## Manual versions

This manual describes the current software version. If any error occurs, inform us and we will try to assist you as soon as possible.

Contact us for further information on topics or routines not yet specified.

Print date: May 29, 2015

| Software | Revision | Date   | By | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|----------|----------|--------|----|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 2.50h    | 0        | 150529 | YR | Update to latest software version.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| internal | 0        | 150512 | YR | Minor improvements.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| internal | 0        | 150410 | YR | Added the SmartMSD chapter.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 2.50g    | 3        | 150218 | YR | Update to latest software version.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 2.50f    | 3        | 150213 | YR | Update to latest software version.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 2.50e    | 3        | 150123 | YR | Chapter HID:<br>* Added new functions:<br>* USB_HID_GetNumBytesInBuffer()<br>* USB_HID_GetNumBytesInBufferEx()<br>* USB_HID_GetNumBytesRemToRead()<br>* USB_HID_GetNumBytesRemToReadEx()<br>* USB_HID_GetNumBytesToWrite()<br>* USB_HID_GetNumBytesToWriteEx()<br>* USB_HID_ReadEPOverlapped()<br>* USB_HID_ReadEPOverlappedEx()<br>* USB_HID_ReadEx()<br>* USB_HID_ReadExTimed()<br>* USB_HID_ReadTimed()<br>* USB_HID_StartReadTransfer()<br>* USB_HID_StartReadTransferEx()<br>* USB_HID_WaitForRX()<br>* USB_HID_WaitForRXEx()<br>* USB_HID_WaitForTX()<br>* USB_HID_WaitForTXEx()<br>* USB_HID_WriteEPOverlapped()<br>* USB_HID_WriteEPOverlappedEx()<br>* USB_HID_WriteEx()<br>* USB_HID_WriteExTimed()<br>* USB_HID_WriteTimed()<br>Removed typos.<br>Improved a lot of function descriptions. |
| 2.50d    | 2        | 141215 | YR | Update to latest software version.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 2.50c    | 2        | 141128 | YR | Update to latest software version.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 2.50b    | 2        | 141125 | YR | Update to latest software version.<br>Added the following function:<br>USB_BULK_TxIsPending                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 2.50a    | 1        | 141106 | YR | Update to latest software version.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| internal | 1        | 140929 | YR | Improved most of the function descriptions in the CDC chapter.<br>Added the following functions:<br>USB_CDC_StartReadTransferEx<br>USB_CDC_GetNumBytesInBufferEx<br>USB_CDC_GetNumBytesRemToReadEx<br>USB_CDC_GetNumBytesToWriteEx<br>USB_Stop()<br>USB_DeInit()                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| 2.50     | 0        | 140725 | YR | Added the RNDIS chapter.<br>Minor improvements.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| 2.40m    | 2        | 140630 | YR | Update to latest software version.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| internal | 2        | 140618 | YR | Updated the introduction chapter.<br>Fixed the descriptions of USB_CDC_Read* and USB_CDC_Receive* functions.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| 2.40l    | 2        | 140606 | SR | Update to latest software version.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 2.40k    | 2        | 140523 | YR | Update to latest software version.<br>Minor improvements to several function descriptions.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 2.40i    | 2        | 140515 | SR | Update to latest software version.<br>Added new drivers<br>Removed RNDIS chapter as the component is not released yet.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |

| Software | Revision | Date   | By | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|----------|----------|--------|----|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 2.40i    | 1        | 140415 | SR | Update to latest software version.<br>Minor bugfix.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 2.40h    | 1        | 140411 | SR | Update to latest software version.<br>Added new driver.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| 2.40g    | 1        | 140410 | SR | Update to latest software version.<br>Minor bugfixes.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| 2.40f    | 1        | 140401 | SR | Update to latest software version.<br>Minor bugfixes.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| 2.40e    | 1        | 140313 | SR | Update to latest software version.<br>Minor bugfixes.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| 2.40d    | 1        | 140224 | SR | Update to latest software version.<br>Minor improvements.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 2.40c    | 1        | 140213 | SR | Update to latest software version.<br>Minor improvements.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 2.40b    | 1        | 140124 | SR | Update to latest software version.<br>Minor improvements.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 2.40a    | 0        | 140110 | YR | Update to latest software version.<br>Minor improvements.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 2.38f    | 1        | 131210 | YR | Removed some typos.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 2.38f    | 0        | 131031 | SR | Update to latest software version.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| 2.38e    | 0        | 131021 | SR | Update to latest software version.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| 2.38d    | 0        | 131015 | SR | Update to latest software version.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| 2.38c    | 0        | 131004 | YR | Update to latest software version.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| 2.38     | 0        | 130920 | YR | Created a separate chapter for Bulk Host API V2.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| internal | 0        | 130705 | MD | Added MTP chapter.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| internal | 0        | 130410 | YR | Added the new Bulk Host API V2.<br>Removed some typos.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| 2.36     | 0        | 130208 | YR | Added Certification chapter.<br>Added RNDIS chapter.<br>Updated available drivers.<br>Removed some typos.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 2.34     | 1        | 111116 | YR | Updated USB Core chapter:<br>* Added description for function:<br>USB_WriteEP0FromISR()<br>Removed some typos.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| 2.34     | 0        | 111111 | SR | Updated CDC chapter:<br>* Added new function: USB_CDC_SetOnBreak()<br>* Updated the functions: USB_MSD_INST_DATA_DRIVER<br>Chapter Target USB driver:<br>* Added new drivers to the list.<br>Removed some typos.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 2.32     | 0        | 101206 | SR | Added new functions in USB Core chapter:<br>* USB_SetVendorRequestHook(), USB_SetIsSelfPowered()<br>Updated the Product IDs in Chapter GettingTheTargetUp\Configuration.<br>Updated MSD chapter:<br>* Added new picture on front page.<br>* Updated chapter Overview<br>* Added new function: USB_MSD_Connect(),<br>USB_MSD_Disconnect(), USB_MSD_RequestDisconnect(),<br>USB_MSD_UpdateWriteProtect(),<br>USB_MSD_WaitForDisconnection(),<br>* Updated the functions: USB_MSD_INST_DATA_DRIVER<br>Updated the CDC chapter:<br>* Added new Ex-Functions<br>* Added new serial status functions.<br>Added new picture to the front page of chapter HID.<br>Update Printer Class chapter:<br>* Added new picture to the front page to the chapter<br>* Added new information to the USB_PRINTER_API.<br>Chapter Target USB driver:<br>* Added new drivers to the list. |
| 2.30     | 0        | 101022 | SR | Added the function for remote wakeup.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| 2.27     | 0        | 100730 | MD | Chapter "Printer Class" added.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |

| Software | Revision | Date   | By    | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|----------|----------|--------|-------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 2.26     | 1        | 090127 | SR    | <p>Chapter USB core:</p> <ul style="list-style-type: none"> <li>* Added new functions: USB_SetMaxPower(), USB_SetOnRxEP0(), USB_SetOnSetupHook()</li> </ul> <p>Chapter Bulk Communication:</p> <ul style="list-style-type: none"> <li>* Added new functions:</li> <li>* USB_BULK_CancelRead()</li> <li>* USB_BULK_CancelWrite()</li> <li>* USB_BULK_ReadTimed()</li> <li>* USB_BULK_SetOnRXHook()</li> <li>* USB_BULK_WaitForTX()</li> <li>* USB_BULK_WaitForRX()</li> <li>* USB_BULK_WriteEx()</li> <li>* USB_BULK_WriteExTimed</li> <li>* USB_BULK_WriteNULLPacket()</li> <li>* USB_BULK_WriteTimed().</li> </ul> <p>Chapter CDC:</p> <ul style="list-style-type: none"> <li>* Added new functions:</li> <li>* USB_CDC_CancelRead()</li> <li>* USB_CDC_CancelWrite()</li> <li>* USB_CDC_ReadTimed()</li> <li>* USB_CDC_ReceiveTimed()</li> </ul> <p>Updated indexes in chapter CDC, Bulk communication, MSD, HID.</p> |
| 2.22     | 1        | 080917 | SR/SK | <p>Added new chapter Combining different USB components (Multi-Interface)</p> <p>All chapter reviewed and cleaned up.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| 2.22     | 0        | 080902 | SR    | <p>Chapter USB core:</p> <ul style="list-style-type: none"> <li>* Added new function USB_EnableIAD.</li> </ul> <p>Chapter Bulk communication:</p> <ul style="list-style-type: none"> <li>* Update description of USB_BULK_Receive.</li> </ul> <p>Chapter MSD component:</p> <ul style="list-style-type: none"> <li>* Updated "Final configuration".</li> <li>* Updated "Class specific configuration functions.</li> </ul> <p>Chapter CDC component:</p> <ul style="list-style-type: none"> <li>* Added new functions: USB_CDC_ReadOverlapped(), USB_CDC_WriteOverlapped(), USB_CDC_WaitForRx, USB_CDC_WaitForTx().</li> </ul> <p>Chapter Target USB driver:</p> <ul style="list-style-type: none"> <li>* Updated available driver list.</li> </ul> <p>Chapter FAQ:</p> <ul style="list-style-type: none"> <li>* Added new</li> </ul>                                                                                   |
| 15.0     | 0        | 080403 | SR    | Update company's address and legal form.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| 14.0     | 0        | 071204 | SR    | <p>Chapter "Target USB driver":</p> <ul style="list-style-type: none"> <li>* Updated "Writing your own driver":</li> <li>- pfStallEP changed to pfSetClrStallEP.</li> <li>- Added new driver ST STR91x.</li> <li>- Added description for pfResetEP.</li> </ul> <p>Chapter "Bulk Communication":</p> <ul style="list-style-type: none"> <li>* Added new function: USB_BULK_Receive()</li> <li>* Added new function: USB_BULK_GetNumBytesInBuffer()</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 13.0     | 0        | 071005 | SK    | <p>Chapter "Target USB driver":</p> <ul style="list-style-type: none"> <li>* Section "Interrupt handling" added.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| 12.0     | 0        | 070706 | SR    | <p>Chapter "USB core":</p> <ul style="list-style-type: none"> <li>* Changed USB_GetStatus to USB_GetState</li> </ul> <p>Chapter "MSD":</p> <ul style="list-style-type: none"> <li>* "MSD_Start.c" changed to "MSD_Start_StorageRAM.c"</li> <li>* Added information to "USB_MS_D_INST_DATA_DRIVER"</li> <li>* "Storage drivers supplied with this release" updated.</li> </ul> <p>Chapter "Bulk communication":</p> <ul style="list-style-type: none"> <li>* Changed text for USB_BULK_GetMode/Ex.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                            |

| Software | Revision | Date   | By | Description                                                                                                                                                                                                                                                                                                                                                                        |
|----------|----------|--------|----|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 11.0     | 0        | 070704 | SK | Chapter "Introduction":<br>* HID section added.<br>Chapter "USB Core":<br>* USB_GetState() added.<br>Chapter "HID":<br>* USBHID_Init() updated.<br>Chapter "Target OS Interface":<br>* USB_OS_RestoreI() removed.<br>* USB_OS_DI() removed.<br>Chapter "Target USB Driver":<br>* STR750 added.                                                                                     |
| 10.0     | 0        | 070618 | SK | Chapter "HID" added.<br>Chapter "USB Core" added.<br>Chapter "Bulk communication":<br>* USB core functions removed.<br>Chapter "Introduction":<br>* Section "Development environment" added.                                                                                                                                                                                       |
| 9.0      | 0        | 070123 | SK | emUSB components renamed:<br>* "emUSB with bulk component" to "emUSB-Bulk"<br>* "emUSB with MSD component" to "emUSB-MSD"<br>* "emUSB with CDC component" to "emUSB-CDC"<br>Chapter "Introduction":<br>* updated and enhanced<br>* emUSB-CDC added                                                                                                                                 |
| 8.0      | 0        | 070121 | SK | Product name changed from "USB-Stack" to "emUSB".<br>Various changes in layout and structure.<br>Chapter "About" added.<br>Chapter "Introduction":<br>* updated<br>* "emUSB structure" graphic added.<br>Chapter "Bulk communication":<br>* USB_SetClassRequestHook():<br>- Function description added.<br>Chapter "CDC":<br>* Head of description of USB_CDC_LINE_CODING changed. |
| 7.0      | 0        | 070109 | SR | Added new chapter CDC.                                                                                                                                                                                                                                                                                                                                                             |
| 6.0      | 0        | 061221 | SR | Added new USBBulk HOST-API function<br>USB_BULK_SetUSBId().<br>Company description added                                                                                                                                                                                                                                                                                           |
| 5.0      | 0        | 061220 | SR | Changed chapter 1.1.1 USB-Bulk stack:<br>Info reg. availability of the Host-driver source.<br>Updated chapter title "Getting the target up"<br>Updated chapter 1.1.2.3 Features<br>Updated chapter 1 - Information of max. data transfer rates updated.                                                                                                                            |
| 4.0      | 0        | 061212 | SR | Added chapter "Mass Storage Device"<br>Changed chapter Background info:<br>-Updated<br>Changed chapter title "Configuring the target" to "Getting the target up"<br>Moved any related information of files provided with the USB stack to "Getting the target up"                                                                                                                  |
| 3.0      | 0        | 061120 | SR | Added the extended HOST API functionality to manual                                                                                                                                                                                                                                                                                                                                |
| 2.0      | 0        | 061115 | SR | Updated chapter:<br>Target USB driver<br>Bulk Communication                                                                                                                                                                                                                                                                                                                        |
| 1.0      | 0        | 060808 | OO | Initial Version                                                                                                                                                                                                                                                                                                                                                                    |

# About this document

## Assumptions

This document assumes that you already have a solid knowledge of the following:

- The software tools used for building your application (assembler, linker, C compiler)
- The C programming language
- The target processor
- DOS command line.

If you feel that your knowledge of C is not sufficient, we recommend *The C Programming Language* by Kernighan and Richie (ISBN 0-13-1103628), which describes the standard in C-programming and, in newer editions, also covers the ANSI C standard.

## How to use this manual

This manual explains all the functions and macros that emUSB offers. It assumes you have a working knowledge of the C language. Knowledge of assembly programming is not required.

## Typographic conventions for syntax

This manual uses the following typographic conventions:

| Style             | Used for                                                                                                                 |
|-------------------|--------------------------------------------------------------------------------------------------------------------------|
| Body              | Body text.                                                                                                               |
| Keyword           | Text that you enter at the command-prompt or that appears on the display (that is system functions, file- or pathnames). |
| Parameter         | Parameters in API functions.                                                                                             |
| Sample            | Sample code in program examples.                                                                                         |
| Sample comment    | Comments in program examples.                                                                                            |
| Reference         | Reference to chapters, sections, tables and figures or other documents.                                                  |
| <b>GUIElement</b> | Buttons, dialog boxes, menu names, menu commands.                                                                        |
| <b>Emphasis</b>   | Very important sections.                                                                                                 |

**Table 1.1: Typographic conventions**



**SEGGER Microcontroller GmbH & Co. KG** develops and distributes software development tools and ANSI C software components (middleware) for embedded systems in several industries such as telecom, medical technology, consumer electronics, automotive industry and industrial automation.

SEGGER's intention is to cut software development time for embedded applications by offering compact flexible and easy to use middleware, allowing developers to concentrate on their application.

Our most popular products are emWin, a universal graphic software package for embedded applications, and embOS, a small yet efficient real-time kernel. emWin, written entirely in ANSI C, can easily be used on any CPU and most any display. It is complemented by the available PC tools: Bitmap Converter, Font Converter, Simulator and Viewer. embOS supports most 8/16/32-bit CPUs. Its small memory footprint makes it suitable for single-chip applications.

Apart from its main focus on software tools, SEGGER develops and produces programming tools for flash micro controllers, as well as J-Link, a JTAG emulator to assist in development, debugging and production, which has rapidly become the industry standard for debug access to ARM cores.

**Corporate Office:**

<http://www.segger.com>

**United States Office:**

<http://www.segger-us.com>

## EMBEDDED SOFTWARE (Middleware)



**emWin**

**Graphics software and GUI**

emWin is designed to provide an efficient, processor- and display controller-independent graphical user interface (GUI) for any application that operates with a graphical display.



**embOS**

**Real Time Operating System**

embOS is an RTOS designed to offer the benefits of a complete multitasking system for hard real time applications with minimal resources.



**embOS/IP**

**TCP/IP stack**

embOS/IP a high-performance TCP/IP stack that has been optimized for speed, versatility and a small memory footprint.



**emFile**

**File system**

emFile is an embedded file system with FAT12, FAT16 and FAT32 support. Various Device drivers, e.g. for NAND and NOR flashes, SD/MMC and Compact-Flash cards, are available.



**USB-Stack**

**USB device/host stack**

A USB stack designed to work on any embedded system with a USB controller. Bulk communication and most standard device classes are supported.

## SEGGER TOOLS

**Flasher**

**Flash programmer**

Flash Programming tool primarily for micro controllers.

**J-Link**

**JTAG emulator for ARM cores**

USB driven JTAG interface for ARM cores.

**J-Trace**

**JTAG emulator with trace**

USB driven JTAG interface for ARM cores with Trace memory. supporting the ARM ETM (Embedded Trace Macrocell).

**J-Link / J-Trace Related Software**

Add-on software to be used with SEGGER's industry standard JTAG emulator, this includes flash programming software and flash breakpoints.





# Table of Contents

|         |                                                                     |    |
|---------|---------------------------------------------------------------------|----|
| 1       | Introduction .....                                                  | 15 |
| 1.1     | Overview .....                                                      | 16 |
| 1.2     | emUSB features .....                                                | 16 |
| 1.3     | emUSB components .....                                              | 17 |
| 1.3.1   | emUSB-Bulk .....                                                    | 18 |
| 1.3.1.1 | Purpose of emUSB-Bulk .....                                         | 18 |
| 1.3.2   | emUSB-MSD .....                                                     | 19 |
| 1.3.2.1 | Purpose of emUSB-MSD .....                                          | 19 |
| 1.3.2.2 | Typical applications .....                                          | 19 |
| 1.3.2.3 | emUSB-MSD features .....                                            | 19 |
| 1.3.2.4 | How does it work? .....                                             | 19 |
| 1.3.3   | emUSB-CDC .....                                                     | 21 |
| 1.3.3.1 | Typical applications .....                                          | 21 |
| 1.3.4   | emUSB-HID .....                                                     | 22 |
| 1.3.4.1 | Typical applications .....                                          | 22 |
| 1.3.5   | emUSB-MTP .....                                                     | 23 |
| 1.3.5.1 | Typical applications .....                                          | 23 |
| 1.3.6   | emUSB-Printer .....                                                 | 24 |
| 1.3.6.1 | Typical applications .....                                          | 24 |
| 1.3.7   | emUSB-RNDIS .....                                                   | 25 |
| 1.3.7.1 | Typical applications .....                                          | 25 |
| 1.4     | Requirements .....                                                  | 26 |
| 1.4.1   | Target system .....                                                 | 26 |
| 1.4.2   | Development environment (compiler) .....                            | 26 |
| 1.5     | File structure .....                                                | 27 |
| 1.5.1   | Bulk communication component .....                                  | 28 |
| 1.5.2   | MSD component .....                                                 | 28 |
| 1.5.3   | CDC component .....                                                 | 28 |
| 1.5.4   | HID component .....                                                 | 28 |
| 2       | Background information .....                                        | 29 |
| 2.1     | USB .....                                                           | 30 |
| 2.1.1   | Short Overview .....                                                | 30 |
| 2.1.2   | Important USB Standard Versions .....                               | 30 |
| 2.1.3   | USB System Architecture .....                                       | 31 |
| 2.1.4   | Transfer Types .....                                                | 33 |
| 2.1.5   | Setup phase / Enumeration .....                                     | 33 |
| 2.1.6   | Product / Vendor IDs .....                                          | 33 |
| 2.2     | Predefined device classes .....                                     | 34 |
| 2.3     | USB hardware analyzers .....                                        | 34 |
| 2.4     | References .....                                                    | 34 |
| 3       | Getting started .....                                               | 35 |
| 3.1     | How to setup your target system .....                               | 36 |
| 3.1.1   | Upgrade a trial version available on the web with source code. .... | 36 |
| 3.1.2   | Upgrading an embOS Start project .....                              | 37 |
| 3.1.3   | Creating a project from scratch .....                               | 39 |
| 3.2     | Select the start application .....                                  | 40 |
| 3.3     | Build the project and test it .....                                 | 40 |
| 3.4     | Configuration .....                                                 | 41 |

|         |                                                                 |     |
|---------|-----------------------------------------------------------------|-----|
| 3.4.1   | General emUSB configuration functions .....                     | 42  |
| 3.4.2   | Additional required configuration functions for emUSB-MSD ..... | 47  |
| 3.4.3   | Descriptors.....                                                | 47  |
| 4       | USB Core.....                                                   | 49  |
| 4.1     | Overview .....                                                  | 50  |
| 4.2     | Target API.....                                                 | 51  |
| 4.2.1   | USB basic functions .....                                       | 52  |
| 4.2.2   | USB configuration functions.....                                | 59  |
| 4.2.3   | USB control functions .....                                     | 68  |
| 4.2.4   | USB IAD functions.....                                          | 70  |
| 4.2.5   | USB Remote wakeup functions.....                                | 71  |
| 5       | Bulk communication.....                                         | 75  |
| 5.1     | Generic bulk stack.....                                         | 76  |
| 5.2     | The Kernel mode driver (PC).....                                | 76  |
| 5.2.1   | Why is a driver necessary? .....                                | 76  |
| 5.2.2   | Supported platforms.....                                        | 76  |
| 5.3     | Installing the driver.....                                      | 76  |
| 5.3.1   | Recompiling the driver .....                                    | 79  |
| 5.3.2   | The .inf file.....                                              | 80  |
| 5.3.3   | Configuration.....                                              | 81  |
| 5.4     | Example application.....                                        | 82  |
| 5.4.1   | Running the example applications.....                           | 83  |
| 5.4.2   | Compiling the PC example application .....                      | 85  |
| 5.5     | Target API.....                                                 | 86  |
| 5.5.1   | Target interface function list .....                            | 87  |
| 5.5.2   | USB-Bulk functions.....                                         | 88  |
| 5.5.3   | Data structures.....                                            | 109 |
| 5.6     | Host API .....                                                  | 111 |
| 5.6.1   | Host API list .....                                             | 112 |
| 5.6.2   | USB-Bulk Basic functions.....                                   | 114 |
| 5.6.3   | USB-Bulk direct input/output functions.....                     | 118 |
| 5.6.4   | USB-Bulk Control functions.....                                 | 124 |
| 6       | Bulk Host API V2 .....                                          | 141 |
| 6.1     | Bulk Host API V2.....                                           | 142 |
| 6.1.1   | Bulk Host API V2 list.....                                      | 143 |
| 6.1.2   | USB-Bulk Basic functions.....                                   | 145 |
| 6.1.3   | USB-Bulk direct input/output functions.....                     | 150 |
| 6.1.4   | USB-Bulk Control functions.....                                 | 157 |
| 6.1.4.1 | USBULK_GetConfigDescriptor() .....                              | 157 |
| 6.1.5   | Data structures.....                                            | 180 |
| 7       | Mass Storage Device Class (MSD) .....                           | 181 |
| 7.1     | Overview .....                                                  | 182 |
| 7.2     | Configuration.....                                              | 183 |
| 7.2.1   | Initial configuration .....                                     | 183 |
| 7.2.2   | Final configuration.....                                        | 183 |
| 7.2.3   | Class specific configuration functions .....                    | 183 |
| 7.2.4   | Running the example application .....                           | 188 |
| 7.2.4.1 | MSD_Start_StorageRAM.c in detail .....                          | 188 |
| 7.3     | Target API.....                                                 | 189 |
| 7.3.1   | API functions .....                                             | 190 |
| 7.3.2   | Extended API functions .....                                    | 197 |
| 7.3.3   | Data structures.....                                            | 203 |
| 7.4     | Storage Driver .....                                            | 212 |
| 7.4.1   | General information.....                                        | 212 |
| 7.4.1.1 | Supported storage types .....                                   | 212 |

|          |                                                  |     |
|----------|--------------------------------------------------|-----|
| 7.4.1.2  | Storage drivers supplied with this release ..... | 212 |
| 7.4.2    | Interface function list .....                    | 212 |
| 7.4.3    | USB_MSD_STORAGE_API in detail .....              | 213 |
| 8        | Smart Mass Storage Component (SmartMSD).....     | 221 |
| 8.1      | Overview .....                                   | 222 |
| 8.2      | Configuration .....                              | 223 |
| 8.2.1    | Initial configuration .....                      | 223 |
| 8.2.2    | Final configuration .....                        | 223 |
| 8.2.3    | Class specific configuration functions .....     | 223 |
| 8.2.4    | Running the example application .....            | 225 |
| 8.3      | Target API .....                                 | 225 |
| 8.3.1    | API functions .....                              | 226 |
| 8.3.2    | Data structures .....                            | 237 |
| 9        | Media Transfer Protocol Class (MTP).....         | 249 |
| 9.1      | Overview .....                                   | 250 |
| 9.1.1    | Getting access to files .....                    | 251 |
| 9.1.2    | Additional information .....                     | 253 |
| 9.2      | Configuration .....                              | 254 |
| 9.2.1    | Initial configuration .....                      | 254 |
| 9.2.2    | Final configuration .....                        | 254 |
| 9.2.3    | Class specific configuration .....               | 254 |
| 9.2.4    | Compile time configuration .....                 | 259 |
| 9.3      | Running the sample application .....             | 259 |
| 9.3.1    | USB_MTP_Start.c in detail .....                  | 259 |
| 9.4      | Target API .....                                 | 261 |
| 9.4.1    | API functions .....                              | 262 |
| 9.4.2    | Data structures .....                            | 265 |
| 9.5      | Storage Driver .....                             | 272 |
| 9.5.1    | General information .....                        | 272 |
| 9.5.2    | Interface function list .....                    | 272 |
| 9.5.3    | USB_MTP_STORAGE_API in detail .....              | 273 |
| 10       | Communication Device Class (CDC).....            | 295 |
| 10.1     | Overview .....                                   | 296 |
| 10.1.1   | Configuration .....                              | 296 |
| 10.2     | The example application .....                    | 297 |
| 10.3     | Installing the driver .....                      | 298 |
| 10.3.1   | The .inf file .....                              | 301 |
| 10.3.2   | Installation verification .....                  | 302 |
| 10.3.3   | Testing communication to the USB device .....    | 303 |
| 10.4     | Target API .....                                 | 306 |
| 10.4.1   | Interface function list .....                    | 307 |
| 10.4.2   | API functions .....                              | 308 |
| 10.4.3   | Data structures .....                            | 329 |
| 11       | Human Interface Device Class (HID).....          | 335 |
| 11.1     | Overview .....                                   | 336 |
| 11.1.1   | Further reading .....                            | 336 |
| 11.1.2   | Categories .....                                 | 337 |
| 11.1.2.1 | True HID's .....                                 | 337 |
| 11.1.2.2 | Vendor specific HID's .....                      | 337 |
| 11.2     | Background information .....                     | 338 |
| 11.2.1   | HID descriptors .....                            | 338 |
| 11.2.1.1 | HID descriptor .....                             | 338 |
| 11.2.1.2 | Report descriptor .....                          | 338 |
| 11.2.1.3 | Physical descriptor .....                        | 339 |
| 11.3     | Configuration .....                              | 340 |

|          |                                                 |     |
|----------|-------------------------------------------------|-----|
| 11.3.1   | Initial configuration .....                     | 340 |
| 11.3.2   | Final configuration.....                        | 340 |
| 11.4     | Example application.....                        | 341 |
| 11.4.1   | HID_Mouse.c .....                               | 341 |
| 11.4.1.1 | Running the example .....                       | 341 |
| 11.4.2   | HID_Echo1.c .....                               | 342 |
| 11.4.2.1 | Running the example .....                       | 342 |
| 11.4.2.2 | Compiling the PC example application .....      | 343 |
| 11.5     | Target API.....                                 | 344 |
| 11.5.1   | Target interface function list .....            | 344 |
| 11.5.2   | USB-HID functions .....                         | 345 |
| 11.5.3   | Data structures.....                            | 358 |
| 11.6     | Host API .....                                  | 359 |
| 11.6.1   | Host API function list .....                    | 360 |
| 11.6.2   | USB-HID functions .....                         | 361 |
| 12       | Printer Class .....                             | 373 |
| 12.1     | Overview .....                                  | 374 |
| 12.1.1   | Configuration.....                              | 374 |
| 12.2     | The example application.....                    | 375 |
| 12.3     | Target API.....                                 | 378 |
| 12.3.1   | Interface function list.....                    | 378 |
| 12.3.2   | API functions .....                             | 379 |
| 13       | Remote NDIS (RNDIS) .....                       | 389 |
| 13.1     | Overview .....                                  | 390 |
| 13.1.1   | Working with RNDIS .....                        | 390 |
| 13.1.2   | Additional information.....                     | 391 |
| 13.2     | Configuration.....                              | 392 |
| 13.2.1   | Initial configuration .....                     | 392 |
| 13.2.2   | Final configuration.....                        | 392 |
| 13.2.3   | Class specific configuration .....              | 392 |
| 13.2.4   | Compile time configuration .....                | 396 |
| 13.3     | Running the sample application.....             | 397 |
| 13.3.0.1 | IP_Config_RNDIS.c in detail.....                | 397 |
| 13.4     | RNDIS + embOS/IP as a "USB Webserver" .....     | 399 |
| 13.5     | Target API.....                                 | 400 |
| 13.5.1   | API functions .....                             | 401 |
| 13.5.1.1 | USB_RNDIS_Add() .....                           | 401 |
| 13.5.1.2 | USB_RNDIS_Task() .....                          | 402 |
| 13.5.2   | Data structures.....                            | 403 |
| 13.5.2.1 | USB_RNDIS_INIT_DATA .....                       | 403 |
| 13.5.2.2 | USB_RNDIS_EVENT_API .....                       | 404 |
| 13.5.2.3 | USB_RNDIS_DRIVER_API.....                       | 405 |
|          | (*pfInit)() .....                               | 406 |
|          | (*pfGetPacketBuffer)().....                     | 406 |
|          | (*pfWritePacket)() .....                        | 406 |
|          | (*pfSetPacketFilter)() .....                    | 407 |
|          | (*pfGetLinkStatus)() .....                      | 407 |
|          | (*pfGetLinkSpeed)().....                        | 407 |
|          | (*pfGetHWAddr)().....                           | 408 |
|          | (*pfGetStats)() .....                           | 409 |
|          | (*pfGetMTU)() .....                             | 410 |
|          | (*pfReset)() .....                              | 410 |
| 13.5.2.4 | USB_RNDIS_DRIVER_DATA.....                      | 411 |
|          | (*pfCreate)().....                              | 412 |
|          | (*pfSignal)() .....                             | 412 |
|          | (*pfWaitTimed)() .....                          | 413 |
| 14       | Combining USB components (Multi-Interface)..... | 415 |

|           |                                                                      |     |
|-----------|----------------------------------------------------------------------|-----|
| 14.1      | Overview .....                                                       | 416 |
| 14.1.1    | Single interface device classes .....                                | 417 |
| 14.1.2    | Multiple interface device classes .....                              | 418 |
| 14.1.3    | IAD class .....                                                      | 418 |
| 14.2      | Configuration .....                                                  | 419 |
| 14.3      | How to combine .....                                                 | 420 |
| 14.4      | emUSB component specific modification .....                          | 424 |
| 14.4.1    | BULK communication component .....                                   | 424 |
| 14.4.1.1  | Device side .....                                                    | 424 |
| 14.4.1.2  | Host side .....                                                      | 424 |
| 14.4.2    | MSD component .....                                                  | 426 |
| 14.4.2.1  | Device side .....                                                    | 426 |
| 14.4.2.2  | Host side .....                                                      | 426 |
| 14.4.3    | CDC component .....                                                  | 426 |
| 14.4.3.1  | Device side .....                                                    | 426 |
| 14.4.3.2  | Host side .....                                                      | 426 |
| 14.4.4    | HID component .....                                                  | 428 |
| 14.4.4.1  | Device side .....                                                    | 428 |
| 14.4.4.2  | Host side .....                                                      | 428 |
| 15        | Target OS Interface .....                                            | 429 |
| 15.1      | General information .....                                            | 430 |
| 15.1.1    | Operating system support supplied with this release .....            | 430 |
| 15.2      | Interface function list .....                                        | 431 |
| 15.3      | Example .....                                                        | 441 |
| 16        | Target USB Driver .....                                              | 445 |
| 16.1      | General information .....                                            | 446 |
| 16.1.1    | Available USB drivers .....                                          | 446 |
| 16.2      | Adding a driver to emUSB .....                                       | 448 |
| 16.3      | Interrupt handling .....                                             | 451 |
| 16.3.1    | ARM7 / ARM9 based cores .....                                        | 451 |
| 16.3.1.1  | ARM specific IRQ handler .....                                       | 452 |
| 16.3.1.2  | Device specifics ATMEL AT91CAP9x .....                               | 453 |
| 16.3.1.3  | Device specifics ATMEL AT91RM9200 .....                              | 453 |
| 16.3.1.4  | Device specifics ATMEL AT91SAM7A3 .....                              | 453 |
| 16.3.1.5  | Device specifics ATMEL AT91SAM7S64, AT91SAM7S128, AT91SAM7S256 ..... | 453 |
| 16.3.1.6  | Device specifics ATMEL AT91SAM7X64, AT91SAM7X128, AT91SAM7X256 ..... | 453 |
| 16.3.1.7  | Device specifics ATMEL AT91SAM7SE .....                              | 453 |
| 16.3.1.8  | Device specifics ATMEL AT91SAM9260 .....                             | 453 |
| 16.3.1.9  | Device specifics ATMEL AT91SAM9261 .....                             | 453 |
| 16.3.1.10 | Device specifics ATMEL AT91SAM9263 .....                             | 453 |
| 16.3.1.11 | Device specifics ATMEL AT91SAMRL64, AT91SAMR64 .....                 | 454 |
| 16.3.1.12 | Device specifics NXP LPC214x .....                                   | 455 |
| 16.3.1.13 | Device specifics NXP LPC23xx .....                                   | 455 |
| 16.3.1.14 | Device specifics NXP (formerly Sharp) LH79524/5 .....                | 455 |
| 16.3.1.15 | Device specifics OKI 69Q62 .....                                     | 455 |
| 16.3.1.16 | Device specifics ST STR71x .....                                     | 455 |
| 16.3.1.17 | Device specifics ST STR750 .....                                     | 455 |
| 16.3.1.18 | Device specifics ST STR750 .....                                     | 455 |
| 16.4      | Writing your own driver .....                                        | 456 |
| 16.4.1    | USB initialization functions .....                                   | 458 |
| 16.4.2    | General USB functions .....                                          | 459 |
| 16.4.3    | General endpoint functions .....                                     | 461 |
| 16.4.4    | Endpoint 0 (control endpoint) related functions .....                | 464 |
| 16.4.5    | OUT-endpoint functions .....                                         | 465 |
| 16.4.6    | IN-endpoint functions .....                                          | 466 |
| 16.4.7    | USB driver interrupt handling .....                                  | 468 |
| 17        | Support .....                                                        | 469 |

|        |                                                                    |     |
|--------|--------------------------------------------------------------------|-----|
| 17.1   | Problems with tool chain (compiler, linker) .....                  | 470 |
| 17.1.1 | Compiler crash.....                                                | 470 |
| 17.1.2 | Compiler warnings.....                                             | 470 |
| 17.1.3 | Compiler errors.....                                               | 470 |
| 17.1.4 | Linker problems .....                                              | 470 |
| 17.2   | Problems with hardware/driver .....                                | 471 |
| 17.3   | Contacting support.....                                            | 471 |
| 18     | Certification .....                                                | 473 |
| 18.1   | What is the Windows Logo Certification and why<br>do I need it?474 |     |
| 18.2   | Certification offer .....                                          | 475 |
| 18.3   | Vendor and Product ID.....                                         | 475 |
| 18.4   | Certification without SEGGER Microcontroller .....                 | 475 |
| 19     | Performance & resource usage .....                                 | 477 |
| 19.1   | Memory footprint .....                                             | 478 |
| 19.1.1 | ROM .....                                                          | 478 |
| 19.1.2 | RAM .....                                                          | 478 |
| 19.2   | Performance.....                                                   | 479 |
| 20     | FAQ.....                                                           | 481 |

# Chapter 1

## Introduction

---

This chapter will give a short introduction to emUSB, covering generic bulk, Mass Storage Device (MSD), Communication Device Class (CDC), Human Interface Device (HID), Media Transfer Protocol (MTP) class, Printer Class and Remote Network Driver Interface Specification (RNDIS) class functionality. Host and target requirements are covered as well.

## 1.1 Overview

This guide describes how to install, configure and use emUSB. It also explains the internal structure of emUSB.

emUSB has been designed to work on any embedded system with a USB client controller. It can be used with USB 1.1 or USB 2.0 devices.

The highest possible transfer rate on USB 2.0 full speed (12 Mbit/second) devices is approximately 1 Mbyte per second. This data rate can indeed be achieved on fast systems, such as Cortex-M devices running at 48 MHz and above.

USB 2.0 high speed mode (480 MBit/second) is also fully supported and is automatically handled. Using USB high speed mode with an ARM9 or faster could achieve values of approx. 18 MBytes/second and faster.

The USB standard defines four types of communication: Control, isochronous, interrupt, and bulk. Experience shows that for most embedded devices the bulk mode is the communication mode of choice because applications can utilize the full bandwidth of the Universal Serial Bus.

## 1.2 emUSB features


Key features of emUSB are:

- High speed
- Can be used with or without an RTOS
- Easy to use
- Easy to port
- No custom USB host driver necessary
- Start / test application supplied
- Highly efficient, portable, and commented ANSI C source code
- Hardware abstraction layer allows rapid addition of support for new devices



## 1.3 emUSB components

emUSB consists of three layers: A driver for hardware access, the emUSB core and at least a USB class driver or the bulk communication component.



The different available hardware drivers, the USB class drivers, and the bulk communication component are additional packages, which can be combined and ordered as they fit to the requirements of your project. Normally, emUSB consists of a driver that fits to the used hardware, the emUSB core and at least one of the USB class drivers.

| Component          | Description                                                  |
|--------------------|--------------------------------------------------------------|
| USB protocol layer |                                                              |
| Bulk               | emUSB bulk component.<br>(emUSB-Bulk)                        |
| MSD                | emUSB Mass Storage Device class component.<br>(emUSB-MSD).   |
| CDC                | emUSB Communication Device Class component.<br>(emUSB-CDC)   |
| HID                | emUSB Human Interface Device Class component.<br>(emUSB-HID) |
| MTP                | emUSB Media Transfer Protocol component.<br>(emUSB-MTP)      |
| Printer            | emUSB Printer Class component.<br>(emUSB-Printer)            |
| RNDIS              | emUSB RNDIS component.<br>(emUSB-RNDIS)                      |
| Core layer         |                                                              |
| emUSB-Core         | The emUSB core is the intrinsic USB stack.                   |
| Hardware layer     |                                                              |
| Driver             | USB controller driver.                                       |

**Table 1.1: emUSB components**

## 1.3.1 emUSB-Bulk

The emUSB-Bulk stack consists of an embedded side, which is shipped as source code, and a driver for the PC, which is typically shipped as an executable (`.sys`). (The source of the PC driver can also be ordered.)

### 1.3.1.1 Purpose of emUSB-Bulk

emUSB-Bulk allows you to quickly and smoothly develop software for an embedded device that communicates with a PC via USB. The communication is like a single, high-speed, reliable channel (very similar to a TCP connection). This bidirectional channel, with built-in flow control, allows the PC to send data to the embedded target, the embedded target to receive these bytes and reply with any number of bytes. The PC is the USB host, the target is the USB client.

## 1.3.2 emUSB-MSD

### 1.3.2.1 Purpose of emUSB-MSD

#### **Access the target device like an ordinary disk drive**

emUSB-MSD enables the use of an embedded target device as a USB mass storage device. The target device can be simply plugged-in and used like an ordinary disk drive, without the need to develop a driver for the host operating system. This is possible because the mass storage class is one of the standard device classes, defined by the USB Implementers Forum (USB IF). Virtually every major operating system on the market supports these device classes out of the box.

#### **No custom host drivers necessary**

Every major OS already provides host drivers for USB mass storage devices, there is no need to implement your own. The target device will be recognized as a mass storage device and can be accessed directly.

#### **Plug and Play**

Assuming the target system is a digital camera using emUSB-MSD, videos or photos taken by this camera can be conveniently accessed with the file system explorer of the used operating system when the camera is connected to the computer.

### 1.3.2.2 Typical applications

Typical applications are:

- Digital camera
- USB stick
- MP3 player
- DVD player

Any target with USB interface: easy access to configuration and data files.

### 1.3.2.3 emUSB-MSD features

Key features of emUSB-MSD are:

- Can be used with RAM, parallel flash, serial flash or mechanical drives
- Support for full speed (12 Mbit/second) and high speed (480 Mbit/second) transfer rates
- OS-abstraction: Can be used with any RTOS, but no OS is required for MSD-only devices

### 1.3.2.4 How does it work?

#### **Use file system support from host OS**

A device which uses emUSB-MSD will be recognized as a mass storage device and can be used like an ordinary disk drive. If the device is unformatted when plugged-in, the host operating system will ask you to format the device. Any file system provided by the host can be used. Typically FAT is used, but other file systems such as NTFS are possible, too. If one of those file systems is used, the host is able to read from and write to the device using the storage functions of the emUSB MSD component, which define unstructured read and write operations. Thus, there is no need to develop extra file system code if the application only accesses data on the target from the host side. This is typically the case for simple storage applications, such as USB memory sticks or ATA to USB bridges.

#### **Only provide file system code on the target if necessary**

Mass storage devices like USB sticks do not require their own file system implementation. File system program code is only required if the application running on the target device has to access the stored data. The development of a file system is a

complex and time-consuming task and increases the time-to market. Thus we recommend the use of a commercial file system like emFile, SEGGER's file system for embedded applications. emFile is a high performance library that is optimized for minimum memory consumption in RAM and ROM, high speed and versatility. It is written in ANSI C and runs on any CPU and on any media. Refer to [www.segger.com/emfile.html](http://www.segger.com/emfile.html) for more information about emFile.

### 1.3.3 emUSB-CDC

emUSB-CDC converts the target device into a serial communication device. A target device running emUSB-CDC is recognized by the host as a serial interface (USB2COM, virtual COM port), without the need to install a special host driver, because the communication device class is one of the standard device classes and every major operating system already provides host drivers for those device classes. All PC software using a COM port will work without modifications with this virtual COM port.

#### 1.3.3.1 Typical applications

Typical applications are:

- Modem
- Telephone system
- Fax machine

### 1.3.4 emUSB-HID

The Human Interface Device class (HID) is an abstract USB class protocol defined by the USB Implementers Forum. This protocol was defined for handling devices that humans use to control the operation of computer systems.

An installation of a custom host USB driver is not necessary because the USB human interface device class is standardized and every major OS already provides host drivers for it.

#### 1.3.4.1 Typical applications

##### Typical examples

- Keyboard
- Mouse and similar pointing devices
- Game pad
- Front-panel controls - for example, switches and buttons
- Bar-code reader
- Thermometer
- Voltmeter
- Low-speed JTAG emulator
- Uninterruptible power supply (UPS)

### 1.3.5 emUSB-MTP

The Media Transfer Protocol (MTP) is a USB class protocol which can be used to transfer files to and from storage devices. MTP is an alternative to MSD as it operates on a file level rather than on a storage sector level.

The advantage of MTP is the ability to access the storage medium from the host PC and from the device at the same time.

Because MTP works at the file level this also eliminates the risk of damaging the file system when the communication to the host has been canceled unexpectedly (e.g. the cable was removed).

MTP is supported by most operating systems without the need to install third-party drivers.

#### 1.3.5.1 Typical applications

Typical applications are:

- Digital camera
- USB stick
- MP3 player
- DVD player
- Telephone

Any target with USB interface: easy access to configuration and data files.

## 1.3.6 emUSB-Printer

emUSB-Printer converts the target device into a printing device. A target device running emUSB-Printer is recognized by the host as a printer. Unless the device identifies itself as a printer already recognized by the host PC, you must install a driver to be able to communicate with the USB device.

### 1.3.6.1 Typical applications

Typical applications are:

- Laser/Inkjet printer
- CNC machine



## 1.3.7 emUSB-RNDIS

emUSB-RNDIS allows to create a virtual Ethernet adapter through which the host PC can communicate with the device using the Internet protocol suite (TCP, UDP, FTP, HTTP, Telnet). This allows the creation of USB based devices which can host a web-server or act as a telnet terminal or a FTP server. emUSB-RNDIS offer a unique customer experience and allows to save development and hardware cost by e.g. using a website as a user interface instead of creating an application for every major OS and by eliminating the Ethernet hardware components from your device.

### 1.3.7.1 Typical applications

Typical applications are:

- USB-Webserver
- USB-Terminal (e.g. Telnet)
- USB-FTP-Server

## 1.4 Requirements

### 1.4.1 Target system

#### Hardware

The target system must have a USB controller. The memory requirements are approximately 6 Kbytes ROM for the emUSB-Bulk stack or 10 Kbytes ROM for emUSB-Bulk and emUSB-MSD and approximately 1 Kbytes of RAM (only used for buffering). Additionally memory for data storage is required, typically either on-board flash memory (parallel or serial) or an external flash memory card is required. In order to have the control when the device is enumerated by the host, a switchable attach is necessary. This is a switchable pull-up connected to the D+-Line of USB.

#### Software

emUSB is optimized to be used with embOS but works with any other supported RTOS or without an RTOS in a superloop. For information regarding the OS integration refer to *Target OS Interface* on page 429.

### 1.4.2 Development environment (compiler)

The CPU used is of no importance; only an ANSI-compliant C compiler complying with at least one of the following international standard is required:

- ISO/IEC/ANSI 9899:1990 (C90) with support for C++ style comments (//)
- ISO/IEC 9899:1999 (C99)
- ISO/IEC 14882:1998 (C++)

If your compiler has some limitations, let us know and we will inform you if these will be a problem when compiling the software. Any compiler for 16/32/64-bit CPUs or DSPs that we know of can be used; most 8-bit compilers can be used as well.

A C++ compiler is not required, but can be used. The application program can therefore also be programmed in C++ if desired.

## 1.5 File structure

The following table shows the contents of the emUSB root directory:

| Directory   | Contents                                                                                                                                                                                                                                             |
|-------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Application | Contains the application program. Depending on which stack is used, several files are available for each stack. Detailed information can be found in the corresponding chapter.                                                                      |
| Config      | Contains configuration files (USB_Conf.h, Config_XXX.h, where XXX describes the driver that is used.).                                                                                                                                               |
| Doc         | Contains the emUSB documentation.                                                                                                                                                                                                                    |
| Hardware    | Contains a simple implementation of the required hardware interface routines. Full implementation of the hardware routine for several CPU and eval board can be found on SEGGER's website: <a href="http://www.segger.com">http://www.segger.com</a> |
| Inc         | Contains include files.                                                                                                                                                                                                                              |
| OS          | Contains operating systems dependent files which allows to run emUSB with different RTOS's.                                                                                                                                                          |
| USB         | Contains the emUSB source code.<br><b>Note:</b> Do not change the source code in this directory.                                                                                                                                                     |

**Table 1.2: Supplied directory structure of emUSB core package**

Depending on the chosen emUSB component, the following additional subdirectories are available:

## 1.5.1 Bulk communication component

| Directory           | Contents                                                                                                                                                                                                                                              |
|---------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Bulk\Windows-Driver | Contains the kernel mode USB driver for the PC (Win32, NT platform), the compiled driver (.sys), the .inf file required for installation. The source code of the Windows driver is included, if a source code version of emUSB-Bulk has been ordered. |
| Bulk\SampleApp      | Contains a PC sample project to help you bring up and test the system.                                                                                                                                                                                |
| USB\Bulk            | Includes all files that are necessary for the generic bulk communication.                                                                                                                                                                             |

**Table 1.3: Additional subdirectories for emUSB bulk communication component**

## 1.5.2 MSD component

| Directory | Contents                                                                                                                                                                 |
|-----------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| USB\MSD   | Contains all files that handle the specific USB-MSD commands. Different storage drivers, such as a RAM storage device driver or emFile device driver are also available. |

**Table 1.4: Additional subdirectories for emUSB MSD component**

## 1.5.3 CDC component

| Directory | Contents                                                                                                                                                      |
|-----------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|
| CDC       | The driver installation file (USBser.inf) located in this directory can be used to install the USB-CDC device (Virtual COM-Port) on > Windows 2000 platforms. |
| USB\CDC   | Contains all files specific for the USB-CDC communication.                                                                                                    |

**Table 1.5: Additional subdirectories for emUSB CDC component**

## 1.5.4 HID component

| Directory     | Contents                                                               |
|---------------|------------------------------------------------------------------------|
| HID\SampleApp | Contains a PC sample project to help you bring up and test the system. |
| USB\HID       | Includes all files that are necessary for the HID component.           |

**Table 1.6: Additional subdirectories for emUSB HID communication component**

# Chapter 2

## Background information

---

This is a short introduction to USB. The fundamentals of USB are explained and links to additional resources are given.  
Information provided in this chapter is *not* required to use the software.

## 2.1 USB

### 2.1.1 Short Overview

The Universal Serial Bus (USB) is a bus architecture for connecting multiple peripherals to a host computer. It is an industry standard — maintained by the USB Implementers Forum — and because of its many advantages it enjoys a huge industry-wide acceptance. Over the years, a number of USB-capable peripherals appeared on the market, for example printers, keyboards, mice, digital cameras etc. Among the top benefits of USB are:

- Excellent plug-and-play capabilities allow devices to be added to the host system without reboots ("hot-plug"). Plugged-in devices are identified by the host and the appropriate drivers are loaded instantly.
- USB allows easy extensions of host systems without requiring host-internal extension cards.
- Device bandwidths may range from a few Kbytes/second to hundreds of Mbytes/second.
- A wide range of packet sizes and data transfer rates are supported.
- USB provides internal error handling. Together with the already mentioned hot-plug capability this greatly improves robustness.
- The provisions for powering connected devices dispense the need for extra power supplies for many low power devices.
- Several transfer modes are supported which ensures the wide applicability of USB.

These benefits did not only lead to broad market acceptance, but it also added several advantages, such as low costs of USB cables and connectors or a wide range of USB stack implementations. Last but not least, the major operating systems such as Microsoft Windows XP, Mac OS X, or Linux provide excellent USB support.

### 2.1.2 Important USB Standard Versions

#### USB 1.1 (September 1998)

This standard version supports isochronous and asynchronous data transfers. It has dual speed data transfer of 1.5 Mbytes/second for low speed and 12 Mbytes/second for full speed devices. The maximum cable length between host and device is five meters. Up to 500 mA of electric current may be distributed to low power devices.

#### USB 2.0 (April 2000)

As all previous USB standards, USB 2.0 is fully forward and backward compatible. Existing cables and connectors may be reused. A new high speed transfer speed of 480 Mbytes/second (40 times faster than USB 1.1 at full speed) was added.

#### USB 3.0 (November 2008)

As all previous USB standards, USB 3.0 is fully forward and backward compatible. Existing cables and connectors may be reused but the new speed can only be used with new USB 3.0 cables and devices. The new speed class is named USB Super-Speed, which offers a maximum rate of 5 Gbit/s.

## 2.1.3 USB System Architecture


A USB system is composed of three parts - a host side, a device side and a physical bus. The physical bus is represented by the USB cable and connects the host and the device.

The USB system architecture is asymmetric. Every single host can be connected to multiple devices in a tree-like fashion using special hub devices. You can connect up to 127 devices to a single host, but the count must include the hub devices as well.

### USB Host

A USB host consists of a USB host controller hardware and a layered software stack. This host stack contains:

- A host controller driver (HCD) which provides the functionality of the host controller hardware.
- The USB Driver (USBD) Layer which implements the high level functions used by USB device drivers in terms of the functionality provided by the HCD.
- The USB Device drivers which establish connections to USB devices. The driver classes are also located here and provide generic access to certain types of devices such as printers or mass storage devices.



## USB Device


Two types of devices exist: hubs and functions. Hubs provide for additional USB attachment points. Functions provide capabilities to the host and are able to transmit or receive data or control information over the USB bus. Every peripheral USB device represents at least one function but may implement more than one function. A USB printer for instance may provide file system like access in addition to printing.

In this guide we treat the term USB device as synonymous with functions and will not consider hubs.

Each USB device contains configuration information which describes its capabilities and resource requirements. A USB device must be configured by the host before its functions can be used. When a new device is connected for the first time, the host enumerates it, requests the configuration from the device, and performs the actual configuration. For example, if an embedded device uses emUSB-MSD, the embedded device will appear as a USB mass storage device, and the host OS provides the driver out of the box. In general, there is no need to develop a custom driver to communicate with target devices that use one of the USB class protocols.

## Descriptors

A device reports its attributes via descriptors. Descriptors are data structures with a standard defined format. A USB device has one *device descriptor* which contains information applicable to the device and all of its configurations. It also contains the number of configurations the device supports. For each configuration, a *configuration descriptor* contains configuration-specific information. The configuration descriptor also contains the number of interfaces provided by the configuration. An interface groups the endpoints into logical units. Each *interface descriptor* contains information about the number of endpoints. Each endpoint has its own *endpoint descriptor* which states the endpoint's address, transfer types etc.



As can be seen, the descriptors form a tree. The root is the device descriptor with  $n$  configuration descriptors as children, each of which has  $m$  interface descriptors which in turn have  $o$  endpoint descriptors each.



## 2.1.4 Transfer Types

The USB standard defines four transfer types: control, isochronous, interrupt, and bulk. Control transfers are used in the setup phase. The application can select one of the other three transfer types. For most embedded applications, bulk is the best choice because it allows the highest possible data rates.

### Control transfers

Typically used for configuring a device when attached to the host. It may also be used for other device-specific purposes, including control of other pipes on the device.

### Isochronous transfers

Typically used for applications which need guaranteed speed. Isochronous transfer is fast but with possible data loss. A typical use is for audio data which requires a constant data rate.

### Interrupt transfers

Typically used by devices that need guaranteed quick responses (bounded latency).

### Bulk transfers

Typically used by devices that generate or consume data in relatively large and bursty quantities. Bulk transfer has wide dynamic latitude in transmission constraints. It can use all remaining available bandwidth, but with no guarantees on bandwidth or latency. Because the USB bus is normally not very busy, there is typically 90% or more of the bandwidth available for USB transfers.

## 2.1.5 Setup phase / Enumeration

The host first needs to get information from the target, before the target can start communicating with the host. This information is gathered in the initial setup phase. The information is contained in the descriptors, which are in the configurable section of the USB-MSD stack. The most important part of target device identification are the Product and Vendor IDs. During the setup phase, the host also assigns an address to the client. This part of the setup is called *enumeration*.

## 2.1.6 Product / Vendor IDs

The Product and Vendor IDs are necessary to identify the USB device. The Product ID describes a specific device type and does not need to be unique between different devices of the same type. USB host systems like Windows use the Product ID/Vendor ID combination to identify which drivers are needed.

For example: all our J-Link v8 devices have the Vendor ID 0x1366 and Product ID 0x0101.

A Vendor and Product ID is necessary only when development of the product is finished; during the development phase, the supplied Vendor and Product IDs can be used as samples.

Possible options to obtain a Vendor ID or Product ID are described in the chapter *Vendor and Product ID* on page 475.

## 2.2 Predefined device classes

The USB Implementers Forum has defined device classes for different purposes. In general, every device class defines a protocol for a particular type of application such as a mass storage device (MSD), human interface device (HID), etc.

Device classes provide a standardized way of communication between host and device and typically work with a class driver which comes with the host operating system.

Using a predefined device class where applicable minimizes the amount of work to make a device usable on different host systems.

emUSB-Device supports the following device classes:

- Mass Storage Device Class (MSD)
- Human Interface Device Class (HID)
- Communication Device Class (CDC)
- Printer Device Class (PDC)

## 2.3 USB hardware analyzers

A variety of USB hardware analyzers are on the market with different capabilities.

If you are developing an application using USB, it should not be necessary to have a USB analyzer, but we still recommend you do.

Simple yet powerful USB-Analyzers are available for less than \$1000.

## 2.4 References

For additional information see the following documents:

- Universal Serial Bus Specification, Revision 2.0
- Universal Serial Bus Mass Storage Class Specification Overview, Rev 1.2
- UFI command specification: USB Mass Storage Class, UFI Command Specification, Rev 1.0

# Chapter 3

## Getting started

---

The first step in getting emUSB up and running is typically to compile it for the target system and to run it in the target system. This chapter explains how to do this.

## 3.1 How to setup your target system


To get the USB up and running, 3 possible ways currently available:

- Upgrade a trial version available on the web with source code
- Upgrading an embOS Start project
- Creating a project from scratch

### 3.1.1 Upgrade a trial version available on the web with source code.


Simply download a trial package available from the SEGGER website.

After downloading, extract the trial project and open the workspace/project file which is located in the start folder.



The source files in the USB folder from the emUSB shipment need to be copied into the USB folder of the trial package.

Afterwards the project needs to be updated by adding the source files into the project.



### 3.1.2 Upgrading an embOS Start project

#### Integrating emUSB

The emUSB default configuration is preconfigured with valid values, which matches the requirements of most applications. emUSB is designed to be used with embOS, SEGGER's real-time operating system. We recommend to start with an embOS sample project and include emUSB into this project.

We assume that you are familiar with the tools you have selected for your project (compiler, project manager, linker, etc.). You should therefore be able to add files, add directories to the include search path, and so on. In this document the IAR Embedded Workbench® IDE is used for all examples and screenshots, but every other ANSI C toolchain can also be used. It is also possible to use make files; in this case, when we say "add to the project", this translates into "add to the make file".


#### Procedure to follow

Integration of emUSB is a relatively simple process, which consists of the following steps:

- Step 1: Open an embOS project and compile it
- Step 2: Add emUSB to the start project
- Step 3: Compile the project

## Step 1: Open an embOS start project

We recommend that you use one of the supplied embOS start projects for your target system. Compile the project and run it on your target hardware.



## Step 2: Adding emUSB to the start project

Add all source files in the following directory to your project:

- Config
- USB
- UTIL (optional)

The `Config` folder includes all configuration files of emUSB. The configuration files are preconfigured with valid values, which match the requirements of most applications. Add the hardware configuration `USB_Config_<TargetName>.c` supplied with the driver shipment.

If your hardware is currently not supported, use the example configuration file and the driver template to write your own driver. The example configuration file and the driver template is located in the `Sample\Driver\Template` folder.

The `Util` folder is an optional component of the emUSB shipment. It contains optimized MCU and/or compiler specific files, for example a special memcpy function.

## Configuring the include path

The include path is the path in which the compiler looks for include files. In cases where the included files (typically header files, `.h`) do not reside in the same directory as the C file to compile, an include path needs to be set. In order to build the project with all added files, you will need to add the following directories to your include path:

- Config
- Inc
- USB

### 3.1.3 Creating a project from scratch

To get the target system to behave like a mass storage device or generic bulk device on the USB bus, a few steps have to be taken:

- A project or make file has to be created for the used toolchain.
- The configuration may need to be adjusted.
- The hardware routines for the USB controller have to be implemented.
- Add the path of the required USB header files to the include path.

To get the target up and running is a lot easier if a USB chip is used for which a target hardware driver is already available. In that case, this driver can be used.


#### Creating the project or make file

The screenshot below gives an idea about a possible project setup.

|                                        |   |   |
|----------------------------------------|---|---|
| Start_AT91SAM7S256 - MSD_Debug_Flash * | ✓ |   |
| Application                            |   |   |
| MSD_Start.c                            |   | * |
| Config                                 |   |   |
| USB_Conf.h                             |   |   |
| Hardware                               |   |   |
| SAM7S                                  |   |   |
| AT91SAM7S.h                            |   |   |
| hw.c                                   |   | * |
| Inc                                    |   |   |
| Global.h                               |   |   |
| HW.h                                   |   |   |
| OS                                     |   |   |
| embOS                                  |   |   |
| ARM_IAR                                |   |   |
| CPU_AT91SAM7S256                       |   | * |
| Inc                                    |   |   |
| LIB                                    |   |   |
| Main.c                                 |   | * |
| OS_Error.c                             |   | * |
| RTOSVECT.asm                           |   | * |
| USB_OS_embOS.c                         |   | * |
| USB                                    |   |   |
| Core                                   |   |   |
| USB.h                                  |   |   |
| USB_memcpy.c                           |   | * |
| USB_Bulk.c                             |   | * |
| USB_Main.c                             |   | * |
| USB_Private.h                          |   |   |
| USB_Setup.c                            |   | * |
| Driver                                 |   |   |
| USB_HW_SAM7S.c                         |   | * |
| MSD                                    |   |   |
| USB_MS_D.c                             |   | * |
| USB_MS_D.h                             |   |   |
| USB_MS_D_Private.h                     |   |   |
| USB_MS_D_STORAGE_RAM.c                 |   | * |
| Output                                 |   |   |

## 3.2 Select the start application

For quick and easy testing of your emUSB integration, start with the code found in the folder Application. Add USB\_HID\_Mouse.c as your applications to your project.



## 3.3 Build the project and test it

Build the project. It should compile without errors and warnings. If you encounter any problem during the build process, check your include path and your project configuration settings. To test the project, download the output into your target and start the application.

After connecting the USB cable to the target device, the mouse pointer should hop from left to right.



## 3.4 Configuration

An application using emUSB must contain the following functions:

| Function                                                  | Description                                   |
|-----------------------------------------------------------|-----------------------------------------------|
| General emUSB configuration functions                     |                                               |
| <a href="#">USB_GetVendorId()</a>                         | Should return the Vendor ID of the target.    |
| <a href="#">USB_GetProductId()</a>                        | Should return the Product ID of the target.   |
| <a href="#">USB_GetVendorName()</a>                       | Should return the manufacturer name.          |
| <a href="#">USB_GetProductName()</a>                      | Should return the product name of the target. |
| <a href="#">USB_GetSerialNumber()</a>                     | Should return the manufacturer name.          |
| Additional required configuration functions for emUSB-MSD |                                               |
| <a href="#">USB_MSD_GetVendorName()</a>                   | Should return the vendor name.                |
| <a href="#">USB_MSD_GetProductVer()</a>                   | Should return the product version.            |
| <a href="#">USB_MSD_GetSerialNo()</a>                     | Should return the serial number.              |

**Table 3.1: Functions that are required in emUSB applications**

These functions are included in every example application. The functions can be used without modifications in the development phase of your application, but you may not bring a product on the market without modifying the information like Vendor ID and Product ID.

| Ids                                    | Description                                            |
|----------------------------------------|--------------------------------------------------------|
| Default Vendor ID for all applications |                                                        |
| 0x8765                                 | Example Vendor ID for all examples.                    |
| Used Product IDs                       |                                                        |
| 0x1234                                 | Example Product ID for all bulk samples.               |
| 0x1000                                 | Example Product ID for all MSD samples.                |
| 0x1200                                 | Example Product ID for the MSD CD-ROM sample.          |
| 0x1111                                 | Example Product ID for all CDC samples.                |
| 0x1112                                 | Example Product ID for HID mouse sample.               |
| 0x1114                                 | Example Product ID for the vendor specific HID sample. |
| 0x2114                                 | Example Product ID for the Printer class sample.       |

**Table 3.2: List of used Product and Vendor IDs**

## 3.4.1 General emUSB configuration functions

### 3.4.1.1 USB\_GetVendorId()

#### Description

Should return the Vendor ID of the target.

#### Prototype

```
U16 USB_GetVendorId(void);
```

#### Example

```
U16 USB_GetVendorId(void) {  
    return 0x8765;  
}
```

#### Additional information

The Vendor ID is assigned by the USB Implementers Forum ([www.usb.org](http://www.usb.org)). For tests, the default number above (or pretty much any other number) can be used. However, you may not bring a product to market without having been assigned your own Vendor ID.

For emUSB-Bulk and emUSB-CDC: If you change this value, do not forget to make the same change to the `.inf` file as described in section *The .inf file* on page 80 or *The .inf file* on page 301. Otherwise, the Windows host will be unable to locate the driver.

### 3.4.1.2 USB\_GetProductId()

#### Description

Should return the Product ID of the target.

#### Prototype

```
U16 USB_GetProductId(void);
```

#### Example

```
U16 USB_GetProductId(void) {  
    return 0x1111;  
}
```

#### Additional information

The Product ID in combination with the Vendor ID creates a worldwide unique identifier. For tests, you can use the default number above (or pretty much any other number).

For emUSB-Bulk and emUSB-CDC: If you change this value, do not forget to make the same change to the `.inf` file as described in section *The .inf file* on page 80 or *The .inf file* on page 301. Otherwise, the Windows host will be unable to locate the driver.

### 3.4.1.3 USB\_GetVendorName()

#### Description

Should return the manufacturer name.

#### Prototype

```
const char * USB_GetVendorName(void);
```

#### Example

```
const char * USB_GetVendorName(void) {  
    return "Vendor";  
}
```

#### Additional information

The manufacturer name is used during the enumeration phase. The product name and the serial number together should give a detailed information about which device is connected to the host.

**Note:** The max string length cannot be more than 126 ANSI characters.

### 3.4.1.4 USB\_GetProductName()

#### Description

Should return the product name.

#### Prototype

```
const char * USB_GetProductName(void);
```

#### Example

```
const char * USB_GetProductName(void) {  
    return "Bulk device";  
}
```

#### Additional information

The product name is used during the enumeration phase. The manufacturer name and the serial number should together give a detailed information about which device is connected to the host.

**Note:** The max string length cannot be more than 126 ANSI characters.

### 3.4.1.5 USB\_GetSerialNumber()

#### Description

Should return the serial number.

#### Prototype

```
const char * USB_GetSerialNumber(void);
```

#### Example

```
const char * USB_GetSerialNumber(void) {  
    return "12345678";  
}
```

#### Additional information

The serial number is used during the enumeration phase. The manufacturer and the product name should together give a detailed information to the user about which device is connected to the host.

**Note:** The max string length cannot be more than 126 ANSI characters.

**Note for MSD:** In order to confirm to the USB bootability specification, the minimum string length must be 12 characters where each character is a hexadecimal digit ('0' through '9' or 'A' through 'F').

### 3.4.2 Additional required configuration functions for emUSB-MSD

Refer to *Configuration* on page 183 for more information about the required additional configuration functions for emUSB-MSD.

### 3.4.3 Descriptors

All configuration descriptors are automatically generated by emUSB and do not require configuration.





# Chapter 4


## USB Core

---

This chapter describes the basic functions of the USB Core.

## 4.1 Overview

This chapter describes the functions of the core layer of USB Core. These functions are required for all USB class drivers and the unclassified bulk communication component.



### General information

To communicate with the host, the example application project includes a USB-specific header `USB.h` and the emUSB source files, if you have a source version of emUSB. These files contain API functions to communicate with the USB host through the USB Core driver.

Every application using USB Core must perform the following steps:

1. Initialize the USB stack. To initialize the USB stack `USB_Init()` has to be called. `USB_Init()` performs the low-level initialization of the USB stack and calls `USB_X_AddDriver()` to add a driver to the USB stack.
2. Add communication endpoints. You have to add the required endpoints with the compatible transfer type for the desired interface before you can use any of the USB class drivers or the unclassified bulk communication component.  
For the emUSB bulk component, refer to `USB_BULK_INIT_DATA` on page 109 for information about the initialization structure that is required when you want to add a bulk interface.  
For the emUSB MSD component, refer to `USB_MSD_INIT_DATA` on page 203 and `USB_MSD_INST_DATA` on page 205 for information about the initialization structures that are required when you want to add an MSD interface.  
For the emUSB CDC component, refer to `USB_CDC_INIT_DATA` on page 329 for information about the initialization structure that is required when you want to add a CDC interface.  
For the emUSB HID component, refer to `USB_HID_INIT_DATA` on page 358 for information about the initialization structure that is required when you want to add a HID interface.
3. Start the USB stack. Call `USB_Start()` to start the USB stack.

Example applications for every supported USB class and the unclassified bulk component are supplied. We recommend using one of these examples as a starting point for your own application. All examples are supplied in the `\Application\` directory.

## 4.2 Target API

This section describes the functions that can be used by the target application.

| Function                                | Description                                                                           |
|-----------------------------------------|---------------------------------------------------------------------------------------|
| USB basic functions                     |                                                                                       |
| <code>USB_AddDriver()</code>            | Adds a USB device driver to the emUSB stack.                                          |
| <code>USB_GetState()</code>             | Returns the state of the USB device.                                                  |
| <code>USB_Init()</code>                 | Initializes the emUSB Core.                                                           |
| <code>USB_IsConfigured()</code>         | Checks if the USB device is configured.                                               |
| <code>USB_Start()</code>                | Starts the emUSB core.                                                                |
| <code>USB_Stop()</code>                 | Stops the emUSB core.                                                                 |
| <code>USB_DeInit()</code>               | Deinitializes the emUSB Core.                                                         |
| USB configuration functions             |                                                                                       |
| <code>USB_AddEP()</code>                | Returns an endpoint "handle" that can be used for the desired USB interface.          |
| <code>USB_SetAddFuncDesc()</code>       | Sets a callback for setting additional information into the configuration descriptor. |
| <code>USB_SetClassRequestHook()</code>  | Sets a callback to handle class setup requests.                                       |
| <code>USB_SetVendorRequestHook()</code> | Sets a callback to handle vendor setup requests.                                      |
| <code>USB_SetIsSelfPowered()</code>     | Sets whether the device is self-powered or not.                                       |
| <code>USB_SetMaxPower()</code>          | Sets the target device's current consumption.                                         |
| <code>USB_SetOnRxEP0()</code>           | Sets a callback to handle data read of endpoint 0.                                    |
| <code>USB_SetOnSetupHook()</code>       | Sets a callback to handle EP0 setup packets.                                          |
| <code>USB__WriteEP0FromISR()</code>     | Writes data to a USB EP.                                                              |
| <code>USB_StallEP()</code>              | Stalls an endpoint.                                                                   |
| <code>USB_WaitForEndOfTransfer()</code> | Waits for a data transfer to be ended.                                                |
| USB IAD functions                       |                                                                                       |
| <code>USB_EnableIAD()</code>            | Allows to combine multi-interface device classes with single-interface classes.       |
| USB RemoteWakeUp functions              |                                                                                       |
| <code>USB_SetAllowRemoteWakeUp()</code> | Allows the device to publish that remote wakeup is available.                         |
| <code>USB_DoRemoteWakeup()</code>       | Performs a remote wakeup to the host.                                                 |

**Table 4.1: Target USB Core interface function list**

## 4.2.1 USB basic functions

### 4.2.1.1 USB\_AddDriver()

#### Description

Adds a USB device driver to the USB stack. This function should be called from within `USB_X_AddDriver()` which is implemented in `USB_Config_*.c`.

#### Prototype

```
void USB_AddDriver(const USB_HW_DRIVER * pDriver);
```

#### Additional information

To add the driver, use `USB_AddDriver()` with the identifier of the compatible driver. Refer to the section *Available USB drivers* on page 446 for a list of supported devices and their valid identifiers.

#### Example

```
/******  
*  
*      USB_X_AddDriver  
*/  
void USB_X_AddDriver(void) {  
    BSP_USB_Init();  
    USB_DRIVER_LPC17xx_ConfigAddr(0x2008C000); // USB controller of LPC1788  
                                              // is located @ 0x2008C000  
    USB_AddDriver(&USB_Driver_NXPLPC17xx);  
}
```

### 4.2.1.2 USB\_GetState()

#### Description

Returns the state of the USB device.

#### Prototype

```
int USB_GetState(void);
```

#### Return value

The return value is a bitwise OR combination of the following state flags.

| USB state flags     |                              |
|---------------------|------------------------------|
| USB_STAT_ATTACHED   | Device is attached. (Note 1) |
| USB_STAT_READY      | Device is ready.             |
| USB_STAT_ADDRESSED  | Device is addressed.         |
| USB_STAT_CONFIGURED | Device is configured.        |
| USB_STAT_SUSPENDED  | Device is suspended.         |

#### Additional information

A USB device has several possible states. Some of these states are visible to the USB and the host, while others are internal to the USB device. Refer to *Universal Serial Bus Specification*, Revision 2.0, Chapter 9 for detailed information.

##### Note 1:

Attached in a USB sense of the word does not mean that the device is physically connected to the PC via a USB cable, it only means that the pull-up resistor on the device side is connected. The status can be "attached" regardless of whether the device is connected to a host or not.

### 4.2.1.3 USB\_Init()

#### Description

Initializes the USB device with its settings.

#### Prototype

```
void USB_Init(void);
```

#### 4.2.1.4 USB\_IsConfigured()

##### Description

Checks if the USB device is initialized and ready.

##### Prototype

```
char USB_IsConfigured(void);
```

##### Return value

- 0: USB device is not configured.
- 1: USB device is configured.

### 4.2.1.5 USB\_Start()

#### Description

Starts the emUSB Core.

#### Prototype

```
void USB_Start(void);
```

#### Additional information

This function should be called after configuring USB Core. It initiates a hardware attach and updates the endpoint configuration. When the USB cable is connected to the device, the host will start enumeration of the device.



#### 4.2.1.6 USB\_Stop()

##### **Description**

Stops the USB communication. This function also makes sure that the device is detached from the USB host.

##### **Prototype**

```
void USB_Stop(void);
```

### 4.2.1.7 USB\_DeInit()

#### Description

De-initializes the complete USB stack.

#### Prototype

```
void USB_DeInit(void);
```

#### Additional information

This function also calls [USB\\_Stop\(\)](#) internally.

Not all drivers have a DeInit callback function, if you need to use DeInit and your driver does not have the callback - please contact SEGGER.

## 4.2.2 USB configuration functions

### 4.2.2.1 USB\_AddEP()

#### Description

Returns an endpoint "handle" that can be used for the desired USB interface.

#### Prototype

```
unsigned USB_AddEP(U8          InDir,
                  U8          TransferType,
                  U16         Interval,
                  U8          * pBuffer,
                  unsigned     BufferSize);
```

| Parameter    | Description                                                                                                                                                   |
|--------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|
| InDir        | Specifies the direction of the desired endpoint.<br>1 - IN<br>0 - OUT                                                                                         |
| TransferType | Specifies the transfer type of the endpoint.<br>The following values are allowed:<br>USB_TRANSFER_TYPE_BULK<br>USB_TRANSFER_TYPE_ISO<br>USB_TRANSFER_TYPE_INT |
| Interval     | Specifies the interval in for the endpoint. This value can be zero for a bulk endpoint.                                                                       |
| pBuffer      | Pointer to a buffer that is used for OUT-transactions.<br>For IN-endpoints this parameter must be NULL.                                                       |
| BufferSize   | Size of the buffer.                                                                                                                                           |

**Table 4.2: USB\_AddEP() parameter list**

#### Return value

> 0: A valid endpoint handle is returned.  
== 0: Error.

#### Additional information

The `Interval` parameter specifies the frequency in which the endpoint should be polled for information by the host.

The frequency is specified in frames. When using USB low/full-speed one frame is sent every millisecond. When using USB high-speed one (micro)frame is sent every 0.125 µs.

For an endpoint of type `USB_TRANSFER_TYPE_ISO` the interval has to be 1.

For an endpoint of type `USB_TRANSFER_TYPE_INT` the interval has to be between 1 and 255.

For endpoints of type `USB_TRANSFER_TYPE_BULK` the value holds no relevance and has to be set to 0.

### 4.2.2.2 USB\_SetAddFuncDesc()

#### Description

Sets a callback for setting additional information into the configuration descriptor.

#### Prototype

```
void USB_SetAddFuncDesc(USB_ADD_FUNC_DESC * pfAddDescFunc);
```

| Parameter                  | Description                                                                             |
|----------------------------|-----------------------------------------------------------------------------------------|
| <code>pfAddDescFunc</code> | Pointer to a function that should be called when building the configuration descriptor. |

**Table 4.3: USB\_SetAddFuncDesc() parameter list**

#### Additional information

USB\_ADD\_FUNC\_DESC is defined as follows:

```
typedef void USB_ADD_FUNC_DESC(USB_INFO_BUFFER * pInfoBuffer);
```

### 4.2.2.3 USB\_SetClassRequestHook()

#### Description

Sets a callback for a function that handles setup class request packets.

#### Prototype

```
void USB_SetClassRequestHook(unsigned Interface,
                             USB_ON_CLASS_REQUEST * pfOnClassrequest);
```

| Parameter        | Description                                                                                |
|------------------|--------------------------------------------------------------------------------------------|
| Interface        | Specifies the Interface number of the class on which the hook shall be installed.          |
| pfOnClassrequest | Pointer to a function that should be called when a setup class request/packet is received. |

**Table 4.4: USB\_SetClassRequestHook() parameter list**

#### Additional information

Note that the callback will be called within an ISR.

If it is necessary to send data from the callback function through endpoint 0, use the function `USB__WriteEP0FromISR()`.

`USB_ON_CLASS_REQUEST` is defined as follows:

```
typedef void USB_ON_CLASS_REQUEST(const USB_SETUP_PACKET * pSetup-
Packet);
```

#### 4.2.2.4 USB\_SetVendorRequestHook()

##### Description

Sets a callback for a function that handles setup vendor request packets.

##### Prototype

```
void USB_SetVendorRequestHook (unsigned InterfaceNum,
                               USB_ON_CLASS_REQUEST * pfOnVendorRequest);
```

| Parameter        | Description                                                                                 |
|------------------|---------------------------------------------------------------------------------------------|
| Interface        | Specifies the Interface number of the class on which the hook shall be installed.           |
| pfOnClassrequest | Pointer to a function that should be called when a setup vendor request/packet is received. |

**Table 4.5: USB\_SetClassRequestHook() parameter list**

##### Additional information

Note that the callback will be called within an ISR, therefore it should never block. If it is necessary to send data from the callback function through endpoint 0, use the function `USB__WriteEP0FromISR()`.

`USB_ON_CLASS_REQUEST` is defined as follows:

```
typedef void USB_ON_CLASS_REQUEST(const USB_SETUP_PACKET * pSetup-
Packet);
```

### 4.2.2.5 USB\_SetIsSelfPowered()

#### Description

Sets whether the device is self-powered or not.

#### Prototype

```
void USB_SetIsSelfPowered(U8 IsSelfPowered);
```

| Parameter                  | Description                                                    |
|----------------------------|----------------------------------------------------------------|
| <code>IsSelfPowered</code> | 0 - Device is not self-powered.<br>1 - Device is self-powered. |

**Table 4.6: USB\_SetClassRequestHook() parameter list**

#### Additional information

This function has to be called before USB\_Start(), as it will specify if the device is self-powered or not.

The default value is 0 (not self-powered).

### 4.2.2.6 USB\_SetMaxPower()

#### Description

Sets the maximum power consumption reported to the host during enumeration.

#### Prototype

```
void USB_SetMaxPower(U8 MaxPower);
```

| Parameter | Description                                                                                         |
|-----------|-----------------------------------------------------------------------------------------------------|
| MaxPower  | Specifies the max power consumption given in mA.<br>MaxPower shall be in range between 0mA - 500mA. |

**Table 4.7: USB\_SetClassRequestHook() parameter list**

#### Additional information

This function shall be called before USB\_Start(), as it will specify how much power the device will consume from the host.

If this function is not called, a default value of 100 mA will be used.



### 4.2.2.7 USB\_SetOnRxEP0()

#### Description

Sets a callback to handle non-setup data presented on endpoint 0.

#### Prototype

```
void USB_SetOnRxEP0(USB_ON_RX_FUNC * pfOnRx);
```

| Parameter              | Description                                                                               |
|------------------------|-------------------------------------------------------------------------------------------|
| <a href="#">pfOnRx</a> | Pointer to a function that should be called when receiving data other than setup packets. |

**Table 4.8: USB\_SetOnRxEP0() parameter list**

#### Additional information

Note that the callback will be called within an ISR, therefore it should never block. If it is necessary to send data from the callback function through endpoint 0, use the function `USB__WriteEP0FromISR()`.

USB\_ON\_RX\_FUNC is defined as follows:

```
typedef void USB_ON_RX_FUNC(const U8 * pData, unsigned NumBytes);
```

### 4.2.2.8 USB\_SetOnSetupHook()

#### Description

Sets a callback for a function that handles setup class request packets.

#### Prototype

```
void USB_SetOnSetupHook (unsigned InterfaceNum, USB_ON_SETUP * pfOnSetup);
```

| Parameter                     | Description                                                                                |
|-------------------------------|--------------------------------------------------------------------------------------------|
| <code>Interface</code>        | Specifies the Interface number of the class on which the hook shall be installed.          |
| <code>pfOnClassrequest</code> | Pointer to a function that should be called when a setup class request/packet is received. |

**Table 4.9: USB\_SetClassRequestHook() parameter list**

#### Additional information

Note that the callback will be called within an ISR.

If it is necessary to send data from the callback function through endpoint 0, use the function `USB__WriteEP0FromISR()`.

USB\_ON\_SETUP is defined as follows:

```
typedef int USB_ON_SETUP(const USB_SETUP_PACKET * pSetupPacket);
```

### 4.2.2.9 USB\_\_WriteEP0FromISR()

#### Description

Writes data to a USB EP.

#### Prototype

```
void USB__WriteEP0FromISR(const void* pData, unsigned NumBytes,
                           char Send0PacketIfRequired);
```

| Parameter                          | Description                                                                                                                                                                                                      |
|------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>pData</code>                 | Data that should be written.                                                                                                                                                                                     |
| <code>NumBytes</code>              | Number of bytes to write.                                                                                                                                                                                        |
| <code>Send0PacketIfRequired</code> | Specifies that a zero-length packet should be sent when the last data packet to the host is a multiple of <code>MaxPacketSize</code> . Normally <code>MaxPacketSize</code> for control mode transfer is 64 byte. |

**Table 4.10: USB\_\_WriteEP0FromISR() parameter list**

## 4.2.3 USB control functions

### 4.2.3.1 USB\_StallEP()

#### Description

Stalls an endpoint.

#### Prototype

```
void USB_StallEP(U8 EPIndex);
```

| Parameter               | Description                               |
|-------------------------|-------------------------------------------|
| <a href="#">EPIndex</a> | Endpoint handle that needs to be stalled. |

**Table 4.11: USB\_StallEP() parameter list**

### 4.2.3.2 USB\_WaitForEndOfTransfer()

#### Description

Waits for a data transfer to complete.

#### Prototype

```
void USB_WaitForEndOfTransfer(U8 EPIndex);
```

| Parameter               | Description                                  |
|-------------------------|----------------------------------------------|
| <a href="#">EPIndex</a> | Endpoint handle to wait for end of transfer. |

**Table 4.12: USB\_WaitForEndOfTransfer() parameter list**

## 4.2.4 USB IAD functions

### 4.2.4.1 USB\_EnableIAD()

#### Description

Enables combination of multi-interface device classes with single-interface classes or other multi-interface classes.

#### Prototype

```
void USB_EnableIAD(void);
```

#### Additional information

Simple device classes such as HID and MSD or BULK use only one interface descriptor to describe the class. The interface descriptor also contains the device class code. The CDC device class uses more than one interface descriptor to describe the class. The device class code will then be written into the device descriptor. It may be possible to add an interface which does not belong to the CDC class, but it may not be correctly recognized by the host, this is not standardized and depends on the host.

In order to allow this, a new descriptor type was introduced:

IAD (Interface Association Descriptor), this descriptor will encapsulate the multi-interface class into this IA descriptor, so that it will be seen as one single interface and will then allow to add other device classes.

If you intend to use the CDC component with any other component, please call `USB_EnableIAD()` before adding the CDC component through `USB_CDC_Add()`.

## 4.2.5 USB Remote wakeup functions

Remote wakeup is a feature that allows a device to wake a host system from a USB suspend state.


In order to do this a special resume signal is sent over the USB data lines.

Additionally the USB host controller and operating system has to be able to handle this signaling.

### Windows OS:

Currently Windows OS only supports the wakeup feature on devices based on HID mouse/keyboard, CDC Modem and RNDIS Ethernet class. Remote wakeup for MSD, generic bulk and CDC serial is not supported by Windows. So therefore a HID mouse class even as dummy interface within your USB configuration is currently mandatory. A sample is provided for adding such a dummy class.

Windows must also be told that the device shall wake the PC from the suspend state. This is done by setting the option "Allow this device to bring the computer out of standby".



### Mac OS X

Mac OS X supports remote wakeup for all device classes.

### 4.2.5.1 USB\_SetAllowRemoteWakeUp()

#### Description

Allows the device to publish that remote wake is available.

#### Prototype

```
void USB_SetAllowRemoteWakeUp(U8 AllowRemoteWakeup);
```

| Parameter                         | Description                                                                                                   |
|-----------------------------------|---------------------------------------------------------------------------------------------------------------|
| <a href="#">AllowRemoteWakeup</a> | 1 - Allows and publishes that remote wakeup is available.<br>0 - Publish that remote wakeup is not available. |

**Table 4.13: USB\_SetAllowRemoteWakeUp() parameter list**

#### Additional information

This function must be called before the function USB\_Start() is called. This ensures that the Host is informed that USB remote wake up is available.



### 4.2.5.2 USB\_DoRemoteWakeup()

#### Description

Performs a remote wakeup in order to wake up the host from the standby/suspend state.

#### Prototype

```
void USB_DoRemoteWakeUp(void);
```

#### Additional information

This function cannot be called from an ISR context



# Chapter 5

## Bulk communication

---

This chapter describes how to get emUSB-Bulk up and running.



## 5.1 Generic bulk stack

The generic bulk stack is located in the directory `USB`. All C files in the directory should be included in the project (compiled and linked as part of your project). The files in this directory are maintained by SEGGER and should not require any modification. All files requiring modifications have been placed in other directories.

## 5.2 The Kernel mode driver (PC)

In order to communicate with a target (client) running emUSB, an emUSB bulk kernel mode driver must be installed on Windows PC's. Typically, this is done as soon as emUSB runs on target hardware.

Installation of the driver and how to recompile it is explained in this chapter.

### 5.2.1 Why is a driver necessary?

In Microsoft's Windows operating systems, all communication with real hardware is implemented with *kernel-mode* drivers. Normal applications run in *user-mode*. In user mode, hardware access is not permitted. All access to hardware is done through the operating system and the operating system uses a kernel mode driver to access the actual hardware. In other words: every piece of hardware requires one or more kernel mode drivers to function. Windows supplies drivers for most common types of hardware, but it does not come with a generic bulk communication driver. It comes with drivers for certain classes of devices, such as keyboard, mouse and mass storage (for example, a USB stick). This makes it possible to connect a USB mouse without having to install a driver for it: Windows already has a driver for it.

Unfortunately, there is no generic kernel mode driver which allows communication to any type of device in bulk mode. This is why a kernel mode driver needs to be supplied in order to work with emUSB-Bulk.

### 5.2.2 Supported platforms

The kernel mode driver works on all NT-type platforms. This includes Windows 2000 and Windows XP (home and professional), Windows 2003 Server and Windows Vista. Windows NT itself does not support USB; Win98 is not supported by the driver.

## 5.3 Installing the driver


When the target device is plugged into the computer's USB port, or when the computer is first powered up after connecting the emUSB device, Windows will detect the new hardware.



The wizard will complete the installation for the detected device. First select the **Search for a suitable driver for my device** option and click on the **Next** button.



In the next step, select the **Specify a location** option and click the **Next** button.



The wizard needs the path to the correct driver files for the new device.




Use the directory navigator to select the `USBulk.inf` file and click the **Open** button.



The wizard confirms the choice and starts to copy, after clicking the **Next** button.



At this point, the installation is complete. Click the **Finish** button to dismiss the wizard.




### 5.3.1 Recompiling the driver

To recompile the driver, the Device Developer Kit (NTDDK), as well as an installation of Microsoft Visual C++ 6.0 or Visual Studio .net is needed.

The workspace is placed in the subdirectory `Driver`. In order to open it, double click the workspace file `USBDriver.dsw`.

A workspace similar to the screenshot below is opened.



Choose **Build | Build USBBulk.sys** (Shortcut: F7) to compile and link the driver.

## 5.3.2 The .inf file

The .inf file is required for installation of the kernel mode driver.

The shipped file is as follows:

```
;
;
;      USB BULK Device driver inf
;
;
[Version]
Signature="$CHICAGO$"
Class=USB
ClassGUID={36FC9E60-C465-11CF-8056-444553540000}
provider=%MfgName%
DriverVer=08/07/2003

[SourceDisksNames]
1="USB BULK Installation Disk",,,

[SourceDisksFiles]
USBULK.sys = 1
USBULK.inf = 1

[Manufacturer]
%MfgName%=DeviceList

[DeviceList]
%USB\VID_8765&PID_1234.DeviceDesc%=USBULK.Dev, USB\VID_8765&PID_1234

;[PreCopySection]
;HKR,,NoSetupUI,,1

[DestinationDirs]
USBULK.Files.Ext = 10,System32\Drivers

[USBULK.Dev]
CopyFiles=USBULK.Files.Ext
AddReg=USBULK.AddReg

[USBULK.Dev.NT]
CopyFiles=USBULK.Files.Ext
AddReg=USBULK.AddReg

[USBULK.Dev.NT.Services]
Addservice = USBULK, 0x00000002, USBULK.AddService

[USBULK.AddService]
DisplayName      = %USBULK.SvcDesc%
ServiceType      = 1                ; SERVICE_KERNEL_DRIVER
StartType        = 3                ; SERVICE_DEMAND_START
ErrorControl      = 1                ; SERVICE_ERROR_NORMAL
ServiceBinary    = %10%\System32\Drivers\USBULK.sys
LoadOrderGroup   = Base

[USBULK.AddReg]
HKR,,DevLoader,,*ntkern
HKR,,NTMPDriver,,USBULK.sys

[USBULK.Files.Ext]
USBULK.sys

;-----;
```



```
[Strings]
MfgName="MyCompany"
USB\VID_8765&PID_1234.DeviceDesc="USB Bulk Device"
USB\BULK.SvcDesc="USB Bulk device driver"
```

**red** - required modifications

**green** - possible modifications

You must personalize the .inf file on the red marked positions. Changes on the green marked positions are optional and not necessary for correct operation of the device.

Replace the red marked positions with the personal Vendor ID (VID) and Product ID (PID). These changes must match the modifications in the configuration functions to work correctly.

The required modifications of the configuration functions are described in the section *Configuration* on page 41.


### 5.3.3 Configuration

To get emUSB up and running as well as doing an initial test, the configuration as it is delivered should not be modified. The configuration section can later on be modified to match your real application. The configuration must only be modified if emUSB should be used in a final product. Refer to section *Configuration* on page 41 for detailed information about the functions which must be adapted.

## 5.4 Example application

Example applications for both the target (client) and the PC (host) are supplied. These can be used for testing the correct installation and proper function of the device running emUSB.

The application is a modified echo server (`BULK_Echo1.c`); the application receives data byte by byte, increments every single byte and sends it back to the host.



To use this application, make sure to use the corresponding example files both on the host-side as on the target side. The example applications on the PC host are named in the same way, just without the prefix `BULK_`, for example, if the host runs `Echo1.exe`, `BULK_Echo1.c` has to be included into your project, compiled and downloaded into your target. There are additional examples that can be used for testing emUSB.

The following start application files are provided:

| File                         | Description                                                                                                        |
|------------------------------|--------------------------------------------------------------------------------------------------------------------|
| <code>BULK_Echo1.c</code>    | This application was described in the upper text.                                                                  |
| <code>BULK_EchoFast.c</code> | This is the faster version of <code>Bulk_Echo1.c</code>                                                            |
| <code>BULK_Test.c</code>     | This application can be used to test emUSB-Bulk with different packet sizes received from and sent to the PC host. |

**Table 5.1: Supplied sample applications**

The example applications for the target-side are supplied in source code in the `Application` directory.

Depending on which application is running on the emUSB device, use one of the following example applications:

| File         | Description                                                                                                                             |
|--------------|-----------------------------------------------------------------------------------------------------------------------------------------|
| Echo1.exe    | If the <code>BULK_Echo1.c</code> sample application is running on the emUSB-Bulk device, use this application.                          |
| EchoFast.exe | If the <code>BULK_EchoFast.c</code> sample application is running on the emUSB-Bulk device, use this <code>EchoFast</code> application. |
| Test.exe     | If the <code>BULK_Test.c</code> application is running on the emUSB-Bulk device, use this application to test the emUSB-Bulk stack.     |

**Table 5.2: Supplied host applications**


To use these examples, the application on the PC host should use the same example file to work correctly. The example applications on the PC host are named in the same way. The example applications for the host-side are supplied in both source code and executable form in the `Bulk\SampleApp` directory. For information how to compile the host examples refer to *Compiling the PC example application* on page 85.

The start application will of course later on be replaced by the real application program. For the purpose of getting emUSB up and running as well as doing an initial test, the start application should not be modified.

### 5.4.1 Running the example applications


To test the emUSB-Bulk component, build and download the application of choice for the target-side. If you connect your target to the host via USB while the example application is running, Windows will detect the new hardware.

To run one of the example applications, simply start the executable, for example by double clicking it. If the USB-Bulk device is not connected to the PC or the driver is not installed, the following message box should pop up.




If a connection can be established, it exchanges data with the target, testing the USB connection.

Example output of `Echo1.exe`:



Example output of `EchoFast.exe`:



```

C:\work\USBBulkStack\Ship\Segger\SampleApp\USBBULK_EchoFast.exe
USB BULK driver version: 2.42a, compiled: Nov 30 2005 14:50:50
Starting Echo...
Enter the packet size in bytes <default: 500>: _
  
```

Example output of `Test.exe`:



```

C:\work\USBBulkStack\Ship\Segger\SampleApp\USBBULK_Test.exe
USB BULK driver version: 2.42a, compiled: Nov 30 2005 14:50:50
Writing one byte
Reading one byte
_
  
```


If the host example application can communicate with the emUSB device, the example application will be in interactive mode for the `Echo1` and the `EchoFast` application. In case of an error, a message box is displayed.

| Error Messages                        | Description                                                            |
|---------------------------------------|------------------------------------------------------------------------|
| Unable to connect to USB BULK device  | The USB device is not connected to the PC or the connection is faulty. |
| Could not write to device             | The PC sample application was not able to write.                       |
| Could not read from device (time-out) | The PC sample application was not able to read.                        |
| Wrong data read                       | The result of the target sample application is not correct.            |

**Table 5.3: List of error messages**

## 5.4.2 Compiling the PC example application

For compiling the example application you need a Microsoft compiler. The compiler is part of Microsoft Visual C++ 6.0 or Microsoft Visual Studio .Net.



The source code of the sample application is located in the subfolder `Bulk\SAMPLEAPP`. Open the file `USBBULK_Start.dsw` and compile the source choose **Build | Build SampleApp.exe** (Shortcut: F7). To run the executable choose **Build | Execute SampleApp.exe** (Shortcut: CTRL-F5).

## 5.5 Target API

This chapter describes the functions that can be used with the target system.

### General information

To communicate with the host, the sample application project includes USB-specific header and source files (USB.h, USB\_Main.c, USB\_Setup.c, USB\_Bulk.c, USB\_Private.h). These files contain API functions to communicate with the USB host through the emUSB driver.

### Purpose of the USB Device API functions

To have an easy start up when writing an application on the device side, these API functions have a simple interface and handle all operations that need to be done to communicate with the host emUSB kernel mode driver.

Therefore, all operations that need to write to or read from the emUSB are handled internally by the provided API functions.

## 5.5.1 Target interface function list

| Routine                                      | Explanation                                                                                          |
|----------------------------------------------|------------------------------------------------------------------------------------------------------|
| USB-Bulk functions                           |                                                                                                      |
| <code>USB_BULK_Add()</code>                  | Adds an USB-Bulk interface to emUSB.                                                                 |
| <code>USB_BULK_CancelRead()</code>           | Cancels a non-blocking read operation that is pending.                                               |
| <code>USB_BULK_CancelWrite()</code>          | Cancels a non-blocking write operation that is pending.                                              |
| <code>USB_BULK_GetNumBytesInBuffer()</code>  | Returns the number of byte in BULK-OUT buffer.                                                       |
| <code>USB_BULK_GetNumBytesRemToRead()</code> | Returns the number of bytes which have to be read.                                                   |
| <code>USB_BULK_GetNumBytesToWrite()</code>   | Returns the number of bytes which have to be written.                                                |
| <code>USB_BULK_Read()</code>                 | USB-Bulk read.                                                                                       |
| <code>USB_BULK_ReadOverlapped()</code>       | Non-blocking version of <code>USB_BULK_Read()</code> .                                               |
| <code>USB_BULK_ReadTimed()</code>            | Starts a read operation that shall be done within a given timeout.                                   |
| <code>USB_BULK_Receive()</code>              | Read data from host and return immediately as soon as data has been received.                        |
| <code>USB_BULK_SetOnRXHook()</code>          | Installs a hook that shall be called when an USB packet is received.                                 |
| <code>USB_BULK_TxIsPending()</code>          | Checks whether the IN endpoint is currently pending.                                                 |
| <code>USB_BULK_WaitForTX()</code>            | Waits for a non-blocking write operation that is pending.                                            |
| <code>USB_BULK_WaitForRX()</code>            | Waits for a non-blocking write operation that is pending.                                            |
| <code>USB_BULK_Write()</code>                | Starts a blocking write operation.                                                                   |
| <code>USB_BULK_WriteEx()</code>              | Starts a blocking write operation that allows to specify whether a NULL packet shall be sent or not. |
| <code>USB_BULK_WriteExTimed()</code>         | Starts an USB-Bulk WriteEx operation that shall be done within a given timeout.                      |
| <code>USB_BULK_WriteOverlapped()</code>      | Non-blocking version of <code>USB_Bulk_Write()</code> .                                              |
| <code>USB_BULK_WriteOverlappedEx()</code>    | Non-blocking version of <code>USB_Bulk_WriteEx()</code> .                                            |
| <code>USB_BULK_WriteNULLPacket()</code>      | Sends a NULL (zero-length) packet to host.                                                           |
| <code>USB_BULK_WriteTimed()</code>           | Starts an USB-Bulk Write operation that shall be done within a given timeout.                        |
| Data structures                              |                                                                                                      |
| <code>USB_BULK_INIT_DATA</code>              | Initialization structure which is required when adding a bulk interface.                             |
| <code>USB_ON_RX_FUNC</code>                  | Function called when data is received.                                                               |

**Table 5.4: Target interface function list**

## 5.5.2 USB-Bulk functions

### 5.5.2.1 USB\_BULK\_Add()

#### Description

Adds interface for USB-Bulk communication to emUSB.

#### Prototype

```
void USB_BULK_Add( const USB_BULK_INIT_DATA * pInitData );
```

| Parameter              | Description                              |
|------------------------|------------------------------------------|
| <code>pInitData</code> | Pointer to USB_BULK_INIT_DATA structure. |

**Table 5.5: USB\_BULK\_Add() parameter list**

#### Additional information

USB\_BULK\_INIT\_DATA is defined as follows:

```
typedef struct {  
    U8 EPIn;    // Endpoint for sending data to the host  
    U8 EPOut;   // Endpoint for receiving data from the host  
};
```



### 5.5.2.2 USB\_BULK\_CancelRead()

#### Description

Cancels any non-blocking/blocking read operation that is pending.

#### Prototype

```
void USB_BULK_CancelRead(void);
```

#### Additional information

This function shall be called when a pending asynchronous read operation should be canceled. The function can be called from any task. In case of canceling a blocking operation, this function must be called from another task.

### 5.5.2.3 USB\_BULK\_CancelWrite()

#### Description

Cancels a non-blocking/blocking read operation that is pending.

#### Prototype

```
void USB_BULK_CancelWrite(void);
```

#### Additional information

This function shall be called when a pending asynchronous write operation should be canceled. It can be called from any task. In case of canceling a blocking operation, this function must be called from another task.

#### 5.5.2.4 USB\_BULK\_GetNumBytesInBuffer()

##### Description

Returns the number of bytes that are available in the internal BULK-OUT endpoint buffer.

##### Prototype

```
unsigned USB_BULK_GetNumBytesInBuffer(void);
```

##### Additional information

If the host is sending more data than your target application has requested, the remaining data will be stored in an internal buffer.

This function shows how many bytes are available in this buffer.

Example:

Your host application sends 50 bytes.

Your target application only requests to receive 1 byte.

In this case the target application will get 1 byte and the remaining 49 bytes are stored in an internal buffer.

When your target application now calls USB\_BULK\_GetNumBytesInBuffer() it will return the number of bytes that are available in the internal buffer (49).

### 5.5.2.5 USB\_BULK\_GetNumBytesRemToRead()

#### Description

This function is to be used in combination with `USB_BULK_ReadOverlapped()`. After starting the read operation this function can be used to periodically check how many bytes still have to be read.

#### Prototype

```
unsigned USB_BULK_GetNumBytesRemToRead(void);
```

#### Return value

$\geq 0$ : Number of bytes which have not yet been read.

#### Additional information

Alternatively the blocking function `USB_BULK_WaitForRX()` can be used.

### 5.5.2.6 USB\_BULK\_GetNumBytesToWrite()

#### Description

This function is to be used in combination with [USB\\_BULK\\_WriteOverlapped\(\)](#)/[USB\\_BULK\\_WriteOverlappedEx\(\)](#).

After starting the write operation this function can be used to periodically check how many bytes still have to be written.

#### Prototype

```
unsigned USB_BULK_GetNumBytesToWrite(void);
```

#### Return value

$\geq 0$ : Number of bytes which have not yet been written.

#### Additional information

Alternatively the blocking function [USB\\_BULK\\_WaitForTX\(\)](#) can be used.

### 5.5.2.7 USB\_BULK\_Read()

#### Description

Reads data from the host. This function blocks until `NumBytes` has been received or until the device is disconnected.

#### Prototype

```
int USB_BULK_Read(void* pData, unsigned NumBytes);
```

| Parameter             | Description                                                 |
|-----------------------|-------------------------------------------------------------|
| <code>pData</code>    | Pointer to a buffer where the received data will be stored. |
| <code>NumBytes</code> | Number of bytes to read.                                    |

**Table 5.6: USB\_BULK\_Read() parameter list**

#### Return value

`== NumBytes`: Successful read.  
`== -1`: Error.

### 5.5.2.8 USB\_BULK\_ReadOverlapped()

#### Description

Reads data from the host asynchronously.

#### Prototype

```
int USB_BULK_ReadOverlapped(void* pData, unsigned NumBytes);
```

| Parameter                | Description                                                 |
|--------------------------|-------------------------------------------------------------|
| <a href="#">pData</a>    | Pointer to a buffer where the received data will be stored. |
| <a href="#">NumBytes</a> | Number of bytes to read.                                    |

**Table 5.7: USB\_BULK\_ReadOverlapped() parameter list**

#### Return value

Number of bytes that have already been received or have been copied from internal buffer. The value can be less or equal to [NumBytes](#).

#### Additional information

This function will not block the calling task. The read transfer will be initiated and the function returns immediately. In order to synchronize, [USB\\_BULK\\_WaitForRX\(\)](#) needs to be called. Alternatively the function [USB\\_BULK\\_GetNumBytesRemToRead\(\)](#) can be called periodically to check whether all bytes have been written or not.

### 5.5.2.9 USB\_BULK\_ReadTimed()

#### Description

Reads data from the host with a given timeout.

#### Prototype

```
int USB_BULK_ReadOverlapped(void* pData, unsigned NumBytes, unsigned ms);
```

| Parameter             | Description                                                 |
|-----------------------|-------------------------------------------------------------|
| <code>pData</code>    | Pointer to a buffer where the received data will be stored. |
| <code>NumBytes</code> | Number of bytes to read.                                    |
| <code>ms</code>       | Timeout in milliseconds.                                    |

**Table 5.8: USB\_BULK\_ReadTimed() parameter list**

#### Return value

Number of bytes that have been read within the given timeout.

#### Additional information

This function blocks a task until all data have been read or a timeout expires. This function also returns when the device is disconnected from host or when a USB reset occurs.



### 5.5.2.10 USB\_BULK\_SetOnRXHook()

#### Description

Sets a callback that is executed on reception of a data packet from the host.

#### Prototype

```
void USB_BULK_SetOnRXHook(USB_ON_RX_EP * pfOnRx);
```

| Parameter              | Description                       |
|------------------------|-----------------------------------|
| <a href="#">pfOnRx</a> | Pointer to the callback function. |

**Table 5.9: USB\_BULK\_SetOnRXHook() parameter list**

#### Additional information

Setting up a callback function may be necessary to allow a monitoring task to suspend and to wake up when data have been received.

The callback function will be called within a interrupt service routine, so we advice that you ensure the callback completes quickly.

### 5.5.2.11 USB\_BULK\_TxIsPending()

#### Description

Checks whether the TX (IN endpoint) is currently pending. Can be called in any context.

#### Prototype

```
int USB_BULK_TxIsPending(void);
```

#### Return value

- 1: We have queued a package to be sent.
- 0: Queue is empty.

### 5.5.2.12 USB\_BULK\_Receive()

#### Description

Reads data from host and returns as soon as data has been received.

#### Prototype

```
int USB_BULK_Receive(void * pData, unsigned NumBytes);
```

| Parameter                | Description                                                 |
|--------------------------|-------------------------------------------------------------|
| <a href="#">pData</a>    | Pointer to a buffer where the received data will be stored. |
| <a href="#">NumBytes</a> | Maximum number of bytes to read.                            |

**Table 5.10: USB\_BULK\_Receive() parameter list**

#### Return value

>= 0: Number of bytes that have been read.  
 -1: Error.

#### Additional information

If no error occurs, this function returns the number of bytes received.

Calling `USB_BULK_Receive()` will return as much data as is currently available—up to the size of the buffer specified.

### 5.5.2.13 USB\_BULK\_WaitForRX()

#### Description

This function is used in combination with `USB_BULK_ReadOverlapped()`, it waits for the read data transfer from the host to complete.

#### Prototype

```
void USB_BULK_WaitForRX(void);
```

#### Additional information

After starting the read operation via `USB_BULK_ReadOverlapped()` this function can be used to wait until the transfer is complete.

### 5.5.2.14 USB\_BULK\_WaitForTX()

#### Description

This function is used in combination with [USB\\_BULK\\_WriteOverlapped\(\)](#), it waits for the write data transfer from the host to complete.

#### Prototype

```
void USB_BULK_WaitForTX(void);
```

#### Additional information

After starting the write operation via [USB\\_BULK\\_WriteOverlapped\(\)](#) this function can be used to wait until the transfer is complete.

### 5.5.2.15 USB\_BULK\_Write()

#### Description

Sends data to the USB host. This function blocks until `NumBytes` has been received or until the device is disconnected.

#### Prototype

```
int USB_BULK_Write(const void * pData, unsigned NumBytes);
```

| Parameter             | Description                  |
|-----------------------|------------------------------|
| <code>pData</code>    | Data that should be written. |
| <code>NumBytes</code> | Number of bytes to write.    |

**Table 5.11: USB\_BULK\_Write() parameter list**

#### Return value

> 0: Number of bytes that have been written.  
0: Error.

### 5.5.2.16 USB\_BULK\_WriteEx()

#### Description

Sends data to the host with the option to send a zero-length packet at the end of the data transfer.

#### Prototype

```
int USB_BULK_WriteEx(const void* pData,
                    unsigned    NumBytes,
                    char        Send0PacketIfRequired);
```

| Parameter                          | Description                                                                                                                                                                                                                                                                  |
|------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>pData</code>                 | Pointer to a buffer that contains the written data.                                                                                                                                                                                                                          |
| <code>NumBytes</code>              | Number of bytes to write.                                                                                                                                                                                                                                                    |
| <code>Send0PacketIfRequired</code> | Specifies that a zero-length packet shall be sent when the last data packet is a multiple of <code>MaxPacketSize</code> . Normally <code>MaxPacketSize</code> for full-speed devices is 64 bytes. For high-speed devices the normal packet size is between 64 and 512 bytes. |

**Table 5.12: USB\_BULK\_WriteEx() parameter list**

#### Additional information

Normally `USB_BULK_Write()` is called to let the stack send that whole packet to the host and send an optional zero-length packet to tell the host that this was the last packet. This is the case when the last packet that shall be sent is `MaxPacketSize` bytes in size.

When using this function, the zero-length packet handling can be controlled. This means the function can be called when sending data in multiple steps. Please make sure that `NumBytes` is always a multiple of `MaxPacketSize`, except for the last transmission.

#### Example

```
static U8 _aDataBuffer[512];

static void _Send(void) {
    unsigned NumBytes2Send;
    unsigned NumBytesRead;

    NumBytes2Send = _GetNumBytes2Send();
    while (NumBytes2Send >= sizeof(_aDataBuffer)) {
        NumBytesRead = _GetData(&_aDataBuffer[0], sizeof(_aDataBuffer));
        USB_BULK_WriteEx(&_aDataBuffer[0], NumBytesRead, 0);
        NumBytes2Send -= NumBytesRead;
    }
    USB_BULK_WriteEx(&_aDataBuffer[0], NumBytes2Send, 1);
}
```

### 5.5.2.17 USB\_BULK\_WriteExTimed()

#### Description

Sends data to the host with the option to send a zero-length packet at the end of the data transfer and a timeout option.

#### Prototype

```
int USB_BULK_WriteEx(const void* pData,
                    unsigned    NumBytes,
                    char        Send0PacketIfRequired
                    unsigned    ms);
```

| Parameter                          | Description                                                                                                                                                                                                                                                                            |
|------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>pData</code>                 | Pointer to a buffer that contains the written data.                                                                                                                                                                                                                                    |
| <code>NumBytes</code>              | Number of bytes to write.                                                                                                                                                                                                                                                              |
| <code>Send0PacketIfRequired</code> | Specifies that a zero-length packet shall be sent when the last data packet to the host is a multiple of <code>MaxPacketSize</code> .<br>Normally <code>MaxPacketSize</code> for full-speed devices is 64 byte. For high-speed devices the normal packet size is between 64-512 bytes. |
| <code>ms</code>                    | Timeout in milliseconds.                                                                                                                                                                                                                                                               |

**Table 5.13: USB\_BULK\_WriteExTimed() parameter list**

#### Return value

Number of bytes that have been written within the given timeout.

#### Additional information

This function blocks a task until all data have been written or a timeout occurs. This function also returns when target is disconnected from host or when a USB reset occurred.



### 5.5.2.18 USB\_BULK\_WriteOverlapped()

#### Description

Writes data to the host asynchronously.

#### Prototype

```
int USB_BULK_WriteOverlapped(const void* pData, unsigned NumBytes);
```

| Parameter                | Description                                      |
|--------------------------|--------------------------------------------------|
| <a href="#">pData</a>    | Pointer to data that should be sent to the host. |
| <a href="#">NumBytes</a> | Number of bytes to write.                        |

**Table 5.14: USB\_BULK\_WriteOverlapped() parameter list**

#### Return value

Number of bytes that were accepted and sent to the host. The value can be less or equal to [NumBytes](#).

#### Additional information

This function will not block the calling task. The write transfer will be initiated and the function returns immediately. In order to synchronize, [USB\\_BULK\\_WaitForTX\(\)](#) needs to be called.

### 5.5.2.19 USB\_BULK\_WriteOverlappedEx()

#### Description

Writes data to the host asynchronously.

#### Prototype

```
int USB_BULK_WriteOverlappedEx(const void* pData,
                               unsigned    NumBytes,
                               char        Send0PacketIfRequired);
```

| Parameter                          | Description                                                                                                                                                                                                                                                                            |
|------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>pData</code>                 | Pointer to data that should be sent to the host.                                                                                                                                                                                                                                       |
| <code>NumBytes</code>              | Number of bytes to write.                                                                                                                                                                                                                                                              |
| <code>Send0PacketIfRequired</code> | Specifies that a zero-length packet shall be sent when the last data packet to the host is a multiple of <code>MaxPacketSize</code> .<br>Normally <code>MaxPacketSize</code> for full-speed devices is 64 byte. For high-speed devices the normal packet size is between 64-512 bytes. |

**Table 5.15: USB\_BULK\_WriteOverlappedEx() parameter list**

#### Return value

Number of bytes that have already been sent to the host. The value can be less or equal to `NumBytes`.

#### Additional information

This function will not block the calling task. The write transfer will be initiated and the function returns immediately. In order to synchronize, `USB_BULK_WaitForTX()` needs to be called.

### 5.5.2.20 USB\_BULK\_WriteTimed()

#### Description

Writes data from the host with a given timeout.

#### Prototype

```
int  USB_BULK_WriteOverlapped(const void* pData,
                              unsigned    NumBytes,
                              unsigned    ms);
```

| Parameter                | Description                                         |
|--------------------------|-----------------------------------------------------|
| <a href="#">pData</a>    | Pointer to a buffer that contains the written data. |
| <a href="#">NumBytes</a> | Number of bytes to write.                           |
| <a href="#">ms</a>       | Timeout in milliseconds.                            |

**Table 5.16: USB\_BULK\_ReadOverlapped() parameter list**

#### Return value

Number of bytes that have been written within the given timeout.

#### Additional information

This function blocks a task until all data has been written or a timeout occurs. This function also returns when target is disconnected from host or when a USB reset occurred.

### 5.5.2.21 USB\_BULK\_WriteNULLPacket()

#### Description

Sends a zero-length packet to the host.

#### Prototype

```
void USB_BULK_WriteNULLPacket(void);
```

#### Additional information

This function is useful to indicate that either no data is available or to indicate that this is the last packet of the data stream.

In normal cases sending a zero-length packet as a termination packet is not necessary since the stack handles this automatically when calling any USB\_BULK write function (except for USB\_BULK\_WriteEx routines).

## 5.5.3 Data structures

### 5.5.3.1 USB\_BULK\_INIT\_DATA

#### Description

Initialization structure which is required when adding a bulk interface to emUSB-Bulk.

#### Prototype

```
typedef struct {
    U8 EPIn;
    U8 EPOut;
} USB_BULK_INIT_DATA;
```

| Member                | Description                               |
|-----------------------|-------------------------------------------|
| <a href="#">EPIn</a>  | Endpoint for sending data to the host.    |
| <a href="#">EPOut</a> | Endpoint for receiving data from the host |

**Table 5.17: USB\_BULK\_INIT\_DATA elements**

#### Example

Example excerpt from BULK\_Echo1.c:

```
static void _AddBULK(void) {
    static U8 _abOutBuffer[USB_MAX_PACKET_SIZE];
    USB_BULK_INIT_DATA Init;

    Init.EPIn = USB_AddEP(1, USB_TRANSFER_TYPE_BULK, USB_MAX_PACKET_SIZE, NULL, 0);
    Init.EPOut = USB_AddEP(0, USB_TRANSFER_TYPE_BULK, USB_MAX_PACKET_SIZE,
        _abOutBuffer, USB_MAX_PACKET_SIZE);
    USB_BULK_Add(&Init);
}
```

### 5.5.3.2 USB\_ON\_RX\_FUNC

#### Description

Callback function prototype that is used when calling the `USB_BULK_SetOnRXHook()` function.

#### Prototype

```
typedef void USB_ON_RX_FUNC(const U8 * pData, unsigned NumBytes);
```

| Member                | Description                                  |
|-----------------------|----------------------------------------------|
| <code>pData</code>    | Pointer to the data that have been received. |
| <code>NumBytes</code> | Number of bytes that have been received.     |

**Table 5.18: USB\_ON\_RX\_FUNC elements**

## 5.6 Host API

This chapter describes the functions that can be used with the Windows host system.

### General information

To communicate with the target USB-Bulk stack, the sample application project includes USB-Bulk specific source and header files (`USBBulk.c`, `USBBULK.h`). These files contain API functions to communicate with the USB-Bulk target through the USB-Bulk driver.

### Purpose of the USB Host API functions

To have an easy start-up when writing an application on the host side, these API functions have a simple interface and handle all required operations to communicate with the target USB-Bulk stack.

Therefore, all operations that need to open a channel, writing to or reading from the USB-Bulk stack, are handled internally by the provided API functions.

Additional information can also be retrieved from the USB driver.

## 5.6.1 Host API list

The functions below are available on the host (Windows PC) side.

| Function                                        | Description                                                                                           |
|-------------------------------------------------|-------------------------------------------------------------------------------------------------------|
| USB-Bulk basic functions                        |                                                                                                       |
| <code>USBBULK_Open()</code>                     | Opens pipes to communicate with the first USB-Bulk device.                                            |
| <code>USBBULK_OpenEx()</code>                   | Opens pipes to communicate with a specified USB-Bulk device.                                          |
| <code>USBBULK_Close()</code>                    | Closes the pipes which are used for the communication with the first USB-Bulk device.                 |
| <code>USBBULK_CloseEx()</code>                  | Closes the pipes which are used for the communication to a specified USB-Bulk device.                 |
| USB-Bulk direct input/output functions          |                                                                                                       |
| <code>USBBULK_Read()</code>                     | Reads data from the first USB-Bulk device.                                                            |
| <code>USBBULK_ReadEx()</code>                   | Reads data from a specified USB-Bulk device.                                                          |
| <code>USBBULK_Write()</code>                    | Writes data to the first USB-Bulk device.                                                             |
| <code>USBBULK_WriteEx()</code>                  | Writes data to a specified USB-Bulk device.                                                           |
| <code>USBBULK_WriteRead()</code>                | Reads and writes data from/to the first USB-Bulk device.                                              |
| <code>USBBULK_WriteReadEx()</code>              | Reads and writes data from/to a specified USB-Bulk device.                                            |
| USB-Bulk control functions                      |                                                                                                       |
| <code>USBBULK_GetDriverCompileDate()</code>     | Gets the compile date and time of the USB-Bulk driver.                                                |
| <code>USBBULK_GetDriverVersion()</code>         | Retrieves the version of the USB-Bulk driver.                                                         |
| <code>USBBULK_GetConfigDescriptor()</code>      | Gets the received target USB configuration descriptor of the first USB-Bulk device.                   |
| <code>USBBULK_GetConfigDescriptorEx()</code>    | Gets the received target USB configuration descriptor of a specified USB-Bulk device.                 |
| <code>USBBULK_GetMode()</code>                  | Returns the read operation mode of the USB-Bulk device.                                               |
| <code>USBBULK_GetModeEx()</code>                | Returns the read operation mode of the USB-Bulk driver.                                               |
| <code>USBBULK_GetNumAvailableDevices()</code>   | Returns the number of connected USB-Bulk devices.                                                     |
| <code>USBBULK_GetReadMaxTransferSize()</code>   | Retrieves the maximum transfer size of a read transaction the driver can receive from an application. |
| <code>USBBULK_GetReadMaxTransferSizeEx()</code> | Retrieves the maximum transfer size of a read transaction the driver can receive from an application. |
| <code>USBBULK_GetSN()</code>                    | Returns the serial number of the USB target device.                                                   |
| <code>USBBULK_GetWriteMaxTransferSize()</code>  | Retrieves the maximum transfer size of a write transaction the driver can handle from an application. |

**Table 5.19: Host API function list**



| Function                                         | Description                                                                                           |
|--------------------------------------------------|-------------------------------------------------------------------------------------------------------|
| <code>USBBULK_GetWriteMaxTransferSizeEx()</code> | Retrieves the maximum transfer size of a write transaction the driver can handle from an application. |
| <code>USBBULK_SetMode()</code>                   | Sets the read operation mode of the USB-Bulk driver.                                                  |
| <code>USBBULK_SetModeEx()</code>                 | Sets the read operation mode of the USB-Bulk driver.                                                  |
| <code>USBBULK_SetTimeout()</code>                | Sets a read timeout for a read transaction.                                                           |
| <code>USBBULK_SetTimeoutEx()</code>              | Sets a read timeout for a read transaction.                                                           |
| <code>USBBULK_SetUSBId()</code>                  | Sets the Vendor ID and Product ID that are used for connecting to the device.                         |

**Table 5.19: Host API function list**

## 5.6.2 USB-Bulk Basic functions

### 5.6.2.1 USBBULK\_Open()

#### Description

Opens a read and write connection to the first connected target device using emUSB-Bulk.

#### Prototype

```
void * USBBULK_Open(void);
```

#### Return value

|                       |                                                                   |
|-----------------------|-------------------------------------------------------------------|
| <code>!= NULL:</code> | If a connection to the target running emUSB-Bulk was established. |
| <code>== NULL:</code> | If a connection could not be established.                         |

### 5.6.2.2 USBULK\_OpenEx()

#### Description

Opens a read and write connection to a specified device using the emUSB-Bulk kernel-mode driver.

#### Prototype

```
void * USBULK_OpenEx(unsigned Id);
```

| Parameter          | Description                      |
|--------------------|----------------------------------|
| <a href="#">Id</a> | Id number of the device [0..31]. |

**Table 5.20: USBULK\_OpenEx() parameter list**

#### Return value

!= NULL: If a connection to the target running emUSB-Bulk was established.  
 == NULL: If a connection could not be established.

### 5.6.2.3 USBBULK\_Close()

#### Description

Closes all connections to the first target device using emUSB-Bulk.

#### Prototype

```
void USBBULK_Close(void);
```

### 5.6.2.4 USBBULK\_CloseEx()

#### Description

Closes all connections to a specified device using emUSB-Bulk.

#### Prototype

```
void USBBULK_CloseEx(unsigned Id);
```

| Parameter          | Description                      |
|--------------------|----------------------------------|
| <a href="#">Id</a> | Id number of the device [0..31]. |

**Table 5.21: USBBULK\_CloseEx() parameter list**

## 5.6.3 USB-Bulk direct input/output functions

### 5.6.3.1 USBBULK\_Read()

#### Description

Reads data from the first target device running emUSB-Bulk.

#### Prototype

```
int USBBULK_Read(void * pBuffer, unsigned NumBytes);
```

| Parameter             | Description                                                 |
|-----------------------|-------------------------------------------------------------|
| <code>pBuffer</code>  | Pointer to a buffer where the received data will be stored. |
| <code>NumBytes</code> | Number of bytes to read.                                    |

**Table 5.22: USBBULK\_Read() parameter list**

#### Return value

`== NumBytes`: All bytes have been successfully read.  
`< NumBytes`: A timeout has occurred during read, when the emUSB driver is in normal mode, otherwise (short-read mode) the emUSB driver returns the number of bytes that have been read from the device before a timeout occurred (less than NumBytes).  
`== -1`: Cannot read from the device.

#### Additional information

`USBBULK_Read()` sends the read request to the USB-Bulk driver. Because the driver can only read a certain number of bytes from the device (the default value is 64 Kbytes) the driver will abort the transaction.

Therefore if `NumBytes` exceeds this limit, `USBBULK_Read()` will read the desired `NumBytes` in chunks of the maximum read size the driver can handle.

### 5.6.3.2 USBULK\_ReadEx()

#### Description

Reads data from a specified target device running emUSB-Bulk.

#### Prototype

```
int USBULK_ReadEx(unsigned Id, void * pBuffer, unsigned NumBytes);
```

| Parameter             | Description                                                 |
|-----------------------|-------------------------------------------------------------|
| <code>Id</code>       | Id number of the device [0..31].                            |
| <code>pBuffer</code>  | Pointer to a buffer where the received data will be stored. |
| <code>NumBytes</code> | Number of bytes to read.                                    |

**Table 5.23: USBULK\_ReadEx() parameter list**

#### Return value

== `NumBytes`: All bytes have been successfully read.  
 < `NumBytes`: A timeout has occurred during read, when the emUSB driver is in normal mode. Otherwise the emUSB driver returns the number of bytes that have been read from the device.  
 == -1: Cannot read from device.

#### Additional information

USBULK\_ReadEx() sends the read request to the emUSB driver. Because the driver can only read a certain amount of bytes from the device (the default value is 64 Kbytes) the driver will abort the transaction.

Therefore, if `NumBytes` exceeds this limit, USBULK\_Read() will read the desired `NumBytes` in chunks of the maximum read size the driver can handle.

### 5.6.3.3 USBULK\_Write()

#### Description

Writes data to the first target device running emUSB-Bulk.

#### Prototype

```
int USBULK_Write(const void * pBuffer, unsigned NumBytes);
```

| Parameter             | Description                      |
|-----------------------|----------------------------------|
| <code>pBuffer</code>  | Pointer to a buffer to transfer. |
| <code>NumBytes</code> | Number of bytes to write.        |

**Table 5.24: USBULK\_Write() parameter list**

#### Return value

`== NumBytes:` All bytes have been successfully written.  
`< NumBytes:` A write error has occurred.

#### Additional information

`USBULK_Write()` sends the write request to the emUSB driver. Because the driver can only write a certain amount of bytes to device (the default value is 64 Kbytes) the driver will abort the transaction.

Therefore if `NumBytes` exceeds this limit, `USBULK_Write()` will write the desired `Num-Bytes` in chunks of the maximum write size the driver can handle.



### 5.6.3.4 USBULK\_WriteEx()

#### Description

Writes data to a specified target device running emUSB-Bulk.

#### Prototype

```
int USBULK_WriteEx(unsigned Id, const void * pBuffer, unsigned NumBytes);
```

| Parameter             | Description                      |
|-----------------------|----------------------------------|
| <code>Id</code>       | Id number of device [0..31].     |
| <code>pBuffer</code>  | Pointer to a buffer to transfer. |
| <code>NumBytes</code> | Number of bytes to write.        |

**Table 5.25: USBULK\_WriteEx() parameter list**

#### Return value

== `NumBytes`: All bytes have been successfully written.  
 < `NumBytes`: A write error has occurred.

#### Additional information

USBULK\_WriteEx() sends the write request to the emUSB driver. Since the driver can only write a certain amount of bytes to the device (the default value is 64 Kbytes) the driver will abort the transaction.

Therefore if `NumBytes` exceeds this limit, USBULK\_Write() will write the desired `NumBytes` in chunks of the maximum write size the driver can handle.

### 5.6.3.5 USBBULK\_WriteRead()

#### Description

Writes and reads data to and from the first target device running emUSB-Bulk.

#### Prototype

```
int USBBULK_WriteRead(const void * pWrBuffer, unsigned WrNumBytes  
                      void * pRdBuffer, unsigned RdNumBytes);
```

| Parameter               | Description                                                 |
|-------------------------|-------------------------------------------------------------|
| <code>pWrBuffer</code>  | Pointer to a buffer to transfer.                            |
| <code>WrNumBytes</code> | Number of bytes to write.                                   |
| <code>pRdBuffer</code>  | Pointer to a buffer where the received data will be stored. |
| <code>RdNumBytes</code> | Number of bytes to read.                                    |

**Table 5.26: USBBULK\_WriteRead() parameter list**

#### Return value

`== NumBytes:` All bytes have been successfully read after writing the data.  
`< NumBytes:` A timeout has occurred during read, when the emUSB driver is in normal mode. Otherwise the emUSB driver returns the number of bytes that have been read from the device.  
`== -1:` Cannot read from the device after write.

#### Additional information

This function cannot be used in short mode enabled.

### 5.6.3.6 USBULK\_WriteReadEx()

#### Description

Writes and reads data to and from specified target device running emUSB-Bulk.

#### Prototype

```
int USBULK_WriteReadEx(unsigned    Id,
                        const void * pWrBuffer,
                        unsigned    WrNumBytes
                        void        * pRdBuffer,
                        unsigned    RdNumBytes);
```

| Parameter  | Description                                                 |
|------------|-------------------------------------------------------------|
| Id         | Id number of device [0..31].                                |
| pWrBuffer  | Pointer to a buffer to transfer.                            |
| WrNumBytes | Number of bytes to write.                                   |
| pRdBuffer  | Pointer to a buffer where the received data will be stored. |
| RdNumBytes | Number of bytes to read.                                    |

**Table 5.27: USBULK\_WriteReadEx() parameter list**

#### Return value

== NumBytes: All bytes have been successfully read after writing the data.  
 < NumBytes: A timeout has occurred during read, when the emUSB driver is in normal mode, otherwise the emUSB driver returns the number of bytes that have been read from device.  
 == -1: Cannot read from the device after write.

#### Additional information

This function cannot be used with short mode enabled.

## 5.6.4 USB-Bulk Control functions

### 5.6.4.1 USBBULK\_GetDriverCompileDate()

#### Description

Gets the compile date and time of the emUSB bulk communication driver.

#### Prototype

```
unsigned USBBULK_GetDriverCompileDate(char * s, unsigned Size);
```

| Parameter            | Description                                           |
|----------------------|-------------------------------------------------------|
| <a href="#">s</a>    | Pointer to a buffer to store the compile date string. |
| <a href="#">Size</a> | Size, in bytes, of the buffer pointed to by s.        |

**Table 5.28: USBBULK\_GetDriverCompileDate() parameter list**

#### Return value

If the function succeeds, the return value is nonzero and the buffer pointed to by [s](#) contains the compile date and time of the emUSB driver in the standard format:

mm dd yyyy hh:mm:ss

If the function fails, the return value is zero.

### 5.6.4.2 USBULK\_GetDriverVersion()

#### Description

Retrieves the version of the emUSB bulk communication driver.

#### Prototype

```
unsigned USBULK_GetDriverVersion(void);
```

#### Return value

If the function succeeds, the return value is the driver version of the driver as decimal value:

<Major Version><Minor Version><Subversion>. 24201 means 2.42a

If the function fails, the return value is zero; the version could not be retrieved.

### 5.6.4.3 USBULK\_GetConfigDescriptor()

#### Description

Gets the received target USB configuration descriptor of the first device running emUSB-Bulk.

#### Prototype

```
int USBULK_GetConfigDescriptor(void * pBuffer, int Size);
```

| Parameter            | Description                                         |
|----------------------|-----------------------------------------------------|
| <code>pBuffer</code> | Pointer to a buffer to store the config descriptor. |
| <code>Size</code>    | Number of bytes to read.                            |

**Table 5.29: USBULK\_GetConfigDescriptor() parameter list**

#### Return value

If the function succeeds, the return value is nonzero and the buffer pointed by `pBuffer` contains the USB target device configuration descriptor.

If the function fails, the return value is zero.

### 5.6.4.4 USBULK\_GetConfigDescriptorEx()

#### Description

Gets the received target USB configuration descriptor of a specified device running emUSB-Bulk.

#### Prototype

```
int USBULK_GetConfigDescriptor(unsigned Id, void * pBuffer, int Size);
```

| Parameter            | Description                                         |
|----------------------|-----------------------------------------------------|
| <code>Id</code>      | Id number of the device [0..31].                    |
| <code>pBuffer</code> | Pointer to a buffer to store the config descriptor. |
| <code>Size</code>    | Number of bytes to read.                            |

**Table 5.30: USBULK\_GetConfigDescriptorEx() parameter list**

#### Return value

If the function succeeds, the return value is nonzero and the buffer pointed by `pBuffer` contains the USB target device configuration descriptor.  
If the function fails, the return value is zero.

### 5.6.4.5 USBBULK\_GetMode()

#### Description

Returns the read operation mode of the driver for the first device running emUSB-Bulk.

#### Prototype

```
unsigned USBBULK_GetMode(void);
```

#### Return value

USBBULK\_MODE\_BIT\_ALLOW\_SHORT\_READ:  
Short read mode is enabled.

0: Short read mode is disabled.



### 5.6.4.6 USBULK\_GetModeEx()

#### Description

Returns the read operation mode of the driver for a specified device running emUSB-Bulk.

#### Prototype

```
unsigned USBULK_GetModeEx(unsigned Id);
```

| Parameter          | Description                  |
|--------------------|------------------------------|
| <a href="#">Id</a> | Id number of device [0..31]. |

**Table 5.31: USBULK\_GetModeEx() parameter list**

#### Return value

USBULK\_MODE\_BIT\_ALLOW\_SHORT\_READ:

Short read mode is enabled.

0: Short read mode is disabled.

### 5.6.4.7 USBULK\_GetNumAvailableDevices()

#### Description

Returns the number of connected USB-Bulk devices.

#### Prototype

```
unsigned USBULK_GetNumAvailableDevices(U32 * pMask);
```

| Parameter          | Description                                                                                               |
|--------------------|-----------------------------------------------------------------------------------------------------------|
| <code>pMask</code> | Pointer to a U32 variable to receive the connected device mask. This parameter can be <code>NULL</code> . |

**Table 5.32: USBULK\_GetNumAvailableDevices() parameter list**

#### Return value

If the function succeeds, the return value is the number of available devices running emUSB-Bulk. For each emUSB device that is connected, a bit in `pMask` is set.

For example if device 0 and device 2 are connected to the host, the value `pMask` points to will be 0x00000005.

If the function fails, the return value is zero.

#### 5.6.4.8 USBULK\_GetReadMaxTransferSize()

##### Description

Retrieves the maximum transfer size of a read transaction the driver can receive from an application for the first device running emUSB-Bulk.

##### Prototype

```
unsigned USBULK_GetReadMaxTransferSize(void);
```

##### Return value

If the function succeeds, the return value is the maximum transfer size in bytes the driver can accept from an application.

If the function fails, the return value is zero.

### 5.6.4.9 USBULK\_GetReadMaxTransferSizeEx()

#### Description

Retrieves the maximum transfer size of a read transaction the driver can receive from an application for a specified device running emUSB-Bulk.

#### Prototype

```
unsigned USBULK_GetReadMaxTransferSizeEx(unsigned Id);
```

| Parameter          | Description                  |
|--------------------|------------------------------|
| <a href="#">Id</a> | Id number of device [0..31]. |

**Table 5.33: USBULK\_GetReadMaxTransferSizeEx() parameter list**

#### Return value

If the function succeeds, the return value is the maximum transfer size in bytes the driver can accept from an application.

If the function fails, the return value is zero.

### 5.6.4.10 USBULK\_GetSN()

#### Description

Retrieves the USB serial number as a string that was returned by the device during enumeration.

#### Prototype

```
int USBULK_GetSN(unsigned Id, char * pBuffer, unsigned NumBytes);
```

| Parameter                | Description                                                   |
|--------------------------|---------------------------------------------------------------|
| <a href="#">Id</a>       | Id number of device [0..31].                                  |
| <a href="#">pBuffer</a>  | Pointer to a buffer to store the serial number of the device. |
| <a href="#">NumBytes</a> | Size of the buffer in bytes.                                  |

**Table 5.34: USBULK\_GetSN() parameter list**

#### Return value

If the function succeeds, the return value is nonzero and the buffer pointed by [pBuffer](#) contains the null-terminated serial number of the device running emUSB-Bulk.  
If the function fails, the return value is zero.

### 5.6.4.11 USBBULK\_GetWriteMaxTransferSize()

#### Description

Retrieves the maximum transfer size of a write transaction the driver can handle from an application (for the first device running emUSB-Bulk).

#### Prototype

```
unsigned USBBULK_GetWriteMaxTransferSize(void);
```

#### Return value

If the function succeeds, the return value is the maximum transfer size in bytes the driver can accept from an application to send data to the target device.

If the function fails, the return value is zero.

### 5.6.4.12 USBULK\_GetWriteMaxTransferSizeEx()

#### Description

Retrieves the maximum transfer size of a write transaction the driver can handle from an application for a specified device running emUSB-Bulk.

#### Prototype

```
unsigned USBULK_GetWriteMaxTransferSizeEx(unsigned Id);
```

| Parameter          | Description                  |
|--------------------|------------------------------|
| <a href="#">Id</a> | Id number of device [0..31]. |

**Table 5.35: USBULK\_GetWriteMaxtransferSizeEx() parameter list**

#### Return value

If the function succeeds, the return value is the maximum transfer size in bytes the driver can accept from an application to send data to the target device.

If the function fails, the return value is zero.

### 5.6.4.13 USBBULK\_SetMode()

#### Description

Sets the read operation mode of the driver for a device running emUSB-Bulk.

#### Prototype

```
unsigned USBBULK_SetMode(unsigned Mode);
```

| Parameter | Description                                                                                                                                               |
|-----------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|
| Mode      | Read and write mode for the USB-Bulk driver.<br>This is a combination of the following flags, combined by binary OR:<br>USBBULK_MODE_BIT_ALLOW_SHORT_READ |

**Table 5.36: USBBULK\_SetMode() parameter list**

#### Return value

If the function succeeds, the return value is nonzero. The read and write mode for the driver has been successfully set.

If the function fails, the return value is zero.

#### Additional information

USBBULK\_MODE\_BIT\_ALLOW\_SHORT\_READ allows short read transfers. Short transfers are transfers of less bytes than requested. If this bit is specified, the read function USBBULK\_Read() returns as soon as data is available, even if it is just a single byte.

#### Example

```
static void _TestMode(void) {
    unsigned Mode;
    char      * pText;

    Mode = USBBULK_GetMode();
    if (Mode & USBBULK_MODE_BIT_ALLOW_SHORT_READ) {
        pText = "USE_SHORT_MODE";
    } else {
        pText = "USE_NORMAL_MODE";
    }
    printf("USB-Bulk driver is in %s\n", pText);
    printf("Set mode to USBBULK_MODE_BIT_ALLOW_SHORT_READ\n");
    USBBULK_SetMode(USBBULK_MODE_BIT_ALLOW_SHORT_READ);
    Mode = USBBULK_GetMode();
    if (Mode & USBBULK_MODE_BIT_ALLOW_SHORT_READ) {
        pText = "USE_SHORT_MODE";
    } else {
        pText = "USE_NORMAL_MODE";
    }
    printf("USB-Bulk driver is now in %s\n", pText);
}
```



### 5.6.4.14 USBBULK\_SetModeEx()

#### Description

Sets the read operation mode of the driver for a specified device running emUSB-Bulk.

#### Prototype

```
unsigned USBBULK_SetModeEx(unsigned Id, unsigned Mode);
```

| Parameter            | Description                                                                                                                                               |
|----------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|
| <a href="#">Id</a>   | Id of the device.                                                                                                                                         |
| <a href="#">Mode</a> | Read and write mode for the USB-Bulk driver.<br>This is a combination of the following flags, combined by binary or:<br>USBBULK_MODE_BIT_ALLOW_SHORT_READ |

**Table 5.37: USBBULK\_SetModeEx() parameter list**

#### Return value

If the function succeeds, the return value is nonzero. The read and write mode for the driver has been successfully set.

If the function fails, the return value is zero.

#### Additional information

USBBULK\_MODE\_BIT\_ALLOW\_SHORT\_READ allows short read transfers. Short transfers are transfers of less bytes than requested. If this bit is specified, the read function USBBULK\_ReadEx() returns as soon as data is available, even if it is just a single byte.

#### Example

```
static void _TestModeEx(unsigned DeviceId) {
    unsigned Mode;
    char      * pText;

    Mode = USBBULK_GetModeEx(DeviceId);
    if (Mode & USBBULK_MODE_BIT_ALLOW_SHORT_READ) {
        pText = "USE_SHORT_MODE";
    } else {
        pText = "USE_NORMAL_MODE";
    }
    printf("USB-Bulk driver is in %s for device %d\n", pText, DeviceId);
    printf("Set mode to USBBULK_MODE_BIT_ALLOW_SHORT_READ\n");
    USBBULK_SetModeEx(DeviceId, USBBULK_MODE_BIT_ALLOW_SHORT_READ);
    Mode = USBBULK_GetModeEx(DeviceId);
    if (Mode & USBBULK_MODE_BIT_ALLOW_SHORT_READ) {
        pText = "USE_SHORT_MODE";
    } else {
        pText = "USE_NORMAL_MODE";
    }
    printf("USB-Bulk driver is now in %s for device %d\n", pText, DeviceId);
}
```

### 5.6.4.15 USBBULK\_SetTimeout()

#### Description

Sets a read timeout for a read operation to the first device running emUSB-Bulk.

#### Prototype

```
void USBBULK_SetTimeout(int Timeout);
```

| Parameter               | Description                                       |
|-------------------------|---------------------------------------------------|
| <a href="#">Timeout</a> | Timeout in milliseconds set for a read operation. |

**Table 5.38: USBBULK\_SetTimeout() parameter list**

### 5.6.4.16 USBULK\_SetTimeoutEx()

#### Description

Sets a read timeout for a read operation.

#### Prototype

```
void USBULK_SetTimeout(unsigned Id, int Timeout);
```

| Parameter               | Description                                       |
|-------------------------|---------------------------------------------------|
| <a href="#">Id</a>      | Id number of device [0..31].                      |
| <a href="#">Timeout</a> | Timeout in milliseconds set for a read operation. |

**Table 5.39: USBULK\_SetTimeOutEx() parameter list**

### 5.6.4.17 USBBULK\_SetUSBId()

#### Description

Sets the Vendor ID and Product ID that are used for connecting to the device.

#### Prototype

```
void USBBULK_SetUSBId(U16 VendorId, U16 ProductId);
```

| Parameter              | Description                                 |
|------------------------|---------------------------------------------|
| <code>VendorId</code>  | The Vendor ID that was assigned by USB.org. |
| <code>ProductId</code> | The Product ID that is used for the device. |

**Table 5.40: USBBULK\_SetUSBId() parameter list**

#### Additional information

It is necessary to call this function before opening any connection to the device.  
The initial values for these IDs are:

`VendorId` = 0x8765

`ProductId` = 0x1234

# Chapter 6

## Bulk Host API V2

---

This chapter describes a new version of the Bulk Host API.



## 6.1 Bulk Host API V2

This chapter describes the functions that can be used with the Windows host system.

### General information

The Bulk API V2 was introduced because the Bulk API V1 is not as flexible as required by modern-day applications.

Improvements in the Bulk API V2 include but are not limited to:

- Dynamic addition of enumerated devices
- Run-time configuration of Vendor IDs and Product IDs
- Masking of multiple Product and Vendor IDs

## 6.1.1 Bulk Host API V2 list

The functions below are available on the host (Windows PC) side.

| Function                                           | Description                                               |
|----------------------------------------------------|-----------------------------------------------------------|
| USB-Bulk basic functions                           |                                                           |
| <code>USBBULK_Open()</code>                        | Opens an existing device.                                 |
| <code>USBBULK_Close()</code>                       | Closes an opened device.                                  |
| <code>USBBULK_Init()</code>                        | Initializes the API module.                               |
| <code>USBBULK_Exit()</code>                        | Called on exit.                                           |
| <code>USBBULK_SetUSBId()</code>                    | Sets the Vendor and Product IDs.                          |
| USB-Bulk direct input/output functions             |                                                           |
| <code>USBBULK_Read()</code>                        | Reads from an opened device.                              |
| <code>USBBULK_Write()</code>                       | Writes data to the device.                                |
| <code>USBBULK_WriteRead()</code>                   | Writes and reads from the device.                         |
| <code>USBBULK_CancelRead()</code>                  | Cancels an initiated read.                                |
| <code>USBBULK_ReadTimed()</code>                   | Reads from an opened device with a timeout.               |
| <code>USBBULK_WriteTimed()</code>                  | Writes data to the device with a timeout.                 |
| <code>USBBULK_FlushRx()</code>                     | Removes data from the receive buffer.                     |
| USB-Bulk control functions                         |                                                           |
| <code>USBBULK_GetConfigDescriptor()</code>         | Returns the configuration descriptor of the device.       |
| <code>USBBULK_GetMode()</code>                     | Returns the transfer mode of the device.                  |
| <code>USBBULK_GetReadMaxTransferSize()</code>      | Returns the max size the driver can read at once.         |
| <code>USBBULK_GetWriteMaxTransferSize()</code>     | Returns the max size the driver can write at once.        |
| <code>USBBULK_ResetPipe()</code>                   | Resets the pipes that are opened to the device.           |
| <code>USBBULK_ResetDevice()</code>                 | Resets the device via a USB reset.                        |
| <code>USBBULK_SetMode()</code>                     | Sets the read and write mode of the device.               |
| <code>USBBULK_SetReadTimeout()</code>              | Sets the read timeout for an opened device.               |
| <code>USBBULK_SetWriteTimeout()</code>             | Sets the write timeout for an opened device.              |
| <code>USBBULK_GetEnumTickCount()</code>            | Returns the time when the USB device has been enumerated. |
| <code>USBBULK_GetReadMaxTransferSizeDown()</code>  | Returns the max read transfer size of the device.         |
| <code>USBBULK_GetWriteMaxTransferSizeDown()</code> | Returns the max write transfer size of the device.        |
| <code>USBBULK_SetReadMaxTransferSizeDown()</code>  | Sets the max read transfer size of the device.            |
| <code>USBBULK_SetWriteMaxTransferSizeDown()</code> | Sets the max write transfer size of the device.           |
| <code>USBBULK_GetSN()</code>                       | Gets the serial number of the device.                     |
| <code>USBBULK_GetDevInfo()</code>                  | Retrieves information about an opened USBBULK device.     |
| <code>USBBULK_GetProductName()</code>              | Returns the product name.                                 |
| <code>USBBULK_GetVendorName()</code>               | Returns the vendor name.                                  |

**Table 6.1: Bulk Host API V2 function list**

| Function                                      | Description                                                            |
|-----------------------------------------------|------------------------------------------------------------------------|
| USB-Bulk general GET functions                |                                                                        |
| <code>USBBULK_GetDriverCompileDate()</code>   | Gets the compile date of the driver.                                   |
| <code>USBBULK_GetDriverVersion()</code>       | Returns the driver version.                                            |
| <code>USBBULK_GetVersion()</code>             | Returns the USBBULK API version.                                       |
| <code>USBBULK_GetNumAvailableDevices()</code> | Returns the number of available devices.                               |
| <code>USBBULK_GetUSBId()</code>               | Returns the set Product and Vendor IDs.                                |
| Data structures                               |                                                                        |
| <code>USBBULK_DEV_INFO</code>                 | Device information structure (Vendor ID, Product ID, SN, Device Name). |

**Table 6.1: Bulk Host API V2 function list**



## 6.1.2 USB-Bulk Basic functions

### 6.1.2.1 USBULK\_Open()

#### Description

Opens an existing device. The ID of the device can be retrieved by the function `USBULK_GetNumAvailableDevices()` via the `pDeviceMask` parameter. Each bit set in the `DeviceMask` represents an available device. Currently 32 devices can be managed at once.

#### Prototype

```
USBULK_API USB_BULK_HANDLE WINAPI USBULK_Open (unsigned DevIndex);
```

| Parameter       | Description                   |
|-----------------|-------------------------------|
| <code>Id</code> | 0..31 Device ID to be opened. |

**Table 6.2: USBULK\_Open() parameter list**

#### Return value

!= 0: Handle to the opened device.  
 == 0: Device cannot be opened.

### 6.1.2.2 USBULK\_Close()

#### Description

Closes an opened device.

#### Prototype

```
USBBULK_API void WINAPI USBULK_Close (USB_BULK_HANDLE hDevice);
```

| Parameter               | Description                                |
|-------------------------|--------------------------------------------|
| <a href="#">hDevice</a> | Handle to the device that shall be closed. |

**Table 6.3: USBULK\_Close() parameter list**

### 6.1.2.3 USBULK\_Init()

#### Description

This function needs to be called before any other. This ensures that all structures and threads are initialized. It also sets a callback in order to be notified when a device is added or removed.

#### Prototype

```
USBULK_API void WINAPI USBULK_Init(USBULK_NOTIFICATION_FUNC *
                                   pfNotification, void * pContext);
```

| Parameter                   | Description                                                   |
|-----------------------------|---------------------------------------------------------------|
| <code>pfNotification</code> | Pointer to the user callback.                                 |
| <code>pContext</code>       | Context data that shall be called with the callback function. |

**Table 6.4: USBULK\_Init() parameter list**

#### Example

```
U32      DeviceMask;

/*****
 *
 *      _OnDevNotify
 *
 *      Function description:
 *      Is called when a new device is found or an existing device is removed.
 *
 *      Parameters:
 *      pContext - Pointer to a context given when USBULK_Init is called
 *      Index    - Device Index that has been added or removed.
 *      Event     - Type of event, currently the following are available:
 *                  USBULK_DEVICE_EVENT_ADD
 *                  USBULK_DEVICE_EVENT_REMOVE
 */
static void __stdcall _OnDevNotify(void * pContext,
                                   unsigned Index,
                                   USBULK_DEVICE_EVENT Event) {

    switch(Event) {
    case USBULK_DEVICE_EVENT_ADD:
        printf("The following DevIndex has been added: %d", Index);
        NumDevices = USBULK_GetNumAvailableDevices(&DeviceMask);
        break;
    case USBULK_DEVICE_EVENT_REMOVE:
        printf("The following DevIndex has been removed: %d", Index);
        NumDevices = USBULK_GetNumAvailableDevices(&DeviceMask);
        break;
    }
}

void MainTask(void) {
<...>
USBULK_Init(_OnDevNotify, NULL);
<...>
}
```

### 6.1.2.4 USBBULK\_Exit()

#### Description

This is a cleanup function, it shall be called when exiting the application.

#### Prototype

```
USBBULK_API void WINAPI USBBULK_Exit(void);
```

#### Additional information

We recommend to call this function before exiting the application in order to remove all handles and resources that have been allocated.

### 6.1.2.5 USBULK\_SetUSBId()

#### Description

Set the Vendor and Product ID mask the USBULK API should look for.

#### Prototype

```
USBULK_API void WINAPI USBULK_SetUSBId(U16 VendorId, U16 ProductId);
```

| Parameter              | Description                                                        |
|------------------------|--------------------------------------------------------------------|
| <code>VendorId</code>  | The desired Vendor ID mask that shall be used with the USBULK API  |
| <code>ProductId</code> | The desired Product ID mask that shall be used with the USBULK API |

**Table 6.5: USBULK\_SetUSBId() parameter list**

#### Additional information

It is necessary to call this function first before opening any connection to the device. The initial values for these IDs are:

`VendorId` = 0x8765

`ProductId` = 0x1234

## 6.1.3 USB-Bulk direct input/output functions

### 6.1.3.1 USBBULK\_Read()

#### Description

Reads data from target device running emUSB-Bulk.

#### Prototype

```
USBBULK_API int WINAPI USBBULK_Read (USB_BULK_HANDLE hDevice,  
                                     void * pBuffer, int NumBytes);
```

| Parameter             | Description                                    |
|-----------------------|------------------------------------------------|
| <code>hDevice</code>  | Handle to the opened device.                   |
| <code>pBuffer</code>  | Pointer to a buffer that shall store the data. |
| <code>NumBytes</code> | Number of bytes to be read.                    |

**Table 6.6: USBBULK\_Read() parameter list**

#### Return value

`== NumBytes:` All bytes have been successfully read.  
`< NumBytes:` A timeout occurred during read, when the emUSB driver is in normal mode, otherwise the emUSB driver returns the number of bytes that have been read from device.  
`<= -1:` Cannot read from the device.

#### Additional information

`USBBULK_Read()` sends the read request to the USB-Bulk driver. Because the driver can only read a certain amount of bytes from the device (the default value is 64 Kbytes) the driver will abort the transaction.

Therefore if `NumBytes` exceeds this limit, `USBBULK_Read()` will read the desired `NumBytes` in chunks of the maximum read size the driver can handle.

### 6.1.3.2 USBULK\_Write()

#### Description

Writes data to the device.

#### Prototype

```
USBULK_API int WINAPI USBULK_Write (USB_BULK_HANDLE hDevice,
                                     const void * pBuffer, int NumBytes);
```

| Parameter             | Description                                 |
|-----------------------|---------------------------------------------|
| <code>hDevice</code>  | Handle to the opened device.                |
| <code>pBuffer</code>  | Pointer to a buffer that contains the data. |
| <code>NumBytes</code> | Number of bytes to be written.              |

**Table 6.7: USBULK\_Write() parameter list**

#### Return value

`== NumBytes`: All bytes have been successfully written.  
`< NumBytes`: A write error occurred.  
`<= -1`: Cannot write to the device.

#### Additional information

`USBULK_Write()` sends the write request to the emUSB driver. Because the driver can only write a certain amount of bytes to device (the default value is 64 Kbytes) the driver will abort the transaction.

Therefore if `NumBytes` exceeds this limit, `USBULK_Write()` will write the desired `NumBytes` in chunks of the maximum write size the driver can handle.

### 6.1.3.3 USBBULK\_WriteRead()

#### Description

Writes and reads data to and from target device running emUSB-Bulk.

#### Prototype

```
USBBULK_API int WINAPI USBBULK_WriteRead(USB_BULK_HANDLE hDevice,  
const void * pWrBuffer, int WrNumBytes, void * pRdBuffer, int RdNumBytes);
```

| Parameter               | Description                                    |
|-------------------------|------------------------------------------------|
| <code>hDevice</code>    | Handle to the opened device.                   |
| <code>pWrBuffer</code>  | Pointer to a buffer that contains the data.    |
| <code>WrNumBytes</code> | Number of bytes to be written.                 |
| <code>pRdBuffer</code>  | Pointer to a buffer that shall store the data. |
| <code>RdNumBytes</code> | Number of bytes to be read.                    |

**Table 6.8: USBBULK\_WriteRead() parameter list**

#### Return value

`== NumBytes:` All bytes have been successfully read after writing the data.  
`< NumBytes:` A timeout occurred during read, when the emUSB driver is in normal mode. Otherwise the emUSB driver returns the number of bytes that have been read from the device.  
`<= -1:` Cannot read from the device after write.

#### Additional information

This function can not be used when short read mode is enabled.



### 6.1.3.4 USBULK\_CancelRead()

#### Description

This function cancels an initiated read operation.

#### Prototype

```
USBULK_API void WINAPI USBULK_CancelRead(USB_BULK_HANDLE hDevice);
```

| Parameter               | Description                  |
|-------------------------|------------------------------|
| <a href="#">hDevice</a> | Handle to the opened device. |

**Table 6.9: USBULK\_CancelRead() parameter list**

### 6.1.3.5 USBULK\_ReadTimed()

#### Description

Reads data from target device running emUSB-Bulk within a given timeout.

#### Prototype

```
USBULK_API int WINAPI USBULK_Read (USB_BULK_HANDLE hDevice,  
                                   void * pBuffer,  
                                   int NumBytes  
                                   unsigned ms);
```

| Parameter             | Description                                    |
|-----------------------|------------------------------------------------|
| <code>hDevice</code>  | Handle to the opened device.                   |
| <code>pBuffer</code>  | Pointer to a buffer that shall store the data. |
| <code>NumBytes</code> | Number of bytes to be read.                    |
| <code>ms</code>       | Timeout in milliseconds.                       |

**Table 6.10: USBULK\_ReadTimed() parameter list**

#### Return value

`== NumBytes`: All bytes have been successfully read.  
`< NumBytes`: A timeout occurred during read, when the emUSB driver is in normal mode, otherwise the emUSB driver returns the number of bytes that have been read from device.  
`<= -1`: Cannot read from the device.

#### Additional information

`USBULK_ReadTimed()` sends the read request to the USB-Bulk driver. Because the driver can only read a certain amount of bytes from the device (the default value is 64 Kbytes) the driver will abort the transaction.

Therefore if `NumBytes` exceeds this limit, `USBULK_ReadTimed()` will read the desired `NumBytes` in chunks of the maximum read size the driver can handle.

### 6.1.3.6 USBULK\_WriteTimed()

#### Description

Writes data to the device within a given timeout.

#### Prototype

```
USBULK_API int WINAPI USBULK_Write (USB_BULK_HANDLE hDevice,
                                   const void * pBuffer,
                                   int NumBytes
                                   unsigned ms);
```

| Parameter             | Description                                 |
|-----------------------|---------------------------------------------|
| <code>hDevice</code>  | Handle to the opened device.                |
| <code>pBuffer</code>  | Pointer to a buffer that contains the data. |
| <code>NumBytes</code> | Number of bytes to be written.              |
| <code>ms</code>       | Timeout in milliseconds.                    |

**Table 6.11: USBULK\_WriteTimed() parameter list**

#### Return value

== `NumBytes`: All bytes have been successfully written.  
 < `NumBytes`: A timeout occurred during write.  
 < 0: A write error occurred.

#### Additional information

`USBULK_WriteTimed()` sends the write request to the emUSB driver. Because the driver can only write a certain amount of bytes to device (the default value is 64 Kbytes) the driver will abort the transaction.

Therefore if `NumBytes` exceeds this limit, `USBULK_WriteTimed()` will write the desired `NumBytes` in chunks of the maximum write size the driver can handle.

### 6.1.3.7 USBBULK\_FlushRx()

#### Description

This function removes all data which was cached by the API from the internal receive buffer.

#### Prototype

```
USBBULK_API int WINAPI USBBULK_FlushRx (USB_BULK_HANDLE hDevice);
```

| Parameter               | Description                  |
|-------------------------|------------------------------|
| <a href="#">hDevice</a> | Handle to the opened device. |

**Table 6.12: USBBULK\_FlushRx() parameter list**

## 6.1.4 USB-Bulk Control functions

### 6.1.4.1 USBULK\_GetConfigDescriptor()

#### Description

Gets the received target USB configuration descriptor of a specified device running emUSB-Bulk.

#### Prototype

```
USBULK_API int WINAPI USBULK_GetConfigDescriptor(USB_BULK_HANDLE hDevice,
                                                void* pBuffer, int Size);
```

| Parameter               | Description                                            |
|-------------------------|--------------------------------------------------------|
| <a href="#">hDevice</a> | Handle to an opened device.                            |
| <a href="#">pBuffer</a> | Pointer to the buffer that shall store the descriptor. |
| <a href="#">Size</a>    | Size of the buffer, given in bytes.                    |

**Table 6.13: USBULK\_GetConfigDescriptor() parameter list**

#### Return value

== 0: Operation failed. Either an invalid handle was used or the buffer that shall store the config descriptor is too small.  
 != 0: The operation was successful.

If the function succeeds, the buffer pointed by [pBuffer](#) contains the USB target device configuration descriptor.

### 6.1.4.2 USBBULK\_GetMode()

#### Description

Returns the current mode of the device.

#### Prototype

```
USBBULK_API unsigned WINAPI USBBULK_GetMode(USB_BULK_HANDLE hDevice);
```

| Parameter               | Description                 |
|-------------------------|-----------------------------|
| <a href="#">hDevice</a> | Handle to an opened device. |

**Table 6.14: USBBULK\_GetMode() parameter list**

#### Return value

USBBULK\_MODE\_BIT\_ALLOW\_SHORT\_READ:  
Short read mode is enabled.

USBBULK\_MODE\_BIT\_ALLOW\_SHORT\_WRITE:  
Short write mode is enabled.

0: Normal mode is set.

#### Additional information

A combination of both modes is possible (bitwise OR).

### 6.1.4.3 USBULK\_GetReadMaxTransferSize()

#### Description

Retrieves the maximum transfer size of a read transaction the driver can receive from an application for a specified device running emUSB-Bulk.

#### Prototype

```
USBULK_API unsigned WINAPI USBULK_GetReadMaxTransferSize(USB_BULK_HANDLE  
                                                         hDevice);
```

| Parameter               | Description                 |
|-------------------------|-----------------------------|
| <a href="#">hDevice</a> | Handle to an opened device. |

**Table 6.15: USBULK\_GetReadMaxTransferSize() parameter list**

#### Return value

- == 0: Operation failed. Either an invalid handle was used or the transfer size cannot be read.
- != 0: The operation was successful.

#### 6.1.4.4 USBULK\_GetWriteMaxTransferSize()

##### Description

Retrieves the maximum transfer size of a write transaction the driver can handle from an application for a specified device running emUSB-Bulk.

##### Prototype

```
USBULK_API unsigned WINAPI USBULK_GetWriteMaxTransferSize(USB_BULK_HANDLE  
                                                         hDevice);
```

| Parameter               | Description                 |
|-------------------------|-----------------------------|
| <a href="#">hDevice</a> | Handle to an opened device. |

**Table 6.16: USBULK\_GetWriteMaxTransferSize() parameter list**

##### Return value

== 0: Operation failed. Either an invalid handle was used or the transfer size cannot be read.  
!= 0: The operation was successful.



### 6.1.4.5 USBULK\_ResetPipe()

#### Description

Resets the pipes that are opened to the device.  
It also flushes any data the USB bulk driver would cache.

#### Prototype

```
USBULK_API int WINAPI USBULK_ResetPipe(USB_BULK_HANDLE hDevice);
```

| Parameter               | Description                 |
|-------------------------|-----------------------------|
| <a href="#">hDevice</a> | Handle to an opened device. |

**Table 6.17: USBULK\_ResetPipe() parameter list**

#### Return value

== 0: Operation failed. Either an invalid handle was used or  
the pipes cannot be flushed.  
!= 0: The operation was successful.

### 6.1.4.6 USBBULK\_ResetDevice()

#### Description

Resets the device via a USB reset.

This can be used when the device does not work properly and may be reactivated via USB reset. This will force a re-enumeration of the device.

#### Prototype

```
USBBULK_API int WINAPI USBBULK_ResetDevice(USB_BULK_HANDLE hDevice);
```

| Parameter               | Description                 |
|-------------------------|-----------------------------|
| <a href="#">hDevice</a> | Handle to an opened device. |

**Table 6.18: USBBULK\_ResetDevice() parameter list**

#### Return value

== 0: Operation failed. Either an invalid handle was used or the pipes cannot be flushed.

!= 0: The operation was successful.

#### Additional information

After the device has been reset it is necessary to re-open the device as the current handle will become invalid.

### 6.1.4.7 USBBULK\_SetMode()

#### Description

Sets the read and write mode of the driver for a specified device running emUSB-Bulk.

#### Prototype

```
USBBULK_API unsigned WINAPI USBBULK_SetMode(USB_BULK_HANDLE hDevice,
                                             unsigned Mode);
```

| Parameter               | Description                                                                                                                                                                                     |
|-------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <a href="#">hDevice</a> | Handle to an opened device.                                                                                                                                                                     |
| <a href="#">Mode</a>    | Read and write mode for the USB-Bulk driver.<br>This is a combination of the following flags, combined by binary or:<br>USBBULK_MODE_BIT_ALLOW_SHORT_READ<br>USBBULK_MODE_BIT_ALLOW_SHORT_WRITE |

**Table 6.19: USBBULK\_SetMode() parameter list**

#### Return value

If the function succeeds, the return value is nonzero. The read and write mode for the driver has been successfully set.

If the function fails, the return value is zero.

#### Additional information

USBBULK\_MODE\_BIT\_ALLOW\_SHORT\_READ allows short read transfers. Short transfers are transfers of less bytes than requested. If this bit is specified, the read function [USBBULK\\_Read\(\)](#) returns as soon as data is available, even if it is just a single byte. USBBULK\_MODE\_BIT\_ALLOW\_SHORT\_WRITE allows short write transfers. [USBBULK\\_Write\(\)](#) returns after writing the minimal amount of data (either [NumBytes](#) or the maximal write transfer size, which can be read by using the function [USBBULK\\_GetWriteMaxTransferSize\(\)](#)).

#### Example

```
static void _TestMode(USB_BULK_HANDLE hDevice) {
    unsigned Mode;
    char      * pText;

    Mode = USBBULK_GetMode(hDevice);
    if (Mode & USBBULK_MODE_BIT_ALLOW_SHORT_READ) {
        pText = "USE_SHORT_MODE";
    } else {
        pText = "USE_NORMAL_MODE";
    }
    printf("USB-Bulk driver is in %s for device %d\n", pText, (int)hDevice);
    printf("Set mode to USBBULK_MODE_BIT_ALLOW_SHORT_READ\n");
    USBBULK_SetMode(hDevice, USBBULK_MODE_BIT_ALLOW_SHORT_READ);
    Mode = USBBULK_GetMode(hDevice);
    if (Mode & USBBULK_MODE_BIT_ALLOW_SHORT_READ) {
        pText = "USE_SHORT_MODE";
    } else {
        pText = "USE_NORMAL_MODE";
    }
    printf("USB-Bulk driver is now in %s for device %d\n", pText, (int)hDevice);
}
```

### 6.1.4.8 USBULK\_SetReadTimeout()

#### Description

Sets the default read timeout for an opened device.

#### Prototype

```
USBULK_API void WINAPI USBULK_SetReadTimeout(USB_BULK_HANDLE hDevice,  
                                              int Timeout);
```

| Parameter            | Description                  |
|----------------------|------------------------------|
| <code>hDevice</code> | Handle to the opened device. |
| <code>Timeout</code> | Timeout in milliseconds.     |

**Table 6.20: USBULK\_SetReadTimeout() parameter list**

### 6.1.4.9 USBULK\_SetWriteTimeout()

#### Description

Sets a default write timeout for an opened device.

#### Prototype

```
USBULK_API void WINAPI USBULK_SetWriteTimeout (USB_BULK_HANDLE hDevice,  
                                              int Timeout);
```

| Parameter            | Description                  |
|----------------------|------------------------------|
| <code>hDevice</code> | Handle to the opened device. |
| <code>Timeout</code> | Timeout in milliseconds.     |

**Table 6.21: USBULK\_SetWriteTimeout() parameter list**

### 6.1.4.10 USBBULK\_GetEnumTickCount()

#### Description

Returns the time when the USB device was enumerated.

#### Prototype

```
USBBULK_API U32 WINAPI USBBULK_GetEnumTickCount(USB_BULK_HANDLE hDevice);
```

| Parameter               | Description                 |
|-------------------------|-----------------------------|
| <a href="#">hDevice</a> | Handle to an opened device. |

**Table 6.22: USBBULK\_GetEnumTickCount() parameter list**

#### Return value

The time when the USB device was enumerated by the driver given in Windows timer ticks (normally 1 ms. ticks).

### 6.1.4.11 USBULK\_GetReadMaxTransferSizeDown()

#### Description

Returns the maximum transfer size the driver supports when reading data from the device. In normal cases the maximum transfer size will be 2048 bytes. As this is a multiple of the maximum packet size, it is necessary that the device does not send a NULL-packet in this case. The Windows USB stack will stop reading data from the USB bus as soon as it reads all requested bytes.

#### Prototype

```
USBULK_API U32 WINAPI USBULK_GetReadMaxTransferSizeDown(USB_BULK_HANDLE
                                                         hDevice);
```

| Parameter               | Description                 |
|-------------------------|-----------------------------|
| <a href="#">hDevice</a> | Handle to an opened device. |

**Table 6.23: USBULK\_GetReadMaxTransferSizeDown() parameter list**

#### Return value

!= 0: Max transfer size the driver will read from device.  
 == 0 : The transfer size cannot be read.

6.1.4.12 USBULK\_GetWriteMaxTransferSizeDown()

Description

Returns the maximum transfer size the driver will accept when writing data to the device.

Prototype

```
USBULK_API U32 WINAPI USBULK_GetWriteMaxTransferSizeDown(USB_BULK_HANDLE
                                                         hDevice);
```

| Parameter | Description                 |
|-----------|-----------------------------|
| hDevice   | Handle to an opened device. |

Table 6.24: USBULK\_GetWriteMaxtransferSizeDown() parameter list

Return value

- == 0: Operation failed. Either an invalid handle was used or the transfer size cannot be read.
- != 0: The operation was successful.



### 6.1.4.13 USBULK\_SetReadMaxTransferSizeDown()

#### Description

Sets the number of bytes the driver will write down to the device at once.

#### Prototype

```
USBULK_API unsigned WINAPI USBULK_SetReadMaxTransferSizeDown(
    USB_BULK_HANDLE hDevice,
    U32 TransferSize);
```

| Parameter                    | Description                                         |
|------------------------------|-----------------------------------------------------|
| <a href="#">hDevice</a>      | Handle to an opened device.                         |
| <a href="#">TransferSize</a> | The number of bytes the driver will set as maximum. |

**Table 6.25: USBULK\_SetReadMaxTransferSizeDown() parameter list**

#### Return value

== 0: Operation failed. Either an invalid handle was used or the mode cannot be set.  
 != 0: The operation was successful.

#### 6.1.4.14 USBULK\_SetWriteMaxTransferSizeDown()

##### Description

Sets the number of bytes the driver will write down to the device at once.

##### Prototype

```
USBULK_API unsigned WINAPI USBULK_SetWriteMaxTransferSizeDown(  
    USB_BULK_HANDLE hDevice,  
    U32 TransferSize);
```

| Parameter                    | Description                                         |
|------------------------------|-----------------------------------------------------|
| <a href="#">hDevice</a>      | Handle to an opened device.                         |
| <a href="#">TransferSize</a> | The number of bytes the driver will set as maximum. |

**Table 6.26: USBULK\_SetWriteMaxTransferSizeDown() parameter list**

##### Return value

== 0: Operation failed. Either an invalid handle was used or the mode cannot be set.

!= 0: Max transfer size the driver will read from device.

### 6.1.4.15 USBULK\_GetSN()

#### Description

Retrieves the USB serial number as a string which was sent by the device during the enumeration.

#### Prototype

```
USBULK_API unsigned WINAPI USBULK_GetSN(USB_BULK_HANDLE hDevice,  
                                         U8 * pBuffer, unsigned NumBytes);
```

| Parameter                | Description                                                            |
|--------------------------|------------------------------------------------------------------------|
| <a href="#">hDevice</a>  | Handle to an opened device.                                            |
| <a href="#">pBuffer</a>  | Pointer to a buffer which shall store the serial number of the device. |
| <a href="#">NumBytes</a> | Size of the buffer given in bytes.                                     |

**Table 6.27: USBULK\_GetSN() parameter list**

#### Return value

== 0: Operation failed. Either an invalid handle was used or the serial number cannot be read.

!= 0: The operation was successful.

If the function succeeds, the return value is nonzero and the buffer pointed by [pBuffer](#) contains the serial number of the device running emUSB-Bulk.

If the function fails, the return value is zero.

### 6.1.4.16 USBBULK\_GetDevInfo()

#### Description

Retrieves information about an opened USBBULK device.

#### Prototype

```
USBBULK_API void WINAPI USBBULK_GetDevInfo(USB_BULK_HANDLE hDevice,  
                                           USBBULK_DEV_INFO * pDevInfo);
```

| Parameter             | Description                         |
|-----------------------|-------------------------------------|
| <code>hDevice</code>  | Handle to the opened device.        |
| <code>pDevInfo</code> | Pointer to a device info structure. |

**Table 6.28: USBBULK\_GetDevInfo() parameter list**

### 6.1.4.17 USBULK\_GetProductName()

#### Description

Retrieves the product name of an opened USBULK device.

#### Prototype

```
USBULK_API void WINAPI USBULK_GetProductName(USB_BULK_HANDLE hDevice,
                                             char * sProductName,
                                             unsigned BufferSize);
```

| Parameter                 | Description                                                |
|---------------------------|------------------------------------------------------------|
| <code>hDevice</code>      | Handle to the opened device.                               |
| <code>sProductName</code> | Pointer to a buffer where the product name shall be saved. |
| <code>BufferSize</code>   | Size of the product name buffer.                           |

**Table 6.29: USBULK\_GetProductName() parameter list**

### 6.1.4.18 USBULK\_GetVendorName()

#### Description

Retrieves the vendor name of an opened USBULK device.

#### Prototype

```
USBULK_API int WINAPI USBULK_GetVendorName(USB_BULK_HANDLE hDevice,  
                                           char * sVendorName,  
                                           unsigned BufferSize);
```

| Parameter                | Description                                               |
|--------------------------|-----------------------------------------------------------|
| <code>hDevice</code>     | Handle to the opened device.                              |
| <code>sVendorName</code> | Pointer to a buffer where the vendor name shall be saved. |
| <code>BufferSize</code>  | Size of the vendor name buffer.                           |

**Table 6.30: USBULK\_GetVendorName() parameter list**

## 6.1.5 USB-Bulk general GET functions

### 6.1.5.1 USBULK\_GetDriverCompileDate()

#### Description

Gets the compile date and time of the emUSB bulk communication driver.

#### Prototype

```
USBULK_API unsigned WINAPI USBULK_GetDriverCompileDate(char * s,  
                                                       unsigned Size);
```

| Parameter            | Description                                           |
|----------------------|-------------------------------------------------------|
| <a href="#">s</a>    | Pointer to a buffer to store the compile date string. |
| <a href="#">Size</a> | Size, in bytes, of the buffer pointed to by s.        |

**Table 6.31: USBULK\_GetDriverCompileDate() parameter list**

#### Return value

== 0: Operation failed. The buffer that shall store the string is too small.

!= 0: The operation was successful.

If the function succeeds, the return value is nonzero and the buffer pointed by [s](#) contains the compile date and time of the emUSB driver in the standard format:  
mm dd yyyy hh:mm:ss

### 6.1.5.2 USBBULK\_GetDriverVersion()

#### Description

Returns the driver version of the driver, if the driver is loaded. Otherwise the function will return 0, as it can only determine the driver version when the driver is loaded.

#### Prototype

```
USBBULK_API unsigned WINAPI USBBULK_GetDriverVersion(void);
```

#### Return value

If the function succeeds, the return value is the driver version of the driver as decimal value:

<Major Version><Minor Version><Subversion>. 24201 (Mmmrr) means 2.42a

If the function fails, the return value is zero; the version could not be retrieved.



### 6.1.5.3 USBBULK\_GetVersion()

#### Description

Returns the USBBULK API version.

#### Prototype

```
USBBULK_API unsigned WINAPI USBBULK_GetVersion(void);
```

#### Return value

The version of the USBBULK API in the following format:

<Major Version><Minor Version><Subversion>. 24201 (Mmmrr) means 2.42a

### 6.1.5.4 USBBULK\_GetNumAvailableDevices()

#### Description

Returns the number of connected USB-Bulk devices.

#### Prototype

```
USBBULK_API unsigned WINAPI USBBULK_GetNumAvailableDevices(U32 * pMask);
```

| Parameter          | Description                                                                                 |
|--------------------|---------------------------------------------------------------------------------------------|
| <code>pMask</code> | Pointer to a U32 variable to receive the connected device mask. This parameter can be NULL. |

**Table 6.32: USBBULK\_GetNumAvailableDevices() parameter list**

#### Return value

The return value is the number of available devices running emUSB-Bulk. For each emUSB device that is connected, a bit in `pMask` is set. For example if device 0 and device 2 are connected to the host, the value `pMask` points to will be 0x00000005.

### 6.1.5.5 USBULK\_GetUSBId()

#### Description

Returns the set Product and Vendor ID mask that is used with the USBULK API.

#### Prototype

```
USBULK_API void WINAPI USBULK_GetUSBId(USB_BULK_HANDLE hDevice,
                                         U16 * pVendorId,
                                         U16 * pProductId);
```

| Parameter                  | Description                                               |
|----------------------------|-----------------------------------------------------------|
| <a href="#">hDevice</a>    | Handle to the opened device.                              |
| <a href="#">pVendorId</a>  | Pointer to a U16 variable that will store the Vendor ID.  |
| <a href="#">pProductId</a> | Pointer to a U16 variable that will store the Product ID. |

**Table 6.33: USBULK\_GetUSBId() parameter list**

## 6.1.6 Data structures

### 6.1.6.1 USBBULK\_DEV\_INFO

#### Description

A structure which can hold the relevant information about a device.

#### Prototype

```
typedef struct _USBBULK_DEV_INFO {  
    U16  VendorId;  
    U16  ProductId;  
    char acSN[256];  
    char acDevName[256];  
} USBBULK_DEV_INFO;
```

| Member                    | Description                                                 |
|---------------------------|-------------------------------------------------------------|
| <a href="#">VendorId</a>  | An U16 which holds the device Vendor ID.                    |
| <a href="#">ProductId</a> | An U16 which holds the device Product ID.                   |
| <a href="#">acSN</a>      | Array of chars which holds the serial number of the device. |
| <a href="#">acDevName</a> | Array of chars which holds the device name.                 |

**Table 6.34: USBBULK\_DEV\_INFO elements**

# Chapter 7

## Mass Storage Device Class (MSD)

---

This chapter gives a general overview of the MSD class and describes how to get the MSD component running on the target.



## 7.1 Overview

The Mass Storage Device (MSD) is a USB class protocol defined by the USB Implementers Forum. The class itself is used to access one or more storage devices such as flash drives or memory sticks.

As the USB mass storage device class is well standardized, every major operating system such as Microsoft Windows (Window ME, Windows 2000, Windows XP, Windows 2003 and Windows Vista), Apple Mac OS X, Linux and many more support it. So therefore an installation of a custom host USB driver is normally not necessary.

emUSB-MSD comes as a whole packet and contains the following:

- Generic USB handling
- MSD device class implementation, including support for direct disk and CD-ROM mode (CD-ROM access is a separate component)
- Several storage drivers for handling different devices
- Example applications

## 7.2 Configuration

### 7.2.1 Initial configuration

To get emUSB-MSD up and running as well as doing an initial test, the configuration as it is delivered should not be modified.

### 7.2.2 Final configuration

The configuration must only be modified, when emUSB is deployed in your final product. Refer to *Configuration* on page 41 for detailed information about the generic information functions which must be adapted.

In order to comply with the Mass Storage Device Bootability specification, the function `USB_GetSerialNumber()` must return a string with at least 12 characters, where each character is a hexadecimal digit ('0' through '9' or 'A' through 'F').

### 7.2.3 Class specific configuration functions

Beside the generic emUSB-MSD configuration functions, the following additional functions can be adapted before the emUSB MSD component is used in a final product. Example implementations of these functions are supplied in the MSD example application `USB_MSD_FS_Start.c`, located in the `Application` directory of emUSB.

| Function                              | Description                                    |
|---------------------------------------|------------------------------------------------|
| emUSB-MSD configuration functions     |                                                |
| <code>USB_MSD_GetVendorName()</code>  | Returns the vendor name.                       |
| <code>USB_MSD_GetProductName()</code> | Returns the MSD product name.                  |
| <code>USB_MSD_GetProductVer()</code>  | Returns the product version of the MSD device. |
| <code>USB_MSD_GetSerialNo()</code>    | Returns the serial number of the MSD device.   |

**Table 7.1: List of MSD class specific configuration functions**

### 7.2.3.1 USB\_MSD\_GetVendorName()

#### Description

Should return the vendor name of the mass storage device.

#### Prototype

```
const char * USB_MSD_GetVendorName(U8 Lun);
```

| Parameter | Description                                                            |
|-----------|------------------------------------------------------------------------|
| Lun       | Specifies the logical unit number whose vendor name shall be returned. |

**Table 7.2: USB\_MSD\_GetVendorName() parameter list**

#### Example

```
const char * USB_MSD_GetVendorName(U8 Lun) {  
    return "Vendor";  
}
```

#### Additional information

The vendor name is used during the enumeration phase. Together with the product name and the serial number it should give a detailed information to the user about which device is connected to the host.

The string should be no longer than 8 bytes.



### 7.2.3.2 USB\_MSD\_GetProductName()

#### Description

Should return the product name of the mass storage device.

#### Prototype

```
const char * USB_MSD_GetProductName(U8 Lun);
```

| Parameter | Description                                                             |
|-----------|-------------------------------------------------------------------------|
| Lun       | Specifies the logical unit number whose product name shall be returned. |

**Table 7.3: USB\_MSD\_GetProductName() parameter list**

#### Example

```
const char * USB_GetProductName(U8 Lun) {  
    return "MSD device";  
}
```

#### Additional information

The product name string should be no longer than 16 bytes.

### 7.2.3.3 USB\_MSD\_GetProductVer()

#### Description

Should return the product version number of the mass storage device.

#### Prototype

```
const char * USB_MSD_GetProductVer(U8 Lun);
```

| Parameter           | Description                                                        |
|---------------------|--------------------------------------------------------------------|
| <a href="#">Lun</a> | Specifies the logical unit number whose version shall be returned. |

**Table 7.4: USB\_MSD\_GetProductVer() parameter list**

#### Example

```
const char * USB_MSD_GetProductVer(U8 Lun) {  
    return "1.00";  
}
```

#### Additional information

The product version string should be no longer than 4 bytes.

### 7.2.3.4 USB\_MSD\_GetSerialNo()

#### Description

Should return the product serial number of the mass storage device.

#### Prototype

```
const char * USB_MSD_GetSerialNo(U8 Lun);
```

| Parameter | Description                                                              |
|-----------|--------------------------------------------------------------------------|
| Lun       | Specifies the logical unit number whose serial number shall be returned. |

**Table 7.5: USB\_MSD\_GetSerialNo() parameter list**

#### Example

```
const char * USB_MSD_GetSerialNo(U8 Lun) {
    return "1234657890AB";
}
```

#### Additional information

The serial number string must be exactly 12 bytes, in order to satisfy the USB bootability specification requirements.

## 7.2.4 Running the example application

The directory `Application` contains example applications that can be used with emUSB and the MSD component. To test the emUSB-MSD component, build and download the application of choice into the target. Remove the USB connection and reconnect the target to the host. The target will enumerate and can be accessed via a file browser.

### 7.2.4.1 MSD\_Start\_StorageRAM.c in detail

The main part of the example application `USB_MSD_Start_StorageRAM.c` is implemented in a single task called `MainTask()`.

```
/* MainTask() - excerpt from USB_MSD_Start_StorageRAM.c */

void MainTask(void);
void MainTask(void) {
    USB_Init();
    _AddMSD();
    USB_Start();
    while (1) {
        while ((USB_GetState() & (USB_STAT_CONFIGURED | USB_STAT_SUSPENDED))
               != USB_STAT_CONFIGURED) {
            BSP_ToggleLED(0);
            USB_OS_Delay(50);
        }
        BSP_SetLED(0);
        USB_MSD_Task();
    }
}
```

The first step is to initialize the USB core stack using `USB_Init()`. The function `_AddMSD()` configures all required endpoints and assigns the used storage medium to the MSD component.

```
/* _AddMSD() - excerpt from MSD_Start_StorageRAM.c */

static void _AddMSD(void) {
    static U8 _abOutBuffer[USB_MAX_PACKET_SIZE];
    USB_MSD_INIT_DATA    InitData;
    USB_MSD_INST_DATA     InstData;

    InitData.EPIn  = USB_AddEP(1, USB_TRANSFER_TYPE_BULK,
                               USB_MAX_PACKET_SIZE, NULL, 0);
    InitData.EPOut = USB_AddEP(0, USB_TRANSFER_TYPE_BULK, USB_MAX_PACKET_SIZE,
                               _abOutBuffer, USB_MAX_PACKET_SIZE);

    USB_MSD_Add(&InitData);
    //
    // Add logical unit 0: RAM drive
    //
    memset(&InstData, 0, sizeof(InstData));
    InstData.pAPI          = &USB_MSD_StorageRAM;
    InstData.DriverData.pStart = (void*)MSD_RAM_ADDR;
    InstData.DriverData.NumSectors = MSD_RAM_NUM_SECTORS;
    InstData.DriverData.SectorSize = MSD_RAM_SECTOR_SIZE;
    USB_MSD_AddUnit(&InstData);
}
```

The example application uses a RAM disk as storage medium.

The example RAM disk has a size of 23 Kbytes (46 sectors with a sector size of 512 bytes). You can increase the size of the RAM disk by modifying the macros `MSD_RAM_NUM_SECTORS` and `MSD_RAM_SECTOR_SIZE` (in multiples of 512), but the size must be at least 23 Kbytes otherwise a Windows host cannot format the disk.

```
/* AddMSD() - excerpt from MSD_Start_StorageRAM.c */

#define MSD_RAM_NUM_SECTORS    46
#define MSD_RAM_SECTOR_SIZE    512
```

## 7.3 Target API

| Function                                            | Description                                                                                     |
|-----------------------------------------------------|-------------------------------------------------------------------------------------------------|
| API functions                                       |                                                                                                 |
| <code>USB_MSD_Add()</code>                          | Adds an MSD-class interface to the USB stack.                                                   |
| <code>USB_MSD_AddUnit()</code>                      | Adds a mass storage device to the emUSB-MSD.                                                    |
| <code>USB_MSD_AddCDRom()</code>                     | Adds a CD-ROM device to the emUSB-MSD.                                                          |
| <code>USB_MSD_SetPreventAllowRemovalHook()</code>   | Sets a callback function to prevent/allow removal of storage medium.                            |
| <code>USB_MSD_SetPreventAllowRemovalHookEx()</code> | Sets a callback function to prevent/allow removal of storage medium.                            |
| <code>USB_MSD_SetReadWriteHook()</code>             | Sets a callback function which is called with every read or write access to the storage medium. |
| <code>USB_MSD_Task()</code>                         | Handles the MSD-specific protocol.                                                              |
| <code>USB_MSD_SetStartStopUnitHook()</code>         | Sets a callback function for the START STOP UNIT command.                                       |
| Extended API functions                              |                                                                                                 |
| <code>USB_MSD_Connect()</code>                      | Connects the storage medium to the MSD.                                                         |
| <code>USB_MSD_Disconnect()</code>                   | Disconnects the storage medium from the MSD.                                                    |
| <code>USB_MSD_RequestDisconnect()</code>            | Sets the DisconnectRequest flag.                                                                |
| <code>USB_MSD_UpdateWriteProtect()</code>           | Updates the IsWriteProtected flag for a storage medium.                                         |
| <code>USB_MSD_WaitForDisconnection()</code>         | Waits for disconnection while timeout is not reached.                                           |
| Data structures                                     |                                                                                                 |
| <code>USB_MSD_INIT_DATA</code>                      | emUSB-MSD initialization structure that is needed when adding an MSD interface.                 |
| <code>USB_MSD_INFO</code>                           | emUSB-MSD storage information.                                                                  |
| <code>USB_MSD_INST_DATA</code>                      | Structure that is used when adding a device to emUSB-MSD.                                       |
| <code>PREVENT_ALLOW_REMOVAL_HOOK</code>             | Callback invoked when the storage medium is removed.                                            |
| <code>PREVENT_ALLOW_REMOVAL_HOOK_EX</code>          | Callback invoked when the storage medium is removed.                                            |
| <code>READ_WRITE_HOOK</code>                        | Callback invoked when accessing the storage medium.                                             |
| <code>USB_MSD_INST_DATA_DRIVER</code>               | Structure that is passed to the driver.                                                         |
| <code>USB_MSD_STORAGE_API</code>                    | Structure that contains callbacks to the storage driver.                                        |
| <code>START_STOP_UNIT_HOOK</code>                   | Callback invoked when the START STOP UNIT command is received.                                  |

**Table 7.6: List of emUSB MSD interface functions and data structures**

## 7.3.1 API functions

### 7.3.1.1 USB\_MSD\_Add()

#### Description

Adds an MSD-class interface to the USB stack.

#### Prototype

```
void USB_MSD_Add      (const USB_MSD_INIT_DATA * pInitData);
```

| Parameter                 | Description                                            |
|---------------------------|--------------------------------------------------------|
| <a href="#">pInitData</a> | Pointer to a <code>USB_MSD_INIT_DATA</code> structure. |

**Table 7.7: USB\_MSD\_Add() parameter list**

#### Additional information

After the initialization of general emUSB, this is the first function that needs to be called when an MSD interface is used with emUSB. The structure `USB_MSD_INIT_DATA` must be initialized before `USB_MSD_Add()` is called. Refer to *USB\_MSD\_INIT\_DATA* on page 203 for more information.

### 7.3.1.2 USB\_MSD\_AddUnit()

#### Description

Adds a mass storage device to emUSB-MSD.

#### Prototype

```
void USB_MSD_AddUnit (const USB_MSD_INST_DATA * pInstData);
```

| Parameter                 | Description                                                                                                       |
|---------------------------|-------------------------------------------------------------------------------------------------------------------|
| <a href="#">pInstData</a> | Pointer to a <code>USB_MSD_INST_DATA</code> structure that is used to add the desired drive to the USB-MSD stack. |

**Table 7.8: USB\_MSD\_AddUnit() parameter list**

#### Additional information

It is necessary to call this function immediately after `USB_MSD_Add()`.

This function will then add an R/W storage device such as a hard drive, MMC/SD cards or NAND flash etc., to emUSB-MSD, which then will be used to exchange data with the host. The structure `USB_MSD_INST_DATA` must be initialized before `USB_MSD_AddUnit()` is called. Refer to `USB_MSD_INST_DATA` on page 205 for more information.

### 7.3.1.3 USB\_MSD\_AddCDRom()

#### Description

Adds a CD-ROM device to emUSB-MSD.

#### Prototype

```
void USB_MSD_AddCDRom(const USB_MSD_INST_DATA * pInstData);
```

| Parameter                 | Description                                                                                                       |
|---------------------------|-------------------------------------------------------------------------------------------------------------------|
| <a href="#">pInstData</a> | Pointer to a <code>USB_MSD_INST_DATA</code> structure that is used to add the desired drive to the USB-MSD stack. |

**Table 7.9: USB\_MSD\_AddCDRom() parameter list**

#### Additional information

Similar to [USB\\_MSD\\_AddUnit\(\)](#), this function should be called after [USB\\_MSD\\_Add\(\)](#). The structure `USB_MSD_INST_DATA` must be initialized before [USB\\_MSD\\_AddCDRom\(\)](#) is called. Refer to *USB\_MSD\_INST\_DATA* on page 205 for more information.



### 7.3.1.4 USB\_MSD\_SetPreventAllowRemovalHook()

#### Description

Sets a callback function to prevent/allow removal of storage medium.

#### Prototype

```
void USB_MSD_SetPreventAllowRemovalHook(U8 Lun,
                                         PREVENT_ALLOW_REMOVAL_HOOK * pfOnPreventAllowRemoval)
```

| Parameter                            | Description                                                                                                                                                                             |
|--------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>pfOnPreventAllowRemoval</code> | Pointer to the callback function <code>PREVENT_ALLOW_REMOVAL_HOOK</code> . For detailed information about the function pointer, refer to <i>PREVENT_ALLOW_REMOVAL_HOOK</i> on page 206. |

**Table 7.10: USB\_MSD\_SetPreventAllowRemovalHook() parameter list**

#### Additional information

The callback is called within the MSD task context. The callback must not block.

### 7.3.1.5 USB\_MSD\_SetPreventAllowRemovalHookEx()

#### Description

Sets a callback function to prevent/allow removal of storage medium.

#### Prototype

```
void USB_MSD_SetPreventAllowRemovalHookEx(U8 Lun,  
                                           PREVENT_ALLOW_REMOVAL_HOOK_EX *  
                                           pfOnPreventAllowRemovalEx)
```

| Parameter                              | Description                                                                                                                                                                                      |
|----------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>pfOnPreventAllowRemovalEx</code> | Pointer to the callback function<br><code>PREVENT_ALLOW_REMOVAL_HOOK_EX</code> . For detailed information about the function pointer, refer to <i>PREVENT_ALLOW_REMOVAL_HOOK_EX</i> on page 207. |

**Table 7.11: USB\_MSD\_SetPreventAllowRemovalHookEx() parameter list**

#### Additional information

The callback is called within the MSD task context. The callback must not block.

### 7.3.1.6 USB\_MSD\_SetReadWriteHook()

#### Description

Sets a callback function which gives information about the read and write blockwise operations to the storage medium.

#### Prototype

```
void USB_MSD_SetReadWriteHook(U8 Lun, READ_WRITE_HOOK * pfOnReadWrite)
```

| Parameter                  | Description                                                                                                                                                       |
|----------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>pfOnReadWrite</code> | Pointer to the callback function <code>READ_WRITE_HOOK</code> . For detailed information about the function pointer, refer to <i>READ_WRITE_HOOK</i> on page 208. |

**Table 7.12: USB\_MSD\_SetReadWriteHook() parameter list**

### 7.3.1.7 USB\_MSD\_Task()

#### Description

Task that handles the MSD-specific protocol.

#### Prototype

```
void USB_MSD_Task(void);
```

#### Additional information

After the USB device has been successfully enumerated and configured, the `USB_MSD_Task()` should be called. When the device is detached or is suspended, `USB_MSD_Task()` will return.

## 7.3.2 Extended API functions

### 7.3.2.1 USB\_MSD\_Connect()

#### Description

Connects the storage medium to the MSD module.

#### Prototype

```
void USB_MSD_Connect (U8 Lun);
```

| Parameter           | Description                                                                                  |
|---------------------|----------------------------------------------------------------------------------------------|
| <a href="#">Lun</a> | Zero-based index for the unit number.<br>Using only one storage medium, this parameter is 0. |

**Table 7.13: USB\_MSD\_Connect() parameter list**

#### Additional information

The storage medium is initially always connected to the MSD component. This function is normally used after the storage medium was disconnected via [USB\\_MSD\\_Disconnect\(\)](#) to carry out file system operations on the device application side.

### 7.3.2.2 USB\_MSD\_Disconnect()

#### Description

Disconnects the storage medium from the MSD module.

#### Prototype

```
void USB_MSD_Disconnect(U8 Lun);
```

| Parameter           | Description                                                                                  |
|---------------------|----------------------------------------------------------------------------------------------|
| <a href="#">Lun</a> | Zero-based index for the unit number.<br>Using only one storage medium, this parameter is 0. |

**Table 7.14: USB\_MSD\_Disconnect() parameter list**

#### Additional information

This function will force the storage medium to be disconnected. The host will be informed that the medium is not present. In order to reconnect the device to the host, the function [USB\\_MSD\\_Connect\(\)](#) shall be used.

See [USB\\_MSD\\_RequestDisconnect\(\)](#) and [USB\\_MSD\\_WaitForDisconnection\(\)](#) for a graceful disconnection method.

### 7.3.2.3 USB\_MSD\_RequestDisconnect()

#### Description

Sets the DisconnectRequest flag.

#### Prototype

```
void USB_MSD_RequestDisconnect(U8 Lun);
```

| Parameter           | Description                                                                                  |
|---------------------|----------------------------------------------------------------------------------------------|
| <a href="#">Lun</a> | Zero-based index for the unit number.<br>Using only one storage medium, this parameter is 0. |

**Table 7.15: USB\_MSD\_RequestDisconnect() parameter list**

#### Additional information

This function sets the disconnect flag for the storage medium. As soon as the next MSD command is sent to the device, the host will be informed that the device is currently not available. To reconnect the storage medium, [USB\\_MSD\\_Connect\(\)](#) shall be called.

### 7.3.2.4 USB\_MSD\_UpdateWriteProtect()

#### Description

Updates the IsWriteProtected flag for a storage medium.

#### Prototype

```
void USB_MSD_UpdateWriteProtect(U8 Lun, U8 IsWriteProtected);
```

| Parameter        | Description                                                                                  |
|------------------|----------------------------------------------------------------------------------------------|
| Lun              | Zero-based index for the unit number.<br>Using only one storage medium, this parameter is 0. |
| IsWriteProtected | 1 - Medium is write protected.<br>0 - Medium is not write protected.                         |

**Table 7.16: USB\_MSD\_UpdateWriteProtect() parameter list**

#### Additional information

This functions updates the write protect status of the storage medium. Please make sure that this function is called when the LUN is disconnected from the host, otherwise the WriteProtected flag is normally not recognized.



### 7.3.2.5 USB\_MSD\_WaitForDisconnection()

#### Description

Waits for disconnection while timeout is not reached.

#### Prototype

```
int USB_MSD_WaitForDisconnection(U8 Lun, U32 TimeOut);
```

| Parameter               | Description                                                                               |
|-------------------------|-------------------------------------------------------------------------------------------|
| <a href="#">Lun</a>     | 0-based index for the unit number.<br>Using only one storage medium, this parameter is 0. |
| <a href="#">TimeOut</a> | Timeout given in timer ticks (not milliseconds!).                                         |

**Table 7.17: USB\_MSD\_WaitForDisconnection() parameter list**

#### Return value

- 0: Error, timeout reached. Storage medium is not disconnected.
- 1: Success, storage medium is disconnected.

#### Additional information

After triggering the disconnection via [USB\\_MSD\\_RequestDisconnect\(\)](#) the stack disconnects the storage medium as soon as the host requests the status of the storage medium. Win2k does not periodically check the status of a USB MSD. Therefore, the timeout is required to leave the loop. The return value can be used to decide if the disconnection should be forced. In this case, [USB\\_MSD\\_Disconnect\(\)](#) shall be called.

7.3.2.6 USB\_MSD\_SetStartStopUnitHook()

Description

Sets a callback function to prevent/allow removal of storage medium.

Prototype

```
void USB_MSD_SetStartStopUnitHook(U8 Lun,
                                   START_STOP_UNIT_HOOK * pfOnStartStopUnit)
```

| Parameter         | Description                                                                                                                                                     |
|-------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| pfOnStartStopUnit | Pointer to the callback function START_STOP_UNIT_HOOK. For detailed information about the function pointer, refer to PREVENT_ALLOW_REMOVAL_HOOK_EX on page 207. |

Table 7.18: USB\_MSD\_SetStartStopUnitHook() parameter list

## 7.3.3 Data structures

### 7.3.3.1 USB\_MSD\_INIT\_DATA

#### Description

emUSB-MSD initialization structure that is required when adding an MSD interface.

#### Prototype

```
typedef struct {
    U8 EPIn;
    U8 EPOut;
    U8 InterfaceNum;
} USB_MSD_INIT_DATA;
```

| Member                       | Description                                                                                          |
|------------------------------|------------------------------------------------------------------------------------------------------|
| <a href="#">EPIn</a>         | Endpoint for sending data to the host.                                                               |
| <a href="#">EPOut</a>        | Endpoint for receiving data from the host.                                                           |
| <a href="#">InterfaceNum</a> | Interface number. This member is normally internally used, so therefore the value shall be set to 0. |

**Table 7.19: USB\_MSD\_INIT\_DATA elements**

#### Additional Information

This structure holds the endpoints that should be used with the MSD interface. Refer to *USB\_AddEP()* on page 59 for more information about how to add an endpoint.

### 7.3.3.2 USB\_MSD\_INFO

#### Description

emUSB-MSD storage interface.

#### Prototype

```
typedef struct {  
    U32 NumSectors;  
    U16 SectorSize;  
} USB_MSD_INFO;
```

| Member                     | Description                  |
|----------------------------|------------------------------|
| <a href="#">NumSectors</a> | Number of available sectors. |
| <a href="#">SectorSize</a> | Size of one sector.          |

**Table 7.20: USB\_MSD\_INFO elements**

### 7.3.3.3 USB\_MSD\_INST\_DATA

#### Description

Structure that is used when adding a device to emUSB-MSD.

#### Prototype

```
typedef struct {
    const USB_MSD_STORAGE_API * pAPI;
    USB_MSD_INST_DATA_DRIVER    DriverData;
    U8                          DeviceType;
    U8                          IsPresent;
    USB_MSD_HANDLE_CMD          * pfHandleCmd;
    U8                          IsWriteProtected;
} USB_MSD_INST_DATA;
```

| Member                           | Description                                                                                                                                                              |
|----------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <a href="#">pAPI</a>             | Pointer to a structure that holds the storage device driver API.                                                                                                         |
| <a href="#">DriverData</a>       | Driver data that are passed to the storage driver. Refer to <i>USB_MSD_INST_DATA_DRIVER</i> on page 209 for detailed information about how to initialize this structure. |
| <a href="#">DeviceType</a>       | Determines the type of the device.                                                                                                                                       |
| <a href="#">IsPresent</a>        | Determines if the medium is storage is present. For non-removable devices always 1.                                                                                      |
| <a href="#">pfHandleCmd</a>      | Optional pointer to a callback function which handles SCSI commands.<br>typedef U8 (USB_MSD_HANDLE_CMD) (U8 Lun);                                                        |
| <a href="#">IsWriteProtected</a> | Specifies whether the storage medium shall be write-protected.                                                                                                           |

**Table 7.21: USB\_MSD\_INST\_DATA elements**

#### Additional Information

All non-optional members of this structure need to be initialized correctly, except `Device Type` because it is done by the functions `USB_MSD_AddUnit()` or `USB_MSD_AddCDROM()`.

### 7.3.3.4 PREVENT\_ALLOW\_REMOVAL\_HOOK

#### Description

Callback function to prevent/allow removal of storage medium. See *USB\_MSD\_SetPreventAllowRemovalHook()* on page 193 for further information.

#### Prototype

```
typedef void (PREVENT_ALLOW_REMOVAL_HOOK) (U8 PreventRemoval);
```

### 7.3.3.5 PREVENT\_ALLOW\_REMOVAL\_HOOK\_EX

#### Description

Ex variant of [PREVENT\\_ALLOW\\_REMOVAL\\_HOOK](#), this function definition additionally includes a parameter for the Lun index. See *USB\_MSD\_SetPreventAllowRemovalHookEx()* on page 194 for further information.

#### Prototype

```
typedef void (PREVENT_ALLOW_REMOVAL_HOOK_EX) (U8 Lun, U8 PreventRemoval);
```

### 7.3.3.6 READ\_WRITE\_HOOK

#### Description

Callback function which is called with every read/write access to the storage medium.

#### Prototype

```
typedef void (READ_WRITE_HOOK) (U8  Lun,  
                                U8  IsRead,  
                                U8  OnOff,  
                                U32 StartLBA,  
                                U32 NumBlocks);
```

| Member                    | Description                                                                                      |
|---------------------------|--------------------------------------------------------------------------------------------------|
| <a href="#">Lun</a>       | Specifies the logical unit number which was accessed through read or write.                      |
| <a href="#">IsRead</a>    | Specifies whether a read or a write access was used (1 for read, 0 for write).                   |
| <a href="#">OnOff</a>     | States whether the read or write request has been initialized (1) or whether it is complete (0). |
| <a href="#">StartLBA</a>  | The first Logical Block Address accessed by the transfer.                                        |
| <a href="#">NumBlocks</a> | The number of blocks accessed by the transfer, starting from the <a href="#">StartLBA</a> .      |

**Table 7.22: READ\_WRITE\_HOOK elements**



### 7.3.3.7 USB\_MSD\_INST\_DATA\_DRIVER

#### Description

USB-MSD initialization structure that is required when adding an MSD interface.

#### Prototype

```
typedef struct {
    void      * pStart;
    U32        StartSector;
    U32        NumSectors;
    U32        SectorSize;
    void      * pSectorBuffer;
    unsigned    NumBytes4Buffer;
} USB_MSD_INST_DATA_DRIVER;
```

| Member                          | Description                                                                                          |
|---------------------------------|------------------------------------------------------------------------------------------------------|
| <a href="#">pStart</a>          | A pointer defining the start address                                                                 |
| <a href="#">StartSector</a>     | The start sector that is used for the driver                                                         |
| <a href="#">NumSectors</a>      | The available number of sectors available for the driver                                             |
| <a href="#">SectorSize</a>      | The sector size that should be used by the driver                                                    |
| <a href="#">pSectorBuffer</a>   | Pointer to an application provided buffer to be used as temporary buffer for storing the sector data |
| <a href="#">NumBytes4Buffer</a> | Size of the application provided buffer                                                              |

**Table 7.23: USB\_MSD\_INST\_DATA\_DRIVER**

#### Additional Information

This structure is passed to the storage driver. Therefore, the member of this structure can depend on the driver that is used.

For the storage driver that are shipped with this software the members of USB\_MSD\_INST\_DATA\_DRIVER have the following meaning:

USB\_MSD\_StorageRAM:

| Member                      | Description                                                 |
|-----------------------------|-------------------------------------------------------------|
| <a href="#">pStart</a>      | A pointer defining the start address of the RAM disk.       |
| <a href="#">StartSector</a> | This member is ignored.                                     |
| <a href="#">NumSectors</a>  | The available number of sectors available for the RAM disk. |
| <a href="#">SectorSize</a>  | The sector size that should be used by the driver.          |

USB\_MSD\_StorageByName:

| Member                          | Description                                                                                                                                                                                                                                                                           |
|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <a href="#">pStart</a>          | Pointer to a string holding the name of the volumes that shall be used, for example "nand:" "mmc:1:"                                                                                                                                                                                  |
| <a href="#">StartSector</a>     | Specifies the start sector.                                                                                                                                                                                                                                                           |
| <a href="#">NumSectors</a>      | Number of sector that shall be used.                                                                                                                                                                                                                                                  |
| <a href="#">SectorSize</a>      | This member is ignored.                                                                                                                                                                                                                                                               |
| <a href="#">pSectorBuffer</a>   | Pointer to an application provided buffer to be used as temporary buffer for storing the sector data                                                                                                                                                                                  |
| <a href="#">NumBytes4Buffer</a> | Size of the buffer provided by the application. Please make sure that the buffer can at least 3 sectors otherwise, pSectorBuffer and NumBytes4Buffer are ignored and an internal sector buffer is used. This sector-buffer is then allocated by using the FS-Storage-Layer functions. |

### 7.3.3.8 USB\_MSD\_STORAGE\_API

#### Description

Structure that contains callbacks to the storage driver.

#### Prototype

```
typedef struct {
    void (*pfInit)                (U8                Lun,
                                   const USB_MSD_INST_DATA_DRIVER * pDriverData);

    void (*pfGetInfo)             (U8                Lun,
                                   USB_MSD_INFO * pInfo);

    U32  (*pfGetReadBuffer)       (U8                Lun,
                                   U32                SectorIndex,
                                   void                ** ppData,
                                   U32                NumSectors);

    char (*pfRead)                (U8                Lun,
                                   U32                SectorIndex,
                                   void                * pData,
                                   U32                NumSector);

    U32  (*pfGetWriteBuffer)      (U8                Lun,
                                   U32                SectorIndex,
                                   void                ** ppData,
                                   U32                NumSectors);

    char (*pfWrite)               (U8                Lun,
                                   U32                SectorIndex,
                                   const void *        pData,
                                   U32                NumSectors);

    char (*pfMediumIsPresent)     (U8                Lun);

    void (*pfDeInit)             (U8                Lun);
} USB_MSD_STORAGE_API;
```

| Member                            | Description                                                                                   |
|-----------------------------------|-----------------------------------------------------------------------------------------------|
| <a href="#">pfInit</a>            | Initializes the storage medium.                                                               |
| <a href="#">pfGetInfo</a>         | Retrieves storage medium information such as sector size and number of sectors available.     |
| <a href="#">pfGetReadBuffer</a>   | Prepares read function and returns a pointer to a buffer that is used by the storage driver.  |
| <a href="#">pfRead</a>            | Reads one or multiple sectors from the storage medium.                                        |
| <a href="#">pfGetWriteBuffer</a>  | Prepares write function and returns a pointer to a buffer that is used by the storage driver. |
| <a href="#">pfWrite</a>           | Writes one or more sectors to the storage medium.                                             |
| <a href="#">pfMediumIsPresent</a> | Checks if medium is present.                                                                  |
| <a href="#">pfDeInit</a>          | Deinitializes the storage medium.                                                             |

**Table 7.24: List of callback functions of USB\_MSD\_STORAGE\_API**

#### Additional Information

USB\_MSD\_STORAGE\_API is used to retrieve information from the storage device driver or access data that needs to be read or written. Detailed information can be found in *Storage Driver* on page 212.

### 7.3.3.9 START\_STOP\_UNIT\_HOOK

#### Description

Callback function which is called when a START STOP UNIT SCSI command is received.

#### Prototype

```
typedef void (START_STOP_UNIT_HOOK) (U8 Lun,
                                     U8 StartLoadEject);
```

| Member                         | Description                                                                 |
|--------------------------------|-----------------------------------------------------------------------------|
| <a href="#">Lun</a>            | Specifies the logical unit number which was accessed through read or write. |
| <a href="#">StartLoadEject</a> | Binary OR of the SCSI LOEJ and START bits.                                  |

**Table 7.25: START\_STOP\_UNIT\_HOOK elements**

#### Additional Information

The LOEJ (load eject) bit is located on bit position 1.

The START bit is located on bit position 0.

For further information please refer to the START STOP UNIT command description in the SCSI documentation.

## 7.4 Storage Driver

This section describes the storage interface in detail.

### 7.4.1 General information

The storage interface is handled through an API-table, which contains all relevant functions necessary for read/write operations and initialization. Its implementation handles the details of how data is actually read from or written to memory.

Additionally, MSD knows two different media types:

- Direct media access, for example RAM-Disk, NAND flash, MMC/SD cards etc.
- CD-ROM emulation.

#### 7.4.1.1 Supported storage types

The supported storage types include:

- RAM, directly connected to the processor via the address bus.
- External flash memory, e.g. SD cards.
- Mechanical drives, for example CD-ROM. This is essentially an ATA/SCSI to USB bridge.

#### 7.4.1.2 Storage drivers supplied with this release

This release comes with the following drivers:

- `USB_MSD_StorageRAM`: A RAM driver which should work with almost any device.
- `USB_MSD_StorageByIndex`: A storage driver that uses the storage layer (logical block layer) of emFile to access the device.
- `USB_MSD_StorageByName`: A storage driver that uses the storage layer (logical block layer) of emFile to access the device.

### 7.4.2 Interface function list

As described above, access to a storage medium is realized through an API-function table (`USB_MSD_STORAGE_API`). The storage functions are declared in `USB\MSD\USB_MSD.h`. The structure is described in section *Data structures* on page 203.

## 7.4.3 USB\_MSD\_STORAGE\_API in detail

### 7.4.3.1 (\*pfInit)()

#### Description

Initializes the storage medium.

#### Prototype

```
void (*pfInit)(U8 Lun, const USB_MSD_INST_DATA_DRIVER * pDriverData);
```

| Parameter   | Description                                                                                                                                                                                                                                                 |
|-------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Lun         | Logical unit number. Specifies for which drive the function is called.                                                                                                                                                                                      |
| pDriverData | Pointer to a USB_MSD_INST_DATA_DRIVER structure that contains all information that is necessary for the driver initialization. For detailed information about the USB_MSD_INST_DATA_DRIVER structure, refer to <i>USB_MSD_INST_DATA_DRIVER</i> on page 209. |

**Table 7.26: (\*pfInit)() parameter list**

### 7.4.3.2 (\*pfGetInfo)()

#### Description

Retrieves storage medium information such as sector size and number of sectors available.

#### Prototype

```
void (*pfGetInfo)(U8 Lun, USB_MSD_INFO * pInfo);
```

| Parameter             | Description                                                                                                                                                         |
|-----------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <a href="#">Lun</a>   | Logical unit number. Specifies for which drive the function is called.                                                                                              |
| <a href="#">pInfo</a> | Pointer to a <code>USB_MSD_INFO</code> structure. For detailed information about the <code>USB_MSD_INFO</code> structure, refer to <i>USB_MSD_INFO</i> on page 204. |

**Table 7.27: (\*pfGetInfo)() parameter list**

### 7.4.3.3 (\*pfGetReadBuffer)()

#### Description

Prepares the read function and returns a pointer to a buffer that is used by the storage driver.

#### Prototype

```
U32 (*pfGetReadBuffer)(U8      Lun,      U32 SectorIndex,
                      void ** ppData, U32 NumSectors);
```

| Parameter                   | Description                                                            |
|-----------------------------|------------------------------------------------------------------------|
| <a href="#">Lun</a>         | Logical unit number. Specifies for which drive the function is called. |
| <a href="#">SectorIndex</a> | Specifies the start sector for the read operation.                     |
| <a href="#">ppData</a>      | Pointer to a pointer to store the read buffer address of the driver.   |
| <a href="#">NumSectors</a>  | Number of sectors to read.                                             |

**Table 7.28: (\*pfGetReadBuffer)() parameter list**

#### Return value

Maximum number of consecutive sectors that can be read at once by the driver.

### 7.4.3.4 (\*pfRead)()

#### Description

Reads one or multiple consecutive sectors from the storage medium.

#### Prototype

```
char (*pfRead)(U8 Lun, U32 SectorIndex, void * pData, U32 NumSector);
```

| Parameter   | Description                                                            |
|-------------|------------------------------------------------------------------------|
| Lun         | Logical unit number. Specifies for which drive the function is called. |
| SectorIndex | Specifies the start sector from where the read operation is started.   |
| pData       | Pointer to buffer to store the read data.                              |
| NumSectors  | Number of sectors to read.                                             |

**Table 7.29: (\*pfRead)() parameter list**

#### Return value

== 0: Success

!= 0: File System error code



### 7.4.3.5 (\*pfGetWriteBuffer)()

#### Description

Prepares the write function and returns a pointer to a buffer that is used by the storage driver.

#### Prototype

```
U32 (*pfGetWriteBuffer)(U8      Lun,      U32 SectorIndex,
                        void ** ppData, U32 NumSectors);
```

| Parameter                   | Description                                                            |
|-----------------------------|------------------------------------------------------------------------|
| <a href="#">Lun</a>         | Logical unit number. Specifies for which drive the function is called. |
| <a href="#">SectorIndex</a> | Specifies the start sector for the write operation.                    |
| <a href="#">ppData</a>      | Pointer to a pointer to store the write buffer address of the driver.  |
| <a href="#">NumSectors</a>  | Number of sectors to write.                                            |

**Table 7.30: (\*pfGetWriteBuffer)() parameter list**

#### Return value

Maximum number of consecutive sectors that can be written into the buffer.

### 7.4.3.6 (\*pfWrite)()

#### Description

Writes one or more consecutive sectors to the storage medium.

#### Prototype

```
char (*pfWrite)(U8 Lun, U32 SectorIndex,  
                const void * pData, U32 NumSectors);
```

| Parameter   | Description                                                            |
|-------------|------------------------------------------------------------------------|
| Lun         | Logical unit number. Specifies for which drive the function is called. |
| SectorIndex | Specifies the start sector for the write operation.                    |
| pData       | Pointer to data to be written to the storage medium.                   |
| NumSectors  | Number of sectors to write.                                            |

**Table 7.31: (\*pfWrite)() parameter list**

#### Return value

== 0: Success

!= 0: Error.

### 7.4.3.7 (\*pfMediumIsPresent)()

#### Description

Checks if medium is present.

#### Prototype

```
char (*pfMediumIsPresent) (U8 Lun);
```

| Parameter           | Description                                                            |
|---------------------|------------------------------------------------------------------------|
| <a href="#">Lun</a> | Logical unit number. Specifies for which drive the function is called. |

**Table 7.32: (\*pfMediumIsPresent)() parameter list**

#### Return value

== 1: Medium is present.

== 0: Medium is not present.

### 7.4.3.8 (\*pfDeInit)()

#### Description

Deinitializes the storage medium.

#### Prototype

```
void (*pfDeInit) (U8 Lun);
```

| Parameter           | Description                                                            |
|---------------------|------------------------------------------------------------------------|
| <a href="#">Lun</a> | Logical unit number. Specifies for which drive the function is called. |


**Table 7.33: (\*pfDeInit)() parameter list**

# Chapter 8

## Smart Mass Storage Component (SmartMSD)

---

This chapter gives a general overview of the SmartMSD component and describes how to get the SmartMSD running on the target.



## 8.1 Overview

The SmartMSD component allows to easily stream files to and from USB devices. Once the USB device is connected to the host, files can be read or written to the application without the need for dedicated storage memory.

This makes the software very flexible: it can be used for various types of applications and purposes, with no additional software or drivers necessary on the host side.

The SmartMSD software analyzes what operation is performed by the host and passes this to the application layer of the embedded target, which then performs the appropriate action. A simple drag and drop is all it takes to initialize this process, which is supported by a unique active file technology.

Smart MSD can access all data which has been created prior to the device being attached to the host, live data cannot be provided.

SmartMSD allows to use the storage device in a virtual manner, which means data does not need to be stored on a physical medium.

The storage device will be shown on the host as a FAT formatted volume with a configurable size and a configurable file list.

With the help of that virtual function, the target device can be used for different applications by simply dragging and dropping files to and from the storage medium:

- Firmware update application.
- Configuration updater.
- File system firewall - protect the target's filesystem from being manipulated by the host.

The component itself is based on MSD class and thus can be used on virtually any OS such as any Windows, Mac OS X or any Linux distribution (including Android) which supports MSD, without installing any third party tools.

## 8.2 Configuration

### 8.2.1 Initial configuration

To get emUSB-SmartMSD up and running as well as doing an initial test, the configuration as is delivered should not be modified.

### 8.2.2 Final configuration

The configuration must only be modified if emUSB is deployed in your final product. Refer to *Configuration* on page 41 for detailed information about the generic information functions which must be adapted.

### 8.2.3 Class specific configuration functions

For basic configuration please refer to the MSD chapter *Class specific configuration functions* on page 183.

In addition to the MSD configuration functions described in Chapter 7.2 "Configuration" the following SmartMSD functions are available.

| Function                                | Description                        |
|-----------------------------------------|------------------------------------|
| emUSB-SmartMSD configuration functions  |                                    |
| <a href="#">USB_SmartMSD_X_Config()</a> | Configures the SmartMSD component. |

**Table 8.1: List of SmartMSD class specific configuration functions**

### 8.2.3.1 USB\_SmartMSD\_X\_Config()

#### Description

Main user configuration function of the SmartMSD component. This function is provided by the user.

#### Prototype

```
void USB_SmartMSD_X_Config(void);
```

#### Example

```
void USB_SmartMSD_X_Config(void) {  
    //  
    // Global configuration  
    //  
    USB_SmartMSD_AssignMemory(&_aMEMBuffer[0], sizeof(_aMEMBuffer));  
    //  
    // Setup LUN0  
    //  
    USB_SmartMSD_SetNumSectors(0, _SmartMSD_NUM_SECTORS);  
    USB_SmartMSD_SetSectorsPerCluster(0, 32); // Anywhere from 1...128, needs to be 2^x  
    USB_SmartMSD_SetNumRootDirSectors(0, 2);  
    USB_SmartMSD_SetUserFunc(0, &_UserFuncAPI);  
    USB_SmartMSD_SetVolumeID(0, "Virt0.MSD"); // Add volume ID  
    //  
    // Push const contents to the volume  
    //  
    USB_SmartMSD_AddConstFiles(0, &_aConstFiles[0], COUNTOF(_aConstFiles));  
}
```

#### Additional information

During the call of `USB_SmartMSD_Init()` this user function is called in order to configure the SmartMSD module according to the user's preferences. In order to allow the user to configure the volume it is necessary to provide either a memory block or memory allocation/free callbacks to SmartMSD component. Otherwise `USB_SMARTMSD_ON_PANIC` is called.



## 8.2.4 Running the example application

The directory `Application` contains example applications that can be used with emUSB and the SmartMSD component. To test the SmartMSD component, build and download the application of choice into the target. Remove the USB connection and reconnect the target to the host. The target will enumerate and can be accessed via a file browser.

## 8.3 Target API

| Function                                         | Description                                                 |
|--------------------------------------------------|-------------------------------------------------------------|
| API functions                                    |                                                             |
| <code>USB_SmartMSD_Init()</code>                 | Adds an MSD-class interface to the USB stack.               |
| User supplied functions                          |                                                             |
| <code>USB_SmartMSD_X_Config()</code>             | Configures SmartMSD. It sets all call-backs.                |
| Configuration functions                          |                                                             |
| <code>USB_SmartMSD_AssignMemory()</code>         | Assigns memory to the module.                               |
| <code>USB_SmartMSD_SetUserFunc()</code>          | Sets various user-supplied functions.                       |
| <code>USB_SmartMSD_SetNumRootDirSectors()</code> | Sets the number of sectors reserved for the root directory. |
| <code>USB_SmartMSD_SetVolumeID()</code>          | Sets volume ID (name) for SmartMSD.                         |
| <code>USB_SmartMSD_SetcbRead()</code>            | Sets the call-back for the read sector operation.           |
| <code>USB_SmartMSD_SetcbWrite()</code>           | Sets the call-back for the write sector operation.          |
| <code>USB_SmartMSD_AddConstFiles()</code>        | Adds constant files to SmartMSD.                            |
| <code>USB_SmartMSD_SetNumSectors()</code>        | Sets the number of sectors available on device.             |
| <code>USB_SmartMSD_SetSectorsPerCluster()</code> | Sets the number of sectors per cluster.                     |
| Data structures                                  |                                                             |
| <code>USB_SMARTMSD_CONST_FILE</code>             | Structure for displaying constant files.                    |
| <code>USB_SMARTMSD_USER_FUNC_API</code>          | Structure for callback functions.                           |
| <code>USB_SMARTMSD_FILE_INFO</code>              | File info structure.                                        |
| <code>USB_SMARTMSD_DIR_ENTRY</code>              | Structure for a directory entry.                            |
| <code>USB_SMARTMSD_DIR_ENTRY_SHORT</code>        | Structure for a short directory entry.                      |
| <code>USB_SMARTMSD_DIR_ENTRY_LONG</code>         | Structure for a long directory entry.                       |
| Function definitions                             |                                                             |
| <code>USB_SMARTMSD_ON_READ_FUNC</code>           | Definition for the read callback.                           |
| <code>USB_SMARTMSD_ON_WRITE_FUNC</code>          | Definition for the write callback.                          |
| <code>USB_SMARTMSD_ON_PANIC</code>               | Definition for the panic callback.                          |
| <code>USB_SMARTMSD_MEM_ALLOC</code>              | Definition for the memory alloc call-back.                  |
| <code>USB_SMARTMSD_MEM_FREE</code>               | Definition for the memory free call-back.                   |

**Table 8.2: List of emUSB SmartMSD interface functions and data structures**

## 8.3.1 API functions

### 8.3.1.1 USB\_SmartMSD\_Init()

#### Description

Adds the SmartMSD component to the USB stack.

#### Prototype

```
void USB_SmartMSD_Init(void);
```

#### Additional information

After the initialization of emUSB-Device, this is the first function that needs to be called when the SmartMSD component is used with emUSB-Device. During the call of the said function the user function `USB_SmartMSD_X_Config()` is called in order to configure the storage itself.

### 8.3.1.2 USB\_SmartMSD\_X\_Config()

#### Description

User supplied function that configures all storages of the SmartMSD component.

#### Prototype

```
void USB_SmartMSD_X_Config (void);
```

#### Additional information

This function is called automatically by `USB_SmartMSD_Init()` in order to allow to configure the storage volumes that SmartMSD should show after configuration. Only the following functions must be called in this context:

| Allowed functions with USB_X_SmartMSD_Config     |
|--------------------------------------------------|
| <code>USB_SmartMSD_AssignMemory()</code>         |
| <code>USB_SmartMSD_SetUserFunc()</code>          |
| <code>USB_SmartMSD_SetNumRootDirSectors()</code> |
| <code>USB_SmartMSD_SetVolumeID()</code>          |
| <code>USB_SmartMSD_SetcbRead()</code>            |
| <code>USB_SmartMSD_SetcbWrite()</code>           |
| <code>USB_SmartMSD_AddConstFiles()</code>        |
| <code>USB_SmartMSD_SetNumSectors()</code>        |
| <code>USB_SmartMSD_SetSectorsPerCluster()</code> |

**Table 8.3: Allowed functions with USB\_X\_SmartMSD\_Config**

### 8.3.1.3 USB\_SmartMSD\_AssignMemory()

#### Description

Assigns memory to the module.

#### Prototype

```
void USB_SmartMSD_AssignMemory (U32 * p, U32 NumBytes);
```

| Parameter                | Description                                                  |
|--------------------------|--------------------------------------------------------------|
| <a href="#">p</a>        | Pointer to the memory which should be dedicated to SmartMSD. |
| <a href="#">NumBytes</a> | Size of the memory block in bytes.                           |

**Table 8.4: USB\_SmartMSD\_AssignMemory() parameter list**

### 8.3.1.4 USB\_SmartMSD\_SetUserFunc()

#### Description

Sets the default user callbacks for the SmartMSD component.

#### Prototype

```
void USB_SmartMSD_SetUserFunc(const USB_SMARTMSD_MSD_USER_FUNC_API *
pUserFunc);
```

| Parameter                 | Description                                                                                                                         |
|---------------------------|-------------------------------------------------------------------------------------------------------------------------------------|
| <a href="#">pUserFunc</a> | Pointer to a <a href="#">USB_SMARTMSD_USER_FUNC_API</a> structure which holds the default function pointers for multiple functions. |

**Table 8.5: USB\_SmartMSD\_SetUserFunc() parameter list**

#### Additional information

Check the description of [USB\\_SMARTMSD\\_USER\\_FUNC\\_API](#) for further details.

The default read and write callbacks can be overwritten by the per-LUN functions [USB\\_SmartMSD\\_SetcbRead\(\)](#) and [USB\\_SmartMSD\\_SetcbWrite\(\)](#).

### 8.3.1.5 USB\_SmartMSD\_SetNumRootDirSectors()

#### Description

Sets the number of sectors which should be used for root directory entries.

#### Prototype

```
void USB_SmartMSD_SetNumRootDirSectors(unsigned Lun, int NumRootDirSectors);
```

| Parameter                         | Description                                                      |
|-----------------------------------|------------------------------------------------------------------|
| <a href="#">Lun</a>               | Specifies the logical unit number.                               |
| <a href="#">NumRootDirSectors</a> | Number of sectors to be reserved for the root directory entries. |

**Table 8.6: USB\_SmartMSD\_SetNumRootDirSectors() parameter list**

#### Additional information

The number of sectors reserved through this function is subtracted from the number of sectors configured by [USB\\_SmartMSD\\_SetNumSectors\(\)](#). These sectors hold the root directory entries for the specified LUN. A single sector contains 512 bytes, a short file name entry (also called 8.3 filenames) needs 32 bytes, therefore a single sector has enough space for 16 root directory entries. Please note that when using LFN (long file names) the number of entries required for a single file is dynamic (depending on the length of the file name).

### 8.3.1.6 USB\_SmartMSD\_SetVolumeID()

#### Description

Sets the volume name for a specified LUN.

#### Prototype

```
int USB_SmartMSD_SetVolumeID(unsigned Lun, const char * sVolumeName);
```

| Parameter                   | Description                                 |
|-----------------------------|---------------------------------------------|
| <a href="#">Lun</a>         | Specifies the logical unit number.          |
| <a href="#">sVolumeName</a> | Pointer to the zero-terminated volume name. |

**Table 8.7: USB\_SmartMSD\_SetVolumeID() parameter list**

#### Additional information

This function is optional, but can be helpful to identify the volume. If it is not used the host operating system chooses a default name for the volume.

### 8.3.1.7 USB\_SmartMSD\_SetcbRead()

#### Description

Sets a callback function for a specific LUN which gives information about the read sector-wise operations to the volume.

#### Prototype

```
void USB_SmartMSD_SetcbRead (unsigned Lun, USB_SMARTMSD_ON_READ_FUNC *  
pfReadSector);
```

| Parameter                    | Description                                                                             |
|------------------------------|-----------------------------------------------------------------------------------------|
| <a href="#">Lun</a>          | Specifies the logical unit number.                                                      |
| <a href="#">pfReadSector</a> | Pointer to a user provided function of type <a href="#">USB_SMARTMSD_ON_READ_FUNC</a> . |

**Table 8.8: USB\_SmartMSD\_SetcbRead() parameter list**

#### Additional information

This callback is called each time a sector is read by the host. The callback should not block.

This callback supersedes the read callback set by [USB\\_SmartMSD\\_SetUserFunc\(\)](#).



### 8.3.1.8 USB\_SmartMSD\_SetcbWrite()

#### Description

Sets a callback function for a specific LUN which gives information about the write sector-wise operations to the volume.

#### Prototype

```
void USB_SmartMSD_SetcbWrite (unsigned Lun, USB_SMARTMSD_ON_WRITE_FUNC *
pfWriteSector);
```

| Parameter                    | Description                                                                              |
|------------------------------|------------------------------------------------------------------------------------------|
| <a href="#">Lun</a>          | Specifies the logical unit number.                                                       |
| <a href="#">pfReadSector</a> | Pointer to a user provided function of type <a href="#">USB_SMARTMSD_ON_WRITE_FUNC</a> . |

**Table 8.9: USB\_SmartMSD\_SetcbWrite() parameter list**

#### Additional information

This callback is called each time a sector is written by the host. The callback should not block.

This callback supersedes the write callback set by [USB\\_SmartMSD\\_SetUserFunc\(\)](#).

### 8.3.1.9 USB\_SmartMSD\_AddConstFiles()

#### Description

Allows to add multiple files which should be shown on a SmartMSD volume as soon as it is connected. A common example would be a "Readme.txt" or a link to the company website.

#### Prototype

```
int USB_SmartMSD_AddConstFiles (unsigned Lun, USB_SMARTMSD_CONST_FILE *
paConstFile, int NumFiles);
```

| Parameter   | Description                                                                |
|-------------|----------------------------------------------------------------------------|
| Lun         | Specifies the logical unit number.                                         |
| paConstFile | Pointer to an array of <a href="#">USB_SMARTMSD_CONST_FILE</a> structures. |
| NumFiles    | The number of items in the <a href="#">paConstFile</a> array.              |

**Table 8.10: USB\_SmartMSD\_AddConstFiles() parameter list**

#### Additional information

For additional information please see [USB\\_SMARTMSD\\_CONST\\_FILE](#).

#### Example

```
#define COUNTOF(a) (sizeof((a))/sizeof((a)[0]))

static const U8 _abFile_SeggerHTML[] = {0x3C, 0x68, 0x74, 0x6D, 0x6C, 0x3E, 0x3C,
0x68, 0x65, 0x61, 0x64, 0x3E, 0x3C, 0x6D, 0x65, 0x74, 0x61, 0x20, 0x68, 0x74, 0x74,
0x70, 0x2D, 0x65, 0x71, 0x75, 0x69, 0x76, 0x3D, 0x22, 0x72, 0x65, 0x66, 0x72, 0x65,
0x73, 0x68, 0x22, 0x20, 0x63, 0x6F, 0x6E, 0x74, 0x65, 0x6E, 0x74, 0x3D, 0x22, 0x30,
0x3B, 0x20, 0x75, 0x72, 0x6C, 0x3D, 0x68, 0x74, 0x74, 0x70, 0x3A, 0x2F, 0x2F, 0x77,
0x77, 0x77, 0x2E, 0x73, 0x65, 0x67, 0x67, 0x65, 0x72, 0x2E, 0x63, 0x6F, 0x6D, 0x2F,
0x69, 0x6E, 0x64, 0x65, 0x78, 0x2E, 0x68, 0x74, 0x6D, 0x6C, 0x22, 0x2F, 0x3E, 0x3C,
0x74, 0x69, 0x74, 0x6C, 0x65, 0x3E, 0x53, 0x45, 0x47, 0x47, 0x45, 0x52, 0x20, 0x53,
0x68, 0x6F, 0x72, 0x74, 0x63, 0x75, 0x74, 0x3C, 0x2F, 0x74, 0x69, 0x74, 0x6C, 0x65,
0x3E, 0x3C, 0x2F, 0x68, 0x65, 0x61, 0x64, 0x3E, 0x3C, 0x62, 0x6F, 0x64, 0x79, 0x3E,
0x3C, 0x2F, 0x62, 0x6F, 0x64, 0x79, 0x3E, 0x3C, 0x2F, 0x68, 0x74, 0x6D, 0x6C, 0x3E};

static USB_VMSD_CONST_FILE _aConstFiles[] = {
// sName      pData      FileSize      FirstClust
{ "Segger.html", _abFile_SeggerHTML, sizeof(_abFile_SeggerHTML), 0, }
};

/*****
 *
 *      USB_VMSD_X_Config
 *
 *      Function description
 *      This function is called by the USB MSD Module during USB_VMSD_Init() and
 *      initializes the VMSD volume.
 */
void USB_VMSD_X_Config(void) {
    <...>
    USB_VMSD_AddConstFiles(1, &_aConstFiles[0], COUNTOF(_aConstFiles));
    <...>
}
```

### 8.3.1.10 USB\_SmartMSD\_SetNumSectors()

#### Description

Sets the number of sectors available on the volume.

#### Prototype

```
void USB_SmartMSD_SetNumSectors (unsigned Lun, int NumSectors);
```

| Parameter                  | Description                                |
|----------------------------|--------------------------------------------|
| <a href="#">Lun</a>        | Specifies the logical unit number.         |
| <a href="#">NumSectors</a> | Specifies the number of sectors for a LUN. |

**Table 8.11: USB\_SmartMSD\_SetNumSectors() parameter list**

### 8.3.1.11 USB\_SmartMSD\_SetSectorsPerCluster()

#### Description

Sets the number of sectors per cluster.

#### Prototype

```
void USB_SmartMSD_SetSectorsPerCluster (unsigned Lun,  
int SectorsPerCluster);
```

| Parameter         | Description                                |
|-------------------|--------------------------------------------|
| Lun               | Specifies the logical unit number.         |
| SectorsPerCluster | Specifies the number of sectors for a LUN. |

**Table 8.12: USB\_SmartMSD\_SetSectorsPerCluster() parameter list**

#### Additional information

`SectorsPerCluster` can be anywhere between 1 and 128, but needs to be a power of 2. Larger clusters save memory because the management overhead is lower, but the maximum number of files is limited by the number of available clusters.

## 8.3.2 Data structures

### 8.3.2.1 USB\_SMARTMSD\_CONST\_FILE

#### Description

This structure contains information about a constant file which cannot be changed at run time and should be shown inside the SmartMSD volume (e.g. Readme.txt). This structure is a parameter for the [USB\\_SmartMSD\\_AddConstFiles\(\)](#) function.

#### Prototype

```
typedef struct {
    const char* sName;
    const U8* pData;
    int FileSize;
    U32 FirstClust;
} USB_SMARTMSD_CONST_FILE;
```

| Member                     | Description                                                                                        |
|----------------------------|----------------------------------------------------------------------------------------------------|
| <a href="#">sName</a>      | Pointer to a zero-terminated string containing the filename.                                       |
| <a href="#">pData</a>      | Pointer to the file data. Can be NULL.                                                             |
| <a href="#">FileSize</a>   | Size of the file. Normally the size of the data pointed to by <a href="#">pData</a> .              |
| <a href="#">FirstClust</a> | Allows to reserve a cluster (block) for a file. This is done automatically when the value is zero. |

**Table 8.13: USB\_SMARTMSD\_CONST\_FILE elements**

#### Additional Information

If a file does not occupy complete sectors the remaining bytes of the last sector are automatically filled with 0s on read.

If [pData](#) is NULL the file is not displayed in the volume. This is useful when the application has certain files which should only be displayed after certain events (e.g. the application displays a Fail.txt when the device is reconnected after an unsuccessful firmware update).

### 8.3.2.2 USB\_SMARTMSD\_USER\_FUNC\_API

#### Description

This structure contains the function pointers for user provided functions. This structure is a parameter for the `USB_SmartMSD_SetUserFunc()` function.

#### Prototype

```
typedef struct _USB_SMARTMSD_USER_FUNC_API {
    USB_SMARTMSD_ON_READ_FUNC * pfOnReadSector;           // Mandatory
    USB_SMARTMSD_ON_WRITE_FUNC * pfOnWriteSector;         // Mandatory
    USB_SMARTMSD_ON_PANIC * pfOnPanic;                   // Optional
    USB_SMARTMSD_MEM_ALLOC * pfMemAlloc;                 // Optional
    USB_SMARTMSD_MEM_FREE * pfMemFree;                   // Optional
} USB_SMARTMSD_USER_FUNC_API;
```

| Member                       | Description                                                                                                                                                                                                             |
|------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>pfOnReadSector</code>  | Pointer to a callback function of type <code>USB_SMARTMSD_ON_READ_FUNC</code> which is called when a sector is read from the host. This function is mandatory and can not be NULL.                                      |
| <code>pfOnWriteSector</code> | Pointer to a callback function of type <code>USB_SMARTMSD_ON_WRITE_FUNC</code> which is called when a sector is written from the host. This function is mandatory and can not be NULL.                                  |
| <code>pfOnPanic</code>       | Pointer to a user provided panic function of type <code>USB_SMARTMSD_ON_PANIC</code> . If this pointer is NULL the internal panic function is called.                                                                   |
| <code>pfMemAlloc</code>      | Pointer to a user provided alloc function of type <code>USB_SMARTMSD_MEM_ALLOC</code> . If this pointer is NULL the internal alloc function is called. If no memory block is assigned <code>pfOnPanic</code> is called. |
| <code>pfMemFree</code>       | Pointer to a user provided free function of type <code>USB_SMARTMSD_MEM_FREE</code> . If this pointer is NULL the internal free function is called. If no memory block is assigned <code>pfOnPanic</code> is called.    |

**Table 8.14: USB\_SMARTMSD\_USER\_FUNC\_API elements**

#### Additional Information

The default callback functions for read and write are overwritten by the per-LUN read and write functions, which are set through `USB_SmartMSD_SetcbRead()` and `USB_SmartMSD_SetcbWrite()`.

### 8.3.2.3 USB\_SMARTMSD\_FILE\_INFO

#### Description

Structure used in the read and write callbacks.

#### Prototype

```
typedef struct {
    const USB_SMARTMSD_DIR_ENTRY* pDirEntry;
} USB_SMARTMSD_FILE_INFO;
```

| Member                    | Description                                                    |
|---------------------------|----------------------------------------------------------------|
| <a href="#">pDirEntry</a> | Pointer to a <a href="#">USB_SMARTMSD_DIR_ENTRY</a> structure. |

**Table 8.15: USB\_SMARTMSD\_FILE\_INFO elements**

#### Additional Information

Check [USB\\_SMARTMSD\\_ON\\_READ\\_FUNC](#), [USB\\_SMARTMSD\\_ON\\_WRITE\\_FUNC](#) and [USB\\_SMARTMSD\\_DIR\\_ENTRY](#) for more information.

### 8.3.2.4 USB\_SMARTMSD\_DIR\_ENTRY

#### Description

Union containing references to directory entries. This union is a member of [USB\\_SMARTMSD\\_FILE\\_INFO](#).

#### Prototype

```
typedef union {
    USB_SMARTMSD_DIR_ENTRY_SHORT ShortEntry;
    USB_SMARTMSD_DIR_ENTRY_LONG LongEntry;
    U8 ac[32];
} USB_SMARTMSD_DIR_ENTRY;
```

| Member                     | Description                                                                     |
|----------------------------|---------------------------------------------------------------------------------|
| <a href="#">ShortEntry</a> | Allows to access the entry as a "short directory entry".                        |
| <a href="#">LongEntry</a>  | Allows to access the entry as a "long directory entry".                         |
| <a href="#">ac</a>         | Allows to write directly to the structure without casting or using the members. |

**Table 8.16: USB\_SMARTMSD\_DIR\_ENTRY elements**

#### Additional Information

Check [USB\\_SMARTMSD\\_DIR\\_ENTRY\\_SHORT](#) and [USB\\_SMARTMSD\\_DIR\\_ENTRY\\_LONG](#) for more information.



### 8.3.2.5 USB\_SMARTMSD\_DIR\_ENTRY\_SHORT

#### Description

Structure used to describe an entry with a short file name. This structure is a member of [USB\\_SMARTMSD\\_DIR\\_ENTRY](#).

#### Prototype

```
typedef struct {
    U8  acFilename[8];
    U8  acExt[3];
    U8  DirAttr;
    U8  NTRes;
    U8  CrtTimeTenth;
    U16 CrtTime;
    U16 CrtDate;
    U16 LstAccDate;
    U16 FstClusHI;
    U16 WrtTime;
    U16 WrtDate;
    U16 FstClusLO;
    U32 FileSize;
} USB_SMARTMSD_DIR_ENTRY_SHORT;
```

| Member                       | Description                                                                                                    |
|------------------------------|----------------------------------------------------------------------------------------------------------------|
| <a href="#">acFilename</a>   | File name, limited to 8 characters (short file name), padded with spaces (0x20).                               |
| <a href="#">acExt</a>        | File extension, limited to 3 characters (short file name), padded with spaces (0x20).                          |
| <a href="#">DirAttr</a>      | File attributes. Available attributes are listed below.                                                        |
| <a href="#">NTRes</a>        | Reserved for use by Windows NT.                                                                                |
| <a href="#">CrtTimeTenth</a> | Millisecond stamp at file creation time. This field actually contains a count of tenths of a second.           |
| <a href="#">CrtTime</a>      | Creation time.                                                                                                 |
| <a href="#">CrtDate</a>      | Date file was created.                                                                                         |
| <a href="#">LstAccDate</a>   | Last access date. Note that there is no last access time, only a date. This is the date of last read or write. |
| <a href="#">FstClusHI</a>    | High word of this entry's first cluster number.                                                                |
| <a href="#">WrtTime</a>      | Time of last write.                                                                                            |
| <a href="#">WrtDate</a>      | Date of last write.                                                                                            |
| <a href="#">FstClusLO</a>    | Low word of this entry's first cluster number.                                                                 |
| <a href="#">FileSize</a>     | File size in bytes.                                                                                            |

**Table 8.17: USB\_SMARTMSD\_DIR\_ENTRY\_SHORT elements**

#### Additional Information

The following file attributes are available for short dir entries:

| Attribute                                   | Explanation                                                                      |
|---------------------------------------------|----------------------------------------------------------------------------------|
| <a href="#">USB_SMARTMSD_ATTR_READ_ONLY</a> | The file is read-only.                                                           |
| <a href="#">USB_SMARTMSD_ATTR_HIDDEN</a>    | The file is hidden.                                                              |
| <a href="#">USB_SMARTMSD_ATTR_SYSTEM</a>    | The file is designated as a system file.                                         |
| <a href="#">USB_SMARTMSD_ATTR_VOLUME_ID</a> | This entry is the volume ID (volume name).                                       |
| <a href="#">USB_SMARTMSD_ATTR_DIRECTORY</a> | The file is a directory.                                                         |
| <a href="#">USB_SMARTMSD_ATTR_ARCHIVE</a>   | The file has the archive attribute.                                              |
| <a href="#">USB_SMARTMSD_ATTR_LONG_NAME</a> | The file has a long file name, see <a href="#">USB_SMARTMSD_DIR_ENTRY_LONG</a> . |

### 8.3.2.6 USB\_SMARTMSD\_DIR\_ENTRY\_LONG

#### Description

Structure used to describe an entry with a long file name. This structure is a member of [USB\\_SMARTMSD\\_DIR\\_ENTRY](#).

This is for information only, the read and write callbacks only receive short file names.

#### Prototype

```
typedef struct {
    U8  Ord;
    U8  acName1[10];
    U8  Attr;
    U8  Type;
    U8  Chksum;
    U8  acName2[12];
    U16 FstClusLO;
    U8  acName3[4];
} USB_SMARTMSD_DIR_ENTRY_LONG;
```

| Member                    | Description                                                                                                                                             |
|---------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|
| <a href="#">Ord</a>       | The order of this entry in the sequence of long dir entries, associated with the short dir entry at the end of the long dir set.                        |
| <a href="#">acName1</a>   | Characters 1-5 of the long-name sub-component in this dir entry.                                                                                        |
| <a href="#">Attr</a>      | Attributes - must be <a href="#">USB_SMARTMSD_ATTR_LONG_NAME</a> .                                                                                      |
| <a href="#">Type</a>      | If zero, indicates a directory entry that is a sub-component of a long name. Other values reserved for future extensions. Non-zero implies other types. |
| <a href="#">Chksum</a>    | Checksum of name in the short dir entry at the end of the long dir set.                                                                                 |
| <a href="#">acName2</a>   | Characters 6-11 of the long-name sub-component in this dir entry.                                                                                       |
| <a href="#">FstClusLO</a> | Must be zero.                                                                                                                                           |
| <a href="#">acName3</a>   | Characters 12-13 of the long-name sub-component in this dir entry.                                                                                      |

**Table 8.18: USB\_SMARTMSD\_DIR\_ENTRY\_LONG elements**

### 8.3.2.7 USB\_SMARTMSD\_ON\_READ\_FUNC

#### Description

Callback function prototype that is used when calling the `USB_SmartMSD_SetUserFunc()` and `USB_SmartMSD_SetcbRead()` functions.

#### Prototype

```
typedef int USB_SMARTMSD_ON_READ_FUNC (U8 * pData, U32 Off, U32 NumBytes,
const USB_SMARTMSD_FILE_INFO * pFile);
```

| Parameter             | Description                                                                     |
|-----------------------|---------------------------------------------------------------------------------|
| <code>pData</code>    | Pointer to a buffer in which the data is stored.                                |
| <code>Off</code>      | Offset in the file which is read by the host.                                   |
| <code>NumBytes</code> | Amount of bytes requested by the host.                                          |
| <code>pFile</code>    | Pointer to a <code>USB_SMARTMSD_FILE_INFO</code> structure describing the file. |

**Table 8.19: USB\_SMARTMSD\_ON\_READ\_FUNC parameter list**

#### Return value

`== 0`: Success.

`!= 0`: An error occurred.

### 8.3.2.8 USB\_SMARTMSD\_ON\_WRITE\_FUNC

#### Description

Callback function prototype that is used when calling the `USB_SmartMSD_SetUserFunc()` and `USB_SmartMSD_SetcbWrite()` functions.

#### Prototype

```
typedef int USB_SMARTMSD_ON_WRITE_FUNC (const U8 * pData, U32 Off, U32  
NumBytes, const USB_SMARTMSD_FILE_INFO * pFile);
```

| Parameter             | Description                                                                     |
|-----------------------|---------------------------------------------------------------------------------|
| <code>pData</code>    | Pointer to the data to be written (received from the host).                     |
| <code>Off</code>      | Offset in the file which the host writes.                                       |
| <code>NumBytes</code> | Amount of bytes to write.                                                       |
| <code>pFile</code>    | Pointer to a <code>USB_SMARTMSD_FILE_INFO</code> structure describing the file. |

**Table 8.20: USB\_SMARTMSD\_ON\_WRITE\_FUNC parameter list**

#### Return value

`== 0`: Success.

`!= 0`: An error occurred.

#### Additional Information

Depending on the behavior of the host operating system it is possible that `pFile` is NULL. In this case we recommend to perform data analysis to recognize the file.

### 8.3.2.9 USB\_SMARTMSD\_ON\_PANIC

#### Description

Callback function prototype that is called when a fatal, unrecoverable error occurs.

#### Prototype

```
typedef void USB_SMARTMSD_ON_PANIC (const char * sErr);
```

| Parameter         | Description                                               |
|-------------------|-----------------------------------------------------------|
| <code>sErr</code> | Pointer to a zero-terminated string describing the error. |

**Table 8.21: USB\_SMARTMSD\_ON\_PANIC parameter list**

### 8.3.2.10 USB\_SMARTMSD\_MEM\_ALLOC

#### Description

Function prototype that is used when memory is being allocated by the SmartMSD module.

#### Prototype

```
typedef void * USB_SMARTMSD_MEM_ALLOC (U32 Size);
```

| Parameter            | Description                           |
|----------------------|---------------------------------------|
| <a href="#">Size</a> | Size of the required memory in bytes. |

**Table 8.22: USB\_SMARTMSD\_MEM\_ALLOC parameter list**

#### Return value

Pointer to the allocated memory or NULL.

### 8.3.2.11 USB\_SMARTMSD\_MEM\_FREE

#### Description

Function prototype that is used when memory is being freed by the SmartMSD module.

#### Prototype

```
typedef void USB_SMARTMSD_MEM_FREE (void * p);
```

| Parameter         | Description                                                                                          |
|-------------------|------------------------------------------------------------------------------------------------------|
| <a href="#">p</a> | Pointer to a memory block which was previously allocated by <a href="#">USB_SMARTMSD_MEM_ALLOC</a> . |

**Table 8.23: USB\_SMARTMSD\_MEM\_FREE parameter list**






# Chapter 9

## Media Transfer Protocol Class (MTP)

---

This chapter gives a general overview of the MTP class and describes how to get the MTP component running on the target.



## 9.1 Overview

The Media Transfer Protocol (MTP) is a USB class protocol which can be used to transfer files to and from storage devices. MTP is an official extension of the Picture Transfer Protocol (PTP) designed to allow digital cameras to exchange image files with a computer. MTP extends this by adding support for audio and video files.

MTP is an alternative to Mass Storage Device (MSD) and it operates at the file level, in contrast to MSD which reads and writes sector data. This type of operation gives MTP some advantages over MSD:

- The cable can be safely removed during the data transfer without damaging the file system.
- The file system does not need to be FAT (can be the SEGGER emFile File System (EFS) or any other proprietary file system)
- The application has full control over which files are visible to the user. Selected files or directories can be hidden.
- Virtual files can be presented.
- Host and target can access storage simultaneously without conflicts.

MTP is supported by most operating systems out of the box and the installation of additional drivers is not required.

emUSB-MTP supports the following capabilities:

- File read
- File write
- Format
- File delete
- Directory create
- Directory delete

The current implementation of emUSB-MTP has the following limitations:

- The device does not notify the host when the data on the storage medium changes (file added/removed, file size change, etc.)


Get in contact with us if you need this feature to be supported.

emUSB-MTP comes as a complete package and contains the following:


- Generic USB handling
- MTP device class implementation
- Storage driver which uses emFile
- Sample application showing how to work with MTP

### 9.1.1 Getting access to files


An MTP device will be displayed under the "Portable Devices" section in the "Computer" window when connected to a PC running the Microsoft Windows 7 operating system:




The file and directories stored on the device are accessed in the usual way using the Windows Explorer:



On the Ubuntu Linux operating system a connected MTP device is shown in the "Computer" window:



The files and directories present on the MTP device can be easily accessed via GUI:



On other operating systems the data stored on MTP devices can be accessed similarly.

### 9.1.2 Additional information

For more technical details about MTP and PTP follow these links:

[MTP specification](#)

[PTP specification](#)

## 9.2 Configuration

### 9.2.1 Initial configuration

To get emUSB-MTP up and running as well as doing an initial test, the configuration as delivered with the sample application should not be modified.

### 9.2.2 Final configuration

The configuration must only be modified when emUSB is integrated in your final product. Refer to section *Configuration* on page 41 for detailed information about the generic information functions which have to be adapted.

### 9.2.3 Class specific configuration

In addition to the emUSB-MTP configuration functions which must be called by the application, the callback functions described below can be adapted before the emUSB-MTP component is used in a final product. A sample implementation of these functions can be found in the `USB_MTP_Start.c` application, located in the `Application` directory of emUSB shipment.

| Function                                | Description                             |
|-----------------------------------------|-----------------------------------------|
| emUSB-MTP configuration functions       |                                         |
| <code>USB_MTP_GetManufacturer()</code>  | Returns the device manufacturer.        |
| <code>USB_MTP_GetModel()</code>         | Returns the device model.               |
| <code>USB_MTP_GetDeviceVersion()</code> | Returns the firmware version of device. |
| <code>USB_MTP_GetSerialNumber()</code>  | Returns the serial number of device.    |

**Table 9.1: List of class specific configuration functions**

### 9.2.3.1 USB\_MTP\_GetManufacturer()

#### Description

Returns the name of the device manufacturer.

#### Prototype

```
const char * USB_MTP_GetManufacturer(void);
```

#### Example

```
const char * USB_MTP_GetManufacturer(void) {  
    return "SEGGER";  
}
```

#### Additional information

It is a human-readable string identifying the manufacturer of this device. This string is returned by the MTP device in the Manufacturer field of the Device Info dataset. For more information, refer to MTP specification.

### 9.2.3.2 USB\_MTP\_GetModel()

#### Description

Should return the model of MTP device.

#### Prototype

```
const char * USB_MTP_GetModel(void);
```

#### Example

```
const char * USB_MTP_GetModel(void) {  
    return "Storage device";  
}
```

#### Additional information

It is a human-readable string identifying the model of the device. This string is returned by the MTP device in the Model field of the Device Info dataset. For more information, refer to MTP specification.



### 9.2.3.3 USB\_MTP\_GetDeviceVersion()

#### Description

Should return the version of MTP device.

#### Prototype

```
const char * USB_MTP_GetDeviceVersion(void);
```

#### Example

```
const char * USB_MTP_GetDeviceVersion(void) {  
    return "1.0";  
}
```

#### Additional information

The string identifies the version of the firmware running on the device. This string is returned by the MTP device in the Device Version field of the Device Info dataset. For more information, refer to MTP specification.

### 9.2.3.4 USB\_MTP\_GetSerialNumber()

#### Description

Should return the serial number of MTP device.

#### Prototype

```
const char * USB_MTP_GetSerialNumber(void);
```

#### Example

```
const char * USB_MTP_GetSerialNumber(void) {  
    return "0123456789ABCDEF0123456789ABCDEF";  
}
```

#### Additional information

The serial number should contain exactly 32 hexadecimal characters. It must be unique among devices sharing the same model name and device version strings. The MTP device returns this string in the `Serial Number` field of the `DeviceInfo` dataset. For more information, refer to MTP specification.

## 9.2.4 Compile time configuration

The following macros can be added to `USB_Conf.h` file in order to configure the behavior of the MTP component.

The following types of configuration macros exist:

### Binary switches “B”

Switches can have a value of either 0 or 1, for deactivated and activated respectively. Actually, anything other than 0 works, but 1 makes it easier to read a configuration file. These switches can enable or disable a certain functionality or behavior. Switches are the simplest form of configuration macros.

### Numerical values “N”

Numerical values are used somewhere in the code in place of a numerical constant.

| Type | Macro                | Default | Description                                                                                                                                                                                                                                           |
|------|----------------------|---------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| N    | MTP_DEBUG_LEVEL      | 0       | Sets the type of diagnostic messages output at runtime. It can take one of these values:<br>0 - no debug messages<br>1 - only error messages<br>2 - error and log messages                                                                            |
| N    | MTP_MAX_NUM_STORAGES | 4       | Maximum number of storage units the storage layer can handle. 4 additional bytes are allocated for each storage unit.                                                                                                                                 |
| B    | MTP_SAVE_FILE_INFO   | 0       | Specifies if the object properties (file size, write protection, creation date, modification date and file id) should be stored in RAM for quick access to them. 50 additional bytes of RAM are required for each object when the switch is set to 1. |
| N    | MTP_MAX_FILE_PATH    | 256     | Maximum number of characters in the path to a file or directory.                                                                                                                                                                                      |
| B    | MTP_SUPPORT_UTF8     | 1       | Names of the files and directories which are exchanged between the MTP component and the file system are encoded in UTF-8 format.                                                                                                                     |

**Table 9.2: MTP configuration macros**

## 9.3 Running the sample application

The directory `Application` contains a sample application which can be used with emUSB and the MTP component. To test the emUSB-MTP component, the application should be built and then downloaded to target. Remove the USB connection and reconnect the target to the host. The target will enumerate and will be accessible via a file browser.

### 9.3.1 USB\_MTP\_Start.c in detail

The main part of the example application `USB_MTP_Start.c` is implemented in a single task called `MainTask()`.

```
// MainTask() - excerpt from USB_MTP_Start.c
```

```

void MainTask(void);
void MainTask(void) {
    USB_Init();
    AddMTP();
    USB_Start();
    while (1) {
        while ((USB_GetState() & (USB_STAT_CONFIGURED | USB_STAT_SUSPENDED))
               != USB_STAT_CONFIGURED) {
            BSP_ToggleLED(0);
            USB_OS_Delay(50);
        }
        BSP_SetLED(0);
        USB_MTP_Task();
    }
}

```

The first step is to initialize the USB core stack by calling `USB_Init()`. The function `_AddMTP()` configures all required endpoints, adds the MTP component to emUSB and assigns a storage medium to it. More than one storage medium can be added. The access to storage medium is done using a storage driver. emUSB comes with a storage driver for the SEGGER emFile file system.

*// \_AddMTP() - excerpt from USB\_MTP\_Start.c*

```

static void _AddMTP(void) {
    USB_MTP_INIT_DATA InitData;
    USB_MTP_INST_DATA InstData;

    //
    // Add the MTP component to USB stack.
    //
    InitData.EPIn = USB_AddEP(1, USB_TRANSFER_TYPE_BULK,
                              USB_MAX_PACKET_SIZE, NULL, 0);
    InitData.EPOut = USB_AddEP(0, USB_TRANSFER_TYPE_BULK,
                               USB_MAX_PACKET_SIZE, _acReceiveBuffer,
                               sizeof(_acReceiveBuffer));
    InitData.EPInt = USB_AddEP(1, USB_TRANSFER_TYPE_INT, 10, NULL, 0);
    InitData.pObjectList = _aObjectList;
    InitData.NumBytesObjectList = sizeof(_aObjectList);
    InitData.pDataBuffer = _aDataBuffer;
    InitData.NumBytesDataBuffer = sizeof(_aDataBuffer);
    USB_MTP_Add(&InitData);
    //
    // Add a storage driver to MTP component.
    //
    InstData.pAPI = &USB_MTP_StorageFS;
    InstData.sDescription = "MTP volume";
    InstData.sVolumeId = "0123456789";
    InstData.DriverData.pRootDir = "";
    USB_MTP_AddStorage(&InstData);
}

```

The size of `_acReceiveBuffer` and `_aDataBuffer` buffers must be a multiple of USB maximum packet size. The sample uses the `USB_MAX_PACKET_SIZE` define which is set to the correct value. The size of the buffer allocated for the object list, `_aObjectList` must be chosen according to the number of files on the storage medium. emUSB-MTP assigns an internal object to each file or directory requested by the USB host. The USB host can request all the files and directories present at once or it can request files and directories as user browses them. An object requires a minimum of 54 bytes. The actual number of bytes allocated depends on the length of the full path to file/directory.

## 9.4 Target API

| Function                                 | Description                                             |
|------------------------------------------|---------------------------------------------------------|
| API functions                            |                                                         |
| <a href="#">USB_MTP_Add()</a>            | Adds an MTP interface to the USB stack.                 |
| <a href="#">USB_MTP_AddStorage()</a>     | Adds a storage device to the emUSB-MTP.                 |
| <a href="#">USB_MTP_Task()</a>           | Handles the MTP communication.                          |
| Data structures                          |                                                         |
| <a href="#">USB_MTP_FILE_INFO</a>        | Stores information about a file or directory.           |
| <a href="#">USB_MTP_INIT_DATA</a>        | Stores the MTP initialization parameters.               |
| <a href="#">USB_MTP_INST_DATA</a>        | Stores the initialization parameters of storage driver. |
| <a href="#">USB_MTP_INST_DATA_DRIVER</a> | Stores parameters that are passed to storage driver.    |
| <a href="#">USB_MTP_STORAGE_API</a>      | Stores callbacks to the functions of storage driver.    |
| <a href="#">USB_MTP_STORAGE_INFO</a>     | Stores information about the storage medium.            |

**Table 9.3: List of emUSB MTP interface functions and data structures**

## 9.4.1 API functions

### 9.4.1.1 USB\_MTP\_Add()

#### Description

Adds an MTP-class interface to the USB stack.

#### Prototype

```
void USB_MTP_Add(const USB_MTP_INIT_DATA * pInitData);
```

| Parameter                 | Description                                            |
|---------------------------|--------------------------------------------------------|
| <a href="#">pInitData</a> | Pointer to a <code>USB_MTP_INIT_DATA</code> structure. |

**Table 9.4: USB\_MTP\_Add() parameter list**

#### Additional information

After the initialization of USB core, this is the first function that needs to be called when an MTP interface is used with emUSB. The structure `USB_MTP_INIT_DATA` has to be initialized before `USB_MTP_Add()` is called. Refer to *USB\_MTP\_INIT\_DATA* on page 266 for more information.

### 9.4.1.2 USB\_MTP\_AddStorage()

#### Description

Adds a storage device to emUSB-MTP.

#### Prototype

```
void USB_MTP_AddStorage(const USB_MTP_INST_DATA * pInstData);
```

| Parameter                 | Description                                                                                                      |
|---------------------------|------------------------------------------------------------------------------------------------------------------|
| <a href="#">pInstData</a> | Pointer to a <code>USB_MTP_INST_DATA</code> structure which contains the parameters of the added storage driver. |

**Table 9.5: USB\_MTP\_AddStorage() parameter list**

#### Additional information

It is necessary to call this function immediately after `USB_MTP_Add()`.

This function adds a storage device such as a hard drive, MMC/SD card or NAND flash etc., to emUSB-MTP, which will be used as source/destination of data exchange with the host. The structure `USB_MTP_INST_DATA` must be initialized before `USB_MTP_AddStorage()` is called. Refer to *USB\_MTP\_INST\_DATA* on page 267 for more information.

### 9.4.1.3 USB\_MTP\_Task()

#### Description

Task which handles the MTP communication.

#### Prototype

```
void USB_MTP_Task(void);
```

#### Additional information

The `USB_MTP_Task()` should be called after the USB device has been successfully enumerated and configured. The function returns when the USB device is detached or suspended.



## 9.4.2 Data structures

### 9.4.2.1 USB\_MTP\_FILE\_INFO

#### Description

Structure which stores information about a file or directory.

#### Prototype

```
typedef struct {
    char * pFilePath;
    char * pFileName;
    U32    FileSize;
    U32    CreationTime;
    U32    LastWriteTime;
    U8     IsDirectory;
    U8     Attributes;
    U8     acId[MTP_NUM_BYTES_FILE_ID];
} USB_MTP_FILE_INFO;
```

| Member                     | Description                                                           |
|----------------------------|-----------------------------------------------------------------------|
| <code>pFilePath</code>     | Pointer to full path to file.                                         |
| <code>pFileName</code>     | Pointer to beginning of file/directory name in <code>pFilePath</code> |
| <code>FileSize</code>      | Size of the file in bytes.                                            |
| <code>CreationTime</code>  | Time and date when the file was created.                              |
| <code>LastWriteTime</code> | Time and data when the file was last modified.                        |
| <code>IsDirectory</code>   | Set to 1 if the path points to a directory.                           |
| <code>Attributes</code>    | Bitmask containing the file or directory attributes.                  |
| <code>acId</code>          | Unique file/directory identifier.                                     |

**Table 9.6: USB\_MTP\_FILE\_INFO elements**

#### Additional Information

The date and time is formatted as follows:

| Bit range | Value range | Description                |
|-----------|-------------|----------------------------|
| 0-4       | 0-29        | 2-second count             |
| 5-10      | 0-59        | Minutes                    |
| 11-15     | 0-23        | Hours                      |
| 16-20     | 1-31        | Day of month               |
| 21-24     | 1-12        | Month of year              |
| 25-31     | 0-127       | Number of years since 1980 |

`acId` should be unique for each file and directory on the file system and it should be persistent between MTP sessions.

The following attributes are supported:

| Bitmask                           | Description                                                           |
|-----------------------------------|-----------------------------------------------------------------------|
| <code>MTP_FILE_ATTR_WP</code>     | File/directory can not be modified                                    |
| <code>MTP_FILE_ATTR_SYSTEM</code> | File/directory is required for the correct functioning of the system. |
| <code>MTP_FILE_ATTR_HIDDEN</code> | File/directory should not be shown to user.                           |

### 9.4.2.2 USB\_MTP\_INIT\_DATA

#### Description

Structure which stores the parameters of the MTP interface.

#### Prototype

```
typedef struct {
    U8      EPIn;
    U8      EPOut;
    U8      EPInt;
    void *  pObjectList;
    U32     NumBytesObjectList;
    void *  pDataBuffer;
    U32     NumBytesDataBuffer;
    //
    // The following fields are used internally by the MTP component.
    //
    U8      InterfaceNum;
    U32     NumBytesAllocated;
    U32     NumObjects;
} USB_MTP_INIT_DATA;
```

| Member                             | Description                                                         |
|------------------------------------|---------------------------------------------------------------------|
| <a href="#">EPIn</a>               | Endpoint for receiving data from host.                              |
| <a href="#">EPOut</a>              | Endpoint for sending data to host.                                  |
| <a href="#">EPInt</a>              | Endpoint for sending events to host.                                |
| <a href="#">pObjectList</a>        | Pointer to a memory region where the list of MTP objects is stored. |
| <a href="#">NumBytesObjectList</a> | Number of bytes allocated for the object list.                      |
| <a href="#">pDataBuffer</a>        | Pointer to a memory region to be used as communication buffer.      |
| <a href="#">NumBytesDataBuffer</a> | Number of bytes allocated for the data buffer.                      |

**Table 9.7: USB\_MTP\_INIT\_DATA elements**

#### Additional Information

This structure holds the endpoints that should be used with the MTP interface. Refer to *USB\_AddEP()* on page 59 for more information about how to add an endpoint.

The number of bytes in the *pDataBuffer* should be a multiple of USB maximum packet size. The number of bytes in the object list depends on the number of files/directories on the storage medium. An object is assigned to each file/directory when the USB host requests the object information for the first time.

### 9.4.2.3 USB\_MTP\_INST\_DATA

#### Description

Structure which stores the parameters of storage driver.

#### Prototype

```
typedef struct {
    const USB_MTP_STORAGE_API * pAPI;
    const char                  * sDescription;
    const char                  * sVolumeId;
    USB_MTP_INST_DATA_DRIVER    DriverData;
} USB_MTP_INST_DATA;
```

| Member                       | Description                                                                                                                                                                                                                                                                                                              |
|------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <a href="#">pAPI</a>         | Pointer to a structure that holds the storage device driver API.                                                                                                                                                                                                                                                         |
| <a href="#">sDescription</a> | Human-readable string which identifies the storage. This string is displayed in Windows Explorer.                                                                                                                                                                                                                        |
| <a href="#">sVolumeId</a>    | Unique volume identifier.                                                                                                                                                                                                                                                                                                |
| <a href="#">DriverData</a>   | Driver data that are passed to the storage driver. Refer to <i>USB_MTP_INST_DATA_DRIVER</i> on page 268 for detailed information about how to initialize this structure. This field must be up to 256 characters long but only the first 128 are significant and these must be unique for all storages of an MTP device. |

**Table 9.8: USB\_MTP\_INST\_DATA elements**

#### Additional Information

The MTP device returns the `sDescription` string in the `Storage Description` parameter and the `sVolumeId` in the `Volume Identifier` of the `StorageInfo` dataset. For more information, refer to MTP specification.

9.4.2.4 USB\_MTP\_INST\_DATA\_DRIVER

Description

Structure which stores the parameters passed to the storage driver.

Prototype

```
typedef struct {
    const char * pRootDir;
} USB_MTP_INST_DATA_DRIVER;
```

| Member                   | Description                                              |
|--------------------------|----------------------------------------------------------|
| <a href="#">pRootDir</a> | Path to directory to be used as the root of the storage. |

Table 9.9: USB\_MTP\_INST\_DATA\_DRIVER

Additional Information

pRootDir can specify the root of the file system or any other subdirectory.

## 9.4.2.5 USB\_MTP\_STORAGE\_API

### Description

Structure that contains callbacks to the storage driver.

### Prototype

```
typedef struct {
    void (*pfInit) (U8 Unit, const USB_MTP_INST_DATA_DRIVER * pDriverData);
    void (*pfGetInfo) (U8 Unit, USB_MTP_STORAGE_INFO * pStorageInfo);
    int (*pfFindFirstFile) (U8 Unit, const char * pDirPath, USB_MTP_FILE_INFO * pFileInfo);
    int (*pfFindNextFile) (U8 Unit, USB_MTP_FILE_INFO * pFileInfo);
    int (*pfOpenFile) (U8 Unit, const char * pFilePath);
    int (*pfCreateFile) (U8 Unit, const char * pDirPath, USB_MTP_FILE_INFO * pFileInfo);
    int (*pfReadFromFile) (U8 Unit, U32 Off, void * pData, U32 NumBytes);
    int (*pfWriteToFile) (U8 Unit, U32 Off, const void * pData, U32 NumBytes);
    int (*pfCloseFile) (U8 Unit);
    int (*pfRemoveFile) (U8 Unit, const char * pFilePath);
    int (*pfCreateDir) (U8 Unit, const char * pDirPath, USB_MTP_FILE_INFO * pFileInfo);
    int (*pfRemoveDir) (U8 Unit, const char * pDirPath);
    int (*pfFormat) (U8 Unit);
    int (*pfRenameFile) (U8 Unit, const char * pDirPath, USB_MTP_FILE_INFO * pFileInfo);
    void (*pfDeInit) (U8 Unit);
    int (*pfGetFileAttributes) (U8 Unit, const char * pFilePath, U8 * pMask);
    int (*pfModifyFileAttributes) (U8 Unit, const char * pFilePath, U8 SetMask, U8 ClrMask);
    int (*pfGetFileCreationTime) (U8 Unit, const char * pFilePath, U32 * pTime);
    int (*pfGetFileLastWriteTime) (U8 Unit, const char * pFilePath, U32 * pTime);
    int (*pfGetFileId) (U8 Unit, const char * pFilePath, U8 * pId);
    int (*pfGetFileSize) (U8 Unit, const char * pFilePath, U32 * pFileSize);
} USB_MTP_STORAGE_API;
```

| Member                            | Description                                                                                         |
|-----------------------------------|-----------------------------------------------------------------------------------------------------|
| <code>(*pfInit)()</code>          | Initializes the storage medium.                                                                     |
| <code>(*pfGetInfo)()</code>       | Returns information about the storage medium such as storage capacity and the available free space. |
| <code>(*pfFindFirstFile)()</code> | Returns information about the first file in a given directory.                                      |
| <code>(*pfFindNextFile)()</code>  | Moves to next file and returns information about it.                                                |

**Table 9.10: List of callback functions of USB\_MTP\_STORAGE\_API**

| Member                                   | Description                                                            |
|------------------------------------------|------------------------------------------------------------------------|
| <code>(*pfOpenFile)()</code>             | Opens an existing file.                                                |
| <code>(*pfCreateFile)()</code>           | Creates a new file.                                                    |
| <code>(*pfReadFromFile)()</code>         | Reads data from the current file.                                      |
| <code>(*pfWriteToFile)()</code>          | Writes data to current file.                                           |
| <code>(*pfCloseFile)()</code>            | Closes the current file.                                               |
| <code>(*pfRemoveFile)()</code>           | Removes a file from storage medium.                                    |
| <code>(*pfCreateDir)()</code>            | Creates a new directory.                                               |
| <code>(*pfRemoveDir)()</code>            | Removes a directory from storage medium.                               |
| <code>(*pfFormat)()</code>               | Formats the storage.                                                   |
| <code>(*pfRenameFile)()</code>           | Changes the name of a file or directory                                |
| <code>(*pfDeInit)()</code>               | Deinitializes the storage medium.                                      |
| <code>(*pfGetFileAttributes)()</code>    | Reads the attributes of a file or directory.                           |
| <code>(*pfModifyFileAttributes)()</code> | Changes the attributes of a file or directory.                         |
| <code>(*pfGetFileCreationTime)()</code>  | Returns the creation time of a file or directory.                      |
| <code>(*pfGetFileLastWriteTime)()</code> | Returns the time of the last modification made to a file or directory. |
| <code>(*pfGetFileId)()</code>            | Returns the unique ID of a file or directory.                          |
| <code>(*pfGetFileSize)()</code>          | Returns the size of a file in bytes.                                   |

**Table 9.10: List of callback functions of USB\_MTP\_STORAGE\_API****Additional Information**

USB\_MTP\_STORAGE\_API is used to retrieve information from the storage driver or to access data that needs to be read or written. Detailed information can be found in *Storage Driver* on page 272.

### 9.4.2.6 USB\_MTP\_STORAGE\_INFO

#### Description

Structure which stores information about the storage medium.

#### Prototype

```
typedef struct {
    U32 NumKbytesTotal;
    U32 NumKbytesFreeSpace;
    U16 FSType;
    U8  IsWriteProtected;
    U8  IsRemovable;
} USB_MTP_STORAGE_INFO;
```

| Member                             | Description                                                |
|------------------------------------|------------------------------------------------------------|
| <a href="#">NumKbytesTotal</a>     | Capacity of storage medium in Kbytes.                      |
| <a href="#">NumKbytesFreeSpace</a> | Available free space on storage medium in Kbytes.          |
| <a href="#">FSType</a>             | Type of file system as specified in MTP.                   |
| <a href="#">IsWriteProtected</a>   | Set to 1 if the storage medium can't be modified.          |
| <a href="#">IsRemovable</a>        | Set to 1 if the storage medium can be removed from device. |

**Table 9.11: USB\_MTP\_STORAGE\_INFO**

## 9.5 Storage Driver

This section describes the storage interface in detail.

### 9.5.1 General information

The storage interface is handled through an API-table, which contains all relevant functions necessary for read/write operations and initialization. Its implementation handles the details of how data is actually read from or written to memory.

This release comes with `USB_MTP_StorageFS` driver which uses `emFile` to access the storage medium.

### 9.5.2 Interface function list

As described above, access to a storage media is realized through an API-function table of type `USB_MTP_STORAGE_API`. The structure is declared in `USB_MTP.h` and it is described in section *Data structures* on page 265.



## 9.5.3 USB\_MTP\_STORAGE\_API in detail

### 9.5.3.1 (\*pfInit)()

#### Description

Initializes the storage medium.

#### Prototype

```
void (*pfInit)(U8 Unit, const USB_MTP_INST_DATA_DRIVER * pDriverData);
```

| Parameter                | Description                                                                                                                                                                                                                                                                            |
|--------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>Unit</code>        | Logical unit number. Specifies for which storage medium the function is called.                                                                                                                                                                                                        |
| <code>pDriverData</code> | Pointer to a <code>USB_MTP_INST_DATA_DRIVER</code> structure that contains all information that are necessary for the driver initialization. For detailed information about the <code>USB_MTP_INST_DATA_DRIVER</code> structure, refer to <i>USB_MTP_INST_DATA_DRIVER</i> on page 268. |

**Table 9.12: (\*pfInit)() parameter list**

#### Additional information

This function is called when the storage driver is added to emUSB-MTP. It is the first function of the storage driver to be called.

### 9.5.3.2 (\*pfGetInfo)()

#### Description

Returns information about storage medium such as capacity and available free space.

#### Prototype

```
void (*pfGetInfo)(U8 Unit, USB_MTP_STORAGE_INFO * pStorageInfo);
```

| Parameter                 | Description                                                                                                                                                                                 |
|---------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>Unit</code>         | Logical unit number. Specifies for which storage medium the function is called.                                                                                                             |
| <code>pStorageInfo</code> | Pointer to a <code>USB_MTP_STORAGE_INFO</code> structure. For detailed information about the <code>USB_MTP_STORAGE_INFO</code> structure, refer to <i>USB_MTP_STORAGE_INFO</i> on page 271. |

**Table 9.13: (\*pfGetInfo)() parameter list**

#### Additional information

Typically, this function is called immediately after the device is connected to USB host when the USB host requests information about the available storage mediums.

### 9.5.3.3 (\*pfFindFirstFile)()

#### Description

Returns information about the first file in a specified directory.

#### Prototype

```
int (*pfFindFirstFile)(U8 Unit,
                      const char * pDirPath,
                      USB_MTP_FILE_INFO * pFileInfo);
```

| Parameter | Description                                                                     |
|-----------|---------------------------------------------------------------------------------|
| Unit      | Logical unit number. Specifies for which storage medium the function is called. |
| pDirPath  | Full path to the directory to be searched.                                      |
| pFileInfo | IN: ---<br>OUT: Information about the file/directory found.                     |

**Table 9.14: (\*pfFindFirstFile)() parameter list**

#### Return value

== 0: File/directory found  
 == 1: No more files/directories found  
 < 0: An error occurred

#### Additional information

The "." and ".." directory entries which are relevant only for the file system should be skipped.

### 9.5.3.4 (\*pfFindNextFile)()

#### Description

Moves to next file and returns information about it.

#### Prototype

```
int (*pfFindNextFile)(U8 Unit, USB_MTP_FILE_INFO * pFileInfo);
```

| Parameter | Description                                                                     |
|-----------|---------------------------------------------------------------------------------|
| Unit      | Logical unit number. Specifies for which storage medium the function is called. |
| pFileInfo | IN: ---<br>OUT: Information about the file/directory found.                     |

**Table 9.15: (\*pfFindNextFile)() parameter list**

#### Return value

== 0: File/directory found  
== 1: No more files/directories found  
< 0: An error occurred

#### Additional information

The "." and ".." directory entries which are relevant only for the file system should be skipped.

### 9.5.3.5 (\*pfOpenFile)()

#### Description

Opens a file for reading.

#### Prototype

```
int (*pfOpenFile)(U8          Unit,
                  const char * pFilePath);
```

| Parameter | Description                                                                     |
|-----------|---------------------------------------------------------------------------------|
| Unit      | Logical unit number. Specifies for which storage medium the function is called. |
| pFilePath | IN: Full path to file.<br>OUT ---.                                              |

**Table 9.16: (\*pfOpenFile)() parameter list**

#### Return value

== 0: File opened

!= 0: An error occurred

#### Additional information

This function is called at the beginning of a file read operation. It is followed by one or more calls to ([\\*pfReadFromFile\(\)](#)). At the end of data transfer the MTP module closes the file by calling ([\\*pfCloseFile\(\)](#)). If the file does not exist an error should be returned. The MTP module opens only one file at a time.

### 9.5.3.6 (\*pfCreateFile)()

#### Description

Opens a file for writing.

#### Prototype

```
int (*pfCreateFile)(U8 Unit,
                    const char * pDirPath,
                    USB_MTP_FILE_INFO * pFileInfo);
```

| Parameter | Description                                                                                                                                                                                                 |
|-----------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Unit      | Logical unit number. Specifies for which storage medium the function is called.                                                                                                                             |
| pDirPath  | IN: Full path to directory where the file should be created.<br>OUT: ---                                                                                                                                    |
| pFileInfo | IN: Information about the file to be created. pFileName points to the name of the file.<br>OUT: pFilePath points to full path of created file, pFileName points to the beginning of file name in pFilePath. |

**Table 9.17: (\*pfCreateFile)() parameter list**

#### Return value

== 0: File created and opened

!= 0: An error occurred

#### Additional information

This function is called at the beginning of a file write operation. The name of the file is specified in the pFileName field of pFileInfo. If the file exists it should be truncated to zero length. When a file is created, the call to (\*pfCreateFile)() is followed by one or more calls to (\*pfWriteToFile)(). If CreationTime and LastWriteTime in pFileInfo are not zero, these should be used instead of the time stamps generated by the file system.

### 9.5.3.7 (\*pfReadFromFile)()

#### Description

Reads data from the current file.

#### Prototype

```
int (*pfReadFromFile)(U8      Unit,
                      U32      Off,
                      void *  pData,
                      U32      NumBytes);
```

| Parameter                | Description                                                                     |
|--------------------------|---------------------------------------------------------------------------------|
| <a href="#">Unit</a>     | Logical unit number. Specifies for which storage medium the function is called. |
| <a href="#">Off</a>      | Byte offset where to read from.                                                 |
| <a href="#">pData</a>    | IN: ---<br>OUT: Data read from file.                                            |
| <a href="#">NumBytes</a> | Number of bytes to read from file.                                              |

**Table 9.18: (\*pfReadFromFile)() parameter list**

#### Return value

== 0: Data read from file

!= 0: An error occurred

#### Additional information

The function reads data from the file opened by [\(\\*pfOpenFile\)\(\)](#).

### 9.5.3.8 (\*pfWriteToFile)()

#### Description

Writes data to current file.

#### Prototype

```
int (*pfWriteToFile) (U8          Unit,
                     U32          Off,
                     const void * pData,
                     U32          NumBytes);
```

| Parameter                | Description                                                                     |
|--------------------------|---------------------------------------------------------------------------------|
| <a href="#">Unit</a>     | Logical unit number. Specifies for which storage medium the function is called. |
| <a href="#">Off</a>      | Byte offset where to write to.                                                  |
| <a href="#">pData</a>    | IN: Data to write to file<br>OUT: ---                                           |
| <a href="#">NumBytes</a> | Number of bytes to write to file.                                               |

**Table 9.19: (\*pfWriteToFile)() parameter list**

#### Return value

== 0: Data written to file

!= 0: An error occurred

#### Additional information

The function writes data to file opened by [\(\\*pfCreateFile\)\(\)](#).



### 9.5.3.9 (\*pfCloseFile)()

#### Description

Closes the current file.

#### Prototype

```
int (*pfCloseFile)(U8 Unit);
```

| Parameter | Description                                                                     |
|-----------|---------------------------------------------------------------------------------|
| Lun       | Logical unit number. Specifies for which storage medium the function is called. |

**Table 9.20: (\*pfCloseFile)() parameter list**

#### Return value

== 0: File closed

!= 0: An error occurred

#### Additional information

The function closes the file opened by `(*pfCreateFile)()` or `(*pfOpenFile)()`.

### 9.5.3.10 (\*pfRemoveFile)()

#### Description

Removes a file/directory from the storage medium.

#### Prototype

```
int (*pfRemoveFile)(U8          Unit,  
                    const char * pFilePath);
```

| Parameter | Description                                                            |
|-----------|------------------------------------------------------------------------|
| Unit      | Logical unit number. Specifies for which drive the function is called. |
| pFilePath | IN: Full path to file/directory to be removed<br>OUT: ---              |

**Table 9.21: (\*pfRemoveFile)() parameter list**

#### Return value

== 0: File removed

!= 0: An error occurred

### 9.5.3.11 (\*pfCreateDir)()

#### Description

Creates a directory on the storage medium.

#### Prototype

```
int (*pfCreateDir)(U8 Unit,
                  const char * pDirPath,
                  USB_MTP_FILE_INFO * pFileInfo);
```

| Parameter | Description                                                                                                                                                                                                     |
|-----------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Unit      | Logical unit number. Specifies for which storage medium the function is called.                                                                                                                                 |
| pDirPath  | IN: Full path to directory where the directory should be created.<br>OUT: ---                                                                                                                                   |
| pFileInfo | IN: Information about the directory to be created. pFileName points to the directory name.<br>OUT: pFilePath points to full path of directory, pFileName points to the beginning of directory name in pFilePath |

**Table 9.22: (\*pfCreateDir)() parameter list**

#### Return value

== 0: Directory created

!= 0: An error occurred

#### Additional information

If `CreationTime` and `LastWriteTime` in `pFileInfo` are not available, zero should be used instead of the time stamps generated by the file system.

### 9.5.3.12 (\*pfRemoveDir())

#### Description

Removes a directory and its contents from the storage medium.

#### Prototype

```
int (*pfRemoveDir)(U8          Unit,  
                  const char * pDirPath);
```

| Parameter | Description                                                                     |
|-----------|---------------------------------------------------------------------------------|
| Unit      | Logical unit number. Specifies for which storage medium the function is called. |
| pDirPath  | IN: Full path to directory to be removed.<br>OUT: ---                           |

**Table 9.23: (\*pfRemoveDir()) parameter list**

#### Return value

== 0: Directory removed  
!= 0: An error occurred

#### Additional information

The function should remove the directory and the entire file tree under it.

### 9.5.3.13 (\*pfFormat)()

#### Description

Initializes the storage medium.

#### Prototype

```
int (*pfFormat)(U8 Unit);
```

| Parameter         | Description                                                                     |
|-------------------|---------------------------------------------------------------------------------|
| <code>Unit</code> | Logical unit number. Specifies for which storage medium the function is called. |

**Table 9.24: (\*pfFormat)() parameter list**

#### Return value

== 0: Storage medium initialized  
 != 0: An error occurred

#### Additional information

The file system layer has to differentiate between two cases, one where the MTP root directory is the same as the root directory of the file system and one where it is only a subdirectory of the file system.

If `pRootDir` which was configured in the call to `(*pfInit)()`, points to a subdirectory of the file system, the storage medium should not be formatted. Instead, all the files and directories underneath `pRootDir` should be removed.

### 9.5.3.14 (\*pfRenameFile)()

#### Description

Changes the name of a file or directory.

#### Prototype

```
int (*pfRenameFile)(U8 Unit, USB_MTP_FILE_INFO * pFileInfo);
```

| Parameter | Description                                                                                                                                                                                                                                                                                                                         |
|-----------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Unit      | Logical unit number. Specifies for which storage medium the function is called.                                                                                                                                                                                                                                                     |
| pFileInfo | IN: Information about the file/directory to be renamed. pFilePath points to the full path and pFileName points to the new name.<br>OUT: pFilePath points to full path of file/directory with the new name, pFileName points to the beginning of file/directory name in pFilePath. The other structure fields should also be filled. |

**Table 9.25: (\*pfRenameFile)() parameter list**

#### Return value

== 0: File/directory renamed  
!= 0: An error occurred

#### Additional information

Only the name of the file/directory should be changed. The path to parent directory should remain the same.

### 9.5.3.15 (\*pfDeInit)()

#### Description

Deinitializes the storage medium.

#### Prototype

```
void (*pfDeInit)(U8 Unit);
```

| Parameter | Description                                                                     |
|-----------|---------------------------------------------------------------------------------|
| Unit      | Logical unit number. Specifies for which storage medium the function is called. |

**Table 9.26: (\*pfDeInit)() parameter list**

#### Additional information

Typically called when the application calls `USB_Stop()` to deinitialize emUSB.

### 9.5.3.16 (\*pfGetFileAttributes)()

#### Description

Returns the attributes of a file or directory.

#### Prototype

```
int (*pfGetFileAttributes)(U8 Unit, const char * pFilePath, U8 * pMask);
```

| Parameter | Description                                                                     |
|-----------|---------------------------------------------------------------------------------|
| Unit      | Logical unit number. Specifies for which storage medium the function is called. |
| pFilePath | Full path to file or directory (0-terminated string).                           |
| pMask     | IN: ---<br>OUT: The bitmask of the attributes.                                  |

**Table 9.27: (\*pfGetFileAttributes)() parameter list**

#### Return value

== 0: Information returned

!= 0: An error occurred

#### Additional information

This function is called only when the compile time switch `MTP_SAVE_FILE_INFO` is set to 0. For the list of supported attributes refer to *USB\_MTP\_FILE\_INFO* on page 265.



### 9.5.3.17 (\*pfModifyFileAttributes)()

#### Description

Sets and clears file attributes.

#### Prototype

```
int (*pfModifyFileAttributes)(U8          Unit,
                             const char * pFilePath,
                             U8          SetMask,
                             U8          ClrMask);;
```

| Parameter | Description                                                                     |
|-----------|---------------------------------------------------------------------------------|
| Unit      | Logical unit number. Specifies for which storage medium the function is called. |
| pFilePath | Full path to file or directory (0-terminated string).                           |
| SetMask   | The bitmask of the attributes which should be set.                              |
| ClrMask   | The bitmask of the attributes which should be cleared.                          |

**Table 9.28: (\*pfModifyFileAttributes)() parameter list**

#### Return value

== 0: Attributes modified

!= 0: An error occurred

#### Additional information

This function is called only when the compile time switch `MTP_SAVE_FILE_INFO` is set to 0. For the list of supported attributes refer to *USB\_MTP\_FILE\_INFO* on page 265.

### 9.5.3.18 (\*pfGetFileCreationTime)()

#### Description

Returns the creation time of file or directory.

#### Prototype

```
int (*pfGetFileCreationTime)(U8 Unit, const char * pFilePath, U32 * pTime);
```

| Parameter | Description                                                                     |
|-----------|---------------------------------------------------------------------------------|
| Unit      | Logical unit number. Specifies for which storage medium the function is called. |
| pFilePath | Full path to file or directory (0-terminated string).                           |
| pTime     | IN: ---<br>OUT: The creation time.                                              |

**Table 9.29: (\*pfGetFileCreationTime)() parameter list**

#### Return value

== 0: Creation time returned

!= 0: An error occurred

#### Additional information

This function is called only when the compile time switch `MTP_SAVE_FILE_INFO` is set to 0. For the encoding of the time value refer to *USB\_MTP\_FILE\_INFO* on page 265.

### 9.5.3.19 (\*pfGetFileLastWriteTime)()

#### Description

Returns the time when the file or directory was last modified.

#### Prototype

```
int (*pfGetFileLastWriteTime)(U8          Unit,
                              const char * pFilePath,
                              U32          * pTime);;
```

| Parameter | Description                                                                     |
|-----------|---------------------------------------------------------------------------------|
| Unit      | Logical unit number. Specifies for which storage medium the function is called. |
| pFilePath | Full path to file or directory (0-terminated string).                           |
| pTime     | IN: ---<br>OUT: The modification time.                                          |

**Table 9.30: (\*pfGetFileLastWriteTime)() parameter list**

#### Return value

== 0: Modification time returned

!= 0: An error occurred

#### Additional information

This function is called only when the compile time switch `MTP_SAVE_FILE_INFO` is set to 0. For the encoding of the time value refer to *USB\_MTP\_FILE\_INFO* on page 265.

### 9.5.3.20 (\*pfGetFileId)()

#### Description

Returns an ID which uniquely identifies the file or directory.

#### Prototype

```
int (*pfGetFileId)(U8 Unit, const char * pFilePath, U8 * pId);
```

| Parameter | Description                                                                                                   |
|-----------|---------------------------------------------------------------------------------------------------------------|
| Unit      | Logical unit number. Specifies for which storage medium the function is called.                               |
| pFilePath | Full path to file or directory (0-terminated string).                                                         |
| pId       | IN: ---<br>OUT: The unique ID of file or directory. Should point to a byte array MTP_NUM_BYTES_FILE_ID large. |

**Table 9.31: (\*pfGetFileId)() parameter list**

#### Return value

== 0: ID returned

!= 0: An error occurred

#### Additional information

This function is called only when the compile time switch `MTP_SAVE_FILE_INFO` is set to 0.

### 9.5.3.21 (\*pfGetFileSize)()

#### Description

Returns the size of a file in bytes.

#### Prototype

```
int (*pfGetFileSize)(U8 Unit, const char * pFilePath, U32 * pFileSize);
```

| Parameter | Description                                                                     |
|-----------|---------------------------------------------------------------------------------|
| Unit      | Logical unit number. Specifies for which storage medium the function is called. |
| pFilePath | Full path to file or directory (0-terminated string).                           |
| pFileSize | IN: ---<br>OUT: The size of file in bytes.                                      |

**Table 9.32: (\*pfGetFileSize)() parameter list**

#### Return value

== 0: Size of file returned

!= 0: An error occurred

#### Additional information

This function is called only when the compile time switch `MTP_SAVE_FILE_INFO` is set to 0.




# Chapter 10

## Communication Device Class (CDC)

---

This chapter describes how to get emUSB up and running as a CDC device.



## 10.1 Overview

The Communication Device Class (CDC) is an abstract USB class protocol defined by the USB Implementers Forum. This protocol covers the handling of the following communication flows:

- VirtualCOM/Serial interface
- Universal modem device
- ISDN communication
- Ethernet communication

This implementation of CDC currently supports the virtual COM/Serial interface, thus the USB device will behave like a serial interface.

Normally, a custom USB driver is not necessary because a kernel mode driver for USB-CDC serial communication is delivered by major Microsoft Windows operating systems. For installing the USB-CDC serial device, an `.inf` file is needed, which is also delivered. Linux handles USB 2 virtual COM ports since Kernel Ver. 2.4. Further information can be found in the Linux Kernel documentation.

### 10.1.1 Configuration

The configuration section should later be modified to match the real application. For the purpose of getting emUSB up and running as well as doing an initial test, the configuration as delivered should not be modified.



## 10.2 The example application

The start application (in the `Application` subfolder) is a simple echo server, which can be used to test emUSB. The application receives data byte by byte and sends it back to the host.

Source code excerpt from `USB_CDC_Start.c`:

```

/*****
*
*      MainTask
*
*  USB handling task.
*  Modify to implement the desired protocol
*/
void MainTask(void);
void MainTask(void) {
    U32 i = 0;

    USB_Init();
    _AddCDC();
    USB_Start();
    while (1) {
        char ac[64];
        char acOut[30];
        int  NumBytesReceived;
        int  NumBytesToSend;

        //
        // Wait for configuration
        //
        while ((USB_GetState() & (USB_STAT_CONFIGURED | USB_STAT_SUSPENDED)) !=
USB_STAT_CONFIGURED) {
            BSP_ToggleLED(0);
            USB_OS_Delay(50);
        }
        BSP_SetLED(0);
        //
        // Receive at maximum of 64 Bytes
        // If less data has been received,
        // this should be OK.
        //
        NumBytesReceived = USB_CDC_Receive(&ac[0], sizeof(ac));
        i++;
        NumBytesToSend = sprintf(acOut, "%.3lu: Received %d byte(s) - \"", i,
NumBytesReceived);
        if (NumBytesReceived > 0) {
            USB_CDC_Write(&acOut[0], NumBytesToSend);
            USB_CDC_Write(&ac[0], NumBytesReceived);
            USB_CDC_Write("\"\\n\\r", 3);
        }
    }
}

```

## 10.3 Installing the driver


When the emUSB-CDC sample application is up and running and the target device is plugged into the computer's USB port, Windows will detect the new hardware.




The wizard will ask you to help determine the correct driver files for the new device. First select the **Search for a suitable driver for my device (recommended)** option, then click the **Next** button.




In the next step, you need to select the **Specify a location** option and click the **Next** button.



Click **Browse** to open the directory navigator.



Use the directory navigator to select `C:\USBStack\CDC` (or your chosen location) and click the **Open** button to select `usbser.inf`.



The wizard confirms your choice and starts to copy, when you click the **Next** button.



At this point, the installation is complete. Click the **Finish** button to dismiss the wizard.



## 10.3.1 The .inf file

The .inf file is required for installation.

It is as follows:

```
;
;   Device installation file for
;   USB 2 COM port emulation
;
;
;
[Version]
Signature="$CHICAGO$"
Class=Ports
ClassGuid={4D36E978-E325-11CE-BFC1-08002BE10318}
Provider=%MFGNAME%
DriverVer=01/08/2007,2.2.0.0
LayoutFile=Layout.inf

[Manufacturer]
%MFGNAME%=USB2SerialDeviceList

[USB2SerialDeviceList]
%USB2SERIAL%=USB2SerialInstall, USB\VID_8765&PID_0234

[DestinationDirs]
USB2SerialCopyFiles=12
DefaultDestDir=12

[USB2SerialInstall]
CopyFiles=USB2SerialCopyFiles
AddReg=USB2SerialAddReg

[USB2SerialCopyFiles]
usbser.sys,,0x20

[USB2SerialAddReg]
HKR,,DevLoader,,*ntkern
HKR,,NTMPDriver,,usbser.sys
HKR,,EnumPropPages32,, "MsPorts.dll,SerialPortPropPageProvider"

[USB2SerialInstall.Services]
AddService = usbser,0x0002,USB2SerialService

[USB2SerialService]
DisplayName = %USB2SERIAL_DISPLAY_NAME%
ServiceType = 1 ; SERVICE_KERNEL_DRIVER
StartType = 3 ; SERVICE_DEMAND_START
ErrorControl = 1 ; SERVICE_ERROR_NORMAL
ServiceBinary = %12%\usbser.sys
LoadOrderGroup = Base

[Strings]
MFGNAME= "Manufacturer"
USB2SERIAL = "USB CDC serial port emulation"
USB2SERIAL_DISPLAY_NAME = "USB CDC serial port emulation"
```

red - required modifications

green - possible modifications

You have to personalize the .inf file on the red marked positions. Changes on the green marked positions are optional and not necessary for the correct function of the device.

Replace the red marked positions with your personal Vendor ID (VID) and Product ID (PID). These changes have to be identical with the modifications in the configuration file USB\_Config.h to work correctly.


The required modifications of the file `USB_Conf.h` are described in the configuration chapter.

## 10.3.2 Installation verification


After the device has been installed, it can verify that the installation of the USB device was successful. Hence, take a look in the device manager to check that the USB device is displayed.

The following steps perform:


- Open the **Run** dialog box from the start menu.  
Type `devmgmt.msc` and click **OK**:



- The **Device Manager** window is displayed and may look like this:



Click on the **Ports (COM & LPT)** branch to open the branch:



You should see the **USB CDC serial port emulation (COM<sub>x</sub>)**, where <sub>x</sub> gives the COM port number has Windows has assigned to the device.


### 10.3.3 Testing communication to the USB device

The start application is a simple echo server. This means each character that is entered and sent through the virtual serial port will be sent back by the USB device and will be shown by a terminal program. To test the communication to the device, a terminal program such as HyperTerminal, should be used.


This section shows how to check the communication between host and USB host using the HyperTerminal program.

This section is relevant for Windows XP and below, for newer Windows versions please use a terminal program of your choice.


- Open the **Run** dialog box from the start menu.  
Type `hypertrm.exe` and press Enter key to open the HyperTerminal.  
HyperTerminal displays the Connection Description dialog.  
Give this new connection a name as shown below and click **OK**.



- After creating the new connection, the **Connect To** dialog box is displayed and will ask which COM port you want to use. Click on the arrow for the **Connect Using** drop down box. Select **COMx**, where x is the port number that is assigned to your device by Windows. To confirm your choice click **OK**.




- The **COMx Property** dialog box is displayed to setup the connection properties. Setup the values as shown below:




- To confirm your selection, click **OK**.



- Now everything is configured and an empty terminal window is shown.



Type any characters, these characters will be sent to target. The echo of the target is shown in the terminal window:



## 10.4 Target API

This chapter describes the functions and data structures that can be used with the target application.

## 10.4.1 Interface function list

| Name                                                         | Description                                                                                                                         |
|--------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------|
| API functions                                                |                                                                                                                                     |
| USB_CDC_Add()                                                | Adds CDC-class to the emUSB interface.                                                                                              |
| USB_CDC_CancelRead()<br>USB_CDC_CancelReadEx()               | Cancels an asynchronous read operation that is pending                                                                              |
| USB_CDC_CancelWrite()<br>USB_CDC_CancelWriteEx()             | Cancels an asynchronous read operation that is pending                                                                              |
| USB_CDC_Read()<br>USB_CDC_ReadEx()                           | Reads data from host.                                                                                                               |
| USB_CDC_ReadOverlapped()<br>USB_CDC_ReadOverlappedEx()       | Reads data from host asynchronously.                                                                                                |
| USB_CDC_ReadTimed()<br>USB_CDC_ReadTimedEx()                 | Reads data from host with a given timeout.                                                                                          |
| USB_CDC_Receive()<br>USB_CDC_ReceiveEx()                     | Reads data from host.                                                                                                               |
| USB_CDC_ReceiveTimed()<br>USB_CDC_ReceiveTimedEx()           | Reads data from host with a given timeout. This function returns immediately as soon as data has been received or a timeout occurs. |
| USB_CDC_SetOnBreak()<br>USB_CDC_SetOnBreakEx()               | Sets a callback for receiving a SEND_BREAK by the host.                                                                             |
| USB_CDC_SetOnLineCoding()<br>USB_CDC_SetOnLineCodingEx()     | Sets a callback for registering changing of the "line-coding" by the host.                                                          |
| USB_CDC_UpdateSerialState()<br>USB_CDC_UpdateSerialStateEx() | Changes the current serial state.                                                                                                   |
| USB_CDC_Write()<br>USB_CDC_WriteEx()                         | Writes data to host.                                                                                                                |
| USB_CDC_WriteOverlapped()<br>USB_CDC_WriteOverlappedEx()     | Writes data to host asynchronously.                                                                                                 |
| USB_CDC_WriteTimed()<br>USB_CDC_WriteTimedEx()               | Writes data to the host with a given timeout.                                                                                       |
| USB_CDC_WaitForRX()<br>USB_CDC_WaitForRXEx()                 | Waits for reading data transfer from the Host to be ended.                                                                          |
| USB_CDC_WaitForTX()<br>USB_CDC_WaitForTXEx()                 | Waits for writing data transfer to the Host to be ended.                                                                            |
| USB_CDC_WriteSerialState()<br>USB_CDC_WriteSerialStateEx()   | Sends the current serial state to the Host.                                                                                         |
| USB_CDC_GetNumBytesRemToReadEx()<br>( )                      | Returns the number of byte which still need to be read.                                                                             |
| USB_CDC_GetNumBytesToWriteEx()                               | Returns the number of byte which still need to be written.                                                                          |
| USB_CDC_StartReadTransferEx()                                | Initiates a read data transfer.                                                                                                     |
| USB_CDC_GetNumBytesInBufferEx()<br>( )                       | Retrives the amount of bytes in the internal read buffer.                                                                           |
| Data structures                                              |                                                                                                                                     |
| USB_CDC_INIT_DATA                                            | Initialization structure that is needed when adding an CDC interface.                                                               |
| USB_CDC_ON_SET_BREAK                                         | Callback function to receive a break condition sent by the host.                                                                    |
| USB_CDC_ON_SET_LINE_CODING                                   | Callback registering line-coding changes.                                                                                           |
| USB_CDC_LINE_CODING                                          | Structure that contains the new line-coding sent by the host.                                                                       |

**Table 10.1: USB-CDC API overview**

## 10.4.2 API functions

### 10.4.2.1 USB\_CDC\_Add()

#### Description

Adds CDC class to the USB interface.

#### Prototype

```
USB_CDC_HANDLE USB_CDC_Add(const USB_CDC_INIT_DATA * pInitData);
```

| Parameter              | Description                                                                                                                                                                        |
|------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>pInitData</code> | Pointer to a <code>USB_CDC_INIT_DATA</code> structure. For detailed information about the <code>USB_CDC_INIT_DATA</code> structure, refer to <i>USB_CDC_INIT_DATA</i> on page 329. |

**Table 10.2: USB\_CDC\_Add() parameter list**

#### Return value

`== 0xFFFFFFFF`: New CDC Instance can not be created.  
`!= 0xFFFFFFFF`: Handle to a valid CDC instance.

#### Additional information

After the initialization of general emUSB, this is the first function that needs to be called when the USB-CDC interface is used with emUSB. The returned value can be used with the CDC Ex-Function in order to talk to the right CDC instance.

For creating more more than one CDC-Instance please make sure the `USB_EnableIAD()` is called before, otherwise none but the first CDC instance will work correctly.

### 10.4.2.2 USB\_CDC\_CancelRead() USB\_CDC\_CancelReadEx()

#### Description

Cancels a non-blocking write operation that is pending.

#### Prototype

```
void USB_CDC_CancelRead(void);  
void USB_CDC_CancelReadEx(USB_CDC_HANDLE hInst);
```

| Parameter             | Description                                                                 |
|-----------------------|-----------------------------------------------------------------------------|
| <a href="#">hInst</a> | Handle to a valid CDC instance, returned by <a href="#">USB_CDC_Add()</a> . |

**Table 10.3: USB\_CDC\_CancelReadEx() parameter list**

#### Additional information

This function shall be called when a pending asynchronous read operation (triggered by [USB\\_CDC\\_ReadOverlapped\(\)](#) [USB\\_CDC\\_ReadOverlappedEx\(\)](#)) should be canceled. The function can be called from any task.

### 10.4.2.3 USB\_CDC\_CancelWrite() USB\_CDC\_CancelWriteEx()

#### Description

Cancels a non-blocking write operation that is pending.

#### Prototype

```
void USB_CDC_CancelWrite(void);  
void USB_CDC_CancelWriteEx(USB_CDC_HANDLE hInst);;
```

| Parameter             | Description                                                                 |
|-----------------------|-----------------------------------------------------------------------------|
| <a href="#">hInst</a> | Handle to a valid CDC instance, returned by <a href="#">USB_CDC_Add()</a> . |

**Table 10.4: USB\_CDC\_CancelWriteEx() parameter list**

#### Additional information

This function shall be called when a pending asynchronously write operation (triggered by [USB\\_CDC\\_WriteOverlapped\(\)](#) [USB\\_CDC\\_WriteOverlappedEx\(\)](#)) should be canceled. It can be called from any task.

### 10.4.2.4 USB\_CDC\_Read() USB\_CDC\_ReadEx()

#### Description

Reads data from the host. This function blocks until `NumBytes` have been read or until the device is disconnected from the host.

#### Prototype

```
int  USB_CDC_Read(void * pData, unsigned NumBytes);
int  USB_CDC_ReadEx(USB_CDC_HANDLE hInst, void* pData, unsigned NumBytes);
```

| Parameter             | Description                                                              |
|-----------------------|--------------------------------------------------------------------------|
| <code>hInst</code>    | Handle to a valid CDC instance, returned by <code>USB_CDC_Add()</code> . |
| <code>pData</code>    | Pointer to a buffer where the received data will be stored.              |
| <code>NumBytes</code> | Number of bytes to read.                                                 |

**Table 10.5: USB\_CDC\_Read()/USB\_CDC\_ReadEx() parameter list**

#### Return value

`== NumBytes`: Number of bytes that have been read.  
`!= NumBytes`: Returns a `USB_STATUS_ERROR`.

#### Additional information

This function blocks a task until all data has been read. In case of a reset or a disconnect `USB_STATUS_ERROR` is returned.

### 10.4.2.5 USB\_CDC\_ReadOverlapped() USB\_CDC\_ReadOverlappedEx()

#### Description

Reads data from the host asynchronously.

#### Prototype

```
int  USB_CDC_ReadOverlapped(void* pData, unsigned NumBytes);  
int  USB_CDC_ReadOverlappedEx(USB_CDC_HANDLE hInst,  
                               void* pData,  
                               unsigned NumBytes);
```

| Parameter                | Description                                                                 |
|--------------------------|-----------------------------------------------------------------------------|
| <a href="#">hInst</a>    | Handle to a valid CDC instance, returned by <a href="#">USB_CDC_Add()</a> . |
| <a href="#">pData</a>    | Pointer to a buffer where the received data will be stored.                 |
| <a href="#">NumBytes</a> | Number of bytes to read.                                                    |

**Table 10.6: USB\_CDC\_ReadOverlapped()/USB\_CDC\_ReadOverlappedEx() parameter list**

#### Return value

> 0: Number of bytes that have been read from the internal buffer (success).  
== 0: No data was found in the internal buffer (success).  
< 0: Error.

#### Additional information

This function will not block the calling task. The read transfer will be initiated and the function returns immediately. In order to synchronize, [USB\\_CDC\\_WaitForRX\(\)](#) [USB\\_CDC\\_WaitForRXEx\(\)](#) needs to be called.

Another synchronisation method would be to periodically call [USB\\_CDC\\_GetNumBytesRemToReadEx\(\)](#) in order to see how many bytes still need to be received (this method is preferred when a non-blocking solution is necessary).

#### Example

See [USB\\_CDC\\_GetNumBytesRemToReadEx\(\)](#).



### 10.4.2.6 USB\_CDC\_ReadTimed() USB\_CDC\_ReadTimedEx()

#### Description

Reads data from the host with a given timeout.

#### Prototype

```
int  USB_CDC_ReadTimed(void* pData, unsigned NumBytes, unsigned ms);
int  USB_CDC_ReadTimedEx(USB_CDC_HANDLE hInst, void* pData, unsigned
NumBytes, unsigned ms);
```

| Parameter             | Description                                                                 |
|-----------------------|-----------------------------------------------------------------------------|
| <code>hInst</code>    | Handle to a valid CDC instance, returned by <code>USB_CDC_Add()</code> .    |
| <code>pData</code>    | Pointer to a buffer where the received data will be stored.                 |
| <code>NumBytes</code> | Number of bytes to read.                                                    |
| <code>ms</code>       | Timeout given in milliseconds. A zero value results in an infinite timeout. |

**Table 10.7: USB\_CDC\_ReadTimed()/USB\_CDC\_ReadTimedEx() parameter list**

#### Return value

`== NumBytes`: Number of bytes that have been read within the given timeout.  
`!= NumBytes`: Returns a `USB_STATUS_ERROR` or `USB_STATUS_TIMEOUT`.

#### Additional information

This function blocks a task until all data has been read or a timeout occurs. In case of a reset or a disconnect `USB_STATUS_ERROR` is returned.

### 10.4.2.7 USB\_CDC\_Receive() USB\_CDC\_ReceiveEx()

#### Description

Reads data from host. The function blocks until any data has been received. In contrast to `USB_CDC_Read()` `USB_CDC_ReadEx()` this function does not wait for all of `NumBytes` to be received, but returns after the first packet has been received.

#### Prototype

```
int USB_CDC_Receive(void * pBuffer, unsigned NumBytes);  
int USB_CDC_ReceiveEx(USB_CDC_HANDLE hInst, void * pBuffer, unsigned  
NumBytes);
```

| Parameter             | Description                                                              |
|-----------------------|--------------------------------------------------------------------------|
| <code>hInst</code>    | Handle to a valid CDC instance, returned by <code>USB_CDC_Add()</code> . |
| <code>pBuffer</code>  | Pointer to a buffer where the received data will be stored.              |
| <code>NumBytes</code> | Number of bytes to read.                                                 |

**Table 10.8: USB\_CDC\_Receive()/USB\_CDC\_ReceiveEx() parameter list**

#### Return value

> 0: Number of bytes that have been read.  
== 0: Zero packet received (not every controller supports this!) or the target was disconnected during the function call.  
< 0: Returns a `USB_STATUS_ERROR`.

#### Additional information

If no error occurs, this function returns the number of bytes received. Calling `USB_CDC_Receive()` will return as much data as is currently available up to the size of the buffer specified. This function also returns when target is disconnected from host or when a USB reset occurred, it will then return the number of bytes read.

### 10.4.2.8 USB\_CDC\_ReceiveTimed() USB\_CDC\_ReceiveTimedEx()

#### Description

Reads data from host. The function blocks until any data has been received. In contrast to `USB_CDC_ReadTimed()` `USB_CDC_ReadTimedEx()` this function does not wait for all of `NumBytes` to be received, but returns after the first packet has been received or after the timeout has been reached.

#### Prototype

```
int USB_CDC_ReceiveTimed(void * pBuffer, unsigned NumBytes, unsigned ms);
int USB_CDC_ReceiveTimedEx(USB_CDC_HANDLE hInst, void * pBuffer, unsigned
NumBytes, unsigned ms);
```

| Parameter             | Description                                                                 |
|-----------------------|-----------------------------------------------------------------------------|
| <code>hInst</code>    | Handle to a valid CDC instance, returned by <code>USB_CDC_Add()</code> .    |
| <code>pBuffer</code>  | Pointer to a buffer where the received data will be stored.                 |
| <code>NumBytes</code> | Number of bytes to read.                                                    |
| <code>ms</code>       | Timeout given in milliseconds. A zero value results in an infinite timeout. |

**Table 10.9: USB\_CDC\_ReceiveTimed()/USB\_CDC\_ReceiveTimedEx() parameter list**

#### Return value

- > 0: Number of bytes that have been read within the given timeout.
- == 0: Zero packet received (not every controller supports this!) or the target was disconnected during the function call.
- < 0: Returns a `USB_STATUS_ERROR` or `USB_STATUS_TIMEOUT`.

#### Additional information

If no error occurs, this function returns the number of bytes received. Calling `USB_CDC_ReceiveTimed()` will return as much data as is currently available up to the size of the buffer specified within the specified timeout. This function also returns when target is disconnected from host or when a USB reset occurred, it will then return the number of bytes read.

### 10.4.2.9 USB\_CDC\_SetOnBreak() USB\_CDC\_SetOnBreakEx()

#### Description

Sets a callback for receiving a SEND\_BREAK by the host.

#### Prototype

```
void USB_CDC_SetOnBreak (USB_CDC_ON_SET_BREAK * pfOnBreak);  
void USB_CDC_SetOnBreakEx(USB_CDC_HANDLE hInst,  
                           USB_CDC_ON_SET_BREAK * pfOnBreak);
```

| Parameter          | Description                                                                                                                                                                                                   |
|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>hInst</code> | Handle to a valid CDC instance, returned by <code>USB_CDC_Add()</code> .                                                                                                                                      |
| <code>pf</code>    | Pointer to the callback function <code>USB_CDC_ON_SET_BREAK</code> . For detailed information about the <code>USB_CDC_ON_SET_BREAK</code> function pointer, refer to <i>USB_CDC_ON_SET_BREAK</i> on page 330. |

**Table 10.10: USB\_CDC\_SetOnBreak()/USB\_CDC\_SetOnBreakEx() parameter list**

#### Additional information

This function is used to register a user callback which should notify the application about a break condition sent by the host. Refer to *USB\_CDC\_ON\_SET\_BREAK* on page 330 for detailed information. The callback is called in an ISR context, therefore it should execute quickly.

### 10.4.2.10 USB\_CDC\_SetOnLineCoding() USB\_CDC\_SetOnLineCodingEx()

#### Description

Sets a callback for registering changing of the “line-coding” by the host.

#### Prototype

```
void USB_CDC_SetOnLineCoding(USB_CDC_ON_SET_LINE_CODING * pf);
void USB_CDC_SetOnLineCodingEx(USB_CDC_HANDLE hInst,
                                USB_CDC_ON_SET_LINE_CODING * pf);
```

| Parameter          | Description                                                                                                                                                                                                                     |
|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>hInst</code> | Handle to a valid CDC instance, returned by <code>USB_CDC_Add()</code> .                                                                                                                                                        |
| <code>pf</code>    | Pointer to the callback function <code>USB_CDC_ON_SET_LINE_CODING</code> . For detailed information about the <code>USB_CDC_ON_SET_LINE_CODING</code> function pointer, refer to <i>USB_CDC_ON_SET_LINE_CODING</i> on page 331. |

**Table 10.11: USB\_CDC\_SetLineCoding()/USB\_CDC\_SetLineCodingEx() parameter list**

#### Additional information

This function is used to register a user callback which notifies the application that the host has changed the line coding refer to *USB\_CDC\_ON\_SET\_LINE\_CODING* on page 331 for detailed information. The callback is called in an ISR context, therefore it should execute quickly.

### 10.4.2.11 USB\_CDC\_UpdateSerialState() USB\_CDC\_UpdateSerialStateEx()

#### Description

Updates the control line state of the.

#### Prototype

```
void USB_CDC_UpdateSerialState(USB_CDC_SERIAL_STATE * pSerialState);  
void USB_CDC_UpdateSerialStateEx(USB_CDC_HANDLE hInst, USB_CDC_SERIAL_STATE  
* pSerialState);
```

| Parameter                 | Description                                                                                                   |
|---------------------------|---------------------------------------------------------------------------------------------------------------|
| <code>hInst</code>        | Handle to a valid CDC instance, returned by <code>USB_CDC_Add()</code> .                                      |
| <code>pSerialState</code> | Pointer to the <code>USB_CDC_SERIAL_STATE</code> structure, refer to <i>USB_CDC_SERIAL_STATE</i> on page 333. |

**Table 10.12: USB\_CDC\_UpdateSerialState()/USB\_CDC\_UpdateSerialStateEx() parameter list**

#### Additional information

This function updates the control line state internally. In order to inform the host about the serial state change, refer to the function *USB\_CDC\_WriteSerialState()* *USB\_CDC\_WriteSerialStateEx()* on page 324.

### 10.4.2.12 USB\_CDC\_Write() USB\_CDC\_WriteEx()

#### Description

Writes data to the host.

#### Prototype

```
void USB_CDC_Write(const void* pData, unsigned NumBytes);
void USB_CDC_WriteEx(USB_CDC_HANDLE hInst, const void* pData, unsigned
NumBytes);
```

| Parameter                | Description                                                |
|--------------------------|------------------------------------------------------------|
| <a href="#">hInst</a>    | Handle to a valid CDC instance, returned by USB_CDC_Add(). |
| <a href="#">pData</a>    | Pointer to data that should be sent to the host.           |
| <a href="#">NumBytes</a> | Number of bytes to write.                                  |

**Table 10.13: USB\_CDC\_Write()/USB\_CDC\_WriteEx() parameter list**

#### Additional information

This function is blocking.

### 10.4.2.13 USB\_CDC\_WriteOverlapped() USB\_CDC\_WriteOverlappedEx()

#### Description

Writes data to the host asynchronously.

#### Prototype

```
void USB_CDC_WriteOverlapped(const void* pData, unsigned NumBytes);
void USB_CDC_WriteOverlappedEx(USB_CDC_HANDLE hInst, const void* pData,
                               unsigned NumBytes);
```

| Parameter                | Description                                                                 |
|--------------------------|-----------------------------------------------------------------------------|
| <a href="#">hInst</a>    | Handle to a valid CDC instance, returned by <a href="#">USB_CDC_Add()</a> . |
| <a href="#">pData</a>    | Pointer to data that should be sent to the host.                            |
| <a href="#">NumBytes</a> | Number of bytes to write.                                                   |

**Table 10.14: USB\_CDC\_WriteOverlapped()/USB\_CDC\_WriteOverlappedEx() parameter list**

#### Return value

> 0: Number of bytes that have been written from the internal buffer (success).  
 == 0: No data was found in the internal buffer (success).  
 < 0: Error.

#### Additional information

This function will not block the calling task. The write transfer will be initiated and the function returns immediately. In order to synchronize, [USB\\_CDC\\_WaitForTX\(\)](#) [USB\\_CDC\\_WaitForTXEx\(\)](#) () needs to be called.

Another synchronisation method would be to periodically call [USB\\_CDC\\_GetNumBytesToWriteEx\(\)](#) in order to see how many bytes still need to be written (this method is preferred when a non-blocking solution is necessary).

#### Example:

See [USB\\_CDC\\_GetNumBytesToWriteEx\(\)](#).



### 10.4.2.14 USB\_CDC\_WriteTimed() USB\_CDC\_WriteTimedEx()

#### Description

Writes data to the host with a given timeout.

#### Prototype

```
int USB_CDC_WriteTimed(const void * pData, unsigned NumBytes, unsigned ms)
int USB_CDC_WriteTimedEx(USB_CDC_HANDLE hInst, const void * pData, unsigned
NumBytes, unsigned ms);
```

| Parameter             | Description                                                                 |
|-----------------------|-----------------------------------------------------------------------------|
| <code>hInst</code>    | Handle to a valid CDC instance, returned by <code>USB_CDC_Add()</code> .    |
| <code>pData</code>    | Pointer to a buffer where the data to send is stored.                       |
| <code>NumBytes</code> | Number of bytes to write.                                                   |
| <code>ms</code>       | Timeout given in milliseconds. A zero value results in an infinite timeout. |

**Table 10.15: USB\_CDC\_WriteTimed()/USB\_CDC\_WriteTimedEx() parameter list**

#### Return value

`>= 0`    Number of bytes that have been written within the given timeout.  
`< 0`     Returns a `USB_STATUS_ERROR` or `USB_STATUS_TIMEOUT`.

#### Additional information

This function blocks a task until all data has been written or a timeout occurs. This function also returns when target is disconnected from host or when a USB reset occurred.

### 10.4.2.15 USB\_CDC\_WaitForRX() USB\_CDC\_WaitForRXEx()

#### Description

This function is to be used in combination with `USB_CDC_ReadOverlapped()` `USB_CDC_ReadOverlappedEx()`. This function waits for the reading data transfer from the host to complete.

#### Prototype

```
void USB_CDC_WaitForRX(void);  
void USB_CDC_WaitForRXEx(USB_CDC_HANDLE hInst);
```

| Parameter          | Description                                                              |
|--------------------|--------------------------------------------------------------------------|
| <code>hInst</code> | Handle to a valid CDC instance, returned by <code>USB_CDC_Add()</code> . |

**Table 10.16: USB\_CDC\_WaitForRX()/USB\_CDC\_WaitForRXEx() parameter list**

#### Additional information

This function shall be called in order to synchronize task with the read data transfer previously initiated.

This function blocks until the number of bytes specified by `USB_CDC_ReadOverlapped()` `USB_CDC_ReadOverlappedEx()` has been read from the host.

### 10.4.2.16 USB\_CDC\_WaitForTX() USB\_CDC\_WaitForTXEx()

#### Description

This function is to be used in combination with `USB_CDC_WriteOverlapped()` `USB_CDC_WriteOverlappedEx()`. This function waits for the writing data transfer to the host to complete.

#### Prototype

```
void USB_CDC_WaitForTX(void);
void USB_CDC_WaitForTXEx(USB_CDC_HANDLE hInst);
```

| Parameter          | Description                                                              |
|--------------------|--------------------------------------------------------------------------|
| <code>hInst</code> | Handle to a valid CDC instance, returned by <code>USB_CDC_Add()</code> . |

**Table 10.17: USB\_CDC\_WaitForTX()/USB\_CDC\_WaitForTXEx() parameter list**

#### Additional information

This function shall be called in order to synchronize task with the write data transfer previously initiated.

This function blocks until the number of bytes specified by `USB_CDC_WriteOverlapped()` `USB_CDC_WriteOverlappedEx()` has been written to the host.

### 10.4.2.17 USB\_CDC\_WriteSerialState() USB\_CDC\_WriteSerialStateEx()

#### Description

Sends the current control line serial state to the host.

#### Prototype

```
void USB_CDC_WriteSerialState(void);  
void USB_CDC_WriteSerialStateEx(USB_CDC_HANDLE hInst);
```

| Parameter             | Description                                                |
|-----------------------|------------------------------------------------------------|
| <a href="#">hInst</a> | Handle to a valid CDC instance, returned by USB_CDC_Add(). |

**Table 10.18: USB\_CDC\_WriteSerialState()/USB\_CDC\_WriteSerialStateEx parameter list**

#### Additional information

This function shall be called in order to inform the host about the control serial state of the CDC instance. It may be called within the same function or in another task dedicated to sending the serial state.

This function blocks until the host has received the serial state.

### 10.4.2.18 USB\_CDC\_GetNumBytesRemToReadEx()

#### Description

This function is to be used in combination with `USB_CDC_ReadOverlapped()` `USB_CDC_ReadOverlappedEx()`. It returns the number of bytes which still have to be read during the transaction.

#### Prototype

```
unsigned USB_CDC_GetNumBytesRemToReadEx(USB_CDC_HANDLE hInst);
```

| Parameter          | Description                                                              |
|--------------------|--------------------------------------------------------------------------|
| <code>hInst</code> | Handle to a valid CDC instance, returned by <code>USB_CDC_Add()</code> . |

**Table 10.19: USB\_CDC\_GetNumBytesRemToReadEx() parameter list**

#### Return value

$\geq 0$ : Number of bytes which still have to be read.  
 $< 0$ : Error.

#### Additional information

Note that this function does not return the number of bytes that have been read, but the number of bytes which still have to be read.  
 This function does not block.

#### Example:

```
NumBytesReceived = USB_CDC_ReadOverlappedEx(hInst, &ac[0], 50);
if (NumBytesReceived > 0) {
    // Already had some data in the internal buffer.
    <...process remaining bytes...>
} else {
    // Wait until we get all 50 bytes
    NumBytesToRead = USB_CDC_GetNumBytesRemToReadEx(hInst);
    while (NumBytesToRead > 0) {
        USB_OS_Delay(50);
        NumBytesToRead = USB_CDC_GetNumBytesRemToReadEx(hInst);
    }
}
```

### 10.4.2.19 USB\_CDC\_GetNumBytesToWriteEx()

#### Description

This function is to be used in combination with `USB_CDC_WriteOverlapped()` `USB_CDC_WriteOverlappedEx()`. It returns the number of bytes which still have to be written during the transaction.

#### Prototype

```
unsigned USB_CDC_GetNumBytesToWriteEx(USB_CDC_HANDLE hInst);
```

| Parameter          | Description                                                              |
|--------------------|--------------------------------------------------------------------------|
| <code>hInst</code> | Handle to a valid CDC instance, returned by <code>USB_CDC_Add()</code> . |

**Table 10.20: USB\_CDC\_GetNumBytesToWriteEx() parameter list**

#### Return value

`>= 0`: Number of bytes which still have to be written.

`< 0`: Error.

#### Additional information

Note that this function does not return the number of bytes that have been read, but the number of bytes which still have to be read.

This function does not block.

#### Example:

```
// NumBytesWritten will contain > 0 values if we had anything in the write buffer.
NumBytesWritten = USB_CDC_WriteOverlappedEx(hInst, &ac[0], TRANSFER_SIZE);
// NumBytesToWrite shows how many bytes still have to be written.
NumBytesToWrite = USB_CDC_GetNumBytesToWriteEx(hInst);
while (NumBytesToWrite > 0) {
    USB_OS_Delay(50);
    NumBytesToWrite = USB_CDC_GetNumBytesToWriteEx(hInst);
}
```

## 10.4.2.20 USB\_CDC\_StartReadTransferEx()

### Description

Initiate a read data transfer. Data will be stored in the internal buffer.

### Prototype

```
void USB_CDC_StartReadTransferEx(USB_CDC_HANDLE hInst);
```

| Parameter          | Description                                                              |
|--------------------|--------------------------------------------------------------------------|
| <code>hInst</code> | Handle to a valid CDC instance, returned by <code>USB_CDC_Add()</code> . |

**Table 10.21: USB\_CDC\_StartReadTransferEx() parameter list**

### Additional information

To check how many bytes have been stored, the function

`USB_CDC_GetNumBytesInBufferEx()` has to be called.

In order to read the data the function `USB_CDC_Read()` `USB_CDC_ReadEx()` needs to be called.

This function does not block.

### Example:

```
//
// Trigger the read transfer.
//
USB_CDC_StartReadTransferEx(hInst);
while (1) {
    //
    // Check whether we received some bytes.
    //
    NumBytesReceived = USB_CDC_GetNumBytesInBufferEx(hInst);
    if (NumBytesReceived) {
        //
        // If we received something - use the normal Read function
        //
        USB_CDC_ReadEx(hInst, &ac[0], NumBytesReceived);
    } else {
        <.. Nothing received yet, do application processing..>
    }
}
```

### 10.4.2.21 USB\_CDC\_GetNumBytesInBufferEx()

#### Description

This function is to be used in combination with `USB_CDC_StartReadTransferEx()`. This functions retrieves the number of bytes which have been stored in the internal read buffer after `USB_CDC_StartReadTransferEx()` has been called.

#### Prototype

```
unsigned USB_CDC_GetNumBytesInBufferEx(USB_CDC_HANDLE hInst);
```

| Parameter          | Description                                                              |
|--------------------|--------------------------------------------------------------------------|
| <code>hInst</code> | Handle to a valid CDC instance, returned by <code>USB_CDC_Add()</code> . |

**Table 10.22: USB\_CDC\_GetNumBytesInBufferEx() parameter list**

#### Return value

> 0: Number of bytes which have been stored in the internal buffer.

== 0: Nothing stored yet.



## 10.4.3 Data structures

### 10.4.3.1 USB\_CDC\_INIT\_DATA

#### Description

Initialization structure that is needed when adding a CDC interface to emUSB.

#### Prototype

```
typedef struct {
    U8 EPIn;
    U8 EPOut;
    U8 EPInt;
} USB_CDC_INIT_DATA;
```

| Member                | Description                               |
|-----------------------|-------------------------------------------|
| <a href="#">EPIn</a>  | Endpoint for sending data to the host     |
| <a href="#">EPOut</a> | Endpoint for receiving data from the host |
| <a href="#">EPInt</a> | Endpoint for sending status information.  |

**Table 10.23: USB\_CDC\_INIT\_DATA elements**

#### Additional Information

[EPInt](#) is not used in this version of the emUSB CDC component, status information are not sent to the host.

### 10.4.3.2 USB\_CDC\_ON\_SET\_BREAK

#### Description

Callback function to receive a break condition sent by the host.

#### Prototype

```
typedef void USB_CDC_ON_SET_BREAK(unsigned BreakDuration);
```

| Member                        | Description                                                                                       |
|-------------------------------|---------------------------------------------------------------------------------------------------|
| <a href="#">BreakDuration</a> | The <a href="#">BreakDuration</a> gives the length of time, in milliseconds, of the break signal. |

**Table 10.24: USB\_CDC\_ON\_SET\_LINE\_CODING elements**

#### Additional Information

This type of callback is used to notify the application that the host has sent a break condition. If [BreakDuration](#) is 0xFFFF, then the host will send a break until another SendBreak request is received with [BreakDuration](#) of 0x0000. Since the callback is called within an interrupt service routine it should execute quickly.

### 10.4.3.3 USB\_CDC\_ON\_SET\_LINE\_CODING

#### Description

Callback function to register line-coding changes.

#### Prototype

```
typedef void USB_CDC_ON_SET_LINE_CODING(USB_CDC_LINE_CODING * pLineCoding);
```

| Member                      | Description                              |
|-----------------------------|------------------------------------------|
| <a href="#">pLineCoding</a> | Pointer to USB_CDC_LINE_CODING structure |

**Table 10.25: USB\_CDC\_ON\_SET\_LINE\_CODING elements**

#### Additional Information

This type of callback is used to notify the application that the host has changed the line coding. For example the baud rate has been changed. The new "line-coding" is passed through the structure `USB_CD_LINE_CODING`. Refer to *USB\_CDC\_LINE\_CODING* on page 332 for more information about the elements of this structure. Since the callback is called within an interrupt service routine it should execute quickly.

### 10.4.3.4 USB\_CDC\_LINE\_CODING

#### Description

Structure that contains the new line-coding sent by the host.

#### Prototype

```
typedef struct {  
    U32 DTERate;  
    U8  CharFormat;  
    U8  ParityType;  
    U8  DataBits;  
} USB_CDC_LINE_CODING;
```

| Member     | Description                                                                            |
|------------|----------------------------------------------------------------------------------------|
| DTERate    | The data transfer rate for the device in bits per second.                              |
| CharFormat | Contain the stop bits:<br>0 - 1 Stop bit<br>1 - 1.5 Stop bits<br>2 - 2 Stop bits       |
| ParityType | Specifies the parity type:<br>0 - None<br>1 - Odd<br>2 - Even<br>3 - Mark<br>4 - Space |
| DataBits   | Specifies the bits per byte: (5, 6, 7, 8, 16)                                          |

**Table 10.26: USB\_CDC\_LINE\_CODING elements**

### 10.4.3.5 USB\_CDC\_SERIAL\_STATE

#### Description

Structure that contains the new line-coding sent by the host.

#### Prototype

```
typedef struct {
    U8 DCD;
    U8 DSR;
    U8 Break;
    U8 Ring;
    U8 FramingError;
    U8 ParityError;
    U8 OverRunError;
    U8 CTS;
} USB_CDC_SERIAL_STATE;
```

| Member       | Description                                                                    |
|--------------|--------------------------------------------------------------------------------|
| DCD          | Data Carrier Detect: Tells that the device is connected to the telephone line. |
| DSR          | Data Set Read: Device is ready to receive data.                                |
| Break        | 1 - Break condition signaled.                                                  |
| Ring         | Device indicates that it has detected a ring signal on the telephone line.     |
| FramingError | When set to 1, the device indicates a framing error.                           |
| ParityError  | When set to 1, the device indicates a parity error.                            |
| OverRunError | When set to 1, the device indicates an over-run error.                         |
| CTS          | Clear to send: Acknowledges RTS and allows the host to transmit.               |

**Table 10.27: USB\_CDC\_LINE\_CODING elements**




# Chapter 11

## Human Interface Device Class (HID)

---

This chapter gives a general overview of the HID class and describes how to get the HID component running on the target.



## 11.1 Overview

The Human Interface Device class (HID) is an abstract USB class protocol defined by the USB Implementers Forum. This protocol was defined for the handling of devices which are used by humans to control the operation of computer systems.

An installation of a custom-host USB driver is not necessary, because the USB human interface device class is standardized and every major OS already provides host drivers for it.

### Method of communication

HID always uses interrupt end points. Since interrupt endpoints are limited to at most one packet of at most 64 bytes per frame (on full speed devices), the transfer rate is limited to 64000 bytes/sec, in reality much less than that.

### 11.1.1 Further reading

The following documents define the HID class and have been used to implement and verify the HID component:

- [HID1]  
Device Class Definition for Human Interface Devices (HID), Firmware Specification—6/27/01 Version 1.11
- [HID2]  
HID Usage Tables, 1/21/2005 Version 1.12



## 11.1.2 Categories

Devices which are in the HID class generally fall into one of two categories:

*True HID*s and *vendor specific HID*s, explained below. One or more examples for both categories are provided.

### 11.1.2.1 True HID

True HID devices are devices which communicate directly with the host operating system, this includes devices which are used by a human to enter data, but do not directly exchange data with an application program running on the host.

#### Typical examples

- Keyboard
- Mouse and similar pointing devices
- Joystick
- Game pad
- Front-panel controls - for example, switches and buttons.

### 11.1.2.2 Vendor specific HID

These are HID devices communicating with an application program. The host OS loads the same driver it loads for any "true HID" and will automatically enumerate the device, but it cannot communicate with the device. When analyzing the report descriptor, the host finds that it cannot exchange information with the device; the device uses a protocol which is meaningless to the HID driver of the host. The host will therefore not exchange information with the device. A host recognizes a vendor specific HID by its vendor-defined usage page in the report descriptor: the numerical value of the usage page lies between 0xFF00 and 0xFFFF.

An application has the chance to communicate with the particular device using API functions offered by the host. This enables an application program to communicate with the device without having to load a driver. HID does not take advantage of the full USB bus bandwidth; bulk communication can be much faster, but requires a driver. Therefore it can be a good choice to select HID as a device class, especially if ease of use is important and high communication speed is not required.


#### Typical examples

- Bar-code reader
- Thermometer
- Voltmeter
- Low-speed JTAG emulator
- UPS (Uninterruptible power supply)

## 11.2 Background information

### 11.2.1 HID descriptors

This section presents an overview of the HID class-specific descriptors. The HID descriptors are defined in the *Device Class Definition for Human Interface Devices (HID)* of the USB Implementers Forum. Refer to the USB Implementers Forum website, [www.usb.org](http://www.usb.org), for detailed information about the USB HID standard.




#### 11.2.1.1 HID descriptor

A HID descriptor contains the report descriptor and optionally the physical descriptors. It specifies the number, type, and size of the report descriptor and the report's physical descriptors.

#### 11.2.1.2 Report descriptor

Data between host and device is exchanged in so called "reports". The report descriptor defines the format of a report. In general, HIDs require a report descriptor as defined in the *Device Class Definition for Human Interface Devices (HID)*. The only exception to this are very basic HIDs such as mice or keyboards. This implementation of HID always requires a report descriptor.

The USB Implementers Forum provides an application which helps to build and modify HID report descriptors. The HID Descriptor Tool can be downloaded from: <http://www.usb.org/developers/hidpage/>



### 11.2.1.3 Physical descriptor

Physical descriptor sets are optional descriptors which provide information about the part or parts of the human body used to activate the controls on a device. Physical descriptors are currently not supported.

## 11.3 Configuration

### 11.3.1 Initial configuration

To get emUSB up and running as well as doing an initial test, the configuration as it is delivered should not be modified. The configuration must only be modified if emUSB should be used in your final product. Refer to the section *Configuration* on page 41 for detailed information about the functions which must be adapted before you can release a final product version.

### 11.3.2 Final configuration

#### Generating a report descriptor

This step is only required if your product is a vendor-specific human interface device. The report descriptor provided in the example application can typically be used without any modification. The vendor-defined usage page should be adapted in a final product. Vendor-defined usage pages can be in the range from 0xFF00 to 0xFFFF. The low byte can be selected by the application programmer. It needs to be identical on both target and host and should be unique (as unique as an 8-bit value can be). The example(s) use the value 0x12; this value is defined at the top of the application program with the macro `USB_HID_DEFAULT_VENDOR_PAGE`.

## 11.4 Example application

Example applications are supplied. These can be used for testing the correct installation and proper function of the device running emUSB.

The following start application files are provided:

| File        | Description                                       |
|-------------|---------------------------------------------------|
| HID_Mouse.c | Simple mouse example. ("True HID" example)        |
| HID_Echo1.c | Modified echo server. ("vendor specific" example) |

**Table 11.1: Supplied example HID applications**

### 11.4.1 HID\_Mouse.c


HID\_Mouse.c is a typical example for a "true HID" implementation. The host identifies the device which is programmed with this example as a mouse. After the device is enumerated, it moves the mouse cursor in an endless loop to the left and after a short delay back to the right.

#### 11.4.1.1 Running the example

1. Add HID\_Mouse.c to your project and build and download the application into the target.
2. When you connect your target to the host via USB, Windows will detect the new HID device.
3. If a connection can be established, it moves the mouse cursor as long as you do not disconnect your target.

## 11.4.2 HID\_Echo1.c

`HID_Echo1.c` is a typical example for a “vendor-specific HID” implementation. The HID start application (`HID_Echo1.c` located in the `Application` subfolder) is a modified echo server; the application receives data byte by byte, increments every single byte and sends them back to the host.




To use this application, include the source code file `HID_Echo1.c` into your project and compile and download it into your target. Run `HIDEcho1.exe` after the target is connected to the host and the enumeration process has been completed. The PC application is supplied as executable in the `HID\SampleApp\Exe` directory. The source code of the PC example is also supplied. Refer to section *Compiling the PC example application* on page 343 for more information to the PC example project.

### 11.4.2.1 Running the example

1. Add `HID_Echo1.c` to your project and build and download the application into the target.
2. Connect your target to the host via USB while the example application is running, Windows will detect the new HID device.
3. If a connection can be established, it exchanges data with the target, testing the USB connection. If the host example application can communicate with the emUSB device, the example application outputs the product name, Vendor and Product ID and the report size which will be used to communicate with the target. The target will be in interactive mode.


Example output of HID\_Echo1.exe:



```

C:\HIDEcho1.exe
Device 0:
Productname: HID generic sample
UID       : 0x8765
PID       : 0x1114
ReportSizes:
  Input    : 64 bytes
  Output   : 64 bytes
Starting Echo...
Enter the number of echoes to be sent to the echo client: _
  
```

4. Enter the number of reports that should be transmitted when the device is connect. Every dot in the terminal window indicates a transmission.



```

C:\HIDEcho1.exe
Device 0:
Productname: HID generic sample
UID       : 0x8765
PID       : 0x1114
ReportSizes:
  Input    : 64 bytes
  Output   : 64 bytes
Starting Echo...
Enter the number of echoes to be sent to the echo client: 5000
.....
  
```

#### 11.4.2.2 Compiling the PC example application

To compile the example application you need a Microsoft compiler. The compiler is part of Microsoft Visual C++ 6.0 or Microsoft Visual Studio .Net. The source code of the example application is located in the subfolder `HID\SampleApp`. Open the file `USBHID_Start.dsw` and compile the source choose **Build | Build SampleApp.exe** (Shortcut: F7). To run the executable choose **Build | Execute SampleApp.exe** (Shortcut: CTRL-F5).

**Note:** The Microsoft Windows Driver Development Kit (DDK) is required to compile the HID host example application. Refer to <http://www.microsoft.com/whdc/dev-tools/ddk/default.mspx> for more information.

## 11.5 Target API

This section describes the functions that can be used on the target system.

### General information

To communicate with the host, the example application project includes USB-specific header and source files. These files contain API functions to communicate with the USB host.

### Purpose of the USB Device API functions

To have an easy start up when writing an application on the device side, these API functions have a simple interface and handle all operations that need to be done to communicate with the host.

Therefore, all operations that need to write to or read from the emUSB are handled internally by the provided API functions.

### 11.5.1 Target interface function list

| Function                                                                                          | Description                                                            |
|---------------------------------------------------------------------------------------------------|------------------------------------------------------------------------|
| API functions                                                                                     |                                                                        |
| <a href="#">USB_HID_Add()</a>                                                                     | Adds HID-class to the emUSB interface.                                 |
| <a href="#">USB_HID_GetNumBytesInBuffer()</a> / <a href="#">USB_HID_GetNumBytesInBufferEx()</a>   | Returns the number of bytes in the internal read buffer.               |
| <a href="#">USB_HID_GetNumBytesRemToRead()</a> / <a href="#">USB_HID_GetNumBytesRemToReadEx()</a> | Returns the number of bytes which still have to be read.               |
| <a href="#">USB_HID_GetNumBytesToWrite()</a> / <a href="#">USB_HID_GetNumBytesToWriteEx()</a>     | Returns the number of bytes which still have to be written.            |
| <a href="#">USB_HID_Read()</a> / <a href="#">USB_HID_ReadEx()</a>                                 | Reads data from the host.                                              |
| <a href="#">USB_HID_ReadEPOverlapped()</a> / <a href="#">USB_HID_ReadEPOverlappedEx()</a>         | Non-blocking version of <a href="#">USB_HID_Read()</a>                 |
| <a href="#">USB_HID_ReadTimed()</a> / <a href="#">USB_HID_ReadExTimed()</a>                       | Starts a read operation that shall be done within a given timeout.     |
| <a href="#">USB_HID_StartReadTransfer()</a> / <a href="#">USB_HID_StartReadTransferEx()</a>       | Initiates a read data transfer.                                        |
| <a href="#">USB_HID_WaitForRX()</a> / <a href="#">USB_HID_WaitForRXEx()</a>                       | Waits for a non-blocking write operation that is pending.              |
| <a href="#">USB_HID_WaitForTX()</a> / <a href="#">USB_HID_WaitForTXEx()</a>                       | Waits for a non-blocking write operation that is pending.              |
| <a href="#">USB_HID_Write()</a> / <a href="#">USB_HID_WriteEx()</a>                               | Writes data to the host.                                               |
| <a href="#">USB_HID_WriteEPOverlapped()</a> / <a href="#">USB_HID_WriteEPOverlappedEx()</a>       | Non-blocking version of <a href="#">USB_HID_Write()</a>                |
| <a href="#">USB_HID_WriteTimed()</a> / <a href="#">USB_HID_WriteExTimed()</a>                     | Starts a write operation that shall be done within a given timeout.    |
| Data structures                                                                                   |                                                                        |
| <a href="#">USB_HID_INIT_DATA</a>                                                                 | Initialization structure that is required when adding a HID interface. |

**Table 11.2: USB-HID target interface function list**



## 11.5.2 USB-HID functions

### 11.5.2.1 USB\_HID\_Add()

#### Description

Adds HID class device to the USB interface.

#### Prototype

```
USB_HID_HANDLE USB_HID_Add(const USB_HID_INIT_DATA * pInitData);
```

| Parameter              | Description                                                                                                                                                                        |
|------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>pInitData</code> | Pointer to a <code>USB_HID_INIT_DATA</code> structure. For detailed information about the <code>USB_HID_INIT_DATA</code> structure, refer to <i>USB_HID_INIT_DATA</i> on page 358. |

**Table 11.3: USB\_HID\_Add() parameter list**

#### Return value

USB\_HID\_HANDLE: Handle to the HID instance (can be zero).

#### Additional information

After the initialization of general emUSB, this is the first function that needs to be called when the USB-HID interface is used with emUSB.

### 11.5.2.2 USB\_HID\_GetNumBytesInBuffer() / USB\_HID\_GetNumBytesInBufferEx()

#### Description

This function is to be used in combination with `USB_HID_StartReadTransfer()` / `USB_HID_StartReadTransferEx()`.

The function will return the number of bytes available in the internal read buffer.

#### Prototype

```
unsigned USB_HID_GetNumBytesInBuffer      (void);  
unsigned USB_HID_GetNumBytesInBufferEx    (USB_HID_HANDLE hInterface);
```

| Parameter               | Description               |
|-------------------------|---------------------------|
| <code>hInterface</code> | Handle to a HID instance. |

**Table 11.4: USB\_HID\_GetNumBytesInBuffer() / USB\_HID\_GetNumBytesInBufferEx() parameter list**

#### Return value

`>= 0`: Number of bytes in the internal read buffer.

### 11.5.2.3 USB\_HID\_GetNumBytesRemToRead() / USB\_HID\_GetNumBytesRemToReadEx()

#### Description

This function is to be used in combination with `USB_HID_ReadEPOverlapped()` / `USB_HID_ReadEPOverlappedEx()`.

After starting the read operation this function can be used to periodically check how many bytes still have to be read.

#### Prototype

```
unsigned USB_HID_GetNumBytesRemToRead (void);
unsigned USB_HID_GetNumBytesRemToReadEx (USB_HID_HANDLE hInterface);
```

| Parameter               | Description               |
|-------------------------|---------------------------|
| <code>hInterface</code> | Handle to a HID instance. |

**Table 11.5: USB\_HID\_GetNumBytesRemToRead() / USB\_HID\_GetNumBytesRemToReadEx() parameter list**

#### Return value

$\geq 0$ : Number of bytes which have not yet been read.

#### Additional information

Alternatively the blocking function `USB_HID_WaitForRX()` / `USB_HID_WaitForRXEx()` can be used.

### 11.5.2.4 USB\_HID\_GetNumBytesToWrite() / USB\_HID\_GetNumBytesToWriteEx()

#### Description

This function is to be used in combination with `USB_HID_WriteEPOverlapped()` / `USB_HID_WriteEPOverlappedEx()`.

After starting the write operation this function can be used to periodically check how many bytes still have to be written.

#### Prototype

```
unsigned USB_HID_GetNumBytesToWrite      (void);  
unsigned USB_HID_GetNumBytesToWriteEx    (USB_HID_HANDLE hInterface);
```

| Parameter               | Description               |
|-------------------------|---------------------------|
| <code>hInterface</code> | Handle to a HID instance. |

**Table 11.6: USB\_HID\_GetNumBytesToWrite() / USB\_HID\_GetNumBytesToWriteEx() parameter list**

#### Return value

$\geq 0$ : Number of bytes which have not yet been written.

Additional information

Alternatively the blocking function `USB_HID_WaitForTX()` / `USB_HID_WaitForTXEx()` can be used.

### 11.5.2.5 USB\_HID\_Read() / USB\_HID\_ReadEx()

#### Description

Reads data from the host. This function blocks until it has received `NumBytes` or until the device is disconnected from the host.

#### Prototype

```
int USB_HID_Read    (void* pData, unsigned NumBytes);
int USB_HID_ReadEx (USB_HID_HANDLE hInterface,
                    void* pData,
                    unsigned NumBytes);
```

| Parameter               | Description                                                 |
|-------------------------|-------------------------------------------------------------|
| <code>hInterface</code> | Handle to a HID instance.                                   |
| <code>pData</code>      | Pointer to a buffer where the received data will be stored. |
| <code>NumBytes</code>   | Number of bytes to read.                                    |

**Table 11.7: USB\_HID\_Read() / USB\_HID\_ReadEx() parameter list**

#### Return value

`>= 0`: Number of bytes that have been received.  
`USB_STATUS_ERROR`: In case of an error.

### 11.5.2.6 USB\_HID\_ReadEPOverlapped() / USB\_HID\_ReadEPOverlappedEx()

#### Description

Reads data from the host asynchronously.

#### Prototype

```
int USB_HID_ReadEPOverlapped (void* pData, unsigned NumBytes);  
int USB_HID_ReadEPOverlappedEx (USB_HID_HANDLE hInterface,  
                                void* pData,  
                                unsigned NumBytes);
```

| Parameter                | Description                                                 |
|--------------------------|-------------------------------------------------------------|
| <a href="#">pData</a>    | Pointer to a buffer where the received data will be stored. |
| <a href="#">NumBytes</a> | Number of bytes to read.                                    |

**Table 11.8: USB\_HID\_ReadEPOverlapped() / USB\_HID\_ReadEPOverlappedEx() parameter list**

#### Return value

Number of bytes that have already been received or have been copied from internal buffer. The value can be less or equal to [NumBytes](#).

#### Additional information

This function will not block the calling task. The read transfer will be initiated and the function returns immediately. In order to synchronize, [USB\\_HID\\_WaitForRX\(\)](#) / [USB\\_HID\\_WaitForRXEx\(\)](#) needs to be called. Alternatively the function [USB\\_HID\\_GetNumBytesToWrite\(\)](#) / [USB\\_HID\\_GetNumBytesToWriteEx\(\)](#) can be called periodically to check whether all bytes have been written or not.

### 11.5.2.7 USB\_HID\_ReadTimed() / USB\_HID\_ReadExTimed()

#### Description

Reads data from the host with a given timeout. This function blocks until the timeout has been reached, it has received **NumBytes** or until the device is disconnected from the host.

#### Prototype

```
int USB_HID_ReadTimed (void* pData, unsigned NumBytes, unsigned ms);
int USB_HID_ReadExTimed (USB_HID_HANDLE hInterface,
                        void* pData,
                        unsigned NumBytes,
                        unsigned ms);
```

| Parameter         | Description                                                 |
|-------------------|-------------------------------------------------------------|
| <b>hInterface</b> | Handle to a HID instance.                                   |
| <b>pData</b>      | Pointer to a buffer where the received data will be stored. |
| <b>NumBytes</b>   | Number of bytes to read.                                    |
| <b>ms</b>         | Timeout in milliseconds.                                    |

**Table 11.9: USB\_HID\_ReadTimed() / USB\_HID\_ReadExTimed() parameter list**

#### Return value

|                            |                                          |
|----------------------------|------------------------------------------|
| <b>&gt;= 0:</b>            | Number of bytes that have been received. |
| <b>USB_STATUS_ERROR:</b>   | In case of an error.                     |
| <b>USB_STATUS_TIMEOUT:</b> | In case of a timeout.                    |

### 11.5.2.8 USB\_HID\_StartReadTransfer() / USB\_HID\_StartReadTransferEx()

#### Description

Initiates a read data transfer. Data will be stored in the internal buffer.

#### Prototype

```
void USB_HID_StartReadTransfer    (void);  
void USB_HID_StartReadTransferEx (USB_HID_HANDLE hInst);
```

| Parameter                  | Description               |
|----------------------------|---------------------------|
| <a href="#">hInterface</a> | Handle to a HID instance. |

**Table 11.10: USB\_HID\_StartReadTransfer() / USB\_HID\_StartReadTransferEx() parameter list**

#### Additional information

After this function has been called the function [USB\\_HID\\_GetNumBytesInBuffer\(\)](#) / [USB\\_HID\\_GetNumBytesInBufferEx\(\)](#) can be used to check how many bytes haben been read. To actually receive the data on the application level [USB\\_HID\\_Read\(\)](#) / [USB\\_HID\\_ReadEx\(\)](#) has to be called. By calling the read function with the previously received number of bytes it is possible to make sure the read function does not block.



### 11.5.2.9 USB\_HID\_WaitForRX() / USB\_HID\_WaitForRXEx()

#### Description

This function is to be used in combination with `USB_HID_ReadEPOverlapped()` / `USB_HID_ReadEPOverlappedEx()`.

After the read function has been called this function can be used to synchronise. It will block until the transfer is completed.

#### Prototype

```
void USB_HID_WaitForRX    (void);  
void USB_HID_WaitForRXEx (USB_HID_HANDLE hInterface);
```

| Parameter               | Description               |
|-------------------------|---------------------------|
| <code>hInterface</code> | Handle to a HID instance. |

**Table 11.11: USB\_HID\_WaitForRX() / USB\_HID\_WaitForRXEx() parameter list**

### 11.5.2.10 USB\_HID\_WaitForTX() / USB\_HID\_WaitForTXEx()

#### Description

This function is to be used in combination with `USB_HID_WriteEPOverlapped()` / `USB_HID_WriteEPOverlappedEx()`.

After the write function has been called this function can be used to synchronise. It will block until the transfer is completed.

#### Prototype

```
void USB_HID_WaitForTX    (void);  
void USB_HID_WaitForTXEx (USB_HID_HANDLE hInterface);
```

| Parameter               | Description               |
|-------------------------|---------------------------|
| <code>hInterface</code> | Handle to a HID instance. |

**Table 11.12: USB\_HID\_WaitForTX() / USB\_HID\_WaitForTXEx() parameter list**

### 11.5.2.11 USB\_HID\_Write() / USB\_HID\_WriteEx()

#### Description

Writes data to the host. This function blocks until it has written **NumBytes** or until the device is disconnected from the host.

#### Prototype

```
void USB_HID_Write    (const void* pData, unsigned NumBytes);
void USB_HID_WriteEx (USB_HID_HANDLE hInterface,
                     const void* pData,
                     unsigned NumBytes);
```

| Parameter         | Description                                      |
|-------------------|--------------------------------------------------|
| <b>hInterface</b> | Handle to a HID instance.                        |
| <b>pData</b>      | Pointer to data that should be sent to the host. |
| <b>NumBytes</b>   | Number of bytes to write.                        |

**Table 11.13: USB\_HID\_Write() / USB\_HID\_WriteEx() parameter list**

### 11.5.2.12 USB\_HID\_WriteEPOverlapped() / USB\_HID\_WriteEPOverlappedEx()

#### Description

Writes data to the host asynchronously.

#### Prototype

```
int USB_HID_WriteEPOverlapped (const void* pData, unsigned NumBytes);  
int USB_HID_WriteEPOverlappedEx (USB_HID_HANDLE hInterface,  
                                const void* pData,  
                                unsigned NumBytes);
```

| Parameter                  | Description                                      |
|----------------------------|--------------------------------------------------|
| <a href="#">hInterface</a> | Handle to a HID instance.                        |
| <a href="#">pData</a>      | Pointer to data that should be sent to the host. |
| <a href="#">NumBytes</a>   | Number of bytes to write.                        |

**Table 11.14: USB\_HID\_WriteEPOverlapped() / USB\_HID\_WriteEPOverlappedEx() parameter list**

#### Return value

Number of bytes that have already been sent to the host. The value can be less or equal to [NumBytes](#).

#### Additional information

This function will not block the calling task. The write transfer will be initiated and the function returns immediately. In order to synchronize, [USB\\_HID\\_WaitForTX\(\)](#) / [USB\\_HID\\_WaitForTXEx\(\)](#) needs to be called. Alternatively the function [USB\\_HID\\_GetNumBytesToWrite\(\)](#) / [USB\\_HID\\_GetNumBytesToWriteEx\(\)](#) can be called periodically to check whether all bytes have been written or not.

### 11.5.2.13 USB\_HID\_WriteTimed() / USB\_HID\_WriteExTimed()

#### Description

Writes data to the host with a given timeout. This function blocks until the timeout has been reached, it has written **NumBytes** or until the device is disconnected from the host.

#### Prototype

```
void USB_HID_WriteTimed (const void* pData, unsigned NumBytes, unsigned ms);
void USB_HID_WriteExTimed (USB_HID_HANDLE hInterface,
                           const void* pData,
                           unsigned NumBytes,
                           unsigned ms);
```

| Parameter         | Description                                      |
|-------------------|--------------------------------------------------|
| <b>hInterface</b> | Handle to a HID instance.                        |
| <b>pData</b>      | Pointer to data that should be sent to the host. |
| <b>NumBytes</b>   | Number of bytes to write.                        |
| <b>ms</b>         | Timeout in milliseconds.                         |

**Table 11.15: USB\_HID\_WriteTimed() / USB\_HID\_WriteExTimed() parameter list**

## 11.5.3 Data structures

### 11.5.3.1 USB\_HID\_INIT\_DATA

#### Description

Initialization structure that is needed when adding a CDC interface to emUSB.

#### Prototype

```
typedef struct {
    U8 EPIn;
    U8 EPOut;
    const U8 * pReport;
    U16 NumBytesReport;
} USB_HID_INIT_DATA;
```

| Member         | Description                                |
|----------------|--------------------------------------------|
| EPIn           | Endpoint for sending data to the host.     |
| EPOut          | Endpoint for receiving data from the host. |
| pReport        | Pointer to a report descriptor.            |
| NumBytesReport | Size of the HID report.                    |

**Table 11.16: USB\_HID\_INIT\_DATA elements**

#### Additional Information

This structure is used when the HID interface is added to emUSB. `EPOut` is not required.

`pReport` points to a report descriptor. A report descriptor is a structure which is used to transmit HID control data to and from a human interface device. A report descriptor defines the format of a report and is composed of report items that define one or more top-level collections. Each collection defines one or more HID reports.

Refer to *Universal Serial Bus Specification, 1.0 Version* and the latest version of the *HID Usage Tables* guide for detailed information about HID input, output and feature reports.

The USB Implementers Forum provide an application that helps to build and modify HID report descriptors. The HID Descriptor Tool can be downloaded from: <http://www.usb.org/developers/hidpage/>.

The report descriptor used in the supplied example application `HID_Echo1.c` should match to the requirements of most "vendor specific HID" applications. The report size is defined to 64 bytes. As mentioned before, interrupt endpoints are limited to at most one packet of at most 64 bytes per frame (on full speed devices).

#### Example

Example excerpt from `HID_Mouse.c`:

```
static void _AddHID(void) {
    USB_HID_INIT_DATA InitData;
    U8 Interval = 10;
    static U8 acBuffer[64];

    memset(&InitData, 0, sizeof(InitData));
    InitData.EPIn = USB_AddEP(USB_DIR_IN, USB_TRANSFER_TYPE_INT, Interval, NULL, 0);
    // Note: Next line is optional. EPOut is not required!
    InitData.EPOut = USB_AddEP(USB_DIR_OUT, USB_TRANSFER_TYPE_INT, Interval, /
                               &acBuffer[0], sizeof(acBuffer));
    InitData.pReport = _aHIDReport;
    InitData.NumBytesReport = sizeof(_aHIDReport);
    USB_HID_Add(&InitData);
}
```

## 11.6 Host API

This chapter describes the functions that can be used with the Windows host system. These functions are only required if the emUSB-HID component is used to design a vendor specific HID.

### General information

To communicate with the target USB-HID stack, the example application project includes a USB-HID specific source and header file (`USBHID.c`, `USBHID.h`). These files contain API functions to communicate with the USB-HID target through the USB-Bulk driver.

### Purpose of the USB Host API functions

To have an easy start-up when writing an application on the host side, these API functions have simple interfaces and handle all operations that need to be done to communicate with the target USB-HID stack.

## 11.6.1 Host API function list

| Function                                     | Description                                   |
|----------------------------------------------|-----------------------------------------------|
| API functions                                |                                               |
| <code>USBHID_Close()</code>                  | Closes the connection an open device.         |
| <code>USBHID_Open()</code>                   | Opens a handle to the device.                 |
| <code>USBHID_Init()</code>                   | Initializes the USB human interface device.   |
| <code>USBHID_Exit()</code>                   | Closes the connection an open device.         |
| <code>USBHID_GetNumAvailableDevices()</code> | Returns the number of available devices.      |
| <code>USBHID_GetProductName()</code>         | Returns the product name.                     |
| <code>USBHID_GetInputReportSize()</code>     | Returns the input report size of the device.  |
| <code>USBHID_GetOutputReportSize()</code>    | Returns the output report size of the device. |
| <code>USBHID_GetProductId()</code>           | Returns the Product ID of the device.         |
| <code>USBHID_GetVendorId()</code>            | Returns the Vendor ID of the device.          |
| <code>USBHID_RefreshList()</code>            | Refreshes connection info list.               |
| <code>USBHID_SetVendorPage()</code>          | Sets the vendor page.                         |

**Table 11.17: USB-HID host interface function list**



## 11.6.2 USB-HID functions

### 11.6.2.1 USBHID\_Close()

#### Description

Closes the connection an open device.

#### Prototype

```
void USBHID_Close (unsigned Id);
```

| Parameter                   | Description                                                                                                          |
|-----------------------------|----------------------------------------------------------------------------------------------------------------------|
| <a href="#">DeviceIndex</a> | Index of the HID device. This is the bit number of the mask returned by <code>USBHID_GetNumAvailableDevices()</code> |

**Table 11.18: USBHID\_Close() parameter list**

### 11.6.2.2 USBHID\_Open()

#### Description

Opens a handle to the device that shall be opened.

#### Prototype

```
int USBHID_Open (unsigned Id)
```

| Parameter                   | Description                                                                                              |
|-----------------------------|----------------------------------------------------------------------------------------------------------|
| <a href="#">DeviceIndex</a> | Index of the HID device. This is the bit number of the mask returned by USBHID_GetNumAvailableDevices(). |

**Table 11.19: USBHID\_Open() parameter list**

#### Return value

== 0: Opening was successful or already opened.  
== 1: Error. Handle to the device could not opened.

### 11.6.2.3 USBHID\_Init()

#### Description

Sets the specific vendor page, initializes the USB HID User API and retrieves the information of the HID device.

#### Prototype

```
void USBHID_Init(U8 VendorPage);
```

| Parameter                  | Description                                                                                                                       |
|----------------------------|-----------------------------------------------------------------------------------------------------------------------------------|
| <a href="#">VendorPage</a> | This parameter specifies the lower 8 bits of the vendor-specific usage page number. It must be identical on both device and host. |

**Table 11.20: USBHID\_Init() parameter list**

### 11.6.2.4 USBHID\_Exit()

#### Description

Closes the connection to all open devices and deinitializes the HID module.

#### Prototype

```
void USBHID_Exit(void);
```

### 11.6.2.5 USBHID\_GetNumAvailableDevices()

#### Description

Returns the number of the available devices.

#### Prototype

```
unsigned USBHID_GetNumAvailableDevices(U32 * pMask);
```

| Parameter             | Description                                                                                                                           |
|-----------------------|---------------------------------------------------------------------------------------------------------------------------------------|
| <a href="#">pMask</a> | Pointer to unsigned integer value which is used to store the bit mask of available devices. This parameter may be <code>NULL</code> . |

**Table 11.21: USBHID\_GetNumAvailableDevices() parameter list**

#### Return value

Returns the number of available devices.

#### Additional information

[pMask](#) will be filled by this routine. It shall be interpreted as bit mask where a bit set means this device is available. For example, device 0 and device 2 are available, if [pMask](#) has the value 0x00000005.

### 11.6.2.6 USBHID\_GetProductName()

#### Description

Stores the name of the device into `pBuffer`.

#### Prototype

```
int USBHID_GetProductName(unsigned Id, char * pBuffer, unsigned NumBytes);
```

| Parameter                | Description                                                                                                   |
|--------------------------|---------------------------------------------------------------------------------------------------------------|
| <code>DeviceIndex</code> | Index of the HID device. This is the bit number of the mask returned by <code>USBHID_GetNumDevices()</code> . |
| <code>pBuffer</code>     | Pointer to a buffer for the product name.                                                                     |
| <code>NumBytes</code>    | Size of the <code>pBuffer</code> in bytes.                                                                    |

**Table 11.22: USBHID\_GetProductName() parameter list**

#### Return value

`== 0`: An error occurred.

`== 1`: Success.

### 11.6.2.7 USBHID\_GetInputReportSize()

#### Description

Returns the input report size of the device.

#### Prototype

```
int USBHID_GetInputReportSize(unsigned Id);
```

| Parameter                   | Description                                                                                                   |
|-----------------------------|---------------------------------------------------------------------------------------------------------------|
| <a href="#">DeviceIndex</a> | Index of the HID device. This is the bit number of the mask returned by <code>USBHID_GetNumDevices()</code> . |

**Table 11.23: USBHID\_GetInputReportSize() parameter list**

#### Return value

`== 0`: An error occurred.

`!= 0`: Size of the report in bytes.

### 11.6.2.8 USBHID\_GetOutputReportSize()

#### Description

Returns the output report size of the device.

#### Prototype

```
int USBHID_GetOutputReportSize(unsigned Id);
```

| Parameter                   | Description                                                                                                   |
|-----------------------------|---------------------------------------------------------------------------------------------------------------|
| <a href="#">DeviceIndex</a> | Index of the HID device. This is the bit number of the mask returned by <code>USBHID_GetNumDevices()</code> . |

**Table 11.24: USBHID\_GetOutputReportSize() parameter list**

#### Return value

`== 0`: An error occurred.

`!= 0`: Size of the report in bytes.



### 11.6.2.9 USBHID\_GetProductId()

#### Description

Returns the Product ID of a device.

#### Prototype

```
U16 USBHID_GetProductId(unsigned Id);
```

| Parameter                   | Description                                                                                                   |
|-----------------------------|---------------------------------------------------------------------------------------------------------------|
| <a href="#">DeviceIndex</a> | Index of the HID device. This is the bit number of the mask returned by <code>USBHID_GetNumDevices()</code> . |

**Table 11.25: USBHID\_GetProductId() parameter list**

#### Return value

`== 0`: An error occurred.

`!= 0`: Product ID.

### 11.6.2.10 USBHID\_GetVendorId()

#### Description

Returns the Vendor ID of the device.

#### Prototype

```
U16 USBHID_GetVendorId(unsigned Id);
```

| Parameter                   | Description                                                                                                   |
|-----------------------------|---------------------------------------------------------------------------------------------------------------|
| <a href="#">DeviceIndex</a> | Index of the HID device. This is the bit number of the mask returned by <code>USBHID_GetNumDevices()</code> . |

**Table 11.26: USBHID\_GetVendorId() parameter list**

#### Return value

`== 0`: An error occurred.

`!= 0`: Vendor ID.

### 11.6.2.11 USBHID\_RefreshList()

#### Description

Refreshes the connection list.

#### Prototype

```
void USBHID_RefreshList(void);
```

#### Additional information

Note that any open handle to the device will be closed while refreshing the connection list.

### 11.6.2.12 USBHID\_SetVendorPage()

#### Description

Sets the vendor page so that all HID devices with the specified page will be found.

#### Prototype

```
void USBHID_SetVendorPage(U8 VendorPage);
```

| Parameter                  | Description                                                                                                                       |
|----------------------------|-----------------------------------------------------------------------------------------------------------------------------------|
| <a href="#">VendorPage</a> | This parameter specifies the lower 8 bits of the vendor specific usage page number. It must be identical on both device and host. |


**Table 11.27: USBHID\_SetVendorPage() parameter list**

# Chapter 12

## Printer Class

---

This chapter describes how to get emUSB up and running as a printer device.



## 12.1 Overview

The Printer Class is an abstract USB class protocol defined by the USB Implementers Forum. This protocol delivers the existing printing command-sets to a printer over USB.

### 12.1.1 Configuration

The configuration section will later on be modified to match the real application. For the purpose of getting emUSB up and running as well as doing an initial test, the configuration as delivered should not be modified.

## 12.2 The example application

The start application (in the Application subfolder) is a simple data sink, which can be used to test emUSB. The application receives data bytes from the host which it displays in the terminal I/O window of the debugger.

Source code of USB\_Printer.c:

```

/*****
 *          SEGGER MICROCONTROLLER GmbH & Co. KG
 *          Solutions for real time microcontroller applications
 *****/
 *
 *          (c) 2003-2011      SEGGER Microcontroller GmbH & Co KG
 *
 *          Internet: www.segger.com      Support:  support@segger.com
 *
 *****/
 *          USB device stack for embedded applications
 *
 *****/
-----
File       : USB_Printer.c
Purpose    : Sample implementation of USB printer device class
-----Literature-----
Universal Serial Bus Device Class Definition for Printing Devices
Version 1.1 January 2000
-----  END-OF-HEADER  -----
*/

#include <stdio.h>
#include <string.h>
#include "USB_PrinterClass.h"
#include "BSP.h"

/*****
 *
 *          static data
 *****/
*/
static U8 _acData[512];

/*****
 *
 *          static code
 *****/
*/

/*****
 *
 *          _GetDeviceIdString
 *
 */
static const char * _GetDeviceIdString(void) {
    const char * s = "CLASS:PRINTER;MODEL:HP LaserJet 6MP;"
                    "MANUFACTURER:Hewlett-Packard;"
                    "DESCRIPTION:Hewlett-Packard LaserJet 6MP Printer;"
                    "COMMAND SET:PJL,MLC,PCLXL,PCL,POSTSCRIPT;";

    return s;
}

/*****
 *
 *          _GetHasNoError
 *
 */
static U8 _GetHasNoError(void) {
    return 1;
}

/*****
 *
 *          _GetIsSelected
 *
 */
static U8 _GetIsSelected(void) {
    return 1;
}

```

```

}

/*****
 *
 *      _GetIsPaperEmpty
 *
 */
static U8 _GetIsPaperEmpty(void) {
    return 0;
}

/*****
 *
 *      _OnDataReceived
 *
 */
static int _OnDataReceived(const U8 * pData, unsigned NumBytes) {
    USB_MEMCPY(_acData, pData, NumBytes);
    _acData[NumBytes] = 0;
    printf(_acData);
    return 0;
}

/*****
 *
 *      _OnReset
 *
 */
static void _OnReset(void) {

}

static USB_PRINTER_API _PrinterAPI = {
    _GetDeviceIdString,
    _OnDataReceived,
    _GetHasNoError,
    _GetIsSelected,
    _GetIsPaperEmpty,
    _OnReset
};

/*****
 *
 *      Public code
 *
 *****/

/*****
 *
 *      USB_GetVendorId
 *
 *      Function description
 *      Returns Vendor ID
 */
U16 USB_GetVendorId(void) {
    return 0x8765;
}

/*****
 *
 *      USB_GetProductId
 *
 *      Function description
 *      Returns Product ID
 */
U16 USB_GetProductId(void) {
    return 0x2114;    // Should be unique for this sample
}

/*****
 *
 *      USB_GetVendorName
 *
 *      Function description
 *      Returns vendor name
 */
const char * USB_GetVendorName(void) {
    return "Vendor";
}

```



```

/*****
*
*      USB_GetProductName
*
*      Function description
*      Returns product name
*/
const char * USB_GetProductName(void) {
    return "Printer";
}

/*****
*
*      USB_GetSerialNumber
*
*      Function description
*      Returns serial number
*/
const char * USB_GetSerialNumber(void) {
    return "12345678901234567890";
}

/*****
*
*      MainTask
*
*      Function description
*      USB handling task.
*      Modify to implement the desired protocol
*/
void MainTask(void);
void MainTask(void) {
    USB_Init();
    USB_PRINTER_Init(&_PrinterAPI);
    USB_Start();
    //
    // Loop: Receive data byte by byte, send back (data + 1)
    //
    while (1) {
        //
        // Wait for configuration
        //
        while ((USB_GetState() & (USB_STAT_CONFIGURED | USB_STAT_SUSPENDED))
            != USB_STAT_CONFIGURED) {
            BSP_ToggleLED(0);
            USB_OS_Delay(50);
        }
        USB_PRINTER_Task();
    }
}
/***** end of file *****/

```

## 12.3 Target API

This chapter describes the functions and data structures that can be used with the target application.

### 12.3.1 Interface function list

| Function                                | Description                                                                                              |
|-----------------------------------------|----------------------------------------------------------------------------------------------------------|
| API functions                           |                                                                                                          |
| <code>USB_PRINTER_Init()</code>         | Initializes the printer class.                                                                           |
| <code>USB_PRINTER_Task()</code>         | Processes the request from USB Host.                                                                     |
| Advanced API functions                  |                                                                                                          |
| <code>USB_PRINTER_Read()</code>         | Reads data from the host.                                                                                |
| <code>USB_PRINTER_ReadTimed()</code>    | Reads data from host with a given timeout.                                                               |
| <code>USB_PRINTER_Receive()</code>      | Reads data from host.                                                                                    |
| <code>USB_PRINTER_ReceiveTimed()</code> | Reads data from host with a given timeout.                                                               |
| <code>USB_PRINTER_Write()</code>        | Writes data to the host.                                                                                 |
| <code>USB_PRINTER_WriteTimed()</code>   | Writes data to the host with a given timeout.                                                            |
| Data structures                         |                                                                                                          |
| <code>USB_PRINTER_API</code>            | List of callback functions the PRINTER module should invoke when processing a request from the USB Host. |

**Table 12.1: USB-Printer interface API**

## 12.3.2 API functions

### 12.3.2.1 USB\_PRINTER\_Init()

#### Description

Initializes the printer class.

#### Prototype

```
void USB_PRINTER_Init(USB_PRINTER_API * pAPI);
```

| Parameter            | Description                                                                                                                  |
|----------------------|------------------------------------------------------------------------------------------------------------------------------|
| <a href="#">pAPI</a> | Pointer to an API table that contains all callback functions that are necessary for handling the functionality of a printer. |

**Table 12.2: USB\_PRINTER\_Init() parameter list**

#### Additional information

After the initialization of general emUSB, this is the first function that needs to be called when the printer class is used with emUSB.

### 12.3.2.2 USB\_PRINTER\_Task()

#### Description

Processes the request received from the USB Host.

#### Prototype

```
void USB_PRINTER_Task(void);
```

#### Additional information

This function blocks as long as the USB device is connected to USB host. It handles the requests by calling the function registered in the call to `USB_PRINTER_Init()`.

### 12.3.2.3 USB\_PRINTER\_Read()

#### Description

Reads data from the host. This function blocks until `NumBytes` have been read or until the device is disconnected from the host.

#### Prototype

```
int USB_PRINTER_Read ( void * pData, unsigned NumBytes);
```

| Parameter             | Description                                                 |
|-----------------------|-------------------------------------------------------------|
| <code>pData</code>    | Pointer to a buffer where the received data will be stored. |
| <code>NumBytes</code> | Number of bytes to read.                                    |

**Table 12.3: USB\_PRINTER\_Read() parameter list**

#### Return value

`== NumBytes:` Number of bytes that have been read.  
`!= NumBytes:` Returns a `USB_STATUS_ERROR`.

#### Additional information

This function blocks a task until all data has been read. In case of a reset or a disconnect `USB_STATUS_ERROR` is returned.

### 12.3.2.4 USB\_PRINTER\_ReadTimed()

#### Description

Reads data from the host with a given timeout.

#### Prototype

```
int USB_PRINTER_ReadTimed ( void * pData, unsigned NumBytes, unsigned ms);
```

| Parameter             | Description                                                                 |
|-----------------------|-----------------------------------------------------------------------------|
| <code>pData</code>    | Pointer to a buffer where the received data will be stored.                 |
| <code>NumBytes</code> | Number of bytes to read.                                                    |
| <code>ms</code>       | Timeout given in milliseconds. A zero value results in an infinite timeout. |

**Table 12.4: USB\_PRINTER\_ReadTimed() parameter list**

#### Return value

`== NumBytes`: Number of bytes that have been read within the given timeout.  
`!= NumBytes`: Returns a `USB_STATUS_ERROR` or `USB_STATUS_TIMEOUT`.

#### Additional information

This function blocks a task until all data has been read or a timeout occurs. In case of a reset or a disconnect `USB_STATUS_ERROR` is returned.

### 12.3.2.5 USB\_PRINTER\_Receive()

#### Description

Reads data from host. The function blocks until any data has been received. In contrast to `USB_PRINTER_Read()` this function does not wait for all of `NumBytes` to be received, but returns after the first packet has been received.

#### Prototype

```
int USB_PRINTER_Receive ( void * pData, unsigned NumBytes);
```

| Parameter             | Description                                                 |
|-----------------------|-------------------------------------------------------------|
| <code>pData</code>    | Pointer to a buffer where the received data will be stored. |
| <code>NumBytes</code> | Number of bytes to read.                                    |

**Table 12.5: USB\_PRINTER\_Receive() parameter list**

#### Return value

- > 0: Number of bytes that have been read.
- == 0: Zero packet received (not every controller supports this!) or the target was disconnected during the function call.
- < 0: Returns a `USB_STATUS_ERROR`.

#### Additional information

If no error occurs, this function returns the number of bytes received. Calling `USB_CDC_Receive()` will return as much data as is currently available up to the size of the buffer specified. This function also returns when target is disconnected from host or when a USB reset occurred, it will then return the number of bytes read.

### 12.3.2.6 USB\_PRINTER\_ReceiveTimed()

#### Description

Reads data from host. The function blocks until any data has been received. In contrast to `USB_PRINTER_ReadTimed()` this function does not wait for all of `NumBytes` to be received, but returns after the first packet has been received or after the timeout has been reached.

#### Prototype

```
int USB_PRINTER_ReceiveTimed( void * pData, unsigned NumBytes, unsigned ms);
```

| Parameter             | Description                                                                 |
|-----------------------|-----------------------------------------------------------------------------|
| <code>pData</code>    | Pointer to a buffer where the received data will be stored.                 |
| <code>NumBytes</code> | Number of bytes to read.                                                    |
| <code>ms</code>       | Timeout given in milliseconds. A zero value results in an infinite timeout. |

**Table 12.6: USB\_PRINTER\_ReceiveTimed() parameter list**

#### Return value

- > 0: Number of bytes that have been read within the given timeout.
- == 0: Zero packet received (not every controller supports this!) or the target was disconnected during the function call.
- < 0: Returns a `USB_STATUS_ERROR` or `USB_STATUS_TIMEOUT`.

#### Additional information

If no error occurs, this function returns the number of bytes received. Calling `USB_PRINTER_ReceiveTimed()` will return as much data as is currently available up to the size of the buffer specified within the specified timeout. This function also returns when target is disconnected from host or when a USB reset occurred, it will then return the number of bytes read.



### 12.3.2.7 USB\_PRINTER\_Write()

#### Description

Writes data to the host.

#### Prototype

```
int USB_PRINTER_Write (const void * pData, unsigned NumBytes);
```

| Parameter                | Description                  |
|--------------------------|------------------------------|
| <a href="#">pData</a>    | Data that should be written. |
| <a href="#">NumBytes</a> | Number of bytes to write.    |

**Table 12.7: USB\_PRINTER\_Write() parameter list**

#### Return value

> 0: Number of bytes that have been written.  
== 0: Error.

#### Additional information

This function is blocking.

### 12.3.2.8 USB\_PRINTER\_WriteTimed()

#### Description

Sends data to the host with a timeout option.

#### Prototype

```
int USB_PRINTER_WriteTimed (const void * pData, unsigned NumBytes, unsigned ms);
```

| Parameter             | Description                                                           |
|-----------------------|-----------------------------------------------------------------------|
| <code>pData</code>    | Data that should be written.                                          |
| <code>NumBytes</code> | Number of bytes to write.                                             |
| <code>ms</code>       | Timeout in milliseconds. A zero value results in an infinite timeout. |

**Table 12.8: USB\_PRINTER\_WriteTimed() parameter list**

#### Return value

> 0: Number of bytes that have been written.  
 == 0: Error.

#### Additional information

This function blocks a task until all data has been written or a timeout occurred. In case of a reset or a disconnect USB\_STATUS\_ERROR is returned.  
 Data structures

### 12.3.2.9 USB\_PRINTER\_API

#### Description

Initialization structure that is needed when adding a printer interface to emUSB. It holds pointer to callback functions the interface invokes when it processes request from USB host.

#### Prototype

```
typedef struct {
    const char * (*pfGetDeviceIdString) (void);
    int          (*pfOnDataReceived) (const U8 * pData, unsigned NumBytes);
    U8           (*pfGetHasNoError) (void);
    U8           (*pfGetIsSelected) (void);
    U8           (*pfGetIsPaperEmpty) (void);
    void         (*pfOnReset) (void);
} USB_PRINTER_API;
```

| Member                           | Description                                                                                                                                                                                                                                                                                                                               |
|----------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>pfGetDeviceIdString</code> | The library calls this function when the USB host requests the printer's identification string. This string shall conform to the IEEE 1284 Device ID Syntax:<br>Example:<br>"CLASS:PRINTER;MODEL:HP LaserJet 6MP;MANUFACTURER:Hewlett-Packard;DESCRIPTION:Hewlett-Packard LaserJet 6MP Printer;COMMAND SET:PJL,MLC,PCLXL,PCL,POSTSCRIPT;" |
| <code>pfOnDataReceived</code>    | This function is called when data arrives from USB host.                                                                                                                                                                                                                                                                                  |
| <code>pfGetHasNoError</code>     | This function should return a non-zero value if the printer has no error.                                                                                                                                                                                                                                                                 |

**Table 12.9: USB\_PRINTER\_API elements**

| Member                         | Description                                                                  |
|--------------------------------|------------------------------------------------------------------------------|
| <code>pfGetIsSelected</code>   | This function should return a non-zero value if the printer is selected.     |
| <code>pfGetIsPaperEmpty</code> | This function should return a non-zero value if the printer is out of paper. |
| <code>pfOnReset</code>         | The library calls this function if the USB host sends a soft reset command.  |

**Table 12.9: USB\_PRINTER\_API elements**




# Chapter 13

## Remote NDIS (RNDIS)

---

This chapter gives a general overview of the Remote Network Driver Interface Specification class and describes how to get the RNDIS component running on the target.



## 13.1 Overview

The Remote Network Driver Interface Specification (RNDIS) is a Microsoft proprietary USB class protocol which can be used to create a virtual Ethernet connection between a USB device and a host PC. A TCP/IP stack like embOS/IP is required on the USB device side to handle the actual IP communication. Any available IP protocol (UDP, TCP, FTP, HTTP, etc.) can be used to exchange data. On a typical Cortex-M CPU running at 120MHz, a transfer speed of about 5 MByte/sec can be achieved when using a high-speed USB connection.


USB RNDIS is supported by all Windows operating systems starting with Windows XP, as well as by Linux with kernel versions newer than 2.6.34. An .inf file is required for the installation on Microsoft Windows systems older than Windows 7. The emUSB-RNDIS package includes .inf files for Windows versions older than Windows 7. OS X will require a third-party driver to work with RNDIS, which can be downloaded from here: <http://joshuawise.com/horndis>

emUSB-RNDIS contains the following components:


- Generic USB handling
- RNDIS device class implementation
- Network interface driver which uses embOS/IP as TCP/IP stack.
- A sample application demonstrating how to work with RNDIS.

### 13.1.1 Working with RNDIS

Any USB RNDIS device connected to a PC running the Windows operating system is listed as a separate network interface in the "Network Connections" window as shown in this screenshot:



The `ping` command line utility can be used to test the connection to target as shown below. If the connection is correctly established the number of the lost packets should be 0.



```
Administrator: C:\Windows\System32\cmd.exe
Microsoft Windows [Version 6.1.7601]
Copyright (c) 2009 Microsoft Corporation. All rights reserved.

c:\Windows\System32>ping SEGGER.RNDIS

Pinging SEGGER.RNDIS [10.0.0.10] with 32 bytes of data:
Reply from 10.0.0.10: bytes=32 time<1ms TTL=64
Reply from 10.0.0.10: bytes=32 time<1ms TTL=64
Reply from 10.0.0.10: bytes=32 time<1ms TTL=64
Reply from 10.0.0.10: bytes=32 time<1ms TTL=64

Ping statistics for 10.0.0.10:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 0ms, Maximum = 0ms, Average = 0ms

c:\Windows\System32>
```

### 13.1.2 Additional information

More technical details about RNDIS can be found here:

<http://msdn.microsoft.com/en-us/library/windows/hardware/ff570660%28v=vs.85%29.aspx>

## 13.2 Configuration

### 13.2.1 Initial configuration

To get emUSB-RNDIS up and running as well as doing an initial test, the configuration as delivered should not be modified.

### 13.2.2 Final configuration

The configuration must only be modified when emUSB is used in your final product. Refer to section *Configuration* on page 41 to get detailed information about the general emUSB-Device configuration functions which have to be adapted.

### 13.2.3 Class specific configuration

emUSB-RNDIS calls the functions below to get the information required at initialization. The functions should be implemented in the application. A sample implementation of these functions can be found in the *IP\_Config\_RNDIS.c*. The file is located in the *Sample\RNDIS* directory of the emUSB shipment. The *IP\_Config\_RNDIS.c* provides a ready to use layer and configuration file to be used with embOS and embOS/IP..

| Function                                     | Description                          |
|----------------------------------------------|--------------------------------------|
| emUSB-RNDIS configuration functions          |                                      |
| <a href="#">USB_RNDIS_GetVendorId()</a>      | Returns IEEE-registered vendor code. |
| <a href="#">USB_RNDIS_GetDescription()</a>   | Returns the device description.      |
| <a href="#">USB_RNDIS_GetDriverVersion()</a> | Returns the firmware version.        |

**Table 13.1: List of class specific configuration functions**



### 13.2.3.1 USB\_RNDIS\_GetVendorId()

#### Description

Returns the IEEE-registered vendor code.

#### Prototype

```
U32 USB_RNDIS_GetVendorId(void);
```

#### Example

```
U32 USB_RNDIS_GetVendorId(void) {  
    return 0x0022C7;  
}
```

#### Additional information

The function is called when the RDNIS device is initialized. It returns a 24-bit Organizationally Unique Identifier (OUI) of the vendor. This is the same value as the one stored in the first 3 bytes of a HW (MAC) address. Only the least significant 24 bits of the returned value are used.

### 13.2.3.2 USB\_RNDIS\_GetDescription()

#### Description

Returns the device description.

#### Prototype

```
const char * USB_RNDIS_GetDescription(void);
```

#### Example

```
const char * USB_RNDIS_GetDescription(void) {  
    return "SEGGER RNDIS device";  
}
```

#### Additional information

Called when the RNDIS device is initialized. Returns a 0-terminated ASCII string describing the device. The string is then sent to the host system.

### 13.2.3.3 USB\_RNDIS\_GetDriverVersion()

#### Description

Returns the firmware version.

#### Prototype

```
U16 USB_RNDIS_GetDriverVersion(void);
```

#### Example

```
U16 USB_RNDIS_GetDriverVersion(void) {  
    return 0x0100;  
}
```

#### Additional information

Called when the RNDIS device is initialized. Returns a 16-bit value representing the firmware version. The high-order byte specifies the major version and the low-order byte the minor version.

## 13.2.4 Compile time configuration

The following macros can be added to `USB_Conf.h` file in order to configure the behavior of the RNDIS component.

The following types of configuration macros exist:

### Binary switches “B”

Switches can have a value of either 0 or 1, for deactivated and activated respectively. Actually, anything other than 0 works, but 1 makes it easier to read a configuration file. These switches can enable or disable a certain functionality or behavior. Switches are the simplest form of configuration macros.

### Numerical values “N”

Numerical values are used somewhere in the code in place of a numerical constant.

| Type | Macro             | Default | Description                                                                                                                                                                |
|------|-------------------|---------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| N    | RNDIS_DEBUG_LEVEL | 0       | Sets the type of diagnostic messages output at runtime. It can take one of these values:<br>0 - no debug messages<br>1 - only error messages<br>2 - error and log messages |

**Table 13.2: RNDIS configuration macros**

## 13.3 Running the sample application

The sample application can be found in the *Sample\RNDIS\IP\_Config\_RNDIS.c* file of the emUSB shipment. In order to use the sample application the SEGGER embOS/IP middleware component is required. To test the emUSB-RNDIS component any of the embOS/IP sample applications can be used in combination with *IP\_Config\_RNDIS.c*. After the sample application is started the USB cable should be connected to the PC and the chosen embOS/IP sample can be tested using the appropriate methods.

### 13.3.0.1 IP\_Config\_RNDIS.c in detail

The main part of the sample application is implemented in the function `MainTask()` which runs as an independent task.

```
// _Connect() - excerpt from IP_Config_RNDIS.c
static int _Connect(unsigned IFaceId) {
    U32 Server = IP_BYTES2ADDR(10, 0, 0, 10);
    IP_DHCPConfigPool(IFaceId, IP_BYTES2ADDR(10, 0, 0, 11), 0xFF000000, 20);
    IP_DHCPConfigDNSAddr(IFaceId, &Server, 1);
    IP_DHCPInit(IFaceId);
    IP_DHCPStart(IFaceId);
    USB_Init();
    _AddRNDIS();
    OS_CREATETASK(&_RNDISTCB, "USB RNDISTask",
                  _RndisTask, TASK_PRIO_RNDIS_TASK, _aRNDISStack);
    USB_Start();
    return 0; // Successfully connected.
}
```

The first step is to initialize the DHCP server component which assigns the IP address for the PC side. The target is configured with the IP address 10.0.0.10. The DHCP server is configured to distribute IP addresses starting from 10.0.0.11, therefore the PC will receive the IP address 10.0.0.11. Then the USB stack is initialized and the RNDIS interface is added to it. The function `_AddRNDIS()` configures all required endpoints and configures the HW address of the PC network interface.

```
// _AddRNDIS() - excerpt from IP_Config_RNDIS.c
static void _AddRNDIS(void) {
    USB_RNDIS_INIT_DATA InitData;
    InitData.EPOut = USB_AddeP(USB_DIR_OUT,
                               USB_TRANSFER_TYPE_BULK,
                               0,
                               _acReceiveBuffer,
                               USB_MAX_PACKET_SIZE);
    InitData.EPIn = USB_AddeP(USB_DIR_IN, USB_TRANSFER_TYPE_BULK, 0, NULL, 0);
    InitData.EPInt = USB_AddeP(USB_DIR_IN, USB_TRANSFER_TYPE_INT, 5, NULL, 0);
    InitData.pEventAPI = &_EventAPI;
    InitData.pDriverAPI = &USB_RNDIS_Driver_IP_NI;
    InitData.DriverData.pHWAddr = "\x00\x22\xC7\xFF\xFF\xF3";
    InitData.DriverData.NumBytesHWAddr = 6;
    USB_RNDIS_Add(&InitData);
}
```

The size of `_acReceiveBuffer` buffer must be a multiple of USB max packet size. The `USB_MAX_PACKET_SIZE` define is set to the correct max packet size value for the corresponding speed (full or high) and is used in the samples to declare buffer sizes. `_EventAPI` is a table with functions which manipulate OS events. The events are used by the RNDIS component to synchronize with the USB interrupt. `USB_RNDIS_Driver_IP_NI` is the network interface driver which implements the connection to the IP stack. The HW address configured here is assigned to the PC network interface. The HW address of the IP stack is configured in the `IP_X_Config()` function of embOS/IP as described below.

```

// Excerpt from IP_Config.c
static OS_EVENT _Event;

static void * _cbCreateEvent(void) {
    OS_EVENT_Create(&_Event);
    return &_Event;
}

static void _cbSignalEvent(void * pEvent) {
    OS_EVENT_Pulse((OS_EVENT *)pEvent);
}

static int _cbWaitEventTimed(void * pEvent, unsigned ms) {
    return OS_EVENT_WaitTimed((OS_EVENT *)pEvent, ms);
}

static USB_RNDIS_EVENT_API _EventAPI = {
    _cbCreateEvent,
    _cbSignalEvent,
    _cbWaitEventTimed
};

```

The IP stack is configured to use the network interface driver of emUSB-RNDIS. For more information about the configuration of the IP stack refer to embOS/IP manual.

```


// IP_X_Config() - excerpt from IP_Config.c
#include "USB_RNDIS_Driver_IP_NI.h"

void IP_X_Config(void) {
    <...>
    //
    // Add and configure the RNDIS driver.
    // The local IP address is 10.0.0.10/8.
    //
    IP_AddEtherInterface(&USB_RNDIS_IP_Driver);
    IP_SetHWAddr("\x00\x22\xC7\xff\xff\xff");
    IP_SetAddrMask(0x0A00000A, 0xFF000000);
    IP_SetIFaceConnectHook(IFaceId, _Connect);
    IP_SetIFaceDisconnectHook(IFaceId, _Disconnect);
    <...>
}

```

## 13.4 RNDIS + embOS/IP as a "USB Webserver"

This method of using RNDIS provides a unique customer experience where a USB device can provide a custom web page or any other service through which a customer can interact with the device.



Initially the PC recognizes an RNDIS device. In case of Windows XP and Vista a driver will be necessary, Windows 7 and above as well as Linux recognize RNDIS automatically. RNDIS from the viewpoint of the PC is a normal Network Interface Controller (NIC) and the PC handles it as such. The default behavior is to request an IP address from a DHCP server. The PC retrieves an IP address from the DHCP-Server in the device. In our standard sample code the device has the local IP 10.0.0.10 and the PC will get 10.0.0.11 from the DHCP server. With this the configuration is complete and the user can access the web-interface located on the USB device via 10.0.0.10. To improve the ease-of-use NetBIOS can be used to give the device an easily readable name.

## 13.5 Target API

| Function                              | Description                                          |
|---------------------------------------|------------------------------------------------------|
| API functions                         |                                                      |
| <a href="#">USB_RNDIS_Add()</a>       | Adds a RNDIS-class interface to the USB stack.       |
| <a href="#">USB_RNDIS_Task()</a>      | Handles the RNDIS protocol.                          |
| Data structures                       |                                                      |
| <a href="#">USB_RNDIS_INIT_DATA</a>   | Initialization data for RNDIS interface.             |
| <a href="#">USB_RNDIS_EVENT_API</a>   | API functions for OS event handling.                 |
| <a href="#">USB_RNDIS_DRIVER_API</a>  | Network interface driver API functions.              |
| <a href="#">USB_RNDIS_DRIVER_DATA</a> | Configuration data for the network interface driver. |

**Table 13.3: List of emUSB RNDIS module functions and data structures**



## 13.5.1 API functions

### 13.5.1.1 USB\_RNDIS\_Add()

#### Description

Adds an RNDIS-class interface to the USB stack.

#### Prototype

```
void USB_RNDIS_Add(const USB_RNDIS_INIT_DATA * pInitData);
```

| Parameter              | Description                                                 |
|------------------------|-------------------------------------------------------------|
| <code>pInitData</code> | IN: Pointer to a USB_RNDIS_INIT_DATA structure.<br>OUT: --- |

**Table 13.4: USB\_RNDIS\_Add() parameter list**

#### Additional information

This function should be called after the initialization of the USB core to add an RNDIS interface to emUSB. The initialization data is passed to the function in the structure pointed to by `pInitData`. Refer to *USB\_RNDIS\_INIT\_DATA* on page 403 for more information.

### 13.5.1.2 USB\_RNDIS\_Task()

#### Description

Handles the RNDIS protocol.

#### Prototype

```
void USB_RNDIS_Task(void);
```

#### Additional information

The function should be called periodically after the USB device has been successfully enumerated and configured. The function returns when the USB device is detached or suspended. For a sample usage refer to *IP\_Config\_RNDIS.c in detail* on page 397.

## 13.5.2 Data structures

### 13.5.2.1 USB\_RNDIS\_INIT\_DATA

#### Description

Initialization data for RNDIS interface.

#### Prototype

```
typedef struct USB_RNDIS_INIT_DATA {
    U8 EPIn;
    U8 EPOut;
    U8 EPInt;
    const USB_RNDIS_EVENT_API * pEventAPI;
    const USB_RNDIS_DRIVER_API * pDriverAPI;
    USB_RNDIS_DRIVER_DATA      DriverData;
} USB_RNDIS_INIT_DATA;
```

| Member                     | Description                                                                                            |
|----------------------------|--------------------------------------------------------------------------------------------------------|
| <a href="#">EPIn</a>       | Endpoint for sending data to the host.                                                                 |
| <a href="#">EPOut</a>      | Endpoint for receiving data from the host.                                                             |
| <a href="#">EPInt</a>      | Endpoint for sending status information.                                                               |
| <a href="#">pEventAPI</a>  | Pointer to the API for OS event handling.<br>(See <i>USB_RNDIS_EVENT_API</i> on page 404)              |
| <a href="#">pDriverAPI</a> | Pointer to the Network interface driver API.<br>(See <i>USB_RNDIS_DRIVER_API</i> on page 405)          |
| <a href="#">DriverData</a> | Configuration data for the network interface driver.<br>(See <i>USB_RNDIS_DRIVER_DATA</i> on page 411) |

**Table 13.5: USB\_RNDIS\_INIT\_DATA elements**

#### Additional information

This structure holds the endpoints that should be used by the RNDIS interface ([EPIn](#), [EPOut](#) and [EPInt](#)). Refer to *USB\_AddEP()* on page 59 for more information about how to add an endpoint.

13.5.2.2 USB\_RNDIS\_EVENT\_API

Description

API for OS event handling.

Prototype

```
typedef struct USB_RNDIS_EVENT_API {
    void * (*pfCreate)      (void);
    void   (*pfSignal)      (void * pEvent);
    int     (*pfWaitTimed)   (void * pEvent, unsigned Timeout);
} USB_RNDIS_EVENT_API;
```

| Member           | Description                          |
|------------------|--------------------------------------|
| (*pfCreate)()    | Creates an OS event.                 |
| (*pfSignal)()    | Signals an OS event.                 |
| (*pfWaitTimed)() | Wait for an OS event to be signaled. |

Table 13.6: USB\_RNDIS\_EVENT\_API elements

Additional information

The functions of this API are used by the emUSB-RNDIS component to wait efficiently in USB\_RNDIS\_Task() for events generated in the USB interrupt. For a detailed description of the API functions refer to *USB\_RNDIS\_EVENT\_API in detail* on page 412.

### 13.5.2.3 USB\_RNDIS\_DRIVER\_API

#### Description

This structure contains the callback functions for the network interface driver.

#### Prototype

```
typedef struct USB_RNDIS_DRIVER_API {
    void (*pfInit) (const USB_RNDIS_DRIVER_DATA * pDriverData);
    void * (*pfGetPacketBuffer) (unsigned NumBytes);
    void (*pfWritePacket) (const void * pData, unsigned NumBytes);
    void (*pfSetPacketFilter) (U32 Mask);
    int (*pfGetLinkStatus) (void);
    U32 (*pfGetLinkSpeed) (void);
    void (*pfGetHWAddr) (U8 * pAddr, unsigned NumBytes);
    U32 (*pfGetStats) (int Type);
    U32 (*pfGetMTU) (void);
    void (*pfReset) (void);
} USB_RNDIS_DRIVER_API;
```

| Member                              | Description                                                           |
|-------------------------------------|-----------------------------------------------------------------------|
| <code>(*pfInit)()</code>            | Initializes the driver.                                               |
| <code>(*pfGetPacketBuffer)()</code> | Returns a buffer for a data packet.                                   |
| <code>(*pfWritePacket)()</code>     | Delivers a data packet to target IP stack.                            |
| <code>(*pfSetPacketFilter)()</code> | Configures the type of accepted data packets.                         |
| <code>(*pfGetLinkStatus)()</code>   | Returns the status of the connection to target IP stack.              |
| <code>(*pfGetLinkSpeed)()</code>    | Returns the connection speed.                                         |
| <code>(*pfGetHWAddr)()</code>       | Returns the HW address of the PC.                                     |
| <code>(*pfGetStats)()</code>        | Returns statistical counters.                                         |
| <code>(*pfGetMTU)()</code>          | Returns the size of the largest data packet which can be transferred. |
| <code>(*pfReset)()</code>           | Resets the driver.                                                    |

**Table 13.7: USB\_RNDIS\_DRIVER\_API elements**

#### Additional information

The emUSB-RNDIS component calls the functions of this API to exchange data and status information with the IP stack running on the target.

## (\*pfInit)()

### Description

Initializes the driver.

### Prototype

```
void (*pfInit)(const USB_RNDIS_DRIVER_DATA * pDriverData);
```

| Parameter                   | Description                                           |
|-----------------------------|-------------------------------------------------------|
| <a href="#">pDriverData</a> | IN: Pointer to driver configuration data.<br>OUT: --- |

**Table 13.8: (\*pfInit)() parameter list**

### Additional information

This function is called when the RNDIS interface is added to USB stack. Typically the function makes a local copy of the HW address passed in the `pDriverData` structure. For more information this structure refer to *USB\_RNDIS\_DRIVER\_DATA* on page 411.

## (\*pfGetPacketBuffer)()

### Description

Returns a buffer for a data packet.

### Prototype

```
void * (*pfGetPacketBuffer)(unsigned NumBytes);
```

| Parameter                | Description                            |
|--------------------------|----------------------------------------|
| <a href="#">NumBytes</a> | Size of the requested buffer in bytes. |

**Table 13.9: (\*pfGetPacketBuffer)() parameter list**

### Return value

!= NULL: Pointer to allocated buffer  
 == NULL: No buffer available

### Additional information

The function should allocate a buffer of the requested size. If the buffer can not be allocated a NULL pointer should be returned. The function is called when a data packet is received from PC. The packet data is stored in the returned buffer.

## (\*pfWritePacket)()

### Description

Delivers a data packet to target IP stack

### Prototype

```
void (*pfWritePacket)(const void * pData, unsigned NumBytes);
```

| Parameter                | Description                                  |
|--------------------------|----------------------------------------------|
| <a href="#">pData</a>    | IN: Data of the received packet.<br>OUT: --- |
| <a href="#">NumBytes</a> | Number of bytes stored in the buffer.        |

**Table 13.10: (\*pfWriteBuffer)() parameter list**

### Additional information

The function is called after a data packet has been received from USB. `pData` points to the buffer returned by the `(*pfGetPacketBuffer)()` function.

## (\*pfSetPacketFilter)()

### Description

Configures the type of accepted data packets

### Prototype

```
void (*pfSetPacketFilter)(U32 Mask);
```

| Parameter            | Description                   |
|----------------------|-------------------------------|
| <a href="#">Mask</a> | Type of accepted data packets |

**Table 13.11: (\*pfSetPacketFilter)() parameter list**

### Additional information

The `Mask` parameter should be interpreted as a boolean value. A value different than 0 indicates that the connection to target IP stack should be established. When the function is called with the `Mask` parameter set to 0 the connection to target IP stack should be interrupted.

## (\*pfGetLinkStatus)()

### Description

Returns the status of the connection to target IP stack.

### Prototype

```
int (*pfGetLinkStatus)(void);
```

### Return value

`==USB_RNDIS_LINK_STATUS_CONNECTED:`  
Connected to target IP stack

`==USB_RNDIS_LINK_STATUS_DISCONNECTED:`  
Not connected to target IP stack

## (\*pfGetLinkSpeed)()

### Description

Returns the connection speed.

### Prototype

```
U32 (*pfGetLinkSpeed)(void);
```

### Return value

The connection speed in units of 100 bits/sec or 0 if not connected.

## (\*pfGetHWAddr)()

### Description

Returns the HW address of PC.

### Prototype

```
void (*pfGetHWAddr)(U8 * pAddr, unsigned NumBytes);
```

| Parameter             | Description                                            |
|-----------------------|--------------------------------------------------------|
| <code>pAddr</code>    | IN: ---<br>OUT: The HW address                         |
| <code>NumBytes</code> | Maximum number of bytes to store to <code>pAddr</code> |

**Table 13.12: (\*pfGetHWAddr)() parameter list**

### Additional information

The returned HW address is the one passed to the driver in the call to `(*pfInit)()`. Typically the HW address is 6 bytes large.



## (\*pfGetStats)()

### Description

Returns statistical counters.

### Prototype

```
U32 (*pfGetStats)(int Type);
```

| Parameter | Description                                                     |
|-----------|-----------------------------------------------------------------|
| Type      | The type of information requested. Can be one of these defines: |

**Table 13.13: (\*pfGetStats)() parameter list**

| Permitted values for parameter Type   |                                                                                                           |
|---------------------------------------|-----------------------------------------------------------------------------------------------------------|
| USB_RNDIS_STATS_WRITE_PACKET_OK       | Number of packets sent without errors to target IP stack                                                  |
| USB_RNDIS_STATS_WRITE_PACKET_ERROR    | Number of packets sent with errors to target IP stack                                                     |
| USB_RNDIS_STATS_READ_PACKET_OK        | Number of packets received without errors from target IP stack                                            |
| USB_RNDIS_STATS_READ_PACKET_ERROR     | Number of packets received with errors from target IP stack                                               |
| USB_RNDIS_STATS_READ_NO_BUFFER        | Number of packets received from target IP stack but dropped.                                              |
| USB_RNDIS_STATS_READ_ALIGN_ERROR      | Number of packets received from target IP stack with alignment errors.                                    |
| USB_RNDIS_STATS_WRITE_ONE_COLLISION   | Number of packets which were not sent to target IP stack due to the occurrence of one collision.          |
| USB_RNDIS_STATS_WRITE_MORE_COLLISIONS | Number of packets which were not sent to target IP stack due to the occurrence of one or more collisions. |

### Return value

Value of the requested statistical counter.

### Additional information

The counters should be set to 0 when the (\*pfReset)() function is called.

**(\*pfGetMTU)()****Description**

Returns the size of the largest data packet which can be transferred.

**Prototype**

```
U32 (*pfGetMTU) (void);
```

**Return value**

The MTU size in bytes. Typically 1500 bytes.

**(\*pfReset)()****Description**

Resets the driver.

**Prototype**

```
void (*pfReset) (void);
```

### 13.5.2.4 USB\_RNDIS\_DRIVER\_DATA

#### Description

Configuration data passed to network interface driver at initialization.

#### Prototype

```
typedef struct USB_RNDIS_DRIVER_DATA {
    const U8 * pHWAddr;
    unsigned   NumBytesHWAddr;
} USB_RNDIS_DRIVER_DATA;
```

| Member                         | Description                                                |
|--------------------------------|------------------------------------------------------------|
| <a href="#">pHWAddr</a>        | HW address (or MAC address) of the host network interface. |
| <a href="#">NumBytesHWAddr</a> | Number of bytes in the HW address. Typically 6 bytes.      |

**Table 13.14: USB\_RNDIS\_DRIVER\_DATA elements**

### 13.5.2.5 USB\_RNDIS\_EVENT\_API in detail

This section describes the functions of the API which are used to handle OS events.

#### Description

This structure contains function pointers which are required by the RNDIS module to handle events, this can be used to map the functions to any RTOS.

#### Prototype

```
typedef struct USB_RNDIS_EVENT_API {
    void * (*pfCreate)      (void);
    void   (*pfSignal)      (void * pEvent);
    int    (*pfWaitTimed)   (void * pEvent, unsigned Timeout);
} USB_RNDIS_EVENT_API;
```

| Member                         | Description                                |
|--------------------------------|--------------------------------------------|
| <a href="#">(*pfCreate)</a>    | Initializes the driver.                    |
| <a href="#">(*pfSignal)</a>    | Returns a buffer for a data packet.        |
| <a href="#">(*pfWaitTimed)</a> | Delivers a data packet to target IP stack. |

**Table 13.15: USB\_RNDIS\_EVENT\_API elements**

#### (\*pfCreate)()

##### Description

Creates a new OS event.

##### Prototype

```
void * (*pfCreate)(void);
```

##### Return value

!= 0: Event has been created, the return value is the pointer to the event.  
 ==0: An error occurred

##### Example

For a sample implementation refer to *IP\_Config\_RNDIS.c in detail* on page 397.

#### (\*pfSignal)()

##### Description

Indicates that the event occurred.

##### Prototype

```
void (*pfSignal)(void * pEvent);
```

| Parameter              | Description                                             |
|------------------------|---------------------------------------------------------|
| <a href="#">pEvent</a> | IN: Pointer to the OS event to be signaled.<br>OUT: --- |

**Table 13.16: (\*pfSignal)() parameter list**

##### Example

For a sample implementation refer to *IP\_Config\_RNDIS.c in detail* on page 397.

## (\*pfWaitTimed)()

### Description

Waits for the event to occur with a timeout.

### Prototype

```
int (*pfWaitTimed)(void * pEvent, unsigned Timeout);
```

| Parameter            | Description                                                  |
|----------------------|--------------------------------------------------------------|
| <code>pEvent</code>  | IN: Pointer to the OS event to wait for.<br>OUT: ---         |
| <code>Timeout</code> | Number of milliseconds to wait for the event to be signaled. |

**Table 13.17: (\*pfWaitTimed)() parameter list**

### Return value

`==0`: Success, the event was signaled within the specified time.

`!= 0`: The event was not signaled within the specified timeout.

### Additional information

The function blocks the execution of the calling task until the event is signaled or the timeout expired.

### Example

For a sample implementation refer to *IP\_Config\_RNDIS.c* in detail on page 397.



# Chapter 14

## Combining USB components (Multi-Interface)

---


In some cases, it is necessary to combine different USB components in one device. This chapter will describe how to do this and which steps are necessary.

## 14.1 Overview

The USB specification allows implementation of more than one component (function) in a single device. This is achieved by combining two or more components. These devices will be recognized by the USB host as composite device and each component will be recognized as an independent device.

One device, for example a data logger, can have two components:


This device can show log data files that were stored on a NAND flash through the MSD component. And the configuration of the data logger can be changed by using a BULK component, CDC component or even HID component.





### 14.1.1 Single interface device classes

Components can be combined because most USB device classes are based on one interface. This means that those components describe themselves at the interface descriptor level and thus makes it easy to combine different or even the same device classes into one device. Such devices classes are MSD, HID and generic bulk.




## 14.1.2 Multiple interface device classes

In contrast to the single interfaces classes there are classes with multiple interfaces such as CDC and AUDIO or VIDEO class. These classes define their class identifier in the device descriptor. All interface descriptors are recognized as part of the component that is defined in the device descriptor. This prevents the combination of multiple interface device classes (for example, CDC) with any other component.

## 14.1.3 IAD class

To remove this limitation the USB organization defines a descriptor type that allows the combination of single interface device classes with multiple interface device classes. This descriptor is called an Interface Association Descriptor (IAD). It decouples the multi-interface class from other interfaces.



Since IAD is an extension to the original USB specification, it is not supported by all hosts, especially older host software. If IAD is not supported, the device may not be enumerated correctly.

### Supported HOST

At the time of writing, IAD is supported by:

- Windows XP with Service pack 2 and newer
- Linux Kernel 2.6.22 and higher

## 14.2 Configuration

In general, no configuration is required. By default, emUSB supports up to four interfaces. If more interfaces are needed the following macro must be modified:

| Type    | Macro                           | Default | Description                                                                         |
|---------|---------------------------------|---------|-------------------------------------------------------------------------------------|
| Numeric | <a href="#">USB_MAX_NUM_IF</a>  | 4       | Defines the maximum number of interfaces emUSB shall handle.                        |
| Numeric | <a href="#">USB_MAX_NUM_IAD</a> | 1       | Defines the maximum number of Interface Association Descriptors emUSB shall handle. |

## 14.3 How to combine

Combining different single interface emUSB components (Bulk, HID, MSD) is an easy step, all that needs to be done is calling the appropriate `USB_XXX_Add()` function. For adding the CDC component additional steps need to be taken. For detailed information, refer to *emUSB component specific modification* on page 424 and check the following sample.

### Requirements

- RTOS, every component requires a separate task.
- Sufficient endpoints for all used device classes. Make sure that your USB device controller has enough endpoints available to handle all the interfaces that shall be integrated.

### Sample application

The following sample application uses embOS as the RTOS. This listing is taken from `USB_CompositeDevice_CDC_MSD.c`.

```

/*****
 *          SEGGER MICROCONTROLLER GmbH & Co. KG
 *      Solutions for real time microcontroller applications
 *****/
 *
 *      (c) 2003-2011      SEGGER Microcontroller GmbH & Co KG
 *
 *      Internet: www.segger.com      Support:  support@segger.com
 *
 *****/
 *
 *      USB device stack for embedded applications
 *
 *****/
-----
File      : USB_CompositeDevice_CDC_MSD.c
Purpose   : Sample showing a USB device with multiple interfaces (CDC+MSD).
-----
END-OF-HEADER
*/

#include <stdio.h>
#include <stdio.h>
#include "USB.h"
#include "USB_CDC.h"
#include "BSP.h"
#include "USB_MSD.h"
#include "FS.h"
#include "RTOS.h"

/*****
 *
 *      Const data
 *
 *****/
*/

/*****
 *
 *      Static data
 *
 *****/
*/
// Data for MSD Task
static OS_STACKPTR int _aMSDStack[512]; /* Task stacks */
static OS_TASK _MSDTCB;                 /* Task-control-blocks */

/*****
 *
 *      Static code
 *
 *****/
*/

/*****
 *
 *      _AddMSD
 *
 *****/

```

```

*   Function description
*   Add mass storage device to USB stack
*/
static void _AddMSD(void) {
    static U8 _abOutBuffer[USB_MAX_PACKET_SIZE];
    USB_MSD_INIT_DATA    InitData;
    USB_MSD_INST_DATA     InstData;

    InitData.EPIn  = USB_AddEP(1, USB_TRANSFER_TYPE_BULK, USB_MAX_PACKET_SIZE, NULL,
0);
    InitData.EPOut = USB_AddEP(0, USB_TRANSFER_TYPE_BULK, USB_MAX_PACKET_SIZE,
_abOutBuffer, USB_MAX_PACKET_SIZE);
    USB_MSD_Add(&InitData);
    //
    // Add logical unit 0: RAM drive, using SDRAM
    //
    memset(&InstData, 0, sizeof(InstData));
    InstData.pAPI          = &USB_MSD_StorageByName;
    InstData.DriverData.pStart = (void *)"";
    USB_MSD_AddUnit(&InstData);
}
/*****
*
*   _MSDTask
*
*   Function description
*   Add mass storage device to USB stack
*/
static void _MSDTask(void) {
    while (1) {
        while ((USB_GetState() & (USB_STAT_CONFIGURED | USB_STAT_SUSPENDED)) !=
USB_STAT_CONFIGURED) {
            USB_OS_Delay(50);
        }
        USB_MSD_Task();
    }
}

/*****
*
*   _OnLineCoding
*
*   Function description
*   Called whenever a "SetLineCoding" Packet has been received
*
*   Notes
*   (1) Context
*       This function is called directly from an ISR in most cases.
*/
static void _OnLineCoding(USB_CDC_LINE_CODING * pLineCoding) {
#if 0
    printf("DTERate=%u, CharFormat=%u, ParityType=%u, DataBits=%u\n",
pLineCoding->DTERate,
pLineCoding->CharFormat,
pLineCoding->ParityType,
pLineCoding->DataBits);
#else
    BSP_USE_PARA(pLineCoding);
#endif
}

/*****
*
*   _AddCDC
*
*   Function description
*   Add communication device class to USB stack
*/
static void _AddCDC(void) {
    static U8 _abOutBuffer[USB_MAX_PACKET_SIZE];
    USB_CDC_INIT_DATA    InitData;

    InitData.EPIn  = USB_AddEP(USB_DIR_IN, USB_TRANSFER_TYPE_BULK, 0, NULL, 0);
    InitData.EPOut = USB_AddEP(USB_DIR_OUT, USB_TRANSFER_TYPE_BULK, 0, _abOutBuffer,
USB_MAX_PACKET_SIZE);
    InitData.EPInt = USB_AddEP(USB_DIR_IN, USB_TRANSFER_TYPE_INT, 8, NULL, 0);
    USB_CDC_Add(&InitData);
    USB_CDC_SetOnLineCoding(_OnLineCoding);
}

```

```

/*****
 *
 *      Public code
 *
 *****/

/*****
 *
 *      Get information that are used during enumeration
 */

/*****
 *
 *      USB_GetVendorName
 *
 *      Function description
 *      Returns vendor Id
 */
U16 USB_GetVendorId(void) {
    return 0x8765;
}

/*****
 *
 *      USB_GetProductId
 *
 *      Function description
 *      Returns the product Id
 */
U16 USB_GetProductId(void) {
    return 0x1256;
}

/*****
 *
 *      USB_GetVendorName
 *
 *      Function description
 *      Returns vendor name.
 */
const char * USB_GetVendorName(void) {
    return "Vendor";
}

/*****
 *
 *      USB_GetProductName
 *
 *      Function description
 *      Returns product name
 */
const char * USB_GetProductName(void) {
    return "MSD/CDC Composite device";
}

/*****
 *
 *      USB_GetSerialNumber
 *
 *      Function description
 *      Returns serial number
 */
const char * USB_GetSerialNumber(void) {
    return "1234567890ABCDEF";
}

/*****
 *
 *      String information routines when inquiring the volume
 */
/*****
 *
 *      USB_MSD_GetVendorName
 */
const char * USB_MSD_GetVendorName(U8 Lun) {
    BSP_USE_PARA(Lun);
    return "Vendor";
}

```

```

/*****
*
*      USB_MSD_GetProductName
*/
const char * USB_MSD_GetProductName(U8 Lun) {
    BSP_USE_PARA(Lun);
    return "MSD Volume";
}

/*****
*
*      USB_MSD_GetProductVer
*/
const char * USB_MSD_GetProductVer(U8 Lun) {
    BSP_USE_PARA(Lun);
    return "1.00";
}

/*****
*
*      USB_MSD_GetSerialNo
*/
const char * USB_MSD_GetSerialNo(U8 Lun) {
    BSP_USE_PARA(Lun);
    return "134657890";
}

/*****
*
*      MainTask
*
*      USB handling task.
*      Modify to implement the desired protocol
*/
#ifdef __cplusplus
extern "C" { /* Make sure we have C-declarations in C++ programs */
#endif
void MainTask(void);
#ifdef __cplusplus
}
#endif
void MainTask(void) {

    USB_Init();
    USB_EnableIAD();
    _AddCDC();
    _AddMSD();
    USB_Start();
    BSP_SetLED(0);
    OS_CREATETASK(&_MSDTCB, "MSDTask", _MSDTask, 200, _aMSDStack);

    while (1) {
        char ac[64];
        int  NumBytesReceived;

        //
        // Wait for configuration
        //
        while ((USB_GetState() & (USB_STAT_CONFIGURED | USB_STAT_SUSPENDED)) !=
USB_STAT_CONFIGURED) {
            BSP_ToggleLED(0);
            USB_OS_Delay(50);
        }
        BSP_SetLED(0);
        NumBytesReceived = USB_CDC_Receive(&ac[0], sizeof(ac));
        if (NumBytesReceived > 0) {
            USB_CDC_Write(&ac[0], NumBytesReceived);
        }
    }
}

/***** end of file *****/

```

## 14.4 emUSB component specific modification

There are different steps for each emUSB component. The next section shows what needs to be done on both sides: device and host-side.

### 14.4.1 BULK communication component

#### 14.4.1.1 Device side

No modification on device side needs to be made.

#### 14.4.1.2 Host side

Windows will recognize the device as a composite device. It will load the drivers for each interface.

In order to recognize the bulk interface in the composite device, the `.inf` file of the device needs to be modified.

Windows will extend the device identification string with the interface number. This has to be added to the device identification string in the `.inf` file.

The provided `.inf` file:

```
;
; Generic USBBulk driver setup information file
; Copyright (c) 2006-2008 by SEGGER Microcontroller GmbH & Co. KG
;
; This file supports:
;   Windows 2000
;   Windows XP
;   Windows Server 2003 x86
;   Windows Vista x86
;   Windows Server 2008 x86
;
[Version]
Signature="$Windows NT$"
Provider=%MfgName%
Class=USB
ClassGUID={36FC9E60-C465-11CF-8056-444553540000}
DriverVer=03/19/2008,2.6.6.0
CatalogFile=USBBulk.cat

[Manufacturer]
%MfgName%=DeviceList

[DeviceList]
%USB\VID_8765&PID_1234.DeviceDesc%=USBBulkInstall, USB\VID_8765&PID_1234&Mi_xx

[USBBulkInstall.ntx86]
CopyFiles=USBBulkCopyFiles

[USBBulkInstall.ntx86.Services]
AddService = usbbulk, 0x00000002, USBBulkAddService, USBBulkEventLog

[USBBulkAddService]
DisplayName     = %USBBulk.SvcDesc%
ServiceType     = 1                      ; SERVICE_KERNEL_DRIVER
StartType       = 3                      ; SERVICE_DEMAND_START
ErrorControl     = 1                      ; SERVICE_ERROR_NORMAL
ServiceBinary    = %10%\System32\Drivers\USBBulk.sys

[USBBulkEventLog]
AddReg=USBBulkEventLogAddReg

[USBBulkEventLogAddReg]
HKR,,EventMessageFile,%REG_EXPAND_SZ%, "%SystemRoot%\System32\IoLogMsg.dll;%%SystemRoot%\System32\drivers\USBBulk.sys"
HKR,,TypesSupported,  %REG_DWORD%,7

[USBBulkCopyFiles]
USBBulk.sys

[DestinationDirs]
DefaultDestDir = 10,System32\Drivers
USBBulkCopyFiles = 10,System32\Drivers
```



```

[SourceDisksNames.x86]
1=%USBBulk.DiskName%, ,

[SourceDisksFiles.x86]
USBBulk.sys = 1

;-----;

[Strings]
MfgName="Segger"
USB\VID_8765&PID_1234.DeviceDesc="USB Bulk driver"
USBBulk.SvcDesc="USBBulk driver"
USBBulk.DiskName="USBBulk Installation Disk"

; Non-Localizable Strings, DO NOT MODIFY!
REG_SZ          = 0x00000000
REG_MULTI_SZ    = 0x00010000
REG_EXPAND_SZ   = 0x00020000
REG_BINARY      = 0x00000001
REG_DWORD       = 0x00010001

; *** EOF ***

```

Please add the red colored text to your .inf file and change xx with the interface number of the bulk component.

The interface number is a zero-based index and is assigned by the emUSB stack when calling the USB\_BULK\_Add() function. If you have called USB\_BULK\_Add() prior to any other USB\_XXX\_Add() functions then the interface number will be 00.

Please note that when USB\_CDC\_Add() is called prior USB\_BULK\_Add(), the interface number for the BULK component will be 02 since the CDC component uses two interfaces (in the example, 00 and 01).

## 14.4.2 MSD component

### 14.4.2.1 Device side

No modification on device side needs to be made.

### 14.4.2.2 Host side

No modification on host side needs to be made.

## 14.4.3 CDC component

### 14.4.3.1 Device side

In order to combine the CDC component with other components, the function `USB_EnableIAD()` needs to be called, otherwise the device will not enumerate correctly. Refer to section *How to combine* on page 420 and check the listing of the sample application.

### 14.4.3.2 Host side

Due to a limitation of the internal CDC serial driver of Windows, a composite device with CDC component and another device component(s) is only properly recognized by Windows XP SP3 and Windows Vista and above. Linux kernel supports IAD with version 2.6.22.

For Windows the `.inf` file needs to be modified.

As in the Bulk communication component, Windows will extend the device identification strings. Therefore the device identification string must be modified.

The provided `.inf` file:

```
;
; Device installation file for
; USB 2 COM port emulation
;
;
;
[Version]
Signature="$Windows NT$"
Class=Ports
ClassGuid={4D36E978-E325-11CE-BFC1-08002BE10318}
Provider=%MFGNAME%
LayoutFile=layout.inf
DriverVer=03/26/2007,6.0.2600.1
CatalogFile=usbser.cat

[Manufacturer]
%MFGNAME%=CDCDevice,NT,NTamd64

[DestinationDirs]
DefaultDestDir = 12

[CDCDevice.NT]
%DESCRIPTION%=DriverInstall,USB\VID_8765&PID_1111&Mi_xx

[CDCDevice.NTamd64]
%DESCRIPTION%=DriverInstall,USB\VID_8765&PID_0234&Mi_xx
%DESCRIPTION%=DriverInstall,USB\VID_8765&PID_1111&Mi_xx

[DriverInstall.NT]
```

```

Include=mdmcpq.inf
CopyFiles=FakeModemCopyFileSection
AddReg=DriverInstall.NT.AddReg

[DriverInstall.NT.AddReg]
HKR,,DevLoader,,*ntkern
HKR,,NTMPDriver,,usbser.sys
HKR,,EnumPropPages32,, "MsPorts.dll,SerialPortPropPageProvider"

[DriverInstall.NT.Services]
AddService=usbser, 0x00000002, DriverServiceInst

[DriverServiceInst]
DisplayName=%SERVICE%
ServiceType=1
StartType=3
ErrorControl=1
ServiceBinary=%12%\usbser.sys

[Strings]
MFGNAME = "Manufacturer"
DESCRIPTION = "USB CDC serial port emulation"
SERVICE = "USB CDC serial port emulation"

```

Please add the red colored text to your .inf file and change xx with the interface number of the CDC component.

The interface number is a zero based index and is assigned by the emUSB stack when calling USB\_CDC\_Add() function.

## **14.4.4 HID component**

### **14.4.4.1 Device side**

No modification on device side needs to be made.

### **14.4.4.2 Host side**

No modification on host device side needs to be made.

# Chapter 15

## Target OS Interface

---

This chapter describes the functions of the operating system abstraction layer.

## 15.1 General information

emUSB includes an OS abstraction layer which should make it possible to use an arbitrary operating system together with emUSB. To adapt emUSB to a new OS one only has to map the functions listed below in section *Interface function list* on page 431 to the native OS functions.

SEGGER took great care when designing this abstraction layer, to make it easy to understand and to adapt to different operating systems.

### 15.1.1 Operating system support supplied with this release

In the current version, abstraction layers for embOS and  $\mu$ C/OS-II are available.

A kernel abstraction layer for using emUSB-Device without any RTOS (superloop) is also supplied.

Abstraction layers for other operating systems are available upon request.

## 15.2 Interface function list

| Routine                          | Explanation                                                                             |
|----------------------------------|-----------------------------------------------------------------------------------------|
| <code>USB_OS_Delay()</code>      | Delays for a given number of ms.                                                        |
| <code>USB_OS_DecRI()</code>      | Decrements the interrupt disable count and enables interrupts if the counter reaches 0. |
| <code>USB_OS_GetTickCnt()</code> | Returns the current system time in ticks.                                               |
| <code>USB_OS_IncDI()</code>      | Increments the interrupt disable count and disables interrupts.                         |
| <code>USB_OS_Init()</code>       | Initializes the OS.                                                                     |
| <code>USB_OS_Panic()</code>      | Called if fatal error is detected.                                                      |
| <code>USB_OS_Signal()</code>     | Wakes the task waiting for signal.                                                      |
| <code>USB_OS_Wait()</code>       | Blocks the task until <code>USB_OS_Signal()</code> is called.                           |
| <code>USB_OS_WaitTimed()</code>  | Blocks the task until <code>USB_OS_Signal()</code> is called or a timeout occurs.       |

**Table 15.1: Target OS interface function list**

## 15.2.1 USB\_OS\_Delay()

### Description

Delays for a given number of ms.

### Prototype

```
void USB_OS_Delay(int ms);
```

| Parameter          | Description   |
|--------------------|---------------|
| <a href="#">ms</a> | Number of ms. |

**Table 15.2: USB\_OS\_Delay() parameter list**



## 15.2.2 USB\_OS\_DecRI()

### Description

Decrements interrupt disable count and enable interrupts if counter reaches 0.

### Prototype

```
void USB_OS_DecRI(void);
```

### 15.2.3 USB\_OS\_GetTickCnt()

**Description**

Returns the current system time in ticks.

**Prototype**

```
U32 USB_OS_GetTickCnt(void);
```

## 15.2.4 USB\_OS\_IncDI()

### Description

Increments interrupt disable count and disables interrupts.

### Prototype

```
void USB_OS_IncDI(void);
```

## 15.2.5 USB\_OS\_Init()

### Description

Initializes OS.

### Prototype

```
void USB_OS_Init(void);
```

## 15.2.6 USB\_OS\_Panic()

### Description

Halts emUSB.

### Prototype

```
void USB_OS_Panic(unsigned ErrCode);
```

| Parameter               | Description |
|-------------------------|-------------|
| <a href="#">ErrCode</a> | Error code. |

**Table 15.3: USB\_OS\_Panic() parameter list**

### Additional information

| Errorcode          | Explanation                                 |
|--------------------|---------------------------------------------|
| <a href="#">1</a>  | USB_ERROR_RX_OVERFLOW                       |
| <a href="#">2</a>  | USB_ERROR_ILLEGAL_MAX_PACKET_SIZE           |
| <a href="#">3</a>  | USB_ERROR_ILLEGAL_EPADDR                    |
| <a href="#">4</a>  | USB_ERROR_IBUFFER_SIZE_TOO_SMALL            |
| <a href="#">5</a>  | USB_ERROR_DRIVER_ERROR                      |
| <a href="#">6</a>  | USB_ERROR_IAD_DESCRIPTOR_EXCEED             |
| <a href="#">7</a>  | USB_ERROR_INVALID_INTERFACE_NO              |
| <a href="#">8</a>  | USB_ERROR_TOO_MANY_CALLBACKS                |
| <a href="#">9</a>  | USB_ERROR_TEST_MODE_NEEDS_POWER_CYCLE       |
| <a href="#">10</a> | USB_ERROR_MSD_MT_DRIVER_NUM_BUFFERS_INVALID |
| <a href="#">11</a> | USB_ERROR_COULD_NOT_ALLOCATE_ENDPOINT       |
| <a href="#">12</a> | USB_ERROR_STRING_DESCRIPTOR_TOO_LONG        |

**Table 15.4: USB\_OS\_Panic(): Errorcodes**

## 15.2.7 USB\_OS\_Signal()

### Description

Wakes the task waiting for signal.

### Prototype

```
void USB_OS_Signal(unsigned EPIndex);
```

| Parameter               | Description     |
|-------------------------|-----------------|
| <a href="#">EPIndex</a> | Endpoint index. |

**Table 15.5: USB\_OS\_Signal() parameter list**

### Additional information

This routine is typically called from within an interrupt service routine.

## 15.2.8 USB\_OS\_Wait()

### Description

Blocks the task until `USB_OS_Signal()` is called.

### Prototype

```
void USB_OS_Wait(unsigned EPIndex);
```

| Parameter               | Description     |
|-------------------------|-----------------|
| <a href="#">EPIndex</a> | Endpoint index. |

**Table 15.6: USB\_OS\_Wait() parameter list**

### Additional information

This routine is called from a task.

## 15.2.9 USB\_OS\_WaitTimed()

### Description

Blocks the task until `USB_OS_Signal()` is called or a timeout occurs.

### Prototype

```
int USB_OS_WaitTimed(unsigned EPIndex, unsigned ms);
```

| Parameter            | Description               |
|----------------------|---------------------------|
| <code>EPIndex</code> | Endpoint index.           |
| <code>ms</code>      | Timeout time given in ms. |

**Table 15.7: USB\_OS\_WaitTimed() parameter list**

### Return value

`== 0`: Task was signaled within the given timeout.

`== 1`: Timeout occurred.

### Additional information

`USB_OS_WaitTimed` is called from a task. This function is used by all available timed routines.



## 15.3 Example

A configuration to use USB with embOS might look like the sample below. This example is also supplied in the subdirectory OS\embOS\.

```

/*****
 *          SEGGER MICROCONTROLLER GmbH & Co. KG
 *      Solutions for real time microcontroller applications
 *****/
 *
 *      (c) 2003-2010      SEGGER Microcontroller GmbH & Co KG
 *
 *      Internet: www.segger.com      Support:  support@segger.com
 *
 *****/
 *      USB device stack for embedded applications
 *
 *****/
-----
File      : USB_OS_embOS.c
Purpose   : Kernel abstraction for embOS
            Do not modify to allow easy updates !
-----
END-OF-HEADER
*/

#include "USB_Private.h"
#include "RTOS.h"

/*****
 *
 *      Static data
 *****/
 *
 *****/

#if OS_VERSION < 33200
static OS_TASK * _apTask[USB_NUM_EPS];
#else
static OS_EVENT _aEvent[USB_NUM_EPS];
#endif

/*****
 *
 *      Public code
 *****/
 *
 *****/
/*****
 *
 *      Depending on the version of embOS, either event objects or
 *      task events. Event object were in version V3.32 introduced.
 *
 *****/
*/

#if OS_VERSION < 33200
/*****
 *
 *      USB_OS_Init
 *
 *      Function description:
 *      This function shall initialize all event objects that are necessary.
 *
 */
void USB_OS_Init(void) {
}

/*****
 *
 *      USB_OS_Signal
 *
 *      Function description
 *      Wake the task waiting for reception
 *      This routine is typically called from within an interrupt
 *      service routine
 *
 */

```

```

void USB_OS_Signal(unsigned EPIndex) {
    if (_apTask[EPIndex] != NULL) {
        OS_SignalEvent(1 << EPIndex, _apTask[EPIndex]);
        _apTask[EPIndex] = NULL;
    }
}

/*****
 *
 *      USB_OS_Wait
 *
 * Function description
 *      Block the task until USB_OS_SignalRx is called
 *      This routine is called from a task.
 */
void USB_OS_Wait(unsigned EPIndex) {
    _apTask[EPIndex] = OS_pCurrentTask;
    OS_WaitEvent(1 << EPIndex);
}

/*****
 *
 *      USB_OS_WaitTimed
 *
 * Function description
 *      Block the task until USB_OS_Signal is called
 *      or a time out occurs
 *      This routine is called from a task.
 */
int USB_OS_WaitTimed(unsigned EPIndex, unsigned ms) {
    int r;
    _apTask[EPIndex] = OS_pCurrentTask;
    r = (int)OS_WaitEventTimed(1 << EPIndex, ms + 1);
    return r;
}

#else
/*****
 *
 *      USB_OS_Init
 *
 * Function description:
 *      This function shall initialize all event objects that are necessary.
 */
void USB_OS_Init(void) {
    unsigned i;

    for (i = 0; i < COUNTOF(_aEvent); i++) {
        OS_EVENT_Create(&_aEvent[i]);
    }
}

/*****
 *
 *      USB_OS_Signal
 *
 * Function description
 *      Wake the task waiting for reception
 *      This routine is typically called from within an interrupt
 *      service routine
 */
void USB_OS_Signal(unsigned EPIndex) {
    OS_EVENT_Pulse(&_aEvent[EPIndex]);
}

/*****
 *
 *      USB_OS_Wait
 *
 * Function description
 *      Block the task until USB_OS_SignalRx is called
 *      This routine is called from a task.
 */
void USB_OS_Wait(unsigned EPIndex) {
    OS_EVENT_Wait(&_aEvent[EPIndex]);
}

```

```

/*****
*
*      USB_OS_WaitTimed
*
* Function description
*   Block the task until USB_OS_Signal is called
*   or a time out occurs
*   This routine is called from a task.
*/
int USB_OS_WaitTimed(unsigned EPIndex, unsigned ms) {
    int r;
    r = (int)OS_EVENT_WaitTimed(&_aEvent[EPIndex], ms + 1);
    return r;
}
#endif
/*****
*
*      USB_OS_Delay
*
* Function description
*   Delays for a given number of ms.
*/
void USB_OS_Delay(int ms) {
    OS_Delay(ms);
}

/*****
*
*      USB_OS_DecRI
*
* Function description
*   Decrement interrupt disable count and enable interrupts
*   if counter reaches 0.
*/
void USB_OS_DecRI(void) {
    OS_DecRI();
}

/*****
*
*      USB_OS_IncDI
*
* Function description
*   Increment interrupt disable count and disable interrupts
*/
void USB_OS_IncDI(void) {
    OS_IncDI();
}

/*****
*
*      USB_OS_Panic
*
* Function description
*   Called if fatal error is detected.
*/
void USB_OS_Panic(unsigned ErrCode) {
    while (ErrCode);
}

/*****
*
*      USB_OS_GetTickCnt
*
* Function description
*   Returns the current system time in ticks.
*/
U32 USB_OS_GetTickCnt(void) {
    return OS_Time;
}

/***** End of file *****/

```



# Chapter 16

## Target USB Driver

---

This chapter describes emUSB hardware interface functions in detail.

## 16.1 General information

### Purpose of the USB hardware interface

emUSB does not contain any hardware dependencies. These are encapsulated through a hardware abstraction layer, which consists of the interface functions described in this chapter. All of these functions for a particular USB controller are typically located in a single file, the USB driver. Drivers for hardware which have already been tested with emUSB are available.

### Range of supported USB hardware

The interface has been designed in such a way that it should be possible to use the most common USB device controllers. This includes USB 1.1 controllers and USB 2.0 controllers, both as external chips and as part of microcontrollers.

### 16.1.1 Available USB drivers

An always up to date list can be found at:

<http://www.segger.com/pricelist-emusb.html>

The following device drivers are available for emUSB:

| Driver (Device)           | Identifier                    |
|---------------------------|-------------------------------|
| ATMEL AV32 UC3x           | USB_Driver_Atmel_AT32UC3x     |
| ATMEL AT91CAP9x           | USB_Driver_Atmel_CAP9         |
| ATMEL AT91SAM3S/AT91SAM4S | USB_Driver_Atmel_SAM3S        |
| ATMEL AT91SAM3Uxx         | USB_Driver_Atmel_SAM3US       |
| ATMEL AT91SAM3x8          | USB_Driver_Atmel_AT91SAM3X    |
| ATMEL AT91RM9200          | USB_Driver_Atmel_RM9200       |
| ATMEL AT91SAM7A3          | USB_Driver_Atmel_SAM7A3       |
| ATMEL AT91SAM7S64         | USB_Driver_Atmel_SAM7S        |
| ATMEL AT91SAM7S128        | USB_Driver_Atmel_SAM7S        |
| ATMEL AT91SAM7S256        | USB_Driver_Atmel_SAM7S        |
| ATMEL AT91SAM7SE          | USB_Driver_Atmel_SAM7SE       |
| ATMEL AT91SAM7X128        | USB_Driver_Atmel_SAM7X        |
| ATMEL AT91SAM7X256        | USB_Driver_Atmel_SAM7X        |
| ATMEL AT91SAM9260         | USB_Driver_Atmel_SAM9260      |
| ATMEL AT91SAM9261         | USB_Driver_Atmel_SAM9261      |
| ATMEL AT91SAM9263         | USB_Driver_Atmel_SAM9263      |
| ATMEL AT91SAM9R64         | USB_Driver_Atmel_SAMRx64      |
| ATMEL AT91SAM9RL64        |                               |
| ATMEL AT91SAM9G20         | USB_Driver_Atmel_SAM9G20      |
| ATMEL AT91SAM9G45         | USB_Driver_Atmel_SAM9G45      |
| ATMEL AT91SAM9XE          | USB_Driver_Atmel_SAM9XE       |
| EnergyMicro EFM32GG       | USB_Driver_EM_EFM32GG990      |
| Freescale iMX25x          | USB_Driver_Freescale_iMX25x   |
| Freescale iMX28x          | USB_Driver_Freescale_iMX28x   |
| Freescale Kinetis K40     | USB_Driver_Freescale_K40      |
| Freescale Kinetis K60     | USB_Driver_Freescale_K60      |
| Freescale MCF227x         | USB_Driver_Freescale_MCF227x  |
| Freescale MCF225x         | USB_Driver_Freescale_MCF225x  |
| Freescale MCF51JMx        | USB_Driver_Freescale_MCF51JMx |
| Freescale Vybrid          | USB_Driver_Freescale_Vybrid   |
| Fujitsu MB9BF50x          | USB_Driver_Fujitsu_MB9BF50x   |
| NXP LPC13xx               | USB_Driver_NXP_LPC13xx        |

**Table 16.1: List of included USB device drivers**

| Driver (Device)                       | Identifier                   |
|---------------------------------------|------------------------------|
| NXP LPC17xx                           | USB_Driver_NXP_LPC17xx       |
| NXP LPC18xx                           | USB_Driver_NXP_LPC18xx       |
| NXP LPC214x                           | USB_Driver_NXP_LPC214x       |
| NXP LPC23xx                           | USB_Driver_NXP_LPC23xx       |
| NXP LPC24xx                           | USB_Driver_NXP_LPC24xx       |
| NXP LPC313x                           | USB_Driver_NXP_LPC313x       |
| NXP LPC318x                           | USB_Driver_NXP_LPC318x       |
| NXP LPC43xx                           | USB_Driver_NXP_LPC43xx       |
| NXP (formerly Sharp) LH79524/5        | USB_Driver_Sharp_LH79524     |
| NXP (formerly Sharp) LH7A40x          | USB_Driver_Sharp_LH7A40x     |
| OKI 69Q62                             | USB_Driver_OKI_69Q62         |
| Renesas H8S2472                       | USB_Driver_Renesas_H8S2472   |
| Renesas H8SX1668R                     | USB_Driver_Renesas_H8SX1668R |
| Renesas RX62N                         | USB_Driver_Renesas_RX62N     |
| Renesas RX63N/RX631                   | USB_Driver_Renesas_RX62N     |
| Renesas SH7203                        | USB_Driver_Renesas_SH7203    |
| Renesas SH7216                        | USB_Driver_Renesas_SH7216    |
| Renesas SH7286                        | USB_Driver_Renesas_SH7286    |
| Renesas (NEC) 78K0R-KE3L              | USB_Driver_NEC_78F102x       |
| Renesas (NEC) $\mu$ PD720150          | USB_Driver_NEC_uPD720150     |
| Renesas (NEC) V850ESJG3H              | USB_Driver_NEC_70F376x       |
| ST STM32                              | USB_Driver_ST_STM32          |
| ST STM32F105/107                      | USB_Driver_ST_STM32F107      |
| ST STR71x                             | USB_Driver_ST_STR71x         |
| ST STR750                             | USB_Driver_ST_STR750         |
| ST STR912                             | USB_Driver_ST_STR91x         |
| Toshiba TMPA900                       | USB_Driver_Toshiba_TMPA900   |
| Toshiba TMPA910                       | USB_Driver_Toshiba_TMPA910   |
| Texas Instruments MSP430X5529         | USB_Driver_TI_MSP430         |
| Texas Instruments (Luminary) LM3S9B9x | USB_Driver_TI_LM3S9B9x       |

**Table 16.1: List of included USB device drivers**

## 16.2 Adding a driver to emUSB

You have to specify the USB device driver which should be used with emUSB. To specify the driver `USB_X_AddDriver()` is called from `USB_Init()`. This function should be used to add a USB driver to your project.

`USB_Init()` initializes the internals of the USB stack and is always the first function which that USB application has to call. `USB_X_HWAttach()` should be used to perform hardware-specific actions which are not part of the USB controller logic (for example, enabling the peripheral clock for USB port).

This function is called from every device driver, but can be empty if your hardware does not need to perform such actions. Modify `USB_X_AddDriver()` and if required, `USB_X_HWAttach()`. In `USB_X_AddDriver()`, `USB_AddDriver()` should be called with the identifier of the driver which is compatible to your hardware as parameter. Refer to the section *Available USB drivers* on page 446 for a list of all supported devices and their valid identifiers.



## 16.2.1 USB\_X\_HWAttach()

### Description

Should be used to perform hardware specific actions which are not part of the USB controller logic.

### Prototype

```
void USB_X_HWAttach(void)
```

### Additional Information

This function can be empty, if no hardware-specific actions are required.

### Example

```
/* Example excerpt from USB_Config_SAM7A3.c */#

#define _AT91C_PIOA_BASE (0xFFFFF400)
#define _AT91C_PIOB_BASE (0xFFFFF600)
#define _AT91C_PMC_BASE (0xFFFFFC00)
#define _PIO_PER_OFFSETS (0x00)
#define _PIO_OER_OFFSETS (0x10)
#define _PIO_CODR_OFFSETS (0x34) /* Clear output data register */
#define _PMC (*(volatile unsigned int*) _AT91C_PMC_BASE)
#define _USB_ID (_PIOB_ID)
#define _USB_OER (*(volatile unsigned int*) (_AT91C_PIOB_BASE + _PIO_OER_OFFSETS))
#define _USB_CODR (*(volatile unsigned int*) (_AT91C_PIOB_BASE + _PIO_CODR_OFFSETS))
#define _USB_DP_PUP_BIT (1)

void USB_X_HWAttach(void) {
    _PMC = (1 << _USB_ID); /* Enable peripheral clock for USB-Port */
    _USB_OER = (1 << _USB_DP_PUP_BIT); /* set USB_DP_PUP to output */
    _USB_CODR = (1 << _USB_DP_PUP_BIT); /* set _USB_DP_PUP_BIT to low state */
}
```

## 16.2.2 USB\_X\_AddDriver()

### Description

Adds a USB hardware driver to the USB stack.

### Prototype

```
void USB_X_AddDriver(void)
```

### Additional information

This function is always called from `USB_Init()`.

### Example

```
/* Example excerpt from USB_Config_SAM7A3.c */  
  
void USB_X_AddDriver(void) {  
    USB_AddDriver(&USB_Driver_AtmelSAM7A3);  
}
```

## 16.3 Interrupt handling


emUSB is interrupt driven and optimized to be used with a real-time operating system. If you use embOS in combination with emUSB, you can skip the following sections.

If you are not using embOS, you have to be familiar with how interrupts are handled on your target system. This includes knowledge about how the CPU handles interrupts, how and which registers are saved, the interrupt vector table, how the interrupt controller works and how it is reset.

### 16.3.1 ARM7 / ARM9 based cores

ARM7 and ARM9 cores will jump to IRQ vector address  $0 \times 18$ , where a jump to an ARM specific IRQ handler should be located. This ARM specific IRQ handler calls a device specific interrupt handler which handles the interrupt controller.

The ARM specific interrupt handler is typically coded in assembly language. It has to ensure that no context information will be lost if an interrupt occurs. The environment of the interrupted function has to be restored after processing the interrupt. The environment of the interrupted function includes the value of the processor registers and the processor status register. The ARM specific interrupt handler calls a high-level interrupt handler which manages the call of the interrupt source specific service routine.



### 16.3.1.1 ARM specific IRQ handler

The ARM specific interrupt handler saves the context of the function which is interrupted, calls the high-level interrupt handler and restores the context. Sample implementations of the high-level handler are supplied in the following device specific sections.

#### Sample implementation interrupt handler

```

EXTERN  IRQ_Handler

IRQ_HandlerASM:
;
; Save temp. registers
;
        stmdb    SP!, {R0-R3,R12,LR}          ; push
;
; push SPSR (req. if we allow nested interrupts)
;
        mrs      R0, SPSR                     ; load SPSR
        stmdb    SP!, {R0}                    ; push SPSR_irq on IRQ stack
;
; Call "C" interrupt handler
;
        ldr      R0, =IRQ_Handler
        mov      LR, PC
        bx      R0
;
; pop SPSR
;
        ldmia    SP!, {R1}                    ; pop SPSR_irq from IRQ stack
        msr      SPSR_cxfs, R1
;
; Restore temp registers
;
        ldmia    SP!, {R0-R3,R12,LR}          ; pop
        subs     PC, LR, #4                    ; RETI

```

### 16.3.1.2 Device specifics ATMEL AT91CAP9x

The interrupt handler needs to read the address of the interrupt source specific handler function.

#### Sample implementation interrupt handler

```
#define _AIC_BASE_ADDR    (0xfffff000UL)
#define _AIC_IVR          (*(volatile unsigned int*)(_AIC_BASE_ADDR + 0x100))
#define _AIC_EOICR        (*(volatile unsigned int*)(_AIC_BASE_ADDR + 0x130))

typedef void             ISR_HANDLER(void);

void IRQ_Handler(void) {
    ISR_HANDLER* pISR;
    pISR = (ISR_HANDLER*) _AIC_IVR;           // Read interrupt vector to release
                                              // NIRQ to CPU core
    pISR();                                   // Call interrupt service routine
    _AIC_EOICR = 0;                          // Reset interrupt controller => Restore
                                              // previous priority
}
```

### 16.3.1.3 Device specifics ATMEL AT91RM9200

For an example implementation of an interrupt handler function refer to *Device specifics ATMEL AT91CAP9x* on page 453.

### 16.3.1.4 Device specifics ATMEL AT91SAM7A3

For an example implementation of an interrupt handler function refer to *Device specifics ATMEL AT91CAP9x* on page 453.

### 16.3.1.5 Device specifics ATMEL AT91SAM7S64, AT91SAM7S128, AT91SAM7S256

For an example implementation of an interrupt handler function refer to *Device specifics ATMEL AT91CAP9x* on page 453.

### 16.3.1.6 Device specifics ATMEL AT91SAM7X64, AT91SAM7X128, AT91SAM7X256

For an example implementation of an interrupt handler function refer to *Device specifics ATMEL AT91CAP9x* on page 453.

### 16.3.1.7 Device specifics ATMEL AT91SAM7SE

For an example implementation of an interrupt handler function refer to *Device specifics ATMEL AT91CAP9x* on page 453.

### 16.3.1.8 Device specifics ATMEL AT91SAM9260

For an example implementation of an interrupt handler function refer to *Device specifics ATMEL AT91CAP9x* on page 453.

### 16.3.1.9 Device specifics ATMEL AT91SAM9261

For an example implementation of an interrupt handler function refer to *Device specifics ATMEL AT91CAP9x* on page 453.

### 16.3.1.10 Device specifics ATMEL AT91SAM9263

For an example implementation of an interrupt handler function refer to *Device specifics ATMEL AT91CAP9x* on page 453.

### **16.3.1.11 Device specifics ATMEL AT91SAMRL64, AT91SAMR64**

For an example implementation of an interrupt handler function refer to *Device specifics ATMEL AT91CAP9x* on page 453.

### 16.3.1.12 Device specifics NXP LPC214x

The interrupt handler needs to read the address of the interrupt source specific handler function.

#### Sample implementation interrupt handler

```
#define _VIC_BASE_ADDR      (0xFFFFF000)
#define _VIC_VECTORADDR    *(volatile unsigned int*)(_VIC_BASE_ADDR + 0x0030)

typedef void      ISR_HANDLER(void);

void IRQ_Handler(void) {
    ISR_HANDLER* pISR;
    pISR = (ISR_HANDLER*) _VIC_VECTORADDR;      // Get current interrupt handler
    pISR();                                     // Call interrupt service routine
    _VIC_VECTORADDR = 0;                       // Clear current interrupt pending
                                              // condition, reset VIC
}
```

### 16.3.1.13 Device specifics NXP LPC23xx

For an example implementation of an interrupt handler function refer to *Device specifics NXP LPC214x* on page 455.

### 16.3.1.14 Device specifics NXP (formerly Sharp) LH79524/5

For an example implementation of an interrupt handler function, please contact SEGGER, [www.segger.com](http://www.segger.com).

### 16.3.1.15 Device specifics OKI 69Q62

For an example implementation of an interrupt handler function, please contact SEGGER, [www.segger.com](http://www.segger.com).

### 16.3.1.16 Device specifics ST STR71x

For an example implementation of an interrupt handler function, please contact SEGGER, [www.segger.com](http://www.segger.com).

### 16.3.1.17 Device specifics ST STR750

For an example implementation of an interrupt handler function, please contact SEGGER, [www.segger.com](http://www.segger.com).

### 16.3.1.18 Device specifics ST STR750

For an example implementation of an interrupt handler function, please contact SEGGER, [www.segger.com](http://www.segger.com).

## 16.4 Writing your own driver

This section is only relevant if you plan to develop a driver for an unsupported device. Refer to *Available USB drivers* on page 446 for a list of currently supported devices.

Access to the USB hardware is realized through an API-function table. The structure `USB_HW_DRIVER` is declared in `USB\USB.h`.

### 16.4.1 Structure `USB_HW_DRIVER`

#### Description

Structure that contains callback function which manage the hardware access.

#### Prototype

```
typedef struct USB_HW_DRIVER {
    void      (*pfInit)                (void);
    U8        (*pfAllocEP)             (U8 InDir, U8 TransferType);
    void      (*pfUpdateEP)            (EP_STAT * pEPStat);
    void      (*pfEnable)              (void);
    void      (*pfAttach)              (void);
    unsigned  (*pfGetMaxPacketSize)    (U8 EPIndex);
    int       (*pfIsInHighSpeedMode)   (void);
    void      (*pfSetAddress)           (U8 Addr);
    void      (*pfSetClrStallEP)       (U8 EPIndex, int OnOff);
    void      (*pfStallEP0)            (void);
    void      (*pfDisableRxInterruptEP)(U8 EpOut);
    void      (*pfEnableRxInterruptEP)(U8 EpOut);
    void      (*pfStartTx)             (U8 EPIndex);
    void      (*pfSendEP)              (U8 EPIndex, const U8 * p,
                                       unsigned NumBytes);

    void      (*pfDisableTx)           (U8 EPIndex);
    void      (*pfResetEP)             (U8 EPIndex);
    int       (*pfControl)             (U8 Cmd, void * p);
} USB_HW_DRIVER;
```

| Member                                          | Description                                                                 |
|-------------------------------------------------|-----------------------------------------------------------------------------|
| USB initialization functions                    |                                                                             |
| <code>pfInit()</code>                           | Initializes the USB controller.                                             |
| General USB functions                           |                                                                             |
| <code>pfAttach()</code>                         | Indicates device attachment.                                                |
| <code>pfEnable()</code>                         | Enables endpoint.                                                           |
| <code>pfControl</code>                          | Used to support additional driver functionality. This function is optional. |
| <code>pfSetAddress()</code>                     | Notifies the USB controller of the new address assigned by the host for it. |
| General endpoints functions                     |                                                                             |
| <code>pfAllocEP</code>                          | Allocates an endpoint to be used with emUSB.                                |
| <code>pfGetMaxPacketSize</code>                 | Returns the maximum packet size of an endpoint.                             |
| <code>pfSetClrStallEP()</code>                  | Sets or clears the stall condition of the endpoint.                         |
| <code>pfUpdateEP()</code>                       | Configures the USB controller's endpoint.                                   |
| <code>pfResetEP()</code>                        | Resets an endpoint including resetting the data toggle of the endpoint.     |
| Endpoint 0 (Control endpoint) related functions |                                                                             |

**Table 16.2: List of callback functions of `USB_HW_DRIVER`**



| Member                                   | Description                                    |
|------------------------------------------|------------------------------------------------|
| <a href="#">pfStallEP0()</a>             | Stalls endpoint 0.                             |
| OUT-endpoints functions                  |                                                |
| <a href="#">pfDisableRxInterruptEP()</a> | Disables OUT-endpoint interrupt.               |
| <a href="#">pfEnableRxInterruptEP()</a>  | Enables OUT-endpoint interrupt.                |
| IN-endpoints functions                   |                                                |
| <a href="#">pfDisableTx</a>              | Disables IN endpoint transfers.                |
| <a href="#">pfSendEP()</a>               | Sends data on the given IN-endpoint.           |
| <a href="#">pfStartTx()</a>              | Starts data transfer on the given IN-endpoint. |

**Table 16.2: List of callback functions of USB\_HW\_DRIVER**

## 16.4.2 USB initialization functions

### 16.4.2.1 (\*pfInit)()

#### Description

Performs any necessary initializations on the USB controller.

#### Prototype

```
void (*pfInit) (void);
```

#### Additional information

The initializations performed in this routine should include what is needed to prepare the device for enumeration. Such initializations might include setting up endpoint 0 and enabling interrupts. It sets default values for EP0 and enables the various interrupts needed for USB operations.

## 16.4.3 General USB functions

### 16.4.3.1 (\*pfAttach)()

#### Description

For USB controllers that have a USB Attach/Detach register (such as the OKI ML69Q6203), this routine sets the register to indicate that the device is attached.

#### Prototype

```
void (*pfAttach)(void);
```

### 16.4.3.2 (\*pfEnable)()

#### Description

This function is used for enabling the USB controller after it was initialized.

#### Prototype

```
void (*pfEnable)(void);
```

#### Additional information

For most USB controllers this function can be empty. This function is only necessary for USB devices that reset their configuration data after an USB-RESET.

### 16.4.3.3 (\*pfControl)()

#### Description

This function is used to support additional driver functionality. This function is optional.

#### Prototype

```
int (*pfControl)(U8 Cmd, void * p);
```

| Parameter           | Description                                 |
|---------------------|---------------------------------------------|
| <a href="#">Cmd</a> | Command that shall be executed.             |
| <a href="#">p</a>   | Pointer to data, necessary for the command. |

**Table 16.3: (\*pfControl)() parameter list**

#### Return value

== 0: Command operation was successful.  
 == 1: Command operation was not successful.  
 == -1: Command was unknown.

#### Additional information

This control function is only called when available. This function will check or changes state of a device driver. Currently the following commands are available:

| Command | Description                      |
|---------|----------------------------------|
| 0       | USB_DRIVER_CMD_SET_CONFIGURATION |
| 1       | USB_DRIVER_CMD_GET_TX_BEHAVIOR   |

**Table 16.4: (\*pfControl): Commands**

### 16.4.3.4 (\*pfSetAddress)()

#### Description

This function is used for notifying the USB controller of the new address that the host has assigned to it during enumeration.

#### Prototype

```
void (*pfSetAddress)(U8 Addr);
```

| Parameter            | Description                           |
|----------------------|---------------------------------------|
| <a href="#">Addr</a> | New address assigned by the USB host. |

**Table 16.5: (\*pfSetAddress)() parameter list**

#### Additional information

If the USB controller does not automatically send a 0-byte acknowledgment in the status stage of the control transfer phase, make sure to set a state variable to [Addr](#) and defer setting the controller's Address register until after the status stage. This is necessary because the host sends the token packet for the status stage to the default address (0x00), which means the device must still be using this address when the packet is sent.

## 16.4.4 General endpoint functions

### 16.4.4.1 (\*pfAllocEP)()

#### Description

Allocates a physical endpoint to be used with emUSB.

#### Prototype

```
U8 (*pfAllocEP)(U8 InDir, U8 TransferType);
```

| Parameter                 | Description                                                                                                                                                                      |
|---------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>InDir</code>        | Indicates the direction of the endpoint.<br>0 indicates an OUT-endpoint.<br>1 indicates an IN-endpoint.                                                                          |
| <code>TransferType</code> | Specifies the transfer type for the desired endpoint.<br>The following transfer types are available:<br>USB_TRANSFER_TYPE_BULK<br>USB_TRANSFER_TYPE_ISO<br>USB_TRANSFER_TYPE_INT |

**Table 16.6: (\*pfAllocEP)() parameter list**

#### Return value

Index number of the logical endpoint. Allowed values are 1..15.

#### Additional information

This function is typically called after stack initialization, in order to have the right endpoint settings for building the descriptors correctly.

It is the responsibility of the driver engineer to give a valid logical endpoint number. If there is no valid endpoint for the desired configuration available, 0 should be returned.

### 16.4.4.2 (\*pfGetMaxPacketSize)()

#### Description

Returns the maximum packet size of an endpoint.

#### Prototype

```
unsigned (*pfGetMaxPacketSize)(U8 EPIndex);
```

| Parameter            | Description     |
|----------------------|-----------------|
| <code>EPIndex</code> | Endpoint index. |

**Table 16.7: (\*pfGetMaxPacketSize)() parameter list**

#### Return value

The maximum packet size in bytes.

### 16.4.4.3 (\*pfSetClrStallEP)()

#### Description

Sets or clears the stall condition of an endpoint.

#### Prototype

```
void (*pfSetClrStallEP)(U8 EPIndex, int OnOff);
```

| Parameter | Description                                                                                                                              |
|-----------|------------------------------------------------------------------------------------------------------------------------------------------|
| EPIndex   | Endpoint that shall be stalled.                                                                                                          |
| OnOff     | Specifies if the stall condition shall be set or cleared.<br>Whereas:<br>0 - Clears the stall condition.<br>1 - Set the stall condition. |

**Table 16.8: (\*pfSetClrStallEP)() parameter list**

#### Additional information

Typically, this function is called whenever a protocol/transfer error occurs.

### 16.4.4.4 (\*pfUpdateEP)()

#### Description

Configures the USB controller's endpoint.

#### Prototype

```
void (*pfUpdateEP)(EP_STAT * pEPStat);
```

| Parameter | Description                                                               |
|-----------|---------------------------------------------------------------------------|
| pEPStat   | Pointer to EP_STAT structure that holds the information for the endpoint. |

**Table 16.9: (\*pfUpdateEP)() parameter list**

#### Additional information

EP\_STAT is defined as follows:

```
typedef struct {
    U16      NumAvailBuffers;
    U16      MaxPacketSize;
    U16      Interval;
    U8       EPType;
    BUFFER   Buffer;
    U8       * pData;
    volatile U32 NumBytesRem;
    U8       EPAddr; // b[6:0]: EPAddr b7: Direction, 1: Device to Host (IN)
    U8       Send0PacketIfRequired;
} EP_STAT;
```

Before a hardware attach is done, this function is called to configure the desired endpoints, so that the additional endpoints are ready for use after the enumeration phase.

### 16.4.4.5 (\*pfResetEP)()

#### Description

Resets an endpoint including resetting the data toggle of the endpoint.

#### Prototype

```
void (*pfResetEP)(U8 EPIndex);
```

| Parameter               | Description                   |
|-------------------------|-------------------------------|
| <a href="#">EPIndex</a> | Endpoint that shall be reset. |

**Table 16.10: (\*pfResetEP)() parameter list**

#### Additional information

Resets the endpoint which includes setting data toggle to DATA0.

It is useful after removing a HALT condition on a BULK endpoint.

Refer to Chapter 5.8.5 in the USB Serial Bus Specification, Rev.2.0.

**Note:** Configuration of the endpoint needs to be unchanged. If the USB controller loses the EP configuration the `pfUpdateEP` of the driver shall be called.

## 16.4.5 Endpoint 0 (control endpoint) related functions

### 16.4.5.1 (\*pfStallEP0)()

#### Description

This function is used for stalling endpoint 0 (by setting the appropriate bit in a control register).

#### Prototype

```
void (*pfStallEP0)(void);
```



## 16.4.6 OUT-endpoint functions

### 16.4.6.1 (\*pfDisableRxInterruptEP)()

#### Description

Disables the OUT-endpoint interrupt.

#### Prototype

```
void (*pfDisableRxInterruptEP)(U8 EPIndex);
```

| Parameter               | Description                                        |
|-------------------------|----------------------------------------------------|
| <a href="#">EPIndex</a> | OUT-endpoint whose interrupt needs to be disabled. |

**Table 16.11: (\*pfDisableRxInterruptEP)() parameter list**

### 16.4.6.2 (\*pfEnableRxInterruptEP)()

#### Description

Enables the OUT-endpoint interrupt.

#### Prototype

```
void (*pfEnableRxInterruptEP)(U8 EPIndex);
```

| Parameter               | Description                                       |
|-------------------------|---------------------------------------------------|
| <a href="#">EPIndex</a> | OUT-endpoint whose interrupt needs to be enabled. |

**Table 16.12: (\*pfEnableRxInterruptEP)() parameter list**

## 16.4.7 IN-endpoint functions

### 16.4.7.1 (\*pfStartTx)()

#### Description

Starts data transfer on the given IN-endpoint.

#### Prototype

```
void (*pfStartTx)(U8 EPIndex);
```

| Parameter               | Description                           |
|-------------------------|---------------------------------------|
| <a href="#">EPIndex</a> | IN-endpoint that needs to be enabled. |

**Table 16.13: (\*pfStartTX)() parameter list**

#### Additional information

This function is called to start sending data to the host.

Depending on the design of the USB controller, one of the following steps needs to be done:

If the USB controller sends a packet and waits for acceptance by the host, your application must:

- Enable IN-endpoint interrupt.
- Send a packet using `USB__Send(EPIndex)`.

If the USB controller waits for an IN-token, your application must:

- Enable the IN-endpoint interrupt.

### 16.4.7.2 (\*pfSendEP)()

#### Description

Sends data on the given IN-endpoint.

#### Prototype

```
void (*pfSendEP)(U8 EPIndex, const U8 * p, unsigned NumBytes);
```

| Parameter                | Description                                |
|--------------------------|--------------------------------------------|
| <a href="#">EPIndex</a>  | IN-endpoint that is used to send the data. |
| <a href="#">p</a>        | Pointer to a buffer that needs to be sent. |
| <a href="#">NumBytes</a> | Number of bytes that needs to be sent.     |

**Table 16.14: (\*pfSendEP)() parameter list**

#### Additional information

This function is called whenever data should be transferred to the host. Because [p](#) might not be aligned, it is the responsibility of the developer to care about the alignment of the USB controller buffer/FIFO.

### 16.4.7.3 (\*pfDisableTx)()

#### Description

Disables IN-endpoint transfers.

#### Prototype

```
void (*pfDisableTx)(U8 EPIndex);
```

| Parameter               | Description                            |
|-------------------------|----------------------------------------|
| <a href="#">EPIndex</a> | IN-endpoint that needs to be disabled. |


**Table 16.15: (\*pfDisableTx)() parameter list**

#### Additional information

Normally, this function should disable the IN-endpoint interrupt. Some USB controllers do not work correctly after the IN interrupt is disabled, therefore this should be done by the software.

## 16.4.8 USB driver interrupt handling

emUSB is interrupt driven. Therefore, it is necessary to have an interrupt handler for the used USB controller. For the drivers available this is already done. If you are writing your own USB driver the following schematic shows which functions need to be called when an USB interrupt occurs:



| Function                           | Description                                             |
|------------------------------------|---------------------------------------------------------|
| <a href="#">USB__HandleSetup()</a> | Determines request type.                                |
| <a href="#">USB__OnBusReset()</a>  | Flushes the input buffer and set the "_IsInReset" flag. |
| <a href="#">USB__OnTx()</a>        | Handles a Tx transfer.                                  |
| <a href="#">USB__OnRx()</a>        | Handles a Rx transfer.                                  |
| <a href="#">USB__OnResume()</a>    | Resumes the device.                                     |
| <a href="#">USB__OnSuspend()</a>   | Suspends the device.                                    |

**Table 16.16: emUSB interrupt handling functions**

# Chapter 17

## Support

---

This chapter can help you if any problem occurs; this could be a problem with the tool chain, with the hardware, the use of the functions, or with the performance and it describes how to contact the support.

## 17.1 Problems with tool chain (compiler, linker)

The following shows some of the problems that can occur with the use of your tool chain. The chapter tries to show what to do in case of a problem and how to contact the support if needed.

### 17.1.1 Compiler crash

You ran into a tool chain (compiler) problem, not a problem with the software. If one of the tools of your tool chain crashes, you should contact your compiler support:

```
"Tool internal error, please contact support"
```

### 17.1.2 Compiler warnings

The code of the software has been tested with different compilers. We spend a lot of time on improving the quality of the code and we do our best to avoid compiler warnings. But the sensitivity of each compiler regarding warnings is different. So we can not avoid compiler warnings for unknown tools.

#### Warnings you should not see

This kind of warnings should not occur:

```
"Function has no prototype"  
"Incompatible pointer types"  
"Variable used without having been initialized"  
'Illegal redefinition of macro'
```

#### Warnings you may see

Warnings such as the ones below should be ignored:

```
"Integer conversion, may lose significant bits"  
'Statement not reached"  
"Meaningless statements were deleted during optimization"
```

Most compilers offer a way to suppress selected warnings.

### 17.1.3 Compiler errors

We assume that the used compiler is ANSI C compatible. If it is compatible there should be no problem to translate the code.

### 17.1.4 Linker problems

#### Undefined externals

If your linker shows the error message "Undefined external symbols..." check if all required files have been included into the project.

## 17.2 Problems with hardware/driver

If your tools are working fine but your USB-Bulk device does not work may be one of the following helps to find the problem.

### **Stack size to low?**

Make sure enough stack has been configured. We can not estimate exactly how much stack will be used by your configuration and with your compiler.

## 17.3 Contacting support

If you need to contact the support, send the following information to [support@segger.com](mailto:support@segger.com):

- A detailed description of the problem
- The configuration file `USB_Conf.h`
- The error messages of the compiler





# Chapter 18

## Certification

---

This chapter describes the process of USB driver certification with Microsoft Windows.


## 18.1 What is the Windows Logo Certification and why do I need it?

The Windows Logo Certification process will sign the driver with a Microsoft certificate which signifies that the device is compatible and safe to use with Microsoft Windows operating systems.


If the driver is not signed the user will be confronted with messages saying that the driver is not signed and may not be safe to use with Microsoft Windows. Depending on which Windows version you are using a different message will be shown.

Users of Windows Server 2008, Windows Vista x64 and Windows 7 x64 will be warned about the missing signature and the driver will show up as installed, but the driver will not be loaded. The user can override this security measure by hitting F8 on Windows start-up and selecting "Disable Driver Signature Enforcement" or editing the registry.

Microsoft Windows XP:



Microsoft Windows Vista/7:



## 18.2 Certification offer

Customers can complete the certification by themselves. But SEGGER also offers certification for our customers. To certify a device a customer needs a valid Vendor ID, registered at [www.usb.org](http://www.usb.org) and a free Product ID. Using the Microsoft Windows Logo Kit a certification package is created. The package is sent to Microsoft for confirmation. After the confirmation is received from Microsoft the customer receives a .cat file which allows the drivers to be installed without problems.

## 18.3 Vendor and Product ID

A detailed description of the Vendor and Product ID can be found in chapter *Product / Vendor IDs* on page 33

The customer can acquire a Vendor ID from the USB Implementers Forum, Inc. ([www.usb.org](http://www.usb.org)). This allows to freely decide which Product ID is used for which product.

## 18.4 Certification without SEGGER Microcontroller

Certification can be completed by the customer themselves. To complete the certification the Windows Logo Kit software is needed. It has to be installed on a Windows 2008 Server x64. A Code Signing certificate from Microsoft, two target devices and two client computers will also be needed, Windows 7 x86 and Windows 7 x64 respectively. After installing and setting up the WLK, the client software has to be downloaded via a Windows share from the Windows 2008 Server. The target devices will have to be connected to the client computer.

Using the WLK, the target devices can be selected and the appropriate tests can be scheduled. A few of the tests need human intermission and a few tests only run with one device, while others only run with two. The tests can take up to 15 hours. The tests have to be done separately for x86 and x64. Two separate submission packages have to be created for both architectures. The submission packages have to be consolidated using the Winqual Submission Tool and signed with the Code Sign certificate.

For further information, as well as the required software see:  
<http://msdn.microsoft.com/en-us/library/windows/hardware/gg487530.aspx>

Please refer to Microsoft's WLK documentation for a detailed description of the certification process.



# Chapter 19

## Performance & resource usage

---

This chapter covers the performance and resource usage of emUSB. It contains information about the memory requirements in typical systems which can be used to obtain sufficient estimates for most target systems.

## 19.1 Memory footprint

emUSB is designed to fit many kinds of embedded design requirements. Several features can be excluded from a build to get a minimal system. Note that the values are only valid for the given configuration.

The tests were run on a 32-bit CPU running at 48MHz. The test program was compiled for size optimization.

### 19.1.1 ROM

The following table shows the ROM requirement of emUSB:

| Description            | ROM                                    |
|------------------------|----------------------------------------|
| emUSB core             | app. 5.5 Kbytes                        |
| Bulk component         | app. 400 Bytes                         |
| MSD component          | app. 5 Kbytes + sizeof(Storage-Layer)* |
| HID component          | app. 400 Bytes                         |
| CDC component          | app. 1.1 Kbytes                        |
| PrinterClass component | app. 400 Bytes                         |
| USB target driver      | app. 1.2 - 3 Kbytes                    |
| MTP component          | app. 8 kBytes                          |

\* ROM size of emFile Storage app. 4 Kbytes.

### 19.1.2 RAM

The following table shows the RAM requirement of emUSB:

| Description            | RAM                                                                                                                                |
|------------------------|------------------------------------------------------------------------------------------------------------------------------------|
| emUSB core             | app. 800 Bytes                                                                                                                     |
| Bulk component         | app. 4 Bytes                                                                                                                       |
| MSD component          | app. 200 Bytes<br>+ configurable sector buffer<br>of minimum 512 bytes                                                             |
| HID component          | app. 30 Bytes                                                                                                                      |
| CDC component          | app. 70 Bytes                                                                                                                      |
| PrinterClass component | app. 2 Kbytes                                                                                                                      |
| USB target driver      | < 1 Kbytes                                                                                                                         |
| MTP component          | app. 200 bytes<br>+ configurable file data buffer<br>of minimum 512 bytes<br>+ configurable object buffer<br>(typically 4 kBytes). |

Additionally 64 or 512 bytes (64 for Full Speed and 512 for High Speed devices) are necessary for each OUT-endpoint as a data buffer. This buffer is assigned within the application.

## 19.2 Performance

The tests were run on a 32-bit CPU running at 48MHz with an Atmel SAM7S device driver using the USB Bulk component.

The following table shows the send and receive speed of emUSB:

| Description   | Speed         |
|---------------|---------------|
| <b>Bulk</b>   |               |
| Send speed    | 800 KByte/sec |
| Receive speed | 760 KByte/sec |





# Chapter 20

## FAQ

---

This chapter answers some frequently asked questions.

Q: Which CPUs can I use emUSB with?

A: It can be used with any CPU (or MPU) for which a C compiler exists. Of course, it will work faster on 16/32-bit CPUs than on 8-bit CPUs.

Q: Do I need a real-time operating system (RTOS) to use the USB-MSD?

A: No, if your target application is a pure storage application. You do not need an RTOS if all you want to do is running the USB-MSD stack as the only task on the target device. If your target application is more than just a storage device and needs to perform other tasks simultaneously, you need an RTOS which handles the multi-tasking.

We recommend using our embOS Real-time OS, since all example and trial projects are based on it.

Q: Do I need extra file system code to use the USB-MSD stack?

A: No, if you access the target data only from the host.

Yes, if you want to access the target data from within the target itself.

There is no extra file system code needed if you only want to access the data on the target from the host side. The host OS already provides several file systems. You have to provide file system program code on the target only if you want to access the data from within the target application itself.

Q: Can I combine different USB components together?

A: In general this is possible, by simply calling the appropriate add function of the USB component. See more information in *Combining USB components (Multi-Interface)* on page 415.

# Index

## B

### Bulk Communication

|                                 |         |
|---------------------------------|---------|
| USB_BULK_Add()                  | 88      |
| USB_BULK_CancelRead()           | 89      |
| USB_BULK_CancelWrite()          | 90      |
| USB_BULK_GetNumBytesInBuffer()  | 91      |
| USB_BULK_GetNumBytesRemToRead() | 92      |
| USB_BULK_GetNumBytesToWrite()   | 93      |
| USB_BULK_INIT_DATA              | 109     |
| USB_BULK_Read()                 | 94      |
| USB_BULK_ReadOverlapped()       | 95      |
| USB_BULK_ReadTimed()            | 96      |
| USB_BULK_Receive()              | 99      |
| USB_BULK_SetOnRXHook            | 97      |
| USB_BULK_WaitForRX()            | 100     |
| USB_BULK_WaitForTX()            | 101     |
| USB_BULK_Write()                | 102     |
| USB_BULK_WriteEx()              | 103     |
| USB_BULK_WriteExTimed()         | 104     |
| USB_BULK_WriteNULLPacket()      | 108     |
| USB_BULK_WriteOverlapped()      | 105–106 |
| USB_BULK_WriteTimed()           | 106     |
| USB_ON_RX_FUNC                  | 110     |

### Bulk Communication(Host)

|                                     |              |
|-------------------------------------|--------------|
| USBBULK_Close()                     | 116, 146     |
| USBBULK_CloseEx()                   | 117          |
| USBBULK_GetConfigDescriptor()       | 126          |
| USBBULK_GetConfigDescriptorEx()     | 127, 157     |
| USBBULK_GetDriverCompileDate()      | 124, 175     |
| USBBULK_GetDriverVersion()          | 125, 176–177 |
| USBBULK_GetMode()                   | 128          |
| USBBULK_GetModeEx()                 | 129, 158     |
| USBBULK_GetNumAvailableDevices()    | 130, 178     |
| USBBULK_GetReadMaxTransferSize()    | 131          |
| USBBULK_GetReadMaxTransferSizeEx()  | 132, 159     |
| USBBULK_GetSN()                     | 133, 171     |
| USBBULK_GetWriteMaxTransferSize()   | 134          |
| USBBULK_GetWriteMaxTransferSizeEx() | 135, 160     |
| USBBULK_Open()                      | 114, 145     |
| USBBULK_OpenEx()                    | 115          |
| USBBULK_Read()                      | 118, 150     |
| USBBULK_ReadEx()                    | 119, 151     |
| USBBULK_SetMode()                   | 136          |
| USBBULK_SetModeEx()                 | 137, 163     |
| USBBULK_SetTimeout()                | 138          |
| USBBULK_SetTimeoutEx()              | 139          |
| USBBULK_SetUSBId()                  | 140, 149     |
| USBBULK_Write()                     | 120, 151     |
| USBBULK_WriteEx()                   | 121          |
| USBBULK_WriteRead                   | 122, 152     |
| USBBULK_WriteReadEx()               | 123, 157     |

## C

|                               |         |
|-------------------------------|---------|
| "C" compiler                  | 26      |
| CDC                           |         |
| USB_CDC_Add()                 | 308     |
| USB_CDC_CancelRead()          | 309     |
| USB_CDC_CancelReadEx          | 309     |
| USB_CDC_CancelWrite()         | 310     |
| USB_CDC_CancelWriteEx()       | 310     |
| USB_CDC_INIT_DATA             | 329     |
| USB_CDC_LINE_CODING           | 332     |
| USB_CDC_ON_SET_LINE_CODING    | 331     |
| USB_CDC_Read()                | 311     |
| USB_CDC_ReadEx()              | 311     |
| USB_CDC_ReadOverlapped()      | 312     |
| USB_CDC_ReadOverlappedEx()    | 312     |
| USB_CDC_ReadTimed()           | 313     |
| USB_CDC_ReadTimedEx()         | 313     |
| USB_CDC_Receive()             | 314     |
| USB_CDC_ReceiveEx()           | 314     |
| USB_CDC_ReceiveTimed()        | 315     |
| USB_CDC_ReceiveTimedEx()      | 315     |
| USB_CDC_SetLineCoding()       | 317–318 |
| USB_CDC_SetOnBreak            | 316     |
| USB_CDC_SetOnBreakEx          | 316     |
| USB_CDC_UpdateSerialState()   | 318     |
| USB_CDC_UpdateSerialStateEx() | 318     |
| USB_CDC_WaitForRX()           | 322     |
| USB_CDC_WaitForRXEx()         | 322     |
| USB_CDC_WaitForTX()           | 323     |
| USB_CDC_WaitForTXEx()         | 323     |
| USB_CDC_Write()               | 319     |
| USB_CDC_WriteEx()             | 319     |
| USB_CDC_WriteOverlapped()     | 320     |
| USB_CDC_WriteSerialState()    | 324     |
| USB_CDC_WriteSerialStateEx()  | 324     |
| USB_CDC_WriteTimed()          | 321     |
| USB_CDC_WriteTimedEx()        | 321     |

## E

### embOS/IP

|                              |    |
|------------------------------|----|
| Integrating into your system | 37 |
|------------------------------|----|

## F

|     |     |
|-----|-----|
| FAQ | 481 |
|-----|-----|

## H

### HID

|                   |     |
|-------------------|-----|
| USB_HID_Add()     | 345 |
| USB_HID_INIT_DATA | 358 |
| USB_HID_Read()    | 346 |

## M

### MSD

|                                      |               |
|--------------------------------------|---------------|
| USB_MSD_Add()                        | 190, 226, 262 |
| USB_MSD_AddCDRom()                   | 192           |
| USB_MSD_AddUnit()                    | 191, 263      |
| USB_MSD_Connect()                    | 197, 200      |
| USB_MSD_Disconnect()                 | 198           |
| USB_MSD_INFO                         | 204           |
| USB_MSD_INIT_DATA                    | 203, 265–266  |
| USB_MSD_INST_DATA                    | 205, 267      |
| USB_MSD_RequestDisconnect()          | 199           |
| USB_MSD_SetPreventAllowRemovalHook() | 193           |
| USB_MSD_SetReadWriteHook()           | 195           |

- USB\_MSD\_Task() ..... 196, 264
- USB\_MSD\_WaitForDisconnection() .... 201
- O**
- OS
  - USB\_OS\_DecRI() ..... 433
  - USB\_OS\_Delay() ..... 432
  - USB\_OS\_GetTickCnt() ..... 434
  - USB\_OS\_IncDI() ..... 435
  - USB\_OS\_Init() ..... 436
  - USB\_OS\_Panic() ..... 437
  - USB\_OS\_Signal() ..... 438
  - USB\_OS\_Wait() ..... 439
  - USB\_OS\_WaitTimed() ..... 440
- S**
- Support ..... 469–482
- Syntax, conventions used ..... 7
- U**
- USB Core
  - USB\_AddDriver() ..... 52
  - USB\_AddEP() ..... 59
  - USB\_DoRemoteWakeup ..... 73
  - USB\_EnableIAD() ..... 70
  - USB\_GetState() ..... 53
  - USB\_IsConfigured() ..... 55
  - USB\_SetAddFuncDesc() ..... 60
  - USB\_SetAllowRemoteWakeup() ..... 72
  - USB\_SetClassRequestHook() ..... 61
  - USB\_SetIsSelfPowered() ..... 63
  - USB\_SetMaxPower() ..... 64
  - USB\_SetOnRxEP0() ..... 65
  - USB\_SetOnSetupHook() ..... 66
  - USB\_StallEP() ..... 68
  - USB\_Start() ..... 56–57
  - USB\_WaitForEndOfTransfer() ..... 69
  - USB\_GetProductId() ..... 43
  - USB\_GetProductName() ..... 45
  - USB\_GetSerialNumber() ..... 46
  - USB\_GetVendorId() ..... 42
  - USB\_GetVendorName() ..... 44
- USB\_HW\_DRIVER
  - (\*pfAllocEP)() ..... 461
  - (\*pfAttach)() ..... 459
  - (\*pfDisableRxInterruptEP)() ..... 465
  - (\*pfDisableTx)() ..... 466
  - (\*pfEnable)() ..... 459
  - (\*pfEnableRxInterruptEP)() ..... 465
  - (\*pfGetMaxPacketSize)() ..... 461
  - (\*pfInit)() ..... 458
  - (\*pfSendEP)() ..... 466
  - (\*pfSetAddress)() ..... 459–460
  - (\*pfSetClrStallEP)() ..... 462–463
  - (\*pfStallEP0)() ..... 464
  - (\*pfUpdateEP)() ..... 462
- USB\_HW\_StartTx() ..... 467
- USB\_Init() ..... 54
- USB\_MSD\_INST\_DATA\_DRIVER ... 209, 268, 271
- USB\_MSD\_STORAGE\_API ..... 210, 269
  - (\*pfDeInit)() ..... 220, 287
  - (\*pfGetInfo)() ..... 214, 274
  - (\*pfGetReadBuffer)() ..... 215, 275
  - (\*pfGetWriteBuffer)() ..... 217, 277
- (\*pfInit)() ..... 213, 273
- (\*pfMediumIsPresent)() .... 219, 279–282, 285– ..... 286
- (\*pfRead)() ..... 216, 276
- (\*pfWrite)() ..... 218, 278, 283–284
- USB\_SetAllowRemoteWakeup ..... 72
- USBHID\_Close() ..... 361
- USBHID\_Exit() ..... 364
- USBHID\_GetInputReportSize() ..... 367
- USBHID\_GetNumAvailableDevices() ..... 365
- USBHID\_GetOutputReportSize() ..... 368
- USBHID\_GetProductId() ..... 369
- USBHID\_GetProductName() ..... 366
- USBHID\_GetVendorId() ..... 370
- USBHID\_Open() ..... 362
- USBHID\_RefreshList() ..... 371
- USBHID\_SetVendorPage() ..... 372

## Данный компонент на территории Российской Федерации

**Вы можете приобрести в компании MosChip.**

Для оперативного оформления запроса Вам необходимо перейти по данной ссылке:

<http://moschip.ru/get-element>

Вы можете разместить у нас заказ для любого Вашего проекта, будь то серийное производство или разработка единичного прибора.

В нашем ассортименте представлены ведущие мировые производители активных и пассивных электронных компонентов.

Нашей специализацией является поставка электронной компонентной базы двойного назначения, продукции таких производителей как XILINX, Intel (ex.ALTERA), Vicor, Microchip, Texas Instruments, Analog Devices, Mini-Circuits, Amphenol, Glenair.

Сотрудничество с глобальными дистрибьюторами электронных компонентов, предоставляет возможность заказывать и получать с международных складов практически любой перечень компонентов в оптимальные для Вас сроки.

На всех этапах разработки и производства наши партнеры могут получить квалифицированную поддержку опытных инженеров.

Система менеджмента качества компании отвечает требованиям в соответствии с ГОСТ Р ИСО 9001, ГОСТ РВ 0015-002 и ЭС РД 009

### Офис по работе с юридическими лицами:

105318, г.Москва, ул.Щербаковская д.3, офис 1107, 1118, ДЦ «Щербаковский»

Телефон: +7 495 668-12-70 (многоканальный)

Факс: +7 495 668-12-70 (доб.304)

E-mail: [info@moschip.ru](mailto:info@moschip.ru)

Skype отдела продаж:

moschip.ru

moschip.ru\_4

moschip.ru\_6

moschip.ru\_9