

## DESCRIPTION

Demonstration circuit 740 is a tracker/sequencer demo board featuring the LTC2922 that monitors up to five external power supplies and ramps up their load voltages by controlling external N-channel MOSFETs. Automatic remote sense switching allows supply generators with sense inputs to compensate for voltage drops across the controlling FETs. Excessive current on the primary supply (Supply #0) trips an electronic circuit breaker that will disconnect all of the loads. Four jumpers (block JP1) are provided to select which non-primary supplies are monitored. The resistors that set the supply monitoring levels may be replaced to customize the board for other supply voltage combinations (see the LTC2922 Datasheet). Five other jumpers (blocks JP2, JP3, and JP4) allow the board to demonstrate supply sequencing. With the proper jumper settings, supplies #3 and #4 will

track up together a selectable time after supplies #0, #1, and #2 track up together. The board includes a power-on LED that, when lit, indicates that the primary supply's load is energized. Oversized solder pads under the load resistors and the circuit breaker current sense resistor accommodate a wide range of component footprints. Solder pads on the back of the board accommodate extra load capacitors or resistors. In addition to providing near-by ground connections for each supply input and output, the board has metal ground strips that are convenient clip points for meter leads.

**Design files for this circuit board are available. Call the LTC factory.**

LTC is a registered trademark of Linear Technology Corporation

**Table 1. Performance Summary ( $T_A = 25^\circ\text{C}$ )**

| PARAMETER                                               | CONDITION                                        | MIN  | TYP  | MAX  | UNITS |
|---------------------------------------------------------|--------------------------------------------------|------|------|------|-------|
| $V_{CC}$ (Supply #0) Voltage Typical<br>Operating Range | Board DC740A-A                                   | 4.50 | 5.00 | 5.50 | V     |
|                                                         | Board DC740A-B                                   | 2.97 | 3.30 | 3.63 | V     |
|                                                         | Board DC740A-C                                   | 2.37 | 2.50 | 2.63 | V     |
| Load ramp rate                                          | Tracking                                         |      | 0.10 |      | V/ms  |
|                                                         | Sequencing, first set of loads                   |      | 0.10 |      | V/ms  |
|                                                         | Sequencing, delayed set of loads                 |      | 0.12 |      | V/ms  |
| Monitor-to-Tracking Delay                               | All monitors in compliance to start of GATE ramp |      | 20   |      | ms    |
| Sequencing Delay                                        | Final GATE voltage to start of PG ramp           |      | 20   |      | ms    |
| Circuit Breaker Trip Current                            |                                                  | 3.7  | 4.2  | 4.7  | A     |

## OPERATING PRINCIPLES

This board may be configured to demonstrate supply tracking or supply sequencing. In tracking mode, all supplies are ramped up simultaneously a selectable delay after all monitoring requirements are met. Supply #0, the  $V_{CC}$  supply, is always monitored; monitoring of other supplies is selectable by means of jumper block JP1.

In sequencing mode, the ramping of one set of supplies follows the ramping of another set of supplies. This demonstration board limits the possible delayed supplies to #3 and/or #4. The delayed supplies may not take advantage of automatic remote sense switching.

# QUICK START GUIDE FOR DEMONSTRATION CIRCUIT 740

## TRACKER/SEQUENCER DEMO BOARD

**Table 2. Supply Requirements for Demo Board 740A with Factory Jumper Settings**

| SUPPLY NUMBER                             | SUPPLY VOLTAGE | SUPPLY VARIATION | DEMO BOARD VERSION | LOAD CURRENT COMPLIANCE | ADDITIONAL LOAD CURRENT             |
|-------------------------------------------|----------------|------------------|--------------------|-------------------------|-------------------------------------|
| #0<br>(Primary Supply = $V_{CC}$ Voltage) | 5.0V           | $\pm 10\%$ max.  | 740A-A             | $>95\text{mA}$          | 3.7A min.<br>4.2A typ.<br>4.7A max. |
|                                           | 3.3V           | $\pm 10\%$ max.  | 740A-B             | $>75\text{mA}$          |                                     |
|                                           | 2.5V           | $\pm 5\%$ max.   | 740A-C             | $>65\text{mA}$          |                                     |
| #1                                        | 2.5V           | $\pm 7.5\%$ max. | 740A-A, -B, -C     | $>30\text{mA}$          | 4.0A max.                           |
| #2                                        | 1.8V           | $\pm 7.5\%$ max. | 740A-A, -B, -C     | $>25\text{mA}$          | 4.0A max.                           |
| #3                                        | 1.5V           | $\pm 7.5\%$ max. | 740A-A, -B, -C     | $>20\text{mA}$          | 3.5A max.                           |
| #4                                        | 1.2V           | $\pm 5\%$ max.   | 740A-A, -B, -C     | $>15\text{mA}$          | 3.5A max.                           |

## QUICK START PROCEDURE

Demonstration circuit 740 is easy to set up to evaluate the operation of the LTC2922. Refer to Figure 1 for proper measurement equipment setup. To test tracking operation, follow steps 1 through 3 below, then proceed to step 7. To test sequencing operation, follow steps 4 through 6, then proceed to step 7.

Use of remote sense switching is optional on a per supply basis (see Figure 1). It is available for all supplies in tracking applications, but only for supplies 0 through 2 in sequencing applications.

The demo board is shipped with the jumpers set for monitoring all five supplies and tracking of all the loads. In addition, a resistor pull-up to  $V_{CC}$  from the PG pin makes the power good output a proper logic signal.

The voltage and current requirements for supply generators when the board has factory jumper settings, and the factory installed values for monitoring resistors RA1-RA4 and RB1-RB4 are summarized in Table 2. Consult the LTC2922 Datasheet to calculate new resistor values to monitor supplies with different voltages or tolerances.

External loads may be added at the load terminals. Make the wires as short as possible to reduce inductance and resistance, and use a gauge proper for the expected load currents.

## TRACKING

- Set the jumpers of block JP1 to choose which supplies, in addition to the primary supply, will be monitored. For example, to monitor all supplies set:

**JP1 Supply#1** Monitor

**JP1 Supply#2** Monitor

**JP1 Supply#3** Monitor

**JP1 Supply#4** Monitor

- Set jumper JP2 to select the resistive pull-up on the PG pin:

**JP2 PG Function** Pull-up

- Set the upper and lower jumpers of blocks JP3 and JP4 to select tracking and automatic remote sense switching:

**JP3 Load#3** Track

**JP3 Load#3** Remote Sense

**JP4 Load#4** Track

**JP4 Load#4** Remote Sense

**NOTE:** Remote sense switching will have no effect if supply generators' sense inputs are not connected to the board's FB turret posts.

Proceed to step 7.

### SEQUENCING

4. Set the jumpers of block JP1 to choose which supplies, in addition to the primary supply, will be monitored. For example, to monitor all supplies, set:

**JP1 Supply#1**      Monitor

**JP1 Supply#2**      Monitor

**JP1 Supply#3**      Monitor

**JP1 Supply#4**      Monitor

5. Set jumper JP2 to select the sequencing function of the PG pin:

**JP2 PG Function**      Sequence

6. Set the upper and lower jumpers of blocks JP3 and JP4 to choose which supplies get a sequencing delay. For example, to sequence both supply #3 and supply #4, set:

**JP3 Load#3**      Sequence

**JP3 Load#3**      Sequence/No Sense

**JP4 Load#4**      Sequence

**JP4 Load#4**      Sequence/No Sense

**NOTE:** When a supply is sequenced, remote sense switching is not available for that supply.

7. With the power off, connect supply generators to the Supply and GND terminal pairs on the left side of the board. Connect sense terminals of the sup-

ply generators (if available) to the FB terminals on the left side of the board.

8. Leave one supply off, turn on all the other supplies. This supply must be selected as a monitored supply, and should be the trigger signal for the oscilloscope.
9. Turn on the final supply and capture selected supply voltage and load voltage waveforms.
10. Make sure that the Load #0 Power On indicator LED is lighted, and that the load voltages nearly equal the supply voltages. (Small differences will occur due to the voltage drop across the controlling FETs.)

**NOTE:** If the loads do not power up, double check the voltage levels and current compliances of the supplies against the required values in Table 2.

11. When the load voltages have successfully ramped, view the scope trace to measure the monitor-to-ramp start delay, the supply ramp rate, and other parameters in Table 1. Note the compensating effect of automatic remote sense switching if supply sense inputs are connected.
12. Check the operation of the electronic circuit breaker by loading the primary supply and noting the disconnection of all supplies. Pulse supply #1 low or short pin "V1 In" to ground momentarily to reset the breaker and initiate tracking or sequencing.





## Данный компонент на территории Российской Федерации

**Вы можете приобрести в компании MosChip.**

Для оперативного оформления запроса Вам необходимо перейти по данной ссылке:

<http://moschip.ru/get-element>

Вы можете разместить у нас заказ для любого Вашего проекта, будь то серийное производство или разработка единичного прибора.

В нашем ассортименте представлены ведущие мировые производители активных и пассивных электронных компонентов.

Нашей специализацией является поставка электронной компонентной базы двойного назначения, продукции таких производителей как XILINX, Intel (ex.ALTERA), Vicor, Microchip, Texas Instruments, Analog Devices, Mini-Circuits, Amphenol, Glenair.

Сотрудничество с глобальными дистрибьюторами электронных компонентов, предоставляет возможность заказывать и получать с международных складов практически любой перечень компонентов в оптимальные для Вас сроки.

На всех этапах разработки и производства наши партнеры могут получить квалифицированную поддержку опытных инженеров.

Система менеджмента качества компании отвечает требованиям в соответствии с ГОСТ Р ИСО 9001, ГОСТ РВ 0015-002 и ЭС РД 009

### Офис по работе с юридическими лицами:

105318, г.Москва, ул.Щербаковская д.3, офис 1107, 1118, ДЦ «Щербаковский»

Телефон: +7 495 668-12-70 (многоканальный)

Факс: +7 495 668-12-70 (доб.304)

E-mail: [info@moschip.ru](mailto:info@moschip.ru)

Skype отдела продаж:

moschip.ru

moschip.ru\_4

moschip.ru\_6

moschip.ru\_9