

# TRON® In-Line Fuseholders

## Single-Pole for Solid Neutral

# HET Series



### Non-Breakaway Holders

Catalog Symbol: HET-AA, HET-AB, HET-BB, HET-JJ, and HET-JK

In-Line Fuseholders, Single-Pole

Water-Resistant

For breakaway holders, see page 2

HET — A HEB fuseholder with a permanently installed solid neutral. Easily identified by white plastic coupling nut.

### Example:

A single-pole, in-line holder for a neutral is required. One solid copper #8 is on the load side, copper crimp for connection. A solid copper #6 is on the line side, and a copper crimp is required.

1. Choose HET- series.
2. Choose "A" for load side.
3. Choose "B" for line side.

Complete Catalog Number: HET-AB.

### Ordering Information:

|            |   |                          |                          |
|------------|---|--------------------------|--------------------------|
| <b>HET</b> | — |                          |                          |
|            |   | <b>Load<br/>Terminal</b> | <b>Line<br/>Terminal</b> |

### Catalog and Specification Data - Non-Breakaway Conductor Terminals

| Terminal Type                                                                                                                                                         | Conductors<br>Size | No. Per<br>Terminal | Solid | Stranded | Catalog<br>Symbol<br>Load &<br>Line<br>(2 & 3) |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------|---------------------|-------|----------|------------------------------------------------|
|   | #12 to #8          | 1                   | •     | •        | A                                              |
|                                                                                                                                                                       | #12                | 2                   | •     | •        |                                                |
|                                                                                                                                                                       | #10                | 2                   | •     | •        | B                                              |
|                                                                                                                                                                       | #6                 | 1                   | •     | •        |                                                |
|                                                                                                                                                                       | #4                 | 1                   | •     | •        |                                                |
|   | #12 to #3          | 1                   | •     | •        | J                                              |
|                                                                                                                                                                       | #12 to #2          | 2                   | •     | •        | K                                              |
|   | #12 to #2          | 1                   | •     | •        | L                                              |

### Catalog Data — Insulating Boots



| Catalog<br>Numbers | Type             |
|--------------------|------------------|
| <b>2A0660</b>      | Single Conductor |
| <b>2A0661</b>      | Two Conductor    |

Insulating boots are not included with non-breakaway parts and must be ordered separately. They come standard with the breakaway series. The HET-AW & HET-JW do not have the boots. These catalog items do not have a breakaway receptacle.

When boots are utilized, extra heat retention requires that fuses are sized at a minimum of 200% of the RMS load current.

Recommended Torque on Coupling Nut: 10-20 in-lb.

# TRON® In-Line Fuseholders

## Single-Pole for Solid Neutral

# HET

## Series

### Breakaway Holders

Catalog Symbol: HET-AW-RLC-A, HET-AW-RLC-B, HET-AW-RLC-C, HET-AW-RLC-J, HET-AW-RYC, HET-BW-RLC-B, HET-BW-RYC, HET-JW, HET-JW-RLC-J, HET-JW-RYC, and HET-AW

### In-Line Fuseholders, Single-Pole

#### Example:

A single-pole, in-line, breakaway holder for a neutral is requested. A single #10 solid, copper crimp is on the load side. A single #10, solid wire and a copper crimp is needed on the line side.

1. Choose HET- series.
2. Choose "A" from 1st page for load side.
3. Choose "W" for breakaway requirement.
4. Choose "RLC-A" for breakaway receptacle on line side.

Complete Catalog Number: HET-AW-RLC-A

### Catalog and Specification Data

#### Breakaway Receptacles

| Terminal Type                                                                      | Conductor Data<br>Size | Catalog Symbol   |       |          |
|------------------------------------------------------------------------------------|------------------------|------------------|-------|----------|
|                                                                                    |                        | No. Per Terminal | Solid | Stranded |
|  | #12 to #8              | 1                | •     | •        |
|                                                                                    | #6                     | 1                | •     | •        |
|                                                                                    | #4                     | 1                | •     | •        |

#### Copper Set-Screw

|                                                                                    |           |   |   |   |
|------------------------------------------------------------------------------------|-----------|---|---|---|
|  | #12 to #3 | 1 | • | • |
|                                                                                    |           |   |   |   |
|  | #12 to #3 | 2 | • | • |
|                                                                                    |           |   |   |   |

#### Solid Breakaway

|                                                                                    |                                      |   |
|------------------------------------------------------------------------------------|--------------------------------------|---|
|  | (Required with breakaway Receptacle) | W |
|------------------------------------------------------------------------------------|--------------------------------------|---|

### Ordering Information:

|            |   |                      |          |   |                      |
|------------|---|----------------------|----------|---|----------------------|
| <b>HET</b> | — |                      | <b>W</b> | — |                      |
|            |   | <b>Load Terminal</b> |          |   | <b>Line Terminal</b> |

Recommended Torque on Coupling Nut: 10-20 in-lb.

The only controlled copy of this Data Sheet is the electronic read-only version located on the Bussmann Network Drive. All other copies of this document are by definition uncontrolled. This bulletin is intended to clearly present comprehensive product data and provide technical information that will help the end user with design applications. Bussmann reserves the right, without notice, to change design or construction of any products and to discontinue or limit distribution of any products. Bussmann also reserves the right to change or update, without notice, any technical information contained in this bulletin. Once a product has been selected, it should be tested by the user in all possible applications.

## Данный компонент на территории Российской Федерации

**Вы можете приобрести в компании MosChip.**

Для оперативного оформления запроса Вам необходимо перейти по данной ссылке:

<http://moschip.ru/get-element>

Вы можете разместить у нас заказ для любого Вашего проекта, будь то серийное производство или разработка единичного прибора.

В нашем ассортименте представлены ведущие мировые производители активных и пассивных электронных компонентов.

Нашей специализацией является поставка электронной компонентной базы двойного назначения, продукции таких производителей как XILINX, Intel (ex.ALTERA), Vicor, Microchip, Texas Instruments, Analog Devices, Mini-Circuits, Amphenol, Glenair.

Сотрудничество с глобальными дистрибьюторами электронных компонентов, предоставляет возможность заказывать и получать с международных складов практически любой перечень компонентов в оптимальные для Вас сроки.

На всех этапах разработки и производства наши партнеры могут получить квалифицированную поддержку опытных инженеров.

Система менеджмента качества компании отвечает требованиям в соответствии с ГОСТ Р ИСО 9001, ГОСТ РВ 0015-002 и ЭС РД 009

### Офис по работе с юридическими лицами:

105318, г.Москва, ул.Щербаковская д.3, офис 1107, 1118, ДЦ «Щербаковский»

Телефон: +7 495 668-12-70 (многоканальный)

Факс: +7 495 668-12-70 (доб.304)

E-mail: [info@moschip.ru](mailto:info@moschip.ru)

Skype отдела продаж:

moschip.ru

moschip.ru\_4

moschip.ru\_6

moschip.ru\_9