

## *Remote/Local Temperature Sensor with SMBus Serial Interface*

## *\_\_\_\_\_\_\_\_\_\_\_\_\_\_\_\_General Description*

The MAX1617 is a precise digital thermometer that reports the temperature of both a remote sensor and its own package. The remote sensor is a diode-connected transistor—typically a low-cost, easily mounted 2N3904 NPN type—that replaces conventional thermistors or thermocouples. Remote accuracy is  $\pm 3^{\circ}$ C for multiple transistor manufacturers, with no calibration needed. The remote channel can also measure the die temperature of other ICs, such as microprocessors, that contain an on-chip, diode-connected transistor.

The 2-wire serial interface accepts standard System Management Bus (SMBus) Write Byte, Read Byte, Send Byte, and Receive Byte commands to program the alarm thresholds and to read temperature data. The data format is 7 bits plus sign, with each bit corresponding to 1°C, in twos-complement format. Measurements can be done automatically and autonomously, with the conversion rate programmed by the user or programmed to operate in a single-shot mode. The adjustable rate allows the user to control the supply-current drain.

The MAX1617 is available in a small, 16-pin QSOP surface-mount package.

Desktop and Notebook Central Office Computers Telecom Equipment LAN Servers Multi-Chip Modules Industrial Controls

### *\_Applications*

Smart Battery Packs Test and Measurement

### *\_\_\_\_\_\_\_\_\_\_\_\_\_\_\_\_\_\_\_Pin Configuration*



### *\_Features*

- ♦ **Two Channels: Measures Both Remote and Local Temperatures**
- ♦ **No Calibration Required**
- ♦ **SMBus 2-Wire Serial Interface**
- ♦ **Programmable Under/Overtemperature Alarms**
- ♦ **Supports SMBus Alert Response**
- ♦ **Accuracy: ±2°C (+60°C to +100°C, local) ±3°C (-40°C to +125°C, local) ±3°C (+60°C to +100°C, remote)**
- ♦ **3µA (typ) Standby Supply Current**
- ♦ **70µA (max) Supply Current in Auto-Convert Mode**
- ♦ **+3V to +5.5V Supply Range**
- ♦ **Small, 16-Pin QSOP Package**

### *\_\_\_\_\_\_\_\_\_\_\_\_\_\_\_Ordering Information*



+*Denotes a lead(Pb)-free/RoHS-compliant package.*

### *\_\_\_\_\_\_\_\_\_\_Typical Operating Circuit*



*For pricing, delivery, and ordering information, please contact Maxim Direct at 1-888-629-4642, or visit Maxim's website at www.maximintegrated.com*

# *Remote/Local Temperature Sensor with SMBus Serial Interface*

### **ABSOLUTE MAXIMUM RATINGS**







*Stresses beyond those listed under "Absolute Maximum Ratings" may cause permanent damage to the device. These are stress ratings only, and functional operation of the device at these or any other conditions beyond those indicated in the operational sections of the specifications is not implied. Exposure to absolute maximum rating conditions for extended periods may affect device reliability.*

### **ELECTRICAL CHARACTERISTICS**

 $(V_{CC} = +3.3V, T_A = 0^\circ C \text{ to } +85^\circ C$ , unless otherwise noted.) (Note 1)



## *Remote/Local Temperature Sensor with SMBus Serial Interface*

## **ELECTRICAL CHARACTERISTICS (continued)**

 $(V_{CC} = +3.3V, T_A = 0^\circ C \text{ to } +85^\circ C$ , unless otherwise noted.) (Note 1)



### **ELECTRICAL CHARACTERISTICS**

 $(V_{CC} = +3.3V, T_A = -55^{\circ}C \text{ to } +125^{\circ}C$ , unless otherwise noted.) (Note 1)



# *Remote/Local Temperature Sensor with SMBus Serial Interface*

### **ELECTRICAL CHARACTERISTICS (continued)**

(V<sub>CC</sub> =  $+3.3V$ ,  $TA = -55°C$  to  $+125°C$ , unless otherwise noted.) (Note 1)



**Note 1:** All devices 100% production tested at T<sub>A</sub> = +85°C. Limits over temperature are guaranteed by design.

**Note 2:** Guaranteed but not 100% tested.

**Note 3:** Quantization error is not included in specifications for temperature accuracy. For example, if the MAX1617 device temperature is exactly +66.7°C, the ADC may report +66°C, +67°C, or +68°C (due to the quantization error plus the +1/2°C offset used for rounding up) and still be within the guaranteed  $\pm 1^{\circ}$ C error limits for the  $+60^{\circ}$ C to  $+100^{\circ}$ C temperature range. See Table 2.

**Note 4:** A remote diode is any diode-connected transistor from Table 1. TR is the junction temperature of the remote diode. See *Remote Diode Selection* for remote diode forward voltage requirements.

**Note 5:** The SMBus logic block is a static design that works with clock frequencies down to DC. While slow operation is possible, it violates the 10kHz minimum clock frequency and SMBus specifications, and may monopolize the bus.

**Note 6:** Note that a transition must internally provide at least a hold time in order to bridge the undefined region (300ns max) of SMBCLK's falling edge.



## *\_Typical Operating Characteristics*

## *Remote/Local Temperature Sensor with SMBus Serial Interface*

### *\_Typical Operating Characteristics (continued)*

 $(T_A = +25^{\circ}C$ , unless otherwise noted.)



Maxim Integrated

# *Remote/Local Temperature Sensor with SMBus Serial Interface*

## *\_Pin Description*



## *\_\_\_\_\_\_\_\_\_\_\_\_\_\_\_Detailed Description*

The MAX1617 is a temperature sensor designed to work in conjunction with an external microcontroller (µC) or other intelligence in thermostatic, process-control, or monitoring applications. The µC is typically a power-management or keyboard controller, generating SMBus serial commands by "bit-banging" general-purpose input-output (GPIO) pins or via a dedicated SMBus interface block.

Essentially an 8-bit serial analog-to-digital converter (ADC) with a sophisticated front end, the MAX1617 contains a switched current source, a multiplexer, an ADC, an SMBus interface, and associated control logic (Figure 1). Temperature data from the ADC is loaded into two data registers, where it is automatically compared with data previously stored in four over/undertemperature alarm registers.

#### *ADC and Multiplexer*

The ADC is an averaging type that integrates over a 60ms period (each channel, typical), with excellent noise rejection.

The multiplexer automatically steers bias currents through the remote and local diodes, measures their forward voltages, and computes their temperatures. Both channels are automatically converted once the conversion process has started, either in free-running or single-shot mode. If one of the two channels is not used, the device still performs both measurements, and the user can simply ignore the results of the unused channel. If the remote diode channel is unused, tie DXP to DXN rather than leaving the pins open.

The DXN input is biased at 0.65V typical above ground by an internal diode to set up the analog-to-digital (A/D) inputs for a differential measurement. The typical DXP–DXN differential input voltage range is 0.25V to 0.95V. To ensure proper operation over full temperature range, ensure  $V_{\text{DXP}} \leq (0.78 \times V_{\text{CC}} - 1.1)$  volts.

Excess resistance in series with the remote diode causes about +1/2°C error per ohm. Likewise, 200µV of offset voltage forced on DXP–DXN causes about 1°C error.

## *Remote/Local Temperature Sensor with SMBus Serial Interface*



# *Remote/Local Temperature Sensor with SMBus Serial Interface MAX1617*

#### *A/D Conversion Sequence*

If a Start command is written (or generated automatically in the free-running auto-convert mode), both channels are converted, and the results of both measurements are available after the end of conversion. A BUSY status bit in the status byte shows that the device is actually performing a new conversion; however, even if the ADC is busy, the results of the previous conversion are always available.

#### *Remote-Diode Selection*

Temperature accuracy depends on having a good-quality, diode-connected small-signal transistor. See Table 1 for a recommended list of diode-connected small-signal transistors. The MAX1617 can also directly measure the die temperature of CPUs and other integrated circuits having on-board temperature-sensing diodes.

The transistor must be a small-signal type with a relatively high forward voltage; otherwise, the A/D input voltage range can be violated. The forward voltage must be greater than 0.25V at 10µA; check to ensure this is true at the highest expected temperature. The forward voltage ( $V_{\text{DXP}}$  -  $V_{\text{DXN}}$ ) must be less than 0.95V at 100 $\mu$ A; additionally, ensure the maximum  $V_{\text{DXP}}$  (DXP) voltage)  $\leq$  (0.78 x V<sub>CC</sub> - 1.1) volts over your expected range of temperature. Large power transistors don't work at all. Also, ensure that the base resistance is less than 100Ω. Tight specifications for forward-current gain (+50 to +150, for example) indicate that the manufacturer has good process controls and that the devices have consistent VBE characteristics.

For heat-sink mounting, the 500-32BT02-000 thermal sensor from Fenwal Electronics is a good choice. This device consists of a diode-connected transistor, an aluminum plate with screw hole, and twisted-pair cable (Fenwal Inc., Milford, MA, 508-478-6000).

#### *Thermal Mass and Self-Heating*

Thermal mass can seriously degrade the MAX1617's effective accuracy. The thermal time constant of the QSOP-16 package is about 140sec in still air. For the MAX1617 junction temperature to settle to within  $+1^{\circ}$ C after a sudden +100°C change requires about five time constants or 12 minutes. The use of smaller packages for remote sensors, such as SOT23s, improves the situation. Take care to account for thermal gradients between the heat source and the sensor, and ensure that stray air currents across the sensor package do not interfere with measurement accuracy.

Self-heating does not significantly affect measurement accuracy. Remote-sensor self-heating due to the diode

### **Table 1. Remote-Sensor Transistor Manufacturers**



*Note: Transistors must be diode-connected (base shorted to collector).*

current source is negligible. For the local diode, the worst-case error occurs when auto-converting at the fastest rate and simultaneously sinking maximum current at the ALERT output. For example, at an 8Hz rate and with ALERT sinking 1mA, the typical power dissipation is V<sub>CC</sub> x 450µA plus 0.4V x 1mA. Package theta J-A is about 150 $\degree$ C/W, so with V<sub>CC</sub> = 5V and no copper PCB heat-sinking, the resulting temperature rise is:

#### $dT = 2.7$ mW x 150 $°C/W = 0.4°C$

Even with these contrived circumstances, it is difficult to introduce significant self-heating errors.

#### *ADC Noise Filtering*

The ADC is an integrating type with inherently good noise rejection, especially of low-frequency signals such as 60Hz/120Hz power-supply hum. Micropower operation places constraints on high-frequency noise rejection; therefore, careful PCB layout and proper external noise filtering are required for high-accuracy remote measurements in electrically noisy environments.

High-frequency EMI is best filtered at DXP and DXN with an external 2200pF capacitor. This value can be increased to about 3300pF (max), including cable capacitance. Higher capacitance than 3300pF introduces errors due to the rise time of the switched current source.

Nearly all noise sources tested cause the ADC measurements to be higher than the actual temperature, typically by  $+1^{\circ}$ C to  $+10^{\circ}$ C, depending on the frequency and amplitude (see *Typical Operating Characteristics*).

## *Remote/Local Temperature Sensor with SMBus Serial Interface*

#### *PCB Layout*

- 1) Place the MAX1617 as close as practical to the remote diode. In a noisy environment, such as a computer motherboard, this distance can be 4 in. to 8 in. (typical) or more as long as the worst noise sources (such as CRTs, clock generators, memory buses, and ISA/PCI buses) are avoided.
- 2) Do not route the DXP–DXN lines next to the deflection coils of a CRT. Also, do not route the traces across a fast memory bus, which can easily introduce +30°C error, even with good filtering. Otherwise, most noise sources are fairly benign.
- 3) Route the DXP and DXN traces in parallel and in close proximity to each other, away from any highvoltage traces such as +12V<sub>DC</sub>. Leakage currents from PCB contamination must be dealt with carefully, since a 20MΩ leakage path from DXP to ground causes about +1°C error.
- 4) Connect guard traces to GND on either side of the DXP–DXN traces (Figure 2). With guard traces in place, routing near high-voltage traces is no longer an issue.
- 5) Route through as few vias and crossunders as possible to minimize copper/solder thermocouple effects.
- 6) When introducing a thermocouple, make sure that both the DXP and the DXN paths have matching thermocouples. In general, PCB-induced thermocouples are not a serious problem. A copper-solder thermocouple exhibits 3µV/°C, and it takes about 200µV of voltage error at DXP–DXN to cause a +1°C measurement error. So, most parasitic thermocouple errors are swamped out.
- 7) Use wide traces. Narrow ones are more inductive and tend to pick up radiated noise. The 10 mil widths and spacings recommended in Figure 2 aren't absolutely necessary (as they offer only a minor improvement in leakage and noise), but try to use them where practical.
- 8) Keep in mind that copper can't be used as an EMI shield, and only ferrous materials such as steel work well. Placing a copper ground plane between the DXP-DXN traces and traces carrying high-frequency noise signals does not help reduce EMI.

#### *PCB Layout Checklist*

- Place the MAX1617 close to a remote diode.
- Keep traces away from high voltages (+12V bus).
- Keep traces away from fast data buses and CRTs.
- Use recommended trace widths and spacings.
- Place a ground plane under the traces.



*Figure 2. Recommended DXP/DXN PC Traces*

- Use guard traces flanking DXP and DXN and connecting to GND.
- Place the noise filter and the 0.1µF V<sub>CC</sub> bypass capacitors close to the MAX1617.
- Add a 200 $Ω$  resistor in series with VCC for best noise filtering (see *Typical Operating Circuit*).

#### *Twisted Pair and Shielded Cables*

For remote-sensor distances longer than 8 in., or in particularly noisy environments, a twisted pair is recommended. Its practical length is 6 feet to 12 feet (typical) before noise becomes a problem, as tested in a noisy electronics laboratory. For longer distances, the best solution is a shielded twisted pair like that used for audio microphones. For example, Belden #8451 works well for distances up to 100 feet in a noisy environment. Connect the twisted pair to DXP and DXN and the shield to GND, and leave the shield's remote end unterminated.

Excess capacitance at DX\_ limits practical remote sensor distances (see *Typical Operating Characteristics*). For very long cable runs, the cable's parasitic capacitance often provides noise filtering, so the 2200pF capacitor can often be removed or reduced in value.

Cable resistance also affects remote-sensor accuracy; 1Ω series resistance introduces about +1/2°C error.

#### *Low-Power Standby Mode*

Standby mode disables the ADC and reduces the supply-current drain to less than 10µA. Enter standby mode by forcing the STBY pin low or via the RUN/STOP bit in the configuration byte register. Hardware and software standby modes behave almost identically: all data is retained in memory, and the SMB interface is alive and listening for reads and writes. The only difference is that in hardware standby mode, the one-shot command does not initiate a conversion.

Standby mode is not a shutdown mode. With activity on the SMBus, extra supply current is drawn (see *Typical Operating Characteristics*). In software standby mode,

# *Remote/Local Temperature Sensor with SMBus Serial Interface MAX1617*

the MAX1617 can be forced to perform A/D conversions via the one-shot command, despite the RUN/STOP bit being high.

Activate hardware standby mode by forcing the STBY pin low. In a notebook computer, this line may be connected to the system SUSTAT# suspend-state signal.

The **STBY** pin low state overrides any software conversion command. If a hardware or software standby command is received while a conversion is in progress, the conversion cycle is truncated, and the data from that conversion is not latched into either temperature reading register. The previous data is not changed and remains available.

Supply-current drain during the 125ms conversion period is always about 450µA. Slowing down the conversion rate reduces the average supply current (see *Typical Operating Characteristics*). In between conversions, the instantaneous supply current is about 25µA due to the current consumed by the conversion rate timer. In standby mode, supply current drops to about 3µA. At very low supply voltages (under the power-onreset threshold), the supply current is higher due to the address pin bias currents. It can be as high as 100µA, depending on ADD0 and ADD1 settings.

#### *SMBus Digital Interface*

From a software perspective, the MAX1617 appears as a set of byte-wide registers that contain temperature data, alarm threshold values, or control bits. A standard SMBus 2-wire serial interface is used to read temperature data and write control bits and alarm threshold data. Each A/D channel within the device responds to the same SMBus slave address for normal reads and writes.

The MAX1617 employs four standard SMBus protocols: Write Byte, Read Byte, Send Byte, and Receive Byte (Figure 3). The shorter Receive Byte protocol allows quicker transfers, provided that the correct data register was previously selected by a Read Byte instruction. Use caution with the shorter protocols in multi-master systems, since a second master could overwrite the command byte without informing the first master.

The temperature data format is 7 bits plus sign in twos-complement form for each channel, with each data bit representing 1°C (Table 2), transmitted MSB first. Measurements are offset by  $+1/2$ °C to minimize internal rounding errors; for example, +99.6°C is reported as +100°C.

**ADDRESS RD S DATA /// P**

8 bits

Data Byte: reads data from the register commanded by the last Read Byte or Write Byte transmission; also used for SMBus Alert Response return address

### *Write Byte Format*



7 bits



*Figure 3. SMBus Protocols*

Maxim Integrated

## *Remote/Local Temperature Sensor with SMBus Serial Interface*

**Address (0001100)**



### **Table 2. Data Format (Twos-Complement) Table 3. Read Format for Alert Response**

#### *Alarm Threshold Registers*

Four registers store alarm threshold data, with high $temperature$  (T<sub>HIGH</sub>) and low-temperature ( $T<sub>LOW</sub>$ ) registers for each A/D channel. If either measured temperature equals or exceeds the corresponding alarm threshold value, an ALERT interrupt is asserted.

The power-on-reset (POR) state of both T<sub>HIGH</sub> registers is full scale (0111 1111, or +127°C). The POR state of both T<sub>LOW</sub> registers is 1100 1001 or -55°C.

#### *Diode Fault Alarm*

There is a continuity fault detector at DXP that detects whether the remote diode has an open-circuit condition. At the beginning of each conversion, the diode fault is checked, and the status byte is updated. This fault detector is a simple voltage detector; if DXP rises above V<sub>CC</sub> - 1V (typical) due to the diode current source, a fault is detected. Note that the diode fault isn't checked until a conversion is initiated, so immediately after power-on reset the status byte indicates no fault is present, even if the diode path is broken.

If the remote channel is shorted (DXP to DXN or DXP to GND), the ADC reads 0000 0000 so as not to trip either



the THIGH or TLOW alarms at their POR settings. In applications that are never subjected to 0°C in normal operation, a 0000 0000 result can be checked to indicate a fault condition in which DXP is accidentally short circuited. Similarly, if DXP is short circuited to  $V_{CC}$ , the ADC reads +127°C for both remote and local channels, and the device alarms.

#### ALERT *Interrupts*

The ALERT interrupt output signal is latched and can only be cleared by reading the Alert Response address. Interrupts are generated in response to THIGH and TLOW comparisons and when the remote diode is disconnected (for continuity fault detection). The interrupt does not halt automatic conversions; new temperature data continues to be available over the SMBus interface after ALERT is asserted. The interrupt output pin is open-drain so that devices can share a common interrupt line. The interrupt rate can never exceed the conversion rate.

The interface responds to the SMBus Alert Response address, an interrupt pointer return-address feature (see *Alert Response Address* section). Prior to taking corrective action, always check to ensure that an interrupt is valid by reading the current temperature.

#### *Alert Response Address*

The SMBus Alert Response interrupt pointer provides quick fault identification for simple slave devices that lack the complex, expensive logic needed to be a bus master. Upon receiving an ALERT interrupt signal, the host master can broadcast a Receive Byte transmission to the Alert Response slave address (0001 100). Then any slave device that generated an interrupt attempts to identify itself by putting its own address on the bus (Table 3).

# *Remote/Local Temperature Sensor with SMBus Serial Interface*



### **Table 4. Command-Byte Bit Assignments**

\**If the device is in hardware standby mode at POR, both temperature registers read 0°C.*

The Alert Response can activate several different slave devices simultaneously, similar to the  $I<sup>2</sup>C$  General Call. If more than one slave attempts to respond, bus arbitration rules apply, and the device with the lower address code wins. The losing device does not generate an acknowledge and continues to hold the ALERT line low until serviced (implies that the host interrupt input is level-sensitive). Successful reading of the alert response address clears the interrupt latch.

#### *Command Byte Functions*

The 8-bit command byte register (Table 4) is the master index that points to the various other registers within the MAX1617. The register's POR state is 0000 0000, so that a Receive Byte transmission (a protocol that lacks the command byte) that occurs immediately after POR returns the current local temperature data.

The one-shot command immediately forces a new conversion cycle to begin. In software standby mode (RUN/STOP bit = high), a new conversion is begun, after which the device returns to standby mode. If a conversion is in progress when a one-shot command is received, the command is ignored. If a one-shot command is received in auto-convert mode (RUN/STOP bit = low) between conversions, a new conversion begins, the conversion rate timer is reset, and the next automatic conversion takes place after a full delay elapses.

### *Configuration Byte Functions*

The configuration byte register (Table 5) is used to mask (disable) interrupts and to put the device in software standby mode. The lower six bits are internally set to (XX1111), making them "don't care" bits. Write zeros to these bits. This register's contents can be read back over the serial interface.

#### *Status Byte Functions*

The status byte register (Table 6) indicates which (if any) temperature thresholds have been exceeded. This byte also indicates whether or not the ADC is converting and whether there is an open circuit in the remote diode DXP–DXN path. After POR, the normal state of all the flag bits is zero, assuming none of the alarm conditions are present. The status byte is cleared by any successful read of the status byte, unless the fault persists. Note that the ALERT interrupt latch is not automatically cleared when the status flag bit is cleared.

When reading the status byte, you must check for internal bus collisions caused by asynchronous ADC timing, or else disable the ADC prior to reading the status byte (via the RUN/STOP bit in the configuration byte). In one-shot mode, read the status byte only after the conversion is complete, which is 150ms max after the oneshot conversion is commanded.

## *Remote/Local Temperature Sensor with SMBus Serial Interface*

## **Table 5. Configuration-Byte Bit Assignments**



### **Table 6. Status-Byte Bit Assignments**



\**These flags stay high until cleared by POR, or until the status byte register is read.*

To check for internal bus collisions, read the status byte. If the least significant seven bits are ones, discard the data and read the status byte again. The status bits LHIGH, LLOW, RHIGH, and RLOW are refreshed on the SMBus clock edge immediately following the stop condition, so there is no danger of losing temperature-related status data as a result of an internal bus collision. The OPEN status bit (diode continuity fault) is only refreshed at the beginning of a conversion, so OPEN

## **Table 7. Conversion-Rate Control Byte**



data is lost. The ALERT interrupt latch is independent of the status byte register, so no false alerts are generated by an internal bus collision.

When auto-converting, if the THIGH and TLOW limits are close together, it's possible for both high-temp and low-temp status bits to be set, depending on the amount of time between status read operations (especially when converting at the fastest rate). In these circumstances, it's best not to rely on the status bits to indicate reversals in long-term temperature changes and instead use a current temperature reading to establish the trend direction.

#### *Conversion Rate Byte*

The conversion rate register (Table 7) programs the time interval between conversions in free-running autoconvert mode. This variable rate control reduces the supply current in portable-equipment applications. The conversion rate byte's POR state is 02h (0.25Hz). The MAX1617 looks only at the 3 LSB bits of this register, so the upper 5 bits are "don't care" bits, which should be set to zero. The conversion rate tolerance is  $\pm 25\%$  at any rate setting.

Valid A/D conversion results for both channels are available one total conversion time (125ms nominal, 156ms maximum) after initiating a conversion, whether conversion is initiated via the RUN/STOP bit, hardware STBY pin, one-shot command, or initial power-up. Changing the conversion rate can also affect the delay until new results are available. See Table 8.

# *Remote/Local Temperature Sensor with SMBus Serial Interface*



## **Table 8. RLTS and RRTE Temp Register Update Timing Chart**

#### *Slave Addresses*

The MAX1617 appears to the SMBus as one device having a common address for both ADC channels. The device address can be set to one of nine different values by pin-strapping ADD0 and ADD1 so that more than one MAX1617 can reside on the same bus without address conflicts (Table 9).

The address pin states are checked at POR only, and the address data stays latched to reduce quiescent supply current due to the bias current needed for high-Z state detection.

The MAX1617 also responds to the SMBus Alert Response slave address (see the *Alert Response Address* section).

#### *POR and UVLO*

The MAX1617 has a volatile memory. To prevent ambiguous power-supply conditions from corrupting the data in memory and causing erratic behavior, a POR voltage detector monitors  $V_{CC}$  and clears the memory if  $V_{CC}$  falls below 1.7V (typical, see *Electrical Characteristics* table). When power is first applied and  $V_{CC}$  rises above 1.75V (typical), the logic blocks begin operating, although reads and writes at V<sub>CC</sub> levels below 3V are not recommended. A second V<sub>CC</sub> comparator, the ADC UVLO comparator, prevents the ADC from converting until there is sufficient headroom ( $V_{CC} = 2.8V$  typical).

### **Table 9. Slave Address Decoding (ADD0 and ADD1)**



*Note: High-Z means that the pin is left unconnected.*

#### **Power-Up Defaults:**

- Interrupt latch is cleared.
- Address select pins are sampled.
- ADC begins auto-converting at a 0.25Hz rate.
- Command byte is set to 00h to facilitate quick remote Receive Byte queries.
- THIGH and TLOW registers are set to max and min limits, respectively.

## *Remote/Local Temperature Sensor with SMBus Serial Interface*



*Figure 4. SMBus Write Timing Diagram*



*Figure 5. SMBus Read Timing Diagram*

#### *Programming Example: Clock-Throttling Control for CPUs*

An untested example of pseudocode for proportional temperature control of Intel mobile CPUs via a powermanagement microcontroller is given in Listing 1. This program consists of two main parts: an initialization routine and an interrupt handler. The initialization routine checks for SMBus communications problems and sets up the MAX1617 configuration and conversion rate. The interrupt handler responds to ALERT signals by reading the current temperature and setting a CPU clock duty factor proportional to that temperature. The relationship between clock duty and temperature is fixed in a lookup table contained in the microcontroller code.

Note: Thermal management decisions should be made based on the latest temperature obtained from the MAX1617 rather than the value of the Status Byte. The MAX1617 has a very quick response to changes in its environment due to its sensitivity and its small thermal mass. High and low alarm conditions can exist in the Status Byte due to the MAX1617 correctly reporting environmental changes around it.

## *Remote/Local Temperature Sensor with SMBus Serial Interface*

/\* Beginning of the header file which sets the constants \*/ int. NumStates  $= 10;$ /\* 0x01, command for reading remote temp register \*/ int  $R$  $R$  $T$  $R$  $= 1$ : int **WCA**  $= 9:$ /\*  $0x09$ , command for writing configuration register \*/ = 10; /\* 0x0A, command for writing conversion rate register \*/<br>= 2; /\* 0x02, command for reading status register \*/ int **WCRW RSL** int int WRHA = 13;  $/*$  0x0D, command for writing remote THIGH limit register  $*/$ WRLN int = 14;  $/*$  0x0E, command for writing remote TLOW limit register \*/ int NoError  $= 0$ ; int Nobody  $= 0$ : int MAX1617Addr = 84; /\* 0x54, default address for MAX1617, ADD0, ADD1=open \*/ /\* 0x00, configure MAX1617 to MASK=0 and RUN/STOP=0 \*/ int  $InitConfig = 0;$ Initiony = 7; /\* 0x00, configure maxiel/ co mass=0 and RON/SIOP=0 \*/<br>Initiony = 7; /\* 0x07, conversion rate of 8Hz \*/<br>HighAdder = 2; /\* 2oC offset for calculating THIGH limit \*/<br>LowSubtracter = 4; /\* 4oC offset for calcul int InitConv int int int  $DiodeFaultMask = 4:$ int TempChangeMask = 24; /\* 0x18, mask for RHIGH and RLOW status bits \*/ int array State [0.. NumStates] of int;  $State[0] = -65$  oC /\* At or above this temperature CPU duty cycle is 100% \*/ State [1] = 72 oC /\* At or above this temperature CPU duty cycle is 87.5% \*/<br>State [2] = 74 oC /\* At or above this temperature CPU duty cycle is 75% \*/<br>State [3] = 76 oC /\* At or above this temperature CPU duty cycle is 6  $State[1] = 72$  oC /\* At or above this temperature CPU duty cycle is 87.5% \*/ array ClockRate[0..NumStates] of real;  $ClockRate[0] = 1.0;$  $ClockRate[1] = 0.875;$  $ClockRate[2] = 0.75;$  $ClockRate[3] = 0.625;$  $ClockRate[4] = 0.5;$  $ClockRate[5] = 0.375;$  $ClockRate[6] = 0.25;$  $ClockRate [7] = 0.125;$  $ClockRate[8] = 0;$  $ClockRate[9] = 0;$  $ClockRate[10] = 0;$ /\* End of the header file \*/

*Listing 1. Pseudocode Example*

## *Remote/Local Temperature Sensor with SMBus Serial Interface*

```
int Initialization()
       int ErrorCode = NoError;/* Test the SMBus communications path to the MAX1617 by writing the configuration,
conversion rate and initial temperature limits; if SMBus communication was unsuccessful,
power the system down. Note that the MAX1617Write procedure takes three parameters: the
command code of the register to be written, the data to write, and a pointer to the the
error code variable. If the error code variable does not equal NoError before the
execution of MAX1617Write, MAX1617Write does nothing. If the SMBus communication fails in
MAX1617Write, the error code variable is set to the type of error (for example a NACK,
i.e. MAX1617 did not acknowledge). This code assumes that the BIOS is already in thermal
state 0 (not throttling, i.e. full CPU clock rate) when the initialization routine is
executed. */
       MAX1617Write(WCA, InitConfig, &ErrorCode); /* MASK=0 and RUN/STOP=0 */
       MAX1617Write(WCRW, InitConv, &ErrorCode); /* CONV = 8Hz */<br>MAX1617Write(WRLM, LowestTemp, &ErrorCode); /* TLOW = -65oC */
       MAX1617Write(WRHA, State[0] + HighAdder, &ErrorCode) /* THIGH = 720C */
       if (ErrorCode != NoError) then {
               /* Power off the system */\mathcal{V}/* End of if (ErrorCode ... */
       return (ErrorCode);
/* After changing the conversion rate to 8Hz, the MAX1617 temperature register will not
have valid (i.e. current temperature) data for 238 milliseconds. */
       /* End of Initialization routine */
Δ.
```
*Listing 1. Pseudocode Example (continued)*

## *Remote/Local Temperature Sensor with SMBus Serial Interface*

```
int ALERT IntHandler()
       int ErrorCode = NoError;₹
       int Wholounnit = Nobody;int FoundState = 0;
       int StatusInfo = 0:
       int TempHigh;
       int TempLow;
/* This interrupt handler verifies that the MAX1617 is the source of the interrupt (and
also clears the interrupt) via the SMBus Alert Response address; checks the status byte to
ensure that a temperature change did indeed cause the interrupt; reads the remote
temperature; programs a corresponding clock-throttling duty cycle, and sets up new Thigh
and Tlow limits. */ReadAlertResponse(&WhoDunnit, &ErrorCode);
       if (WhoDunnit == MAX1617Addr) then {
               MAX1617Read(RSL, &StatusInfo, &ErrorCode);
               if (((StatusInfo & CollisionMask) != 0) and (ErrorCode == NoError)) then
                      MAX1617Read(RSL, &StatusInfo, &ErrorCode);
               if (StatusInfo & DiodeFaultMask) != 0) then \{/* Shut down system because thermal diode doesn't work */
               else if ((StatusInfo & TempChangeMask) != 0) then {
                      MAX1617Read(RRTE, &TempRead, &ErrorCode);
                      while ((TempRead >= State [FoundState + 1]) and
                              (FoundState < (NumStates - 1)) do FoundState++;
                       if (FoundState == (NumStates - 1)) then {
                              /* Ahhhhh!!! SHUT SYSTEM OFF!!!! */
                      else {
                              /* adjust clock duty cycle */
                              Template = Templead + HighAdder;TempLow = TempRead - LowSubtracter;
                              MAX1617Write(WRHA, TempHigh, &Error);
                              MAX1617Write(WRLN, TempLow, &Error);
                                      /* End of if (FoundState ... */
                              }
                       \mathcal{E}/* End of if (((StatusInfo .. else if ... *//* Handle local temp status bits if set */
       else {
               /* Handle cases for other interrupt sources */
                      /* End of if (WhoDunnit ... */
               Δ.
       return(ErrorCode);
       /* End of Alert_IntHandler interrupt handler routine */
```

```
Listing 1. Pseudocode Example (continued)
```
## *Remote/Local Temperature Sensor with SMBus Serial Interface*

### *Package Information*

For the latest package outline information and land patterns (footprints), go to **[www.maximintegrated.com/packages](http://www.maximintegrated.com/packages)**. Note that a "+", "#", or "-" in the package code indicates RoHS status only. Package drawings may show a different suffix character, but the drawing pertains to the package regardless of RoHS status.



## *Remote/Local Temperature Sensor with SMBus Serial Interface*

## *Revision History*





*Maxim Integrated cannot assume responsibility for use of any circuitry other than circuitry entirely embodied in a Maxim Integrated product. No circuit patent licenses are implied. Maxim Integrated reserves the right to change the circuitry and specifications without notice at any time. The parametric values (min and max limits) shown in the Electrical Characteristics table are guaranteed. Other parametric values quoted in this data sheet are provided for guidance.*

20 *Maxim Integrated 160 Rio Robles, San Jose, CA 95134 USA 1-408-601-1000*

© 2012 Maxim Integrated Products, Inc. Maxim Integrated and the Maxim Integrated logo aretradmarks of Maxim Integrated Products, Inc.



info@moschip.ru

 $\circled{1}$  +7 495 668 12 70

Общество с ограниченной ответственностью «МосЧип» ИНН 7719860671 / КПП 771901001 Адрес: 105318, г.Москва, ул.Щербаковская д.3, офис 1107

### Данный компонент на территории Российской Федерации

Вы можете приобрести в компании MosChip.

Для оперативного оформления запроса Вам необходимо перейти по данной ссылке:

### http://moschip.ru/get-element

 Вы можете разместить у нас заказ для любого Вашего проекта, будь то серийное производство или разработка единичного прибора.

В нашем ассортименте представлены ведущие мировые производители активных и пассивных электронных компонентов.

Нашей специализацией является поставка электронной компонентной базы двойного назначения, продукции таких производителей как XILINX, Intel (ex.ALTERA), Vicor, Microchip, Texas Instruments, Analog Devices, Mini-Circuits, Amphenol, Glenair.

Сотрудничество с глобальными дистрибьюторами электронных компонентов, предоставляет возможность заказывать и получать с международных складов практически любой перечень компонентов в оптимальные для Вас сроки.

На всех этапах разработки и производства наши партнеры могут получить квалифицированную поддержку опытных инженеров.

Система менеджмента качества компании отвечает требованиям в соответствии с ГОСТ Р ИСО 9001, ГОСТ РВ 0015-002 и ЭС РД 009

### Офис по работе с юридическими лицами:

105318, г.Москва, ул.Щербаковская д.3, офис 1107, 1118, ДЦ «Щербаковский»

Телефон: +7 495 668-12-70 (многоканальный)

Факс: +7 495 668-12-70 (доб.304)

E-mail: info@[moschip](mailto:info@moschip.ru).ru

Skype отдела продаж: moschip.ru moschip.ru\_4

moschip.ru\_6 moschip.ru\_9