

Software - IBS CMD SWT G4 - 2721439

Please be informed that the data shown in this PDF Document is generated from our Online Catalog. Please find the complete data in the user's documentation. Our General Terms of Use for Downloads are valid (<http://phoenixcontact.com/download>)



Network configuration software for INTERBUS Generation 4

Product Description

A bus system for open, flexible control architectures must provide the user with a concept for universal and, above all, manufacturer-independent operation and diagnostics of a system, in order to provide the required manufacturer-neutrality. The configuration, startup, and diagnostics software CMD (Configuration Monitoring Diagnostics) was developed for INTERBUS. The key features of this software are the independence from the control system used and the flexibility with regard to program expansions, new functions, and utility programs. The DRIVECOM user group, for example, offers utility programs for parameterizing drives according to the DRIVECOM profile.

In order to meet the requirements of users, we continue to apply our INTERBUS expertise to this software.

CMD for all phases:

CMD is a tool that can be used throughout the entire lifecycle of a plant, from planning and configuration, through system startup and operation monitoring, and beyond to diagnostics in the event of maintenance. For the user this eliminates the costs and effort of learning to use several software tools.

The CMD software allows the user to determine the configuration of the INTERBUS system during the configuration phase. The I/O points can be assigned logical addresses or variables, through which the control program will later access the distributed I/Os.

During startup, a function test can be carried out on subsystems using an integrated monitor function.

The diagnostic functions continuously provide detailed information about the bus status, possible error causes, and suggestions on how to remedy them.

CMD for globally established operating systems:

CMD can be run under Windows operating systems for standard PC systems (Windows® NT 4.0 SP6, Windows® 2000, Windows® XP). The familiar interface makes it easy to get started with the software and thereby operate the entire INTERBUS system easily and safely.

The CMD G4 software is not released for Windows 7 operating systems and above. However, the follow-up software Config+ also supports current and future operating systems.



Key Commercial Data

| | |
|--------------|---------------|
| Packing unit | 1 pc |
| GTIN | |
| GTIN | 4017918132347 |
| Sales Key | 11 |

Technical data

License information

| | |
|-------------------------------|---------------|
| Intended use for the software | Configuration |
| | Diagnostics |

Software - IBS CMD SWT G4 - 2721439

Technical data

License information

| | |
|--|--------------------------|
| | Data acquisition |
| | Communication |
| | Startup |
| | Servicing |
| | DIN EN 61131-3 compliant |
| | Security |

Functions

| | |
|-----------------------|--|
| Basic functions | Executing important commands (start/stop/...) |
| | Reading in the installed bus structure |
| | Detecting/representing error states (plain text from knowledge database) |
| | Saving diagnostics data in flash memory or parameterizing memory of the controller board |
| | Diagnostics of INTERBUS FO paths (transmission quality) |
| | Configuration comparison of Ethernet topologies (parameterized with real topology) |
| | Reading out the Controller Diagnose Archive |
| Supported controllers | INTERBUS Generation 4 controller board |
| Number of I/O nodes | not relevant |

Hardware requirements

| | |
|-------------------------|---|
| Hard disk | 62 Mbyte |
| RAM | > 10 Mbyte |
| Note on the main memory | 16 MB or more recommended |
| CPU | Min. 80486/ 33 MHz |
| Interfaces | Free serial interface for online connection |
| Optical drive | CD-ROM |
| Monitor resolution | SVGA mit min. 800 x 600 |
| Operating equipment | Keyboard, mouse |

Software requirements

| | |
|---------------------------------|---|
| Operating system | Windows® NT 4.0 SP6 |
| | Windows® 2000 |
| | Windows® XP |
| Note about the operating system | Does not support Windows® 7 and above operating systems |

Scope of delivery

| | |
|-------------------|--|
| Scope of delivery | Software on CD-ROM, Quick Start Guide, Diagnostics Guide |
|-------------------|--|

Phoenix Contact 2018 © - all rights reserved
<http://www.phoenixcontact.com>

PHOENIX CONTACT GmbH & Co. KG
Flachmarktstr. 8
32825 Blomberg
Germany
Tel. +49 5235 300
Fax +49 5235 3 41200
<http://www.phoenixcontact.com>

Данный компонент на территории Российской Федерации

Вы можете приобрести в компании MosChip.

Для оперативного оформления запроса Вам необходимо перейти по данной ссылке:

<http://moschip.ru/get-element>

Вы можете разместить у нас заказ для любого Вашего проекта, будь то серийное производство или разработка единичного прибора.

В нашем ассортименте представлены ведущие мировые производители активных и пассивных электронных компонентов.

Нашей специализацией является поставка электронной компонентной базы двойного назначения, продукции таких производителей как XILINX, Intel (ex.ALTERA), Vicor, Microchip, Texas Instruments, Analog Devices, Mini-Circuits, Amphenol, Glenair.

Сотрудничество с глобальными дистрибьюторами электронных компонентов, предоставляет возможность заказывать и получать с международных складов практически любой перечень компонентов в оптимальные для Вас сроки.

На всех этапах разработки и производства наши партнеры могут получить квалифицированную поддержку опытных инженеров.

Система менеджмента качества компании отвечает требованиям в соответствии с ГОСТ Р ИСО 9001, ГОСТ РВ 0015-002 и ЭС РД 009

Офис по работе с юридическими лицами:

105318, г.Москва, ул.Щербаковская д.3, офис 1107, 1118, ДЦ «Щербаковский»

Телефон: +7 495 668-12-70 (многоканальный)

Факс: +7 495 668-12-70 (доб.304)

E-mail: info@moschip.ru

Skype отдела продаж:

moschip.ru

moschip.ru_4

moschip.ru_6

moschip.ru_9