TAM813

TAM

Capillary tube thermostats with 1.5 m capillary tube

The sensor cartridge at the end of the capillary tube is the actual active (temperature-sensitive) part of the sensor. Changes in temperature on the capillary tube have no effect on the switching point. Pressure-tight installation of the sensor in pressure vessels of all kinds is possible with the aid of an immersion well.

SIL 2 according IEC 61508-2

Technical data

Body	Diecast aluminium GD Al Si 12 according to DIN 1725.
Mounting position	Any, preferably vertical
Max. ambient temperature at switching device	+70°C
Capillary tube	Cu capillary tube, 1.5 m long Other capillary tube lengths are not possible
Sensor cartridge	8 mm Ø, 100 mm long, material: Cu
Contact arrangement	Single pole changeover switch
Switching capacity	8 (5) A 250 VAC
Degree of protection	IP 54 according to DIN EN60529 (with vertical installation)
Mounting	Temperature sensor with or without immersion tube in containers, air ducts etc. Switching device with 2 screws (Ø 4) directly on a flat wall surface
Calibration	Scale value corresponds to the lower switching point (with falling temperature), the upper switching point is higher by the amount of the switching differential
Plug connection	Via angled plug to DIN EN175301
Switching temperature	Adjustable via the setting spindle with a screw-driver
Switching differential	Not adjustable

Product Summary

Type	Setting range	Switching differential (mean values)	Max. permissible temperature at sensor
TAM022	–20 to + 20 °C	1.5 K	110 °C
TAM150	+10 to + 50 °C	1.5 K	110 °C
TAM490	+40 to + 90 °C	2.0 K	125 °C
TAM813	+80 to +130 °C	2.0 K	150 °C

Ex-**TAM** see page 119

Accessories

Immersion tube type … R 1, R 2, R 3, RN 1, RN 2, see page 157.

Dimensioned drawing (mm)



General technical information

for series TX, TRM and TAM







Adjustment of thermostats at lower switching point
Setpoint x_S corresponds to the lower switching point (with falling temperature), the upper switching point x_O (with rising temperature) is higher by the amount of the switching differential x_d.

Setting the switching temperature (setpoint adjustment)
Prior to adjustment, the setscrew above the scale must be loosened by approx. 2 turns and retightened after setting.
The switching temperature is set via the spindle. The set switching temperature is shown by the scale.
In view of tolerances and variations in the characteristics of sensors and springs, and due to friction in the switching kinematics, slight discrepancies between the setting value and the switching point are unavoidable. The thermostats are usually calibrated in such a way that the setpoint adjustment and the actual switching temperature correspond as closely as possible in the middle of the range. Possible deviations spread to both sides equally.
Clockwise: low switching temperature
Anticlockwise: high switching temperature

Changing the switching differential (only for switching device TRMV...)
The switching differential is changed by turning the setscrew within the spindle. The lower switching point is not changed by the differential adjustment; only the upper switching point is shifted by the differential. One turn of the differential screw changes the switching differential by about 1/2 of the total differential range.
When adjusting please note:
Switching temperature: Clockwise for lower switching point.
Anticlockwise for higher switching point.
Switching differential: Clockwise for larger differential. Anticlockwise for smaller differential.

Electrical connection
Plug connection to DIN EN175301. Cable entry Pg 11, max. cable diameter 10 mm.
Cable outlet possible in 4 directions spaced 90° apart.

Temperature limiter with reclosing lockout
Additional function ZFT205 and ZFT206: All thermostats can be equipped with a mechanical interlock. On reaching the value set on the scale, the microswitch trips over and remains in this position.
The lock can be released by pressing the unlocking button (identified by a red dot on the scale side of the switching device). The interlock can take effect with rising or falling temperature, depending on the version.

Mounting position
A vertical mounting position is preferable if at all possible. IP 54 protection is guaranteed with a vertical mounting position. A different mounting position may alter the protection class, but the operation of the thermostat is not affected.

Outdoor installation of thermostats
FEMA thermostats can be installed out of doors provided they are mounted vertically and suitably protected against the direct effects of weather. At ambient temperatures below 0°C, ensure that condensation cannot occur in the sensor or in the switching device.

Mechanical thermostats

Principal technical data

	Standard version	Terminal connection
		
	...200	...300
Switch housing	Diecast aluminium GDAlSi 12	Diecast aluminium GDAlSi 12
Switching function and connection scheme (applies only to version with microswitch)	Floating changeover contact With rising pressure single pole switching from 3–1 to 3–2 	Floating changeover contact. With rising pressure single pole switching from 3–1 to 3–2 
Switching capacity (applies only to version with microswitch)	8 A at 250 VAC 5 A at 250 VAC inductive 8 A at 24 VDC 0.3 A at 250 VDC min. 10 mA, 12 VDC	8 A at 250 VAC 5 A at 250 VAC inductive 8 A at 24 VDC 0.3 A at 250 VDC min. 10 mA, 12 VDC
Mounting position	Vertical or horizontal, preferably vertical	Vertical
Protection class (in vertical position)	IP 54	IP 65
Electrical connection	Plug connection to DIN EN175301	Terminal connection
Cable entry	Pg 11	M 16 x 1.5
Ambient temperature	–15 to +70 °C	–15 to +70 °C
Switching point	Adjustable with spindle	Adjustable with spindle after the terminal box cover is removed
Switching differential	Adjustable or not adjustable (see Product Summary)	Not adjustable
Medium temperature	Max. 70 °C, briefly 85 °C	Max. 70 °C, briefly 85 °C
Vibration strength	No significant deviations up to 4 g. At higher accelerations, the switching differential is reduced slightly. Use over 25 g is not permitted.	
Isolation values	Overvoltage category III, contamination class 3, reference surge voltage 4000 V. Conformity to DIN VDE 0110 is confirmed.	
Sensor systems		



Room sensor TRM



Capillary tube sensor TAM



Rod sensor TX+R10



Air duct sensor TX+R6

Mechanical thermostats

Principal technical data

	Terminal connection	Ex version
		
	...500 (Ex-i)	**...700 (Ex-d)**
Switch housing	Diecast aluminium GDAlSi 12	Diecast aluminium GDAlSi 12
Switching function and connection scheme (applies only to version with microswitch)	Floating changeover contact With rising pressure single pole switching from 3–1 to 3–2 	Floating changeover contact. With rising pressure single pole switching from 3–1 to 3–2 
Switching capacity (applies only to version with microswitch)	max. 100 mA, 24 VDC min. 2 mA, 24 VDC	3 A at 250 VAC 2 A at 250 VAC inductive 3 A at 24 VDC 0.03 A at 250 VDC min. 2 mA, 24 VDC
Mounting position	Vertical or horizontal, vertically upright	Vertically upright
Protection class (in vertical position)	IP 65	IP 65
Explosion protection with immersion well	**Ex II 1/2G Ex ia IIC T6 Ga/Gb** **Ex II 1/2D Ex ia IIIC T80 °C**	**CE 0035 Ex II 2G Ex d e IIC T6 Gb** **CE 0035 Ex II 1/2D Ex ta/tb IIIC T80 °C Da/Db** **Exception: EX-TRM...:** **Ex II 2G Ex d e IIC T6 Gb** **Ex II 2D Ex tb IIIC T80°C Db**
Electrical connection	Terminal connection	Terminal connection
Cable entry	M 16 x 1.5	M 16 x 1.5
Ambient temperature	–15 to +60 °C	–20 to +60 °C
Switching point	Adjustable with spindle after the terminal box cover is removed	Adjustable with spindle after the terminal box cover is removed
Switching differential	not adjustable	Not adjustable
Medium temperature	Max. 60 °C	Max. 60 °C
Vibration strength	No significant deviations up to 4 g. At higher accelerations, the switching differential is reduced slightly. Use over 25 g is not permitted.	
Isolation values	Overvoltage category III, contamination class 3, reference surge voltage 4000 V. Conformity to DIN VDE 0110 is confirmed.	

Sensor systems



Room sensor TRM



Capillary tube sensor TAM



Rod sensor TX+R10



Air duct sensor TX+R6

Plug connection 200 series	Description	Connection scheme
	**Standard version** Microswitch, single pole switching	
ZFT213	**Gold-plated contacts** with low contact resistance (e. g. for low voltage) Adjustable switching diff. is not available	
ZFT301	**Terminal connection housing (IP 65)**	
ZFT351	**Protection class IP 65 and switch housing with surface protection** (terminal connection housing)	
ZFT513	**Ex-i-version** 500 housing, blue cable entry and terminal connection Gold-plated contacts, protection class IP 65 ATEX-Approval: please see page 10–13 **Power supply circuit:** U_i 24 V DC I_i 100 mA C_i 1 nF L_i 100 µH	

* Additional prices are to be added to the standard equipment prices in each case.
For devices which differ from the standard equipment, the code of the switching device is part of the type designation.
** Switching point adjustment: Please specify switching point and direction of action (rising or falling temperature).

Example for ordering:

TX150-513
- Code of additional function
- Code for temperature range
- Type

Service functions

Devices with service functions will be produced individually according to the customer's specifications. The system requires that these product combinations be identified in such a way as to prevent any possibility of confusion. These combinations are characterised by a product code with the suffix "-S" on the packaging label as well as separate labels with barcodes for each service function.

Service functions	
ZFT5970	**Setting of switching point according to customer's instructions**
ZFT5971	**Setting of switching points according to customer's instructions with lead sealing**
ZFT1978	**Labelling of units** according to customer's instructions with sticker **Test certificates according to EN 10 204**
WZ2.2	Factory certificate 2.2 based on non-specific specimen test
AZ3.1B1	Acceptance test certificate 3.1 based on specific test

**** Switching point adjustment:** Please specify **switching point and direction of action** (rising or falling pressure).
Service functions are available for the following type series (including Ex-versions):
Thermostats: TAM, TX, TRM,
Ordering devices with service functions: See page 33.

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Honeywell:

TAM490 TAM150-301 TAM150-305 TAM150-351 TAM490-205 TAM813 TAM813-563 TAM022-513 TAM022-351 TAM150-213 TAM813-205 TAM022 TAM490-351 TAM490-305 TAM490-301 TAM490-213 TAM022-206 TAM490-513 TAM150 TAM022-301 TAM813-313 TAM022-306 TAM813-351 TAM813-513 TAM813-305 TAM813-301 TAM150-513 TAM150-205 TAM150-206

Общество с ограниченной ответственностью «МосЧип» ИНН 7719860671 / КПП 771901001
Адрес: 105318, г.Москва, ул.Щербаковская д.3, офис 1107

Данный компонент на территории Российской Федерации

Вы можете приобрести в компании MosChip.

Для оперативного оформления запроса Вам необходимо перейти по данной ссылке:

http://moschip.ru/get-element

Вы можете разместить у нас заказ для любого Вашего проекта, будь то серийное производство или разработка единичного прибора.

В нашем ассортименте представлены ведущие мировые производители активных и пассивных электронных компонентов.

Нашей специализацией является поставка электронной компонентной базы двойного назначения, продукции таких производителей как XILINX, Intel (ex.ALTERA), Vicor, Microchip, Texas Instruments, Analog Devices, Mini-Circuits, Amphenol, Glenair.

Сотрудничество с глобальными дистрибьюторами электронных компонентов, предоставляет возможность заказывать и получать с международных складов практически любой перечень компонентов в оптимальные для Вас сроки.

На всех этапах разработки и производства наши партнеры могут получить квалифицированную поддержку опытных инженеров.

Система менеджмента качества компании отвечает требованиям в соответствии с ГОСТ Р ИСО 9001, ГОСТ РВ 0015-002 и ЭС РД 009

Офис по работе с юридическими лицами:

105318, г.Москва, ул.Щербаковская д.3, офис 1107, 1118, ДЦ «Щербаковский»

Телефон: +7 495 668-12-70 (многоканальный)

Факс: +7 495 668-12-70 (доб.304)

E-mail: info@moschip.ru

Skype отдела продаж:
moschip.ru
moschip.ru_4
moschip.ru_6
moschip.ru_9